




# Parts Catalog

DNDA / DWDA  
DNDB / DWDB

## PMG GENERATOR SET



## General Information

For part or service, contact the distributor from whom you purchased this equipment or refer to the nearest Authorized Cummins Distributor.

To avoid errors or delays in filling your parts order, always give the full MODEL, SERIAL and ID No. from the namplate.

For handy reference, insert "YOUR" nameplate information in the spaces below.

		AC Generator Set	
		Model _____	
kw	kva	pf	phase
voltage	amps		
duty	overload		
rpm	hs		
class of insulation	pmq voltage		
field amp max	field voltage max		
generator model no.			
voltage regulator model no.			
ID no.			
generator set serial no.			
BS5000	NEMA		

# Important Safety Precautions

---

Read and observe these safety precautions when using or working on electric generators, engines and related equipment. Also read and follow the literature provided with the equipment.

Proper operation and maintenance are critical to performance and safety. Electricity, fuel, exhaust, moving parts and batteries present hazards that can cause severe personal injury or death.

## FUEL, ENGINE OIL, AND FUMES ARE FLAMMABLE AND TOXIC

Fire, explosion, and personal injury can result from improper practices.

- Used engine oil, and benzene and lead, found in some gasoline, have been identified by government agencies as causing cancer or reproductive toxicity. When checking, draining or adding fuel or oil, do not ingest, breathe the fumes, or contact gasoline or used oil.
- Do not fill tanks with engine running. Do not smoke around the area. Wipe up oil or fuel spills. Do not leave rags in engine compartment or on equipment. Keep this and surrounding area clean.
- Inspect fuel system before each operation and periodically while running.
- Equip fuel supply with a positive fuel shutoff.
- Do not store or transport equipment with fuel in tank.
- Keep an ABC-rated fire extinguisher available near equipment and adjacent areas for use on all types of fires except alcohol.
- Unless provided with equipment or noted otherwise in installation manual, fuel lines must be copper or steel, secured, free of leaks and separated or shielded from electrical wiring.
- Use approved, non-conductive flexible fuel hose for fuel connections. Do not use copper tubing as a flexible connection. It will work-harden and break.

## EXHAUST GAS IS DEADLY

- Engine exhaust contains carbon monoxide (CO), an odorless, invisible, poisonous gas. Learn the symptoms of CO poisoning.
- Never sleep in a vessel, vehicle, or room with a genset or engine running unless the area is equipped with an operating CO detector with an audible alarm.
- Each time the engine or genset is started, or at least every day, thoroughly inspect the exhaust system. Shut down the unit and repair leaks immediately.

- Warning: Engine exhaust is known to the State of California to cause cancer, birth defects and other reproductive harm.

*Make sure exhaust is properly ventilated.*

- Vessel bilge must have an operating power exhaust.
- Vehicle exhaust system must extend beyond vehicle perimeter and not near windows, doors or vents.
- Do not use engine or genset cooling air to heat an area.
- Do not operate engine/genset in enclosed area without ample fresh air ventilation.
- Expel exhaust away from enclosed, sheltered, or occupied areas.
- Make sure exhaust system components are securely fastened and not warped.

## MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Do not remove any guards or covers with the equipment running.
- Keep hands, clothing, hair, and jewelry away from moving parts.
- Before performing any maintenance, disconnect battery (negative [-] cable first) to prevent accidental starting.
- Make sure fasteners and joints are secure. Tighten supports and clamps, keep guards in position over fans, drive belts, etc.
- If adjustments must be made while equipment is running, use extreme caution around hot manifolds and moving parts, etc. Wear safety glasses and protective clothing.

## BATTERY GAS IS EXPLOSIVE

- Wear safety glasses and do not smoke while servicing batteries.
- Always disconnect battery negative (-) lead first and reconnect it last. Make sure you connect battery correctly. A direct short across battery terminals can cause an explosion. Do not smoke while servicing batteries. Hydrogen gas given off during charging is explosive.
- Do not disconnect or connect battery cables if fuel vapors are present. Ventilate the area thoroughly.

## **DO NOT OPERATE IN FLAMMABLE AND EXPLOSIVE ENVIRONMENTS**

Flammable vapor can be ignited by equipment operation or cause a diesel engine to overspeed and become difficult to stop, resulting in possible fire, explosion, severe personal injury and death. **Do not operate diesel equipment where a flammable vapor environment can be created by fuel spill, leak, etc., unless equipped with an automatic safety device to block the air intake and stop the engine.**

## **HOT COOLANT CAN CAUSE SEVERE PERSONAL INJURY**

- Hot coolant is under pressure. Do not loosen the coolant pressure cap while the engine is hot. Let the engine cool before opening the pressure cap.

## **ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH**

- Do not service control panel or engine with unit running. High voltages are present. Work that must be done while unit is running should be done only by qualified service personnel.
- Do not connect the generator set to the public utility or to any other electrical power system. Electrocution can occur at a remote site where line or equipment repairs are being made. An approved transfer switch must be used if more than one power source is connected.
- Disconnect starting battery (negative [-] cable first) before removing protective shields or touching electrical equipment. Use insulative mats placed on dry wood platforms. Do not wear jewelry, damp clothing or allow skin surface to be damp when handling electrical equipment.
- Use insulated tools. Do not tamper with interlocks.
- Follow all applicable state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag open switches to avoid accidental closure.
- With transfer switches, keep cabinet closed and locked. Only authorized personnel should have cabinet or operational keys. Due to serious shock hazard from high voltages within cabinet, all service and adjustments must be performed by an electrician or authorized service representative.

If the cabinet must be opened for any reason:

1. Move genset operation switch or Stop/Auto/Handcrank switch (whichever applies) to Stop.
2. Disconnect genset batteries (negative [-] lead first).
3. Remove AC power to automatic transfer switch. If instructions require otherwise, use extreme caution due to shock hazard.

## **MEDIUM VOLTAGE GENERATOR SETS (601V TO 15kV)**

- Medium voltage acts differently than low voltage. Special equipment and training are required to work on or around medium voltage equipment. Operation and maintenance must be done only by persons trained and qualified to work on such devices. Improper use or procedures will result in severe personal injury or death.
- Do not work on energized equipment. Unauthorized personnel must not be permitted near energized equipment. Induced voltage remains even after equipment is disconnected from the power source. Plan maintenance with authorized personnel so equipment can be de-energized and safely grounded.

## **GENERAL SAFETY PRECAUTIONS**

- Do not work on equipment when mentally or physically fatigued or after consuming alcohol or drugs.
- Carefully follow all applicable local, state and federal codes.
- Never step on equipment (as when entering or leaving the engine compartment). It can stress and break unit components, possibly resulting in dangerous operating conditions from leaking fuel, leaking exhaust fumes, etc.
- Keep equipment and area clean. Oil, grease, dirt, or stowed gear can cause fire or damage equipment by restricting airflow.
- Equipment owners and operators are solely responsible for operating equipment safely. Contact your authorized Onan/Cummins dealer or distributor for more information.

**KEEP THIS DOCUMENT NEAR EQUIPMENT FOR EASY REFERENCE.**

## TABLE OF CONTENTS

INDEX .....	1
INTRODUCTION .....	2
ENGINE COMPONENTS .....	3
EXHAUST SYSTEM .....	4
AIR CLEANER (STANDARD) .....	5
AIR CLEANER (HEAVY DUTY) .....	6
ELECTRONIC GOVERNOR .....	7
COOLING SYSTEM (RADIATOR) .....	9
CHASSIS.....	11
HEATER ENGINE COOLANT .....	12
GENERATOR .....	13
STATOR SECTION OF GENERATOR .....	15
ROTOR SECTION OF GENERATOR .....	17
OVERSPEED SWITCH .....	18
OVERSPEED SENSOR .....	19
PERMANENT MAGNET EXCITER .....	20
CONTROL HEATER .....	21
GENERATOR SET CONTROL .....	23
ENGINE CONTROL .....	25
GENERATOR CONTROL .....	27
WATTMETER.....	28
POTENTIAL TRANSFORMER .....	29
NUMERICAL INDEX .....	30



## Index

Actuator, Governor 7  
Adapter, Exhaust 4  
  
Bell, End - Generator 15  
  
Cable, Battery 3  
Cable, Pickup - Magnetic 19  
Cap, Radiator 9  
Cap, Rain - Exhaust 4  
Chassis 11  
Cleaner, Air 5,6  
Control, Engine 25  
Control, Generator 27  
Control, Generator Set 23  
Cooling System 9  
  
Drain, Oil 3  
  
Exhaust System 4  
  
Fan, Cooling 9  
Filter, Air 5,6  
  
Gasket, Drain - Oil 3  
Gauge, Pressure - Oil 25  
Gauge, Temperature - Oil 25  
Gauge, Temperature - Water 25  
Generator 13  
Governor, Electronic 7  
Guard, Belt 9  
Guard, Fan 9  
  
Harness, Wiring - Control (AC) 27  
Harness, Wiring - Control (DC) 25  
Harness, Wiring - Control To Engine 25  
Heater, Control 21  
Heater, Coolant - Engine 12  
Hose, Drain - Oil 3  
Hose, Radiator 9  
Housing, Control 23  
  
Indicator, Service - Air Cleaner 5,6  
Light, Indicator 25  
Line, Fuel - Flex 3  
  
Meter, Ampere 27  
Meter, Frequency 27  
Meter, Tach 27  
Meter, Time - Running 27  
  
Pickup, Magnetic 19  
  
Radiator 9  
Rotor, Exciter 17  
Rotor, Exciter - Components 17  
Rotor, Generator 17  
  
Sender, Pressure - Oil 3  
Sender, Temperature - Lo Engine 3  
Sender, Temperature - Oil 3  
Sender, Temperature - Water 3  
Silencer, Exhaust 4  
Stator, Exciter 15  
Stator, Generator 15  
Switch, Overspeed 18  
Switch, Pressure - Lo Oil 3  
Switch, Push - Reset/Panel 25  
Switch, Push - Run/Stop/Remote 25  
Switch, Rotary - Generator Control 27  
Switch, Temperature - Hi Water 3  
Switch, Temperature - Pre Water 3  
  
Thermostat, Heater - Water 12  
Transformer, Current 23  
Transformer, Potential 29  
  
Valve, Drain - Oil 3  
Voltmeter 25, 27  
  
Wattmeter 28

## Introduction

This Parts Manual applies to the Standard Gen Sets Listed below. The illustrations are arranged in groups of related items, and each part or assembly is identified by a Reference Number. All parts illustrated are typical, and unless otherwise mentioned in the description column the parts are interchangeable between models.

These typical illustrations are subject to change and reflect only the latest replacement parts arrangement. The Right and Left sides of the Set are determined by FACING the FRONT (Engine end) of the Set.

### Set Data Table

MODEL IDENTIFICATION	RATING	RPM RATING	BATTERY VOLTAGE
60.0 DNDA/DWDA - */ # @	60,000 WATTS	1500 RPM	24 VDC
80.0 DNDA/DWDA - */ # @	80,000 WATTS	1800 RPM	24 VDC
85.0 DNDB/DWDB - */ # @	85,000 WATTS	1500 RPM	24 VDC
100.0 DNDB/DWDB - */ # @	100,000 WATTS	1800 RPM	24 VDC

### Electrical Data Table

*VOLTAGE CODE	VOLTS	HERTZ	WIRE	PHASE	NOTES
H	347/600	60	4	3	
L	120/208	60	12	3	
	127/220	60	12	3	
	139/240	60	12	3	
	240/416	60	12	3	
	254/440	60	12	3	
	277/480	60	12	3	
Z	110/190	50	12	3	
	115/200	50	12	3	
	120/208	50	12	3	
	127/220	50	12	3	
	220/380	50	12	3	
	230/400	50	12	3	
	240/416	50	12	3	
	254/440	50	12	3	

\* - Voltage Codes follow Model Letter designations.

# - Specification Number: Number 1 is Standard, all others indicate variations.


@ - Specification Letter: Letter advances ( A to B, B to C, etc) with major manufacturing changes.

+ - The Stators are Reconnectible.

### Engine Replacement Parts


The Engine replacement parts can be ordered from the Cummins Engine Distributer except those parts modified or added during the Gen Set Assembly. When ordering engine parts, refer to the Engine Data plate and supply the Model, Serial, and CPL numbers. For assistance in ordering the Engine replacement parts, contact the nearest Cummins Engine Distributor or the Supplier from whom you purchased the Generator Set.

**Engine Components  
(External)**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	193-0353	1	Sender, Temperature - Oil	22	850-2012	1	Washer, Lock (M12)
2	187-0146	1	Washer, Sealing	23	505-0098	1	Nipple, Close
3	856-0013	3	Washer, Lock - EIT (1/2")	24	102-1147	1	Gasket, Drain - Oil Pan
4	332-2739	1	Bracket Assembly, Terminal	25	102-1237	1	Adapter, Drain - Oil
5	800-2112	1	Screw, Cap - Hex Head (M12-1.75 x 30mm)	26	504-0011	1	Valve, Shutoff
6	309-0554	1	Switch, Temperature	27	505-0185	2	Nipple, Half
7	812-0075	1	Screw, Machine - Round Head (#8-32 x 1/4")	28	503-0197	2	Clamp, Hose
8	850-0025	2	Washer, Lock (#8)	29	503-0098	1	Hose, Drain (6")
9	309-0553	1	Switch, Temperature	30	505-0248	1	Elbow, Pipe - Street
10	800-2060	1	Screw, Cap - Hex Head (M8-1.25 x 35mm)	31	309-0169	1	Switch, Pressure - Oil
11	850-2008	1	Washer, Lock (M8)	32	505-0104	1	Nipple, Pipe - Short
12	309-0269	1	Switch, Temperature	33	505-0059	1	Tee, Pipe - Black
13	193-0375	1	Sender, Temperature	34	193-0244	1	Sender, Pressure - Oil
14	526-0008	2	Washer, Flat (#10)	35	505-0026	1	Coupling, Pipe
15	850-0030	1	Washer, Lock (#10)	36	309-0272	1	Switch, Pressure - Oil
16	871-0010	1	Nut, Cap - Hex Head (#10-32)	38	505-1373	1	Bushing, Reducer
17	416-0446	1	Cable, Battery (9")	39	145-0596	1	Spring, Extension - Throttle
18	332-0941	2	Tie, Cable	40	871-0028	1	Nut, Hex (3/8-16)
19	416-0444	1	Cable, Battery (44")	41	850-0050	1	Washer, Lock - Spring (3/8")
20	416-0893	1	Cable, Battery (10")	42	860-0008	1	Nut, Hex (#8-32)
21	800-2110	1	Screw, Cap - Hex Head (M12-1.75 x 20mm)	43	115-0025	1	Nut, Hex (1/4-28)
				44	850-0040	1	Washer, Lock - Spring (1/4")
				45	501-0441	1	Line, Fuel - Flex (Fuel In)
				46	503-0685	1	Clamp, Hose
				47	501-0502	1	Line, Fuel - Flex (Fuel Out)

## Exhaust System




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-2062-03	1	Cap, Rain	3	155-2263	1	Silencer
2	155-2175	1	Clamp, Muffler	4	154-2253	1	Adapter, Exhaust

Air Cleaner - Standard




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0998	2	Clamp, Hose	12	140-2148	1	Element, Air Cleaner
2	503-0868	1	Clamp, Hose	13	821-0033	3	Screw, Self-locking - Hex Head (7/16-14 x 3/4")
3	503-1543	1	Hose, Reducing	14	870-0437	3	Nut, Lock (7/16-14)
4	140-1548	1	Indicator, Service	15	140-0078	2	Band, Mounting
5	140-1260	1	Adapter, Indicator	16	800-2110	4	Screw, Cap - Hex Head (M12 x .8 x 20mm)
6	140-2166	1	Tube, Inlet - Air	17	850-2012	4	Washer, Lock - Spring (M12)
7	503-1542	1	Elbow, Hose - Reducing	18	750-1010	1	Nut, Hex (M12)
8	140-2157	1	Cap, Air Cleaner	19	503-0999	1	Clamp, Hose
9	815-0115	2	Screw, Machine - Fillister Head (1/4-20 x 1")	20	140-2153	1	Bracket, Mounting
10	863-0002	2	Nut, Square (1/4-20)	21	140-2154	1	Brace, Mounting
11	140-2147	1	Cleaner, Air (Includes Element)				

# Air Cleaner - Heavy Duty




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
2	503-0868	4	Clamp, Hose	12	140-2148	1	Element, Air Cleaner
3	503-1460	1	Hose	140-2150	1	Primary	
4	140-1548	1	Indicator, Service	13	821-0033	4	Secondary
5	140-1260	1	Adapter, Indicator	14	870-0437	4	Screw, Self-locking - Hex
6	140-2152	1	Tube, Inlet - Air	15	140-1599	2	Head (7/16-14 x 3/4")
7	503-1467	1	Elbow	16	800-2110	4	Nut, Lock (7/16-14)
8	140-1435	1	Cap, Air Cleaner	17	850-2012	4	Band, Mounting
9	815-0115	2	Screw, Machine - Fillister	18	750-1010	1	Screw, Cap - Hex Head
			Head (1/4-20 x 1")	20	140-2153	1	(M12 x .8 x 20mm)
10	863-0002	2	Nut, Square, (1/4-20)	21	140-2154	1	Washer, Lock - Spring (M12)
11	140-2149	1	Cleaner, Air (Includes				Nut, Hex (M12)
			Element)				Bracket, Mounting
							Brace, Mounting

# Electronic Governor



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	332-1445	5	Tie, Cable	11	526-0327	2	Washer, Flat (13/64)
2	150-2201	1	Sensor, Speed - Includes Leads, Less Terminals	12	870-0131	2	Nut, Hex - W/ET (#10-32)
3			Terminal, Electrical (For all Electrical Leads)	13	526-0008	2	Washer, Flat (#10)
4	332-1279	8	Spade, #6	14	526-0196	3	Washer, Flat - Aluminum
	332-0325	1	Ring, #10	15	870-0053	2	Nut, Hex (#10-32)
	332-1087	1	Ring, 1/2"	16	150-2218-02	1	Rod - Governor
4	813-0103	4	Screw, Machine - Round Head (#10-32 x 3/4")	17	150-2200	2	Joint, Ball
5	870-0131	4	Nut, Hex - W/ET (#10-32) (Not used all installations)	18	150-2203	1	Lever, Actuator - Governor
6	151-0611	1	Control, Governor	19	800-0012	4	Screw, Cap - Hex Head (1/4-20 x 2 1/4")
7	800-2110	2	Screw, Cap - Hex Head (M12 x 1.75 x 20mm)	20	526-0018	4	Washer, Flat (1/4)
8	850-2012	2	Washer, Flat (M12)	21	870-0212	4	Nut, Self-locking - Hex (1/4-20)
9	150-2007	1	Bracket, Mounting	22	151-0632	1	Actuator, Governor (24VDC)
10	815-0172	2	Screw, Machine - Hex Head (#10-32 x 1")	23	800-2060	3	Screw, Cap - Hex Head (M8 x 1.25 x 35mm)
				24	850-2008	3	Washer, Lock (M8)
				25	526-0115	3	Washer, Flat (M8)
				26	150-2187	1	Bracket, Governor


**Cooling System  
(Radiator)**



**Cooling System  
(Radiator)**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	800-2084	1	Screw, Cap - Hex Head (M10 x 1.5 x 16mm)	15	130-3117	1	Fan, Radiator
2	526-2120	1	Washer, Flat (M10)	16	130-3114	1	Spacer, Fan
3	850-2010	1	Washer, Lock - Spring (M10)	17	503-0354	4	Clamp, Hose
4	800-2110	5	Screw, Cap - Hex Head (M12 x 1.75 x 20mm)	18	503-1379-02	1	Hose, Radiator
5	526-2140	5	Washer, Flat (M12)	19	503-1379-03	1	Hose, Radiator
6	850-2012	5	Washer, Lock - Spring (M12)	20	130-3147	1	Tube, Outlet - Radiator
7	821-0009	9	Screw, Self-locking - Hex (1/4-20 x 3/8")	21	503-0365	4	Clamp, Hose
8	130-3121	1	Plate, Bottom	22	503-1391-01	2	Hose, Radiator
9	130-3124	1	Guard, Belt (Right Side)	23	130-3149	1	Tube, Inlet - Radiator
10	130-3125	1	Guard, Belt (Left Side)	24	502-0153	1	Plug, Hex Head (1/4 NPT)
11	130-3127	1	Guard, Belt - Alternator	25	504-0003	1	Cock, Drain
12	130-3126	1	Guard, Belt - Alternator	26	502-1033	2	Adapter, Metric To NPT
13	718-1044	4	Screw, Cap - Hex Head (M8 x 1.25 x 60mm)	27		1	Cap, Radiator
14	850-2008	4	Washer, Lock - Spring (M8)	28	800-0028	4	Screw, Cap - Hex Head (5/16-18 x 1")
				29	526-0022	4	Washer, Flat (5/16)
				30	850-0045	4	Washer, Lock - Spring (5/16)
				31	862-0015	4	Nut, Hex (5/16-18)
				32	130-3278	1	Radiator


**Chassis**



## Chassis

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	870-0212	1	Nut, Lock (1/4-20)	15	800-2120	4	Screw, Cap - Hex Head (M12 x 1.75 x 70mm)
2	416-0854	1	Bracket, Mounting - Battery	16	850-2012	5	Washer, Lock (M12)
3	416-0853	1	Holddown, Battery	17	800-0092	10	Screw, Cap - Hex Head (1/2-13 x 1-1/2")
4	800-0026	1	Screw, Cap - Hex Head (5/16-18 x 3/4")	18	850-0060	10	Washer, Lock - EIT (5/16)
5	856-0008	1	Washer, Lock - EIT (5/16)	19	526-0219	10	Washer, Flat (1/2")
6	870-0257	1	Nut, Lock (5/16-18)	20	862-0016	10	Nut, Hex (1/2-13)
7	332-1473	1	Lug, Solderless	21	800-0520	3	Screw, Cap - Hex Head (M12 x 1.75 x 25mm)
8	800-2111	1	Screw, Cap - Hex Head (1/2-13 x 1-1/2")	22	403-2567	1	Washer, Lock - EIT (1/2")
9	856-0013	1	Washer, Lock - EIT (1/2")	23	402-0568	1	Support, Engine
10	800-0092	1	Screw, Cap - Hex Head (1/2-13 x 1-1/2")	24	800-0156	4	Mount, Vibration
11	862-0016	1	Nut, Hex (1/2-13)	25	862-0008	4	Screw, Cap - Hex Head (3/4-10 x 2-1/4")
12	850-0060	1	Washer, Lock - Spring (1/2")	26	850-0079	2	Nut, Hex (3/4-10)
13	856-0013	1	Washer Lock - EIT (1/2")	27	526-0238	2	Washer, Lock - Spring (3/4")
14	337-0090	1	Strap, Electrical	28	402-0466	2	Washer, Flat (3/4")
							Mount, Vibration


## Engine Coolant Heater



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Heater, Engine Coolant
	333-0291-01	1	120 VAC
	333-0291-02	1	240 VAC

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
2			Cable, Electrical (Includes Thermostat Switch)
	333-0292-01	1	120 VAC
	333-0292-02	1	240 VAC
3	505-0851	1	Bushing, Reducer


## Generator



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1		1	Module, Overspeed Switch (See Separate Page for Components)	4	Note 1		Generator (See Separate Pages for Stator and Rotor Components)
	821-2045	4	Attaching Parts Screw, Self-locking - Hex Hd (M8 x 1.25 x 16mm)		800-0156	4	Attaching Parts Generator to Chassis Screw, Cap - Hex Head (3/4-10 x 2-1/2")
2		1	Module, Overspeed Sensor (See Separate Page for Components)		850-0079	4	Washer, Lock - Spring (3/4")
	821-2045	4	Attaching Parts Screw, Self-locking - Hex Hd (M8 x 1.25 x 16mm)		526-0238	4	Washer, Flat (3/4")
3		1	Module, Permanent Magnet Exciter (See Separate Page for Components)		862-0016	2	Nut, Hex (1/2-13)
	249-0298	4	Attaching Parts Screw, Cap - Hex Head (M8 x 16mm)		800-2088	12	Adapter to Flywheel Housing Screw, Cap - Hex Head (M10 x 1.5 x 35mm)
	249-0218	4	Washer, Lock (M8)		850-2010	12	Washer, Lock - Spring (M10) Drive Disc to Flywheel
	249-0315	4	Clamp, Retaining		805-0015	8	Bolt - Hex Head (3/8-16 x 3/4", Grade 8)
					526-0124	8	Washer, Flat (1-1/2"OD x 13/32"ID)

Note 1: For replacement Generator please supply the complete Gen Set nameplate and Generator nameplate data. The Replacement Generator will be shipped from closest warehouse or the factory. The replacement will not included PMG Exciter Module, Generator to Flywheel Housing Adapter, Drive Discs and Terminal Box.

**Generator  
Stator Section**




**Generator  
Stator Section**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	249-0401	1	Lid <b>Attaching Parts</b>	13	249-0368	2	Grille, Inlet - Air
	249-0304	4	Screw, Captive	14	249-0302	4	Screw, Cap - Hex Head (M10 x 65mm)
2	305-0779	1	Regulator, Voltage Standard	15	249-0202	4	Washer, Lock - Spring (M10)
	305-0778	1	3 Phase (Used with PMG Exciter & 3 Phase Sensing Module)	16	249-0362	1	Cap, Bearing - Outer
	249-0398	4	<b>Attaching Parts</b> Pillar, Threaded	17	249-0444	1	Circlip
3	249-0564	1	Module, 3 Phase Sensing <b>Attaching Parts</b>	18	249-0201	8	Screw, Cap - Hex Head (M10 x 35mm)
	249-0398	4	Pillar, Threaded	19	249-0202	8	Washer, Lock - Spring (M10)
4	249-0395	1	Box	20	249-0312	1	Bearing, Ball
5	300-3209-02	1	Module, Frequency Detection <b>Attaching Parts</b>	21	249-0361	1	Cap, Bearing - Inner
	249-0295	4	Screw, Cap - Hex Head (M5 x 35mm)	22	249-0297	4	Screw, Cap - Hex Head
	249-0288	4	Washer, Plastic (M5)	23	249-0291	4	(M6 x 55mm) Standard Gen
	249-0287	4	Nut, Hex - Nylon (M5)	24	249-0212	4	(M6 x 70mm) Ext Stack Gen
6	NFS	1	Lid	249-0334	1	Washer, Lock - Spring (M6)	
7	NFS	2	Panel, Side	249-0366	1	Stator, Exciter	
8	NFS	1	Panel, Front	25	249-0354	1	Standard Generator
9	NFS	1	Panel, Rear	26	249-0355	1	Extended Stack Generator
10	249-0428	1	Resistor (Voltage Code H Only)	27	NFS	1	Bracket, End-Standard Gen
11	249-0289	3	Block, Terminal - AUX	249-0201	8	Bracket, End-Extended Stack Gen	
12	249-0424	1	Base, Terminal - AUX	249-0202	8	Stator, Generator (Includes	
				28	249-0404	4	Terminal Studs and Links)
							Attaching Parts Stator to
							Adapter
							Screw, Cap - Hex Head
							(M10 x 35mm)
							Washer, Lock - Spring (M10)
							Link, Terminal!

NFS - Not For Sale

**Generator  
Rotor Section**




**Generator  
Rotor Section**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	249-0341	2	Screen, Air - Adapter <b>Attaching Parts</b>	8	249-0336	1	Rotor, Exciter (Does Not Include Rectifier Assy)
	249-0294	8	Screw, Cap - Hex Head (M5 x 12mm)	8a	249-0367	1	Standard Generator Rotor, Exctier (Does Not Include Rectifier Assy)
	249-0307	8	Washer, Lock - Spring (M5)	9	249-0271	1	Extended Stack Generators
	249-0308	8	Washer, Flat (M5)	10	249-0340	1	<b>Key</b>
2	249-0370		Adapter, Generator	11	249-0281	1	Rectifier Assy, Forward (Includes Item 11 Diodes)
3	249-0290	8	Screw, Cap - Hex Head (M16 x 75mm)	12	249-0341	1	Set, Forward Polarity Diode
4	249-0402	1	Plate, Pressure	13	249-0282	1	Rectifier Assy, Reverse (Includes Item 13 Diodes)
5	249-0327	3	Disc, Drive	14	249-0283	1	Set, Reverse Polarity Diode
6	249-0364	1	Spacer				Varister
7	NFS	1	Rotor, Generator (Includes Exciter, Key, and Rectifier Assemblies)		249-0294	2	<b>Attaching Parts</b> Screw, Cap - Hex Head (M5 x 12mm)


NFS - Not For Sale

**Generator  
Overspeed Switch**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	862-0001	2	Nut, Hex (1/4-20)	6	517-0136	1	Plug, Plastic
2	853-0013	1	Washer, Lock - EIT (1/4")	7	150-2207	1	Cover, Overspeed Switch
3	150-0723	1	Point, Overspeed	8	718-1058	1	Screw, Cap - Hex Head
4	870-0250	1	Nut, Insulated	9	856-0010	1	(M10 x 1.5 x 45mm)
5	150-2206	1	Plate, Mounting	10	150-0956	1	Washer, Lock - EIT (3/8")
821-0005	4		Screw, Self-locking - Hex (#10-32 x 1/2")	11	370-4032	1	Switch, Overspeed Spacer, Sleeve

**Generator  
Overspeed Sensor**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	862-0001	2	Nut, Hex (1/4-20)	9	854-0031	1	Washer, Lock - IT (3/4")
2	853-0013	1	Washer, Lock - EIT (1/4")	10	150-1406	1	Sensor, Speed
3	150-0723	1	Point, Overspeed	11	150-2207	1	Cover, Overspeed Switch
4	870-0250	1	Nut, Insulated	12	718-1058	1	Screw, Cap - Hex Head (M10 x 1.5 x 45mm)
5	150-2206	1	Plate, Mounting	13	856-0010	1	Washer, Lock - EIT (3/8")
	821-0005	4	Screw, Self-locking - Hex (#10-32 x 1/2")	14	150-0956	1	Switch, Overspeed
6	332-1445	5	Tie, Cable	15	370-4031	1	Spacer, Sleeve
7	338-2189-02	1	Harness, Wiring	16	150-2204	1	Wheel - Speed Sensor
8	868-0011	2	Nut, Jam - Hex (3/4-16)	17	370-4032	1	Spacer, Sleeve

**Generator**  
**Permanent Magnet Exciter**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	249-0422 249-0294	1	Cover	3	249-0426	1	Stator, Exciter with Frame
		3	Screw, Cap - Hex Head (M5 x 12mm)	4	249-0427 249-0399	1	Rotor, Exciter Bolt
	249-0307	3	Washer, Lock (M5)		249-0202	1	Washer, Lock (M10)
2	249-0423	3	Pillar, Threaded	5	249-0313	1	Pin, Dowel

Control Heater



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	870-0183	2	Nut, Self-locking - Hex (#6-32)	9	333-0151	1	Heater, Electrical 120VAC
2	301-1886	1	Cover		333-0378	1	240VAC
3	860-0006	1	Nut, Hex (#6-32)	10	130-1107	2	Spacer
4	854-0006	2	Washer, Lock - IT (#6)	11	870-0257	2	Nut, Self-locking - Hex (5/16-18)
5	812-0070	2	Screw, Machine - Round Head (#6-32 x 1-1/4")	12	335-0161	1	Cable, Electrical (120VAC Application)
6	309-0128	1	Thermostat, Adjustable	13	338-2121	1	Harness Wiring with Diode, less plug (240VAC Application)
7	800-0034	2	Screw, Cap - Hex Head (5/16-18 x 2-1/4")	14	357-0013	1	Diode
8	526-0113	2	Washer, Flat (5/16")	15	98-3232	1	Decal, Warning - Shock Hazard (Not Illustrated)

### Generator Set Control




# Generator Set Control

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	821-0005	18	Screw, Self-locking - Hex (#10-32 x 1/2")	10	NFS	1	Control, Generator (See Separate Page for Components)
2	NFS	3	Panel, Box - Control	11	332-0941	6	Tie, Cable
3	812-0156	4	Screw, Machine - Round Head (1/4-20 x 1/2")	12			Transformer, Current - Reconnectible
4	850-0040	4	Washer, lock - Spring (1/4")	302-1794-02	3		80kW Voltage Code H
5	NFS	1	Transformer Assy, Potential (See Separate Page for Components)	302-1794-03	3		65 & 80kW Voltage Code L,
6	800-0051	4	Screw, Cap - Hex Head (5/16-18 x 1/2")	302-1794-04	3		65 & 80kW Voltage Code Z,
7	850-0045	4	Washer, Lock - Spring (5/16")	13	508-0051	1	100kW Voltage Code H.
8	NFS	1	Control, Set (See Item 9 & 10 for Components)	14	821-0018	6	85 & 100kW Voltage Code L,
9	NFS	1	Control, Engine (See Separate Page for Components)	15	870-0212	6	85 & 100kW Voltage Code Z.
				16	NFS	1	Grommet
				17	NFS	1	Screw, Self-locking - Hex Head (1/4-20 x 5/8")
							Nut, Self-locking - Hex (1/4-20)
							Housing, Control
							Adapter, Housing to Terminal Box

NFS - Not For Sale

**Engine Control**




# Engine Control

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	815-0544	24	Screw, Machine - Round Head With IT Lock Washer (#6-32 x 1/2")	17	322-0369-02	12	Lamp, Incandescent - 1/3 Watt 28 VDC
2	300-2899	1	Board, Time Delay, Start/Stop - 24 VDC (A15)	18	323-1310	1	Housing, 13 Pin (J3)
3			Board, Magnetic Sensor, Start Disconnect/Over Speed Sensor (A16)	19	323-1302	13	Contact, Pin
	300-2903	1	Standard	20	322-0361	1	Lamp, Incandescent - 28 VDC (DS11)
	300-2904	1	Precision	21	517-0131	1	Holder, Lamp
4	300-2906	1	Board, Over-Under Voltage Sensor - 24 VDC (A17)	22	303-0280	1	Plug, Button
5	300-2856	1	Board, Relay - 24 VDC (A13)	23	308-0785	1	Potentiometer (R11)
6	300-2863	1	Board, Relay - 24 VDC (A14)	24	308-0784	1	Switch, Push (S11)
7			Board, Engine Monitor (A11) (Includes Fuses and Connectors)	26	301-6257	1	Switch, Push (S12)
	300-2808	1	24 VDC, 2 Light	27	193-0250	3	Cover
	300-2812	1	24 VDC, 12 Light	28	193-0352	1	Resistor, Gauge (R12)
8	321-0270	2	Fuse, Cartridge - 20 Amp (F1, F2)	29	193-0351	1	Gauge, Pressure - Oil (M11)
9	321-0231	1	Fuse, Cartridge - 15 Amp (F3)	30	302-1790	1	Gauge, Temperature - Water (M12)
10	321-0094	2	Fuse, Cartridge - 5 Amp (F4, F5)	31	302-0885	1	Ammeter (M13)
11	323-1305	1	Connector, 8 Pin (P1)	815-0385		2	Meter, Totalizing - Time (M14)
12	323-1303	1	Connector, 6 Pin (P2)			2	Screw, Machine - Round Head (#6-31 x 1/2")
13	323-1309	1	Connector, 13 Pin (P3)	34	517-0221	1	Nut, Hex with ET Lockwasher (#6-32)
14	323-1307	1	Connector, 12 Pin (P4)	35	322-0052	1	Clamp, Loop
15	NFS	1	Bracket, Mounting		870-0131	1	Nut, Hex with ET Lockwasher (#10-32 x 1/2")
	821-0004	4	Screw, Self-locking - Hex Hd (#10-32 x 5/16")	36	NFS	1	Door, Control
16			Module, Indicator - Fault (Includes Replaceable Lamps, Harness with Connector Housing & Contact Pins)(A12)	37	338-1817	1	Harness, Wiring - DC Meter (Includes Connector & Pins)
	322-0358-02	1	24 VDC, 2 Light	38	323-1308	1	Housing, 12 Pin (J4)
	322-0360-02	1	24 VDC, 12 Light		323-1302	12	Contact, Pin
	815-0385	2	Screw, Machine - Round Head (#6-32 x 1/2")	39	338-2171	1	Harness, Wiring - Control to Engine (Includes Connectors and Pins)
	870-0183	2	Nut, Self-locking - Hex (#6-32)	40	323-1304	1	Housing, 6 Pin
					323-1200	6	Contact, Pin
					41	1	Housing, 8 Pin
					323-1200	8	Contact, Pin

NFS - Not For Sale

**Generator Control**




# Generator Control

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	332-1445	2	Tie, Cable Harness, Wiring	14	308-0284	1	Switch, Rotary (S21)
2	338-1818	1	Control with Meters (Includes Terminal Block)	15	303-0261	1	Rheostat (R21)
				16	406-0334	2	Clip, Fastener
				17	406-0333	2	Stud, Fastener
				18	NFS	1	Door, Control
	338-1853	1	Control without Meters		821-0004	3	Screw, Self-locking - Hex (#10-32 x 5/16")
	812-0065	2	Screw, Machine - Round Head (#6-32 x 5/8")				
3	332-0607	1	Block, Terminal (TB1)	19	307-1987	2	Clip, Relay
4	332-2723	1	Strip, Marker	20	307-1056	1	Relay, 24 VDC (K21)
5	322-0363	1	Light, Indicator - Dual (DS21, DS22)	21	323-0804	1	Socket, Relay
6	517-0131	1	Plug, Button		815-0544	2	Screw, Machine - Round Head with IT Lock Washer (#6-32 x 1/2")
7			Voltmeter (M21)				
	302-1148	1	Dual Scale 0-300/0-600V	22	NFS	1	Terminal Board Asembly
	302-1753	1	Single Scale 0-750V		812-0065	4	Screw, Machine - Round Head (#6-32 x 5/8")
8	303-0032	1	Knob				
9			Ammeter (M22)	23	332-0751	1	Block, Terminal
			Single Scale Voltage Code H		812-0066	2	Screw, Machine - Round Head (#6-32 x 3/4")
	302-1691	1	80kW, 0-100 Amp				
	302-1805-02	1	100kW, 0-150 Amp	24	332-0853	1	Strip, Marker
			Dual Scale Volt. Codes L & Z	25	NFS	1	Plate
	302-1684	1	65 & 80kW, 0-150/0-300 Amp	26	406-0332	2	Receptacle, Fastener
	302-1685	1	85 & 100kW, 0-200/0-400 Amp	27	871-0015	1	Nut, Hex (1/4-20)
10	302-1720	1	Meter, Frequency (M23)	28	853-0013	1	Washer, Lock - ET (1/4")
11		1	Wattmeter (M24) (See Separate page for Components)	29	337-0049	1	Strap, Electrical (Ground)
12	NFS	1	Cover, Meter Hole		800-0024	1	Screw, Cap - Hex Head (5/16-18 x 1/2")
	815-0385	2	Screw, Machine - Round Head, Black (#6-32 x 1/2")	30	508-0051	1	Washer, Lock - EIT (5/16")
	870-0183	2	Nut, Hex with ET Lockwasher (#6-32)	31	402-0527	2	Grommet
13	332-0052	1	Clamp, Loop		800-0051	4	Mount, Vibration
	870-0131	1	Nut, Self-locking - Hex with ET Lock Washer (#10-32)				Screw, Cap - Hex Head (5/16-18 x 1/2")
				32	NFS	4	Washer, Lock - Spring (5/16")
						1	Box, Control


NFS - Not For Sale

# WATTMETER



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	821-0017	2	Screw, Cap - Hex Head (5/16-18 x 1/2")	8	301-6987	1	Bracket, Mounting
2	850-0045	2	Washer, Lock (5/16)	9	338-1936	1	Harness, Wiring
3	862-0014	2	Nut, Hex (5/16-18)	10	302-1722	1	Wattmeter (Less Dial)
4	860-0008	8	Nut, Hex (#8-32)	11	302-1721-04	1	Dial, Wattmeter
5	856-0002	16	Washer, Lock - ET (#8)		302-1721-05	1	DNDA,DWDA
6	302-1833-01	1	Transducer, Watt	12	813-0102	2	DND8,DWDB
7	402-0354	4	Mount, Shock	13	319-0030	1	Screw, Machine - Round Head (#10-32 x 3/8")
							Plate, Support - Transducer

Potential Transformer



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	812-0079	6	Screw, Machine - Round Head (#8-32 x 1/2")	5	850-0025	2	Washer, Lock - Spring (#8)
2	850-0025	6	Washer, Lock - Spring (#8)	6	332-2562	1	Block, Terminal (10 Place)
3	315-0642	3	Transformer, Potential	7	332-2563	1	Strip, Marker
4	812-0077	2	Screw, Machine - Round Head (#8-32 x 3/8")	8	NFS	1	Bracket, Mounting

NFS - Not For Sale

### Numerical Index

Part No.	Page						
98-3232	21	151-0632	7	249-0367	17	305-0779	15
102-1147	3	154-2253	4	249-0368	15	307-1056	27
102-1237	3	155-2062-03	4	249-0370	17	307-1987	27
115-0025	3	155-2175	4	249-0395	15	308-0284	27
130-1107	21	155-2263	4	249-0398	15	308-0784	25
130-3114	9	187-0146	3	249-0399	20	308-0785	25
130-3117	9	193-0244	3	249-0401	15	309-0128	21
130-3121	9	193-0250	25	249-0402	17	309-0169	3
130-3124	9	193-0330	25	249-0404	15	309-0269	3
130-3125	9	193-0351	25	249-0422	20	309-0272	3
130-3126	9	193-0352	25	249-0423	20	309-0553	3
130-3127	9	193-0353	3	249-0424	15	309-0554	3
130-3278	9	193-0375	3	249-0426	20	315-0642	29
140-0078	5	249-0201	15	249-0427	20	319-0030	28
140-1260	5	249-0202	15	249-0428	15	321-0094	25
140-1260	6	249-0202	20	249-0444	15	321-0231	25
140-1435	6	249-0212	15	249-0564	15	321-0270	25
140-1548	5	249-0218	13	300-2808	25	322-0017	25
140-1548	6	249-0271	17	300-2812	25	322-0052	25
140-1599	6	249-0281	17	300-2856	25	322-0358-02	25
140-2147	5	249-0282	17	300-2863	25	322-0360-02	25
140-2148	5	249-0283	17	300-2899	25	322-0361	25
140-2148	6	249-0287	15	300-2903	25	322-0363	27
140-2149	6	249-0288	15	300-2904	25	322-0369-02	25
140-2150	6	249-0289	15	300-2906	25	323-0804	27
140-2152	6	249-0290	17	300-3209-02	15	323-1200	25
140-2153	5	249-0291	15	301-1886	21	323-1302	25
140-2153	6	249-0294	17	301-6257	25	323-1303	25
140-2154	5	249-0294	20	301-6987	28	323-1304	25
140-2154	6	249-0295	15	302-0885	25	323-1305	25
140-2157	5	249-0297	15	302-1148	27	323-1306	25
140-2166	5	249-0298	13	302-1684	27	323-1307	25
145-0596	3	249-0302	15	302-1684	27	323-1308	25
150-0723	18	249-0304	15	302-1691	27	323-1309	25
150-0723	19	249-0307	17	302-1715	25	323-1310	25
150-0956	18	249-0307	20	302-1720	27	332-0052	27
150-0956	19	249-0308	17	302-1721-04	28	332-0325	7
150-1406	19	249-0312	15	302-1721-05	28	332-0607	27
150-2007	7	249-0313	20	302-1722	28	332-0751	27
150-2187	7	249-0315	13	302-1753	27	332-0853	27
150-2200	7	249-0327	17	302-1790	25	332-0941	3
150-2201	7	249-0334	15	302-1794-02	23	332-0941	23
150-2203	7	249-0336	17	302-1794-03	23	332-1087	7
150-2204	19	249-0340	17	302-1794-04	23	332-1279	7
150-2206	18	249-0341	17	302-1805-02	27	332-1445	7
150-2206	19	249-0354	15	302-1833-01	28	332-1445	19
150-2207	18	249-0361	15	303-0032	27	332-1445	27
150-2207	19	249-0362	15	303-0261	27	332-1473	11
150-2218-02	7	249-0364	17	303-0280	25	332-2562	29
151-0611	7	249-0366	15	305-0778	15	332-2563	29

## Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
332-2723	27	503-1391-01	9	800-0520	11	850-0045	28
332-2739	3	503-1460	6	800-2060	3	850-0050	3
333-0151	21	503-1467	6	800-2060	7	850-0060	11
333-0291-01	12	503-1542	5	800-2084	9	850-0079	11
333-0291-02	12	503-1543	5	800-2088	13	850-0079	13
333-0292-01	12	504-0003	9	800-2110	3	850-2008	3
333-0292-02	12	504-0011	3	800-2110	5	850-2008	7
333-0378	21	505-0026	3	800-2110	6	850-2008	9
335-0161	21	505-0059	3	800-2110	7	850-2010	9
337-0049	27	505-0098	3	800-2110	9	850-2010	13
337-0090	11	505-0104	3	800-2111	11	850-2012	3
338-1817	25	505-0185	3	800-2112	3	850-2012	5
338-1818	27	505-0248	3	800-2120	11	850-2012	6
338-1853	27	505-0851	12	805-0015	13	850-2012	7
338-1936	28	505-1373	3	812-0065	27	850-2012	9
338-2121	21	508-0051	23	812-0065	27	850-2012	11
338-2171	25	508-0051	27	812-0066	27	853-0013	18
338-2189-02	19	517-0131	25	812-0070	21	853-0013	19
357-0013	21	517-0131	27	812-0075	3	853-0013	27
370-4031	19	517-0136	18	812-0077	29	854-0006	21
370-4032	18	517-0221	25	812-0079	29	854-0031	19
370-4032	19	526-0008	3	812-0156	23	856-0002	28
402-0354	28	526-0008	7	813-0102	28	856-0008	11
402-0466	11	526-0018	7	813-0103	7	856-0008	27
402-0527	27	526-0022	9	815-0115	5	856-0010	18
402-0568	11	526-0113	21	815-0115	6	856-0010	19
403-2567	11	526-0115	7	815-0172	7	856-0013	3
406-0332	27	526-0124	13	815-0385	25	856-0013	11
406-0333	27	526-0196	7	815-0385	27	860-0006	21
406-0334	27	526-0219	11	815-0544	25	860-0008	3
416-0444	3	526-0238	11	815-0544	27	860-0008	28
416-0446	3	526-0238	13	821-0004	25	862-0001	18
416-0853	11	526-0327	7	821-0004	27	862-0001	19
416-0854	11	526-2120	9	821-0005	18	862-0008	11
416-0893	3	526-2140	9	821-0005	19	862-0014	28
501-0441	3	718-1044	9	821-0005	23	862-0015	9
501-0502	3	718-1058	18	821-0009	9	862-0016	11
502-0153	9	718-1058	19	821-0017	28	862-0016	13
502-1033	9	750-1010	5	821-0018	23	863-0002	5
503-0098	3	750-1010	6	821-0033	5	863-0002	6
503-0197	3	800-0012	7	821-0033	6	868-0011	19
503-0354	9	800-0024	27	821-2045	13	870-0053	7
503-0365	9	800-0026	11	850-0025	3	870-0131	7
503-0685	3	800-0028	9	850-0025	29	870-0131	25
503-0868	5	800-0034	21	850-0030	3	870-0131	27
503-0868	6	800-0051	23	850-0040	3	870-0183	21
503-0998	5	800-0051	27	850-0040	23	870-0183	25
503-0999	5	800-0092	11	850-0045	9	870-0183	27
503-1379-02	9	800-0156	11	850-0045	23	870-0212	7
503-1379-03	9	800-0156	13	850-0045	27	870-0212	11

## Numerical Index

Part No.	Page						
870-0212	23						
870-0250	18						
870-0250	19						
870-0257	11						
870-0257	21						
870-0437	5						
870-0437	6						
871-0010	3						
871-0015	27						
871-0028	3						

**NOTES**

Cummins Power Products  
P.O. Box 32025  
Minneapolis, MN 55432

Cummins Power Products Ltd  
P.O. Box 30  
54 Broadway  
Peterborough, Cambs. PE1 1QE  
England

Cummins Power Products  
F.E. Pte Ltd.  
8 Tanjong Penjuru  
Singapore 2260