

ONAN DIESEL ELECTRIC
GENERATING PLANTS

5721
DRP

Alternating Current Models

Battery Charging Models

D. W. ONAN & SONS, INC. MINNEAPOLIS, MINN.

GENERAL INFORMATION

THE PURPOSE OF THIS BOOK. This instruction book is furnished so that the operator may learn of the characteristics of the plant. A thorough study of the book will help the operator to keep the plant in good operating condition so that it will give efficient service. An understanding of the plant will also assist the operator in determining the cause of trouble if it occurs.

KEEP THIS BOOK HANDY Such simple mistakes as the use of improper oil, improper fuel, or the neglect of routine servicing may result in failure of the plant at a time when it is urgently needed. It is suggested that this book be kept near the plant so that it may be referred to when necessary.

SERVICE. If trouble occurs and the operator is unable to determine the cause after a thorough study of this book, or if he is unable to determine what repair parts are required, needed information will be furnished upon request. When asking for information, be sure to state the Model, Spec., and Serial numbers of the plant. This information is absolutely necessary and may be obtained from the nameplate on the plant.

MANUFACTURER'S WARRANTY

The manufacturer warrants each new engine or electric plant to be free from defects in material and workmanship. Under normal use and service our obligation under this warranty is limited to the furnishing of any part without charge which, within ninety (90) days after delivery to the original user shall be returned to us or our authorized service station with transportation charges prepaid, and which our examination shall disclose to have been defective.

Our liability in case of defective workmanship, material or any costs incurred in remedying any claimed defective condition in any unit or such unit having been repaired, altered, or which installation and service recommendations have not been complied with, is limited strictly to the proper adjustment authorized by the factory.

This warranty does not include or cover standard accessories used, such as carburetors, magnetos, fuel pumps, etc., made by other manufacturers. Such accessories have separate warranties made by the respective manufacturers. Repair or exchange of such accessories will be made by us on the basis of such warranty.

This warranty is in lieu of all other warranties expressed or implied.

IMPORTANT—RETURN WARRANTY CARD ATTACHED TO PLANT.

TABLE OF CONTENTS

SUBJECT	PAGE NO.
Description	1
Engine	3
Generator Controls - Special Accessories	7
Installation	9
General - Location	10
Ventilation - Mounting Base	11
Mounting the Plant	12
Exhaust Line - Fuel Tank	14
Fuel Lines - Wiring - Wiring Table	15
Connecting the Load	16
Remote Control Connections - Connecting the Starting Battery	21
Preparation	22
Recommended Fuel - Recommended Oil	25
Oil Capacities - Preparation for Starting	26
Operation	27
Starting the Plant	28
Main Causes of Failure to Start	29
Points to Check After Starting the Plant	30
Fuel Knock	31
When to Operate the Plant	34
Stopping the Plant - Controls and Their Functions (A. C. Plants)	35
Controls and Their Functions (Battery Charging Plants)	36
Abnormal Operating Conditions	38
Cold Temperatures	39
High Temperatures	40
Dust and Dirt	41
Periodic Service	43
Daily Service - Weekly Service	45
Monthly Service	46
Semi-Yearly Service	48
Special Adjustments	49
Governor	50
Other Adjustments:	51
Adjusting Valve Clearance	52
Timing the Injection Pump to the Engine	53
Oil Pressure By-Pass - Crankcase Breather Valve	54
Transfer Pump - Rocker Arm Removal	55
Push Rods - Nozzle Adjustment	56
Correcting Injection Pump Throttle Lever Position	57
Correcting Length of Throttle Rod - Resetting Injection Pump Throttle Stop	58
Maintenance and Repair	59
Engine	60
Assembly Torques	61
Table of Clearances	62
Generator	63
Servicing the Generator	64
Controls	65
Troubles and Remedies	66
Wiring Diagrams	67

LIST OF ILLUSTRATIONS

FIG. NO.	SUBJECT	PAGE NO.
1	Two Cylinder Diesel Electric Generating Set	1
2	Dimensional Outline	6
3	Location	7
4	Typical Installation	8
5	Ventilation	9
6	Mounting Base	10
7	Shock Mounting	11
8	Exhaust Installation	12
9	Fuel System - Prior to Spec F	13
9A	Fuel System - Spec F and Spec G	14
10	Fuel System - Beginning With Spec H	15
11	Taping Wire Connections	16
12	Single Phase - 2 Wire Load Connections	17
13	Single Phase - 3 Wire Load Connections	18
14	Three Phase - 3 Wire Load Connections	19
15	Three Phase - 4 Wire Load Connections	20
16	Remote Control Connections - AC Models Only	21
17	Connecting the Starting Battery	22
18	Oil Fill and Indicator	24
19	Bleeding the Fuel System - Prior Spec F	24
19A	Bleeding the Fuel System - Spec F and Spec G	24
20	Bleeding the Fuel System - Beginning With Spec H	25
21	Control Panel	26
22	Top View of Engine	40
23	Servicing the Fuel Filter - Beginning Spec H	41
24	Servicing the Fuel Filter - Prior to Spec F	42
24A	Servicing the Fuel Filter - Spec F and Spec G	44
25	Servicing the Generator Bearing	48
26	Governor Adjustment	50
27	Timing the Injection Pump to the Engine	51
28	Crankcase Breather Valve	52
29	Transfer Pump Linkage	54
30	Rocker Arm Installation	55
31	Nozzle Adjustment	57
32	Throttle Lever Adjustment	59
33	Resetting Injection Pump Throttle Stop	61
34	Cylinder Block Inspection	62
35	Piston and Piston Ring Service	63
36	Reducing Connecting Rod Bearing Clearance	64
37	Valve Grinding	65
38	Removing the Flywheel	66
39	Installing a New Flywheel	67
40	Replacing the Gear Cover	68
41	Governor Cup Assembly	69
42	Removing the Crankshaft Gear	70
43	Checking Camshaft Endplay	71
44	Timing Gear Marks	71
45	Bearing Installation	72
46	Oil Seal Installation	73
47	Oil Pump Removal	73
48	Oil Intake Cup Position in Adapter	74
49	Neutral Brush Position & Constant-Pressure Type Springs	76
50	Outward View of Generator	77
51	Checking Generator Bearing Runout	78
52	Care of Commutator and Brushes	78
53	Test Lamp Set	C

PLANT RUNNING HOURS COMPARED TO AUTOMOBILE RUNNING MILES

The engine of your generating plant makes as many revolutions in one hour, as the average automobile engine does when the car travels a distance of 41 miles. 100 running hours time on a generating plant engine is equivalent in total RPM's to approximately 4100 running miles on an automobile.

However, do not conclude that the wear on the generating plant engine and the wear on the automobile engine would be the same. The generating plant engine is built much more ruggedly, (having larger main bearings, bigger oil capacity and has a heavier crankshaft proportionately per horsepower) than most automobile engines. Given the proper care and periodic servicing the generating plant engine will continue to give many more hours of efficient service than an automobile engine will after having been run the equivalent number of running miles.

Compare the running time of your generating plant engine with the number of miles traveled by an automobile. The oil in an auto is checked every one or two hundred miles (3 to 5 hrs. running time) and changed every 1000 to 1500 miles (25 to 45 hrs.) whereas in a generating plant or stationary power engine, the oil should be checked every 6 to 8 running hours (250 to 350 miles) and changed every 50 to 100 operating hours (2000 to 4000 miles) depending on operating conditions.

About every 5,000 to 10,000 miles (120 to 250 hours), services have to be performed on an auto, such as checking ignition points, replacing spark plugs, condensers, etc. Similarly on your generating plant engine, these same services have to be performed periodically except the change period is reckoned in hours. 10,000 miles on an auto is equivalent to about 250 running hours on your plant engine.

To arrive at an approximate figure of comparative generating plant running hours as against automobile engine running miles, multiply the total number of running hours by 41 to find the equivalent of running miles on an automobile.

Your generating plant engine can "take it" and will give many hours of efficient performance provided it is serviced regularly.

Below is a chart showing the comparison between a generating plant engine running hours and an automobile running miles.

GENERATING PLANT RUNNING HOURS	AUTOMOBILE RUNNING MILES	GENERATING PLANT RUNNING HOURS	AUTOMOBILE RUNNING MILES
DAILY 1 Hr.	41 Miles	30 Hrs.	1,230 Miles
4 Hrs.	164 "	MONTHLY 120 "	4,920 "
AVERAGE 8 "	328 "	AVERAGE 180 "	7,380 "
		240 "	9,840 "
		365 "	14,965 "
WEEKLY 28 "	1,148 "	YEARLY 1,460 "	59,860 "
AVERAGE 43 "	1,773 "	AVERAGE 2,190 "	89,790 "
54 "	2,294 "	2,920 "	119,750 "

NOTE: Electric generating plants do not operate economically when used to power electric refrigerators and will add from 4 to 8 operating hours per day in addition to the regular lighting load.

D

DESCRIPTION

GENERAL. - The Diesel powered electric generating plants to which this manual applies are complete electric generating sets. Each plant includes an engine, generator and necessary accessories. Each plant is thoroughly tested before leaving the factory to assure that all parts are in good condition and that each plant will produce its rated output.

This manual contains instructions on installing, operating, servicing, adjusting and repairing your unit. Read all instructions carefully. Correct installation, operation and servicing are important in assuring long hours of trouble free operation.

All instructions apply to 50 cycle a-c (alternating current) plants as well as to 60 cycle a-c plants unless otherwise noted. The main difference is in the current frequency. Most electrical appliances can be used on either frequency but is advisable to check appliances to be used with 50 cycle plants before purchasing to assure that they are adaptable to the current frequency.

Instructions also apply to battery charging d-c (direct current) plants.




FIG. 1 - TWO CYLINDER DIESEL ELECTRIC GENERATING SET
ENGINE DETAILS

TYPE. - 4 cycle; opposed two cylinder; 3-1/2" bore; 3-1/2" stroke; 67.3 cubic inch piston displacement. 17.3 to 1 compression ratio; 11.0 horsepower at 1800 rpm air cooled; solid injection full diesel.

DESCRIPTION

CYLINDERS-CRANKCASE: Cast integral to form a rugged one piece unit; cylinder fins conduct heat rapidly from the cylinders to maintain normal operating temperature. Ventilated crankcase.

VALVES: Special alloy steel; overhead type; stellite faced exhaust valves; solid stellite exhaust seat inserts; replaceable.

PISTON: Aluminum alloy; 5-ring. Cooled by oil spray. Taper and cam ground.

CRANKSHAFT: Forged steel; short; extra heavy, unusually rigid; fully counterweighted; drilled oil passages.

BEARINGS: Main bearings are aluminum alloy; precision type; easily replaceable; 2-3/4" diameter. Connecting rod bearings are integral on aluminum alloy connecting rods. Trimetal bearings and bronze pin bushings on forged steel rods. Large surface (2-3/8" diameter), long wearing.

FUEL SYSTEM: Diaphragm type transfer pump; two cam-operated, high pressure, throttling type injection pumps (one for each cylinder); solid injection type nozzles. Models prior to "Spec F" use a double unit fuel filter having a strainer type primary filter and a ceramic type secondary filter. Models "Spec F and G" have a micron cartridge type fuel filter and a separate air accumulator tank. Models beginning with "Spec H" use a primary fuel filter having a cleanable permanent brass disc type element and a separate secondary filter having a replaceable cartridge, a sludge drain plug, and an air bleeder plug.

RECOMMENDED FUELS: No. 2 furnace oil. Premium Diesel fuels are not required.

AIR CLEANERS: Two large oil bath air cleaners.

INTAKE AIR HEATERS: Two electric heater coils (one built into each manifold) preheat the intake air for low-temperature starting.

IGNITION: Compression starting and running. Two glow plugs (one installed in each cylinder head) help ignite the fuel during the starting period. (Glow plugs not used on models prior to Spec F.)

GOVERNOR: Centrifugal ball type; enclosed; accessible for adjustment; governor solenoid gives positive stopping of plant.

LUBRICATION: Gear type oil pump; main bearings, connecting rod bearings, wrist pins and rocker arms pressure lubricated; other internal moving parts spray lubricated; oil pressure gauge; oil sump capacity (including filter), 6 qts. U.S. Measure; oil pressure cut-off switch. (Oil pressure cut-off switch not used on models prior to Spec F.)

DESCRIPTION

COOLING: Air-cooling; axial flow type blower; housing directs cooling air over and around the cylinder and cylinder heads.

STARTING REMOTE: Electric cranking controlled by start-stop switch from a remote station or at the plant. (Starting is at the plant only on Battery Charger.)

GENERATOR

The generator is an air cooled, four pole, self-excited, revolving armature type. It is easily removable from the engine.

The single ball-bearing armature is driven by a disc which is directly and solidly connected to the engine flywheel to assure permanent alignment. (Models built previous to specification letter "F" used a drive hub, an armature through stud and some used a roller-bearing instead of a ball-bearing).

The brush rig position is adjustable, and a witness mark designates the neutral brush position.

A-C PLANTS. - The a-c windings of the armature are connected to the collector rings, while the d-c windings are connected to the commutator. The d-c windings provide excitation and charge the 12 volt starting battery. Engine cranking is by a separate automotive type starting motor. The rated capacity is 5,000 watts, plus a generous short period overload for 60 cycle plants, but no overload available for 50 cycle plants.

BATTERY CHARGING PLANTS. - The field coils have a series winding for cranking the engine. The rated capacity is 5,000 watts with short period overloads available.

CONTROLS

The control panel, mounted over the generator is equipped with ammeter, switches, relays, and resistors necessary for the operation of the plant. On alternating current plants, optional equipment may be connected, such as an automatic line failure control or remote control switches.

SPECIAL ACCESSORIES

The following accessories are available.

55 GALLON UNDERGROUND FUEL TANK AND FITTINGS. - Underwriters approved tanks of heavy-gauge galvanized steel complete with tank fittings. Specify Part Number 415B3.

FUEL LINES AND FITTINGS. - 25 feet of 5/16" copper tubing complete with fittings. Specify Kit Number 415K7 (2 kits required).

DESCRIPTION

PRIMING KTT. - Designed for cold weather starting. Easily installed. Simple to operate. Incorporates using a special ethyl-ether starting fluid in capsule form by atomizing the fluid into the engine induction system.

OIL LEVEL REGULATOR. - This regulator is gravity operated and float controlled. It serves to maintain the lubricating oil level in the crankcase as desirable during periods of unattended operation.

KEEP FUEL

Clean!

DIRTY FUEL IS ONE OF THE
MAJOR CAUSES OF PLANT
FAILURE.

REMEMBER-EVEN A TINY PARTICLE
OF DIRT IN THE INJECTION SYSTEM
MAY STOP YOUR PLANT!

INSTALLATION

GENERAL. - The correct installation of your Diesel powered electric generating plant is of great importance to you. Its economy of operation, the ease with which it can be serviced and the life expectancy of the plant itself are a few of the main points affected by the installation.

Probably the most important single factor is proper ventilation. The plant is cooled entirely by air being drawn into the blower housing by the blower and forced at high speed over and around the cooling fins of the cylinder and cylinder head, carrying away heat from the engine at a rapid rate. As long as the air being drawn into the blower is cool and of ample volume, the engine maintains a normal operating temperature. However, if the air inlet and air outlet of the enclosure are not large enough to supply ample ventilation, heated air from the engine is recirculated and is again drawn into the blower housing and circulated over the engine. Thus the air becomes hotter each time it is recirculated, the engine temperature rises and damage from overheating is likely to occur.

The following instructions should be followed as closely as possible. If the instructions cannot be followed as given, use them as a guide and make the best installation that conditions permit.

LOCATION. - The location selected for your plant should be as near to the center of the electrical load as practicable. For example: If several buildings are to be serviced with electricity, it is much better and costs less to run lines from a central point to each of the building, than to run lines from one building to another. Not only will the voltage-drop from plant to load be less but smaller wire can be used to carry the same amount of current without much voltage loss between the plant and the point of service.

The enclosure should be clean, dry, well ventilated, and if necessary, heated in very cold weather.





FIG. 3 - LOCATION

FIG. 2 - DIMENSIONAL OUTLINE
(Earlier models differ slightly.)

OVERALL LENGTH IS:
38-3/4" for 2 Wire Plants;
Approx. 39-3/4" for 3 Wire Plants;
Approx. 40-3/4" for 4 Wire Plants.



INSTALLATION

VENTILATION. - Provide ample ventilation. There should be at least two openings, preferably at opposite ends of the enclosure, to provide ample ventilation. The openings should be adjustable so that the volume of air can be controlled for cold weather operation. The area of the air inlet should be at least 3-1/2 square feet. The area of the air outlet should be at least as large as that of the inlet.

The installation of additional openings may be necessary under certain conditions to prevent recirculation of heated air. If this becomes necessary, air outlets in the roof or in the wall near the ceiling will help. The size of the air inlet can be increased or an additional air inlet installed nearby.




FIG. 5 - VENTILATION

Where possible these openings should be made with reference to the prevailing winds so that a minimum amount of dust reaches the engine, particularly if the unit is operated where flying lint or chaff is likely to be carried to the intake air stream. In such installations the air inlet should be screened and the screen kept clean to prevent restrictions of the air flow.

MOUNTING BASE. - The plant should be mounted on a permanent base, at least two inches larger on all sides than the plant base and about 12 inches high. The base should not be located closer than 24 inches to any wall or partition.




FIG. 4 - TYPICAL INSTALLATION

INSTALLATION

EXHAUST LINE. - Pipe all exhaust gases out of doors. Later models have a single exhaust outlet located under the generator. Earlier models have two exhaust outlets; one on each side of the plant. On those, use the most convenient outlet, covering the other outlet with the plate provided. The exhaust outlet is 1-1/4" P.S. Connect flexible exhaust hose between the plant and iron pipe. Use 1-1/4" pipe for the first 10 feet, increasing the pipe size one size for each additional 10 feet used. Support the exhaust line with metal shields wherever it passes through a wall or partition, the opening for the shields being at least 2" larger on all sides than the exhaust line. Install the exhaust muffler on the exhaust line outside of the enclosure. Support the muffler if necessary. Provide a suitable cover to prevent rain or snow from entering the exhaust muffler, or point end of muffler downward. This cover must not restrict the flow of gases from the plant.

If the exhaust line must be pitched upward at any point, construct a condensation trap of suitable pipe fittings and install it at the point where the upward pitch begins. See the illustration, EXHAUST INSTALLATION.




FIG. 8 - EXHAUST INSTALLATION

FUEL TANK. - The fuel tank supplied with the plant should be installed so that the top of the tank is at least 6 inches below the bottom of the tank not more than 4 feet below the transfer pump inlet. These figures also apply if a different fuel tank is used. Fuel lines supplied with the plant are 24" long and the tank must be within this distance unless additional line is installed.

If a different fuel tank is used, be sure the fuel outlet is near the bottom of the tank and the opening for the return fuel line is in the top of the tank. See the illustration, FUEL SYSTEM.

INSTALLATION

The plant base mounting hole centers are 10" x 23". If a concrete base is used, set 5/16" x 6" bolts in position until the cement is used, set the form to hold the bolts so that not more than 4" extends across the cleats on the bolts. A mixture of 1 part cement to 2 part sand and 4 parts gravel or crushed stone will make a good base. Be sure the mounting surface of the base is smooth and level. Allow the cement to harden for 3 days before mounting the plant on the base.




FIG. 6 - MOUNTING BASE

If timbers are used as a mounting base, they should be large enough to adequately support the plant and allow space for draining the oil. The timbers should also be securely fastened to the foundation they are to rest on.

MOUNTING THE PLANT. - Shock mounting cushions are supplied with mounting holes in the base as shown in the illustration SHOCK MOUNTING.




FIG. 7 - SHOCK MOUNTING

INSTALLATION

To remedy or help locate air leakage, raise the fuel supply 2 feet above the pump level, then watch for leaks.

FUEL LINES. - Two flexible fuel lines are supplied with each unit, one for the supply line and one for the return line. Connect the supply line from the base of the fuel tank to the fuel filter. Connect the return line from the fitting on the bracket to the top of the fuel tank. Metal fuel lines may be used from the tank to a point near the plant and the flexible lines connected at this point.

Be sure all fuel line connections are leak proof. Air leaks in the supply line will cause hard starting and inefficient operation.

WIRING. - Use sufficiently large insulated wire to connect the load to the generator leads at the plant. The wire size will depend largely on the distance and permissible voltage drop between the plant and the load and the amount and kind of load. Consult a competent electrician to help you plan your wiring. Check National and local codes before purchasing and installing electrical supplies. Include in your purchases a circuit breaker or fused switch between the plant and the first load circuit. Be sure the rating and type is correct for your unit.

WIRING TABLE

Unity Power Factor. 2% Voltage Drop (2.3 Volts)

WIRE SIZE NO. 14 12 10 8 6 4 2

Watts Amps

Watts	Amps	14	12	10	8	6	4	2
100	.87	510	810	1280	2040	3250	5300	8200
200	1.74	255	405	640	1020	1625	2650	4100
300	2.61	170	270	430	680	1080	1770	2730
400	3.48	125	200	320	510	810	1325	2050
500	4.35	100	160	255	410	650	1060	1640
750	6.52	65	100	170	275	430	710	1090
1000	8.69	50	80	125	205	325	530	820
1500	13.04	35	55	85	140	215	350	550
2000	17.38	25	50	65	100	160	265	410
2500	21.73	20	35	50	80	130	210	350
5000	43.36			25	40	65	105	160

* Above figures represent a point to point distance for a 2 wire run. If 4% voltage drop is permissible, double the distance listed. If only 1% voltage is allowable, divide the distances listed by 2.

Single Phase 115 Volt A.C. - Use 115 Volt Table Above.

Single Phase 115-230 Volt, A.C. 3 Wire - Use 115 Volt table above for each 115 Volt circuit.

(Wiring Table notes are continued on next page.)

13




FIG. 9 - FUEL SYSTEM (Units Prior to Spec F)




FIG. 9A - FUEL SYSTEM (Spec F and Spec G Units)




FIG. 10 - FUEL SYSTEM (Units Beginning with Spec H)

INSTALLATION

1 PHASE - 3 WIRE PLANTS. - The method of connecting leads together is the same as given for 1 phase, 2 wire plants. However, these plants have three wires coming out of the generator marked "M1", "M2", and "M3". Both 115 volt current and 230 volt current are obtainable. The lead marked "M2" is grounded and is to be connected to the grounded terminal of the fused switch or circuit breaker. The leads marked "M1" and "M3" are "hot" and are to be connected to the hot terminals on the plant side of the fused switch or circuit breaker, one lead to each terminal.

Two 115 volt circuits are available. One circuit across "M1" and "M2" the other across "M2" and "M3". The load on each circuit should not be more than 1/2 the rated capacity of the plant.

One 230 volt circuit is available. This circuit is across "M1" and "M3"; "M2" (ground) is not used with the 230 volt circuit. If only 230 volt current is used, the full rated capacity of the plant is available.

Both 115 volt current and 230 volt current may be used at the same time. However, the total load on all circuits should not exceed the plant capacity. For example: A total of 2500 watts is available on each 115 volt circuit of a 5000 watt, single phase, three wire plant. If 1000 watts of current is used from each 115 volt circuit, only 3000 watts of 230 volt current can be used at the same time. If 2000 watts of 230 volt current is used, only 1500 watts of 115 volt current is available on each 115 volt circuit.




FIG. 13 - 1 PHASE - 3 WIRE LOAD CONNECTIONS

3 PHASE - 3 WIRE PLANTS. - The method of connecting leads together is the same as given for 1 phase, 2 wire plants. However these plants have three leads coming out of the generator marked "M1", "M2" and "M3". Connect these leads to the terminals on the plant side of the fused switch or circuit breaker, one lead to each terminal. Single phase, 230 volt current and three phase, 230 volt current are obtainable. None of the leads are grounded.

INSTALLATION

Single Phase 230 Volt A.C. - Double the distances listed in the 115-Volt table above. Use Amps Column.

Three Phase 230 Volt circuit - Multiply the distances in the 115 Volt Table by 2-1/4 for the same load. Use the Amps Column.




FIG. 11 - TAPING WIRE

CONNECTIONS

CONNECTING THE LOAD. - Where connections are made by joining two wires, always be sure to tape the connections thoroughly. Apply two layers of half-lapped electrician's tape and two layers of half-lapped friction tape, extending both well beyond the ends of the connection.

1 PHASE - 2 WIRE PLANT. - Two methods of load connections prevail. Beginning with Spec H models, load wires from the fused switch or circuit breaker should enter the knock-out hole in the cover for the output terminal studs at the rear of the control box. Terminals are marked "M1" and "M2" to agree with markings on the generator leads. Installation of terminals on the load wires must be in accordance with the generator leads using eye terminals and bolts connected directly to the generator leads.

The generator leads are marked "M1" and "M2". The lead marked "M1" is the hot lead and is to be connected to the "hot" side of the fused switch or circuit breaker. The lead marked "M2" is the "grounded" lead and is to be connected to the ground terminal of the switch or circuit breaker. The main line wires are then connected at the main fuse or circuit breaker. Be sure to connect the "hot" side of the main line to the "hot" side of the fused switch or circuit breaker.




FIG. 12 - 1 PHASE - 2 WIRE LOAD CONNECTIONS




FIG. 14 - 3 PHASE - 3 WIRE LOAD CONNECTIONS

For 3 phase, 3 wire current, connect one main line wire to each of the three output terminals of the fused switch or circuit breaker. If the direction of rotation of the connected load is not correct after the plant is started, reverse the connections between any two terminals to correct the direction of rotation. To assure in phase connections, use a phase sequence indicator.

Three, 230 volt, single phase circuits may be obtained by connecting the two load wires of any single phase 230 volt circuit to any two of the three output terminals of the fused switch or circuit breaker. It is not advisable to use only one of the three, 230 volt single phase circuits. Use all three and connect an equal load to each of the three circuits to prevent unbalancing the generator. The load on any one of the three single phase circuits must not be more than $\frac{1}{3}$ the rated capacity of the plant.

3 PHASE - 4 WIRE PLANT. - The method of connecting leads together is the same as given for 1 phase, 2 wire plants. However, these plants have four leads coming out of the generator marked "M1", "M2", "M3" and "M0", the lead marked "M0" being the ground lead. Both single phase and three phase current are available.

Connect one "hot" generator to each of the three "hot" terminals of a fused switch or circuit breaker. Connect the ground lead "M0" to the neutral terminal of the fused switch or circuit breaker.

For a 3 phase circuit, connect one main line wire to each of the three output terminals of the fused switch or circuit breaker. Do not connect any lead to the "neutral" terminal. If the direction of rotation of the connected load is not correct after starting the plant, reverse any two of the three load connections at the switch to correct the direction of rotation. To assure in phase connections, use a phase sequence indicator.

INSTALLATION

Three, 1 phase circuits may be obtained by connecting the "hot" wire of each single phase circuit to one of the output terminals (one "hot" lead to each terminal) of the fused switch or circuit breaker and the ground lead of each single phase circuit to the "neutral" terminal of the fused switch or circuit breaker. It is not advisable to use only one of the three, single phase circuits. Use all three and connect an equal load to each of any one of the three, single phase circuits must not be more than $\frac{1}{3}$ the rated capacity of the generator.



PLANT VOLTAGE	A	B	C
120/208 VOLT	208V-1 PHASE	208V-1 PHASE	208V-3 PHASE
220/380 VOLT	380V-1 PHASE	380V-1 PHASE	380V-3 PHASE

FIG. 15 - 3 PHASE - 4 WIRE LOAD CONNECTIONS

CONNECTING THE LOAD (Non-Battery Charging Plants) Refer to the wiring diagram.

CONNECTING THE BATTERY (Battery Charging Plants.) The circuit from the generator to the battery is already fused as shown on the wiring diagram. A fused switch should be installed between the battery and the load. The load fuse size will be determined by the installation. Prepare the batteries for operation and install them according to the battery manufacturers instructions.

REMOTE CONTROL CONNECTIONS (AC Plants Only). - One or more start-stop stations may be installed at various points. The wire length from the plant to the switch determines the wire size necessary. Use No. 18 wire up to 85 ft., No. 16 wire up to 135 ft., No. 14 wire up to 215 ft. and No. 12 wire up to 350 ft.

Make wire connections to agree with the illustration REMOTE CONTROL CONNECTIONS. Note that there is a terminal block marked "Remote Control", B+, 1, 2, and 3. Terminal No. 1 is a common ground, terminal 2 is in the stopping circuit and terminal 3 is in the starting circuit. The terminal marked B+ is to be used only with an automatic control installation.

INSTALLATION

case the battery may become damaged. Cable lugs should make clean full contact on the battery terminal posts to prevent loss of current at this point. Coat lugs and terminal posts with a thin coating of vaseline to help prevent corrosion.

If a single 12 volt battery is used, connect the long battery cable with the larger lug from the positive (+) post on the battery to the terminal on the starter. Connect the other long cable from the negative (-) post on the battery to the oil base stud as illustrated. The short jumper cable is not used with a single 12 volt battery. Secure cable connections at all points.

If two 6-volt batteries are to be connected in series to form a 12-volt battery, connect the short jumper cable from the negative (-) post of one battery to the positive (+) post of the second battery. Then make the longer cable connections as described in the foregoing paragraph.

CAUTION: DO NOT POSITIVE GROUND THE BATTERY OR A DEAD SHORT WILL BURN UP THE CHARGE CIRCUIT AS THE GENERATOR HAS NEGATIVE POLARITY.




FIG. 17 - CONNECTING THE STARTING BATTERY

INSTALLATION

Connections for two styles of momentary contact toggle switches for use as Remote Start-Stop Stations are illustrated. Connect all number "2" or "OFF" switch terminals to the number "2" terminal on the plant terminal block. Likewise, connect together all number "3" or "ON" terminals and also, all number "1" or "single" (not marked) terminals. The switch is to be mounted vertically, "START" or "ON" position should be upward to conform with operation at the plant when a toggle switch is used.

REMOTE CONTROL CONNECTIONS (32 V. Battery Charging Plants.) - Refer to instructions for ac plants except distances apply as follows: Use No. 18 wire up to 200 ft., No. 16 wire up to 335 ft., No. 14 wire up to 500 ft., and No. 12 wire up to 800 ft.

REMOTE CONTROL CONNECTIONS (32 V. Battery Charging Plants.) - Refer to instructions for ac plants except distances apply as follows: Use No. 18 wire up to 200 ft., No. 16 wire up to 335 ft., No. 14 wire up to 500 ft., and No. 12 wire up to 800 ft.




FIG. 18 - REMOTE CONTROL CONNECTIONS - A-C MODELS ONLY

CONNECTING THE STARTING BATTERIES (AC Plants). - "Wet" starting batteries are in a well charged condition when shipped from the factory. However, if they are not placed in service within 30 to 40 days, they may have become partly discharged. If such is the case, they should be given a freshening charge before being placed in service. If "dry" batteries are supplied, they must be prepared for use according to the instructions given on the tag attached to the batteries.

Batteries should always be installed on a wooden or metal rack to permit a free circulation of air around the battery. Cables for making connections between the plant and the battery are supplied with all remote start plants even though the starting batteries are not. If necessary, spread the cable lug open slightly. Don't use a hammer to drive the cable lugs onto the battery terminal posts, be-

plished, they must be prepared for use according to the instructions given on the tag attached to the batteries.

VECTRIX PLANT

MODEL NO. SPEC. NO.

IMPORTANT

CASE

IMP

COURT

MMP

PHASE

MRS

MUSE

VILL

FUEL. - Fill the fuel tank with clean recommended fuel.

PREPARATION

PREPARATION

CRANKCASE. - Fill the crankcase with 6 quarts (U.S. Measure) of heavy duty detergent SAE No. 30 oil. This includes oil for the filter. If the preparation is for cold temperature operation, do not put oil into the crankcase until just before starting. See COLD TEMPERATURES under Abnormal Operating Conditions. SAE No. 10 oil may be used at temperatures below 40°F.

CAUTION: Always be sure to replace the oil filler cap securely. A partial vacuum is created in the engine crankcase when the unit is in operation. Air leakage at the oil filler cap or gumming up of the flapper valve in the crankcase breather tube would destroy this partial vacuum and may result in oil leakage at the oil seals.




FIG. 16 - OIL FILL AND INDICATOR

AIR CLEANERS. - Fill the cups of both air cleaners to the level indicated with oil of the same SAE No. as used in the engine crankcase, except as noted for cold temperature operation. **DON'T OVERFILL.** The excess oil will be drawn into the combustion chamber by the air stream and may result in serious damage due to too heavy a charge in the combustion chamber causing the engine to "run away" (Exceed its maximum safe operating speed).

CIRCUIT BREAKER. - See that the main line switch or circuit breaker is at "OFF" position.

GOVERNOR LINKAGE. - If available, use only graphite on ball joints, especially under dusty conditions. Otherwise, use light oil on all governor joints.

FUEL VALVE. - Open the fuel shut-off valve at the fuel tank. **BLEED FUEL SYSTEM.** - Before starting a new engine, an engine that has been idle for a long period of time or an engine that has run out of fuel, it is necessary to bleed the fuel system.

Remove the bleed plug from the secondary filter. Then work the primer lever on the transfer pump until fuel fills the filter. Do not replace the plug until the injection pumps are bled. Remove the bleeder plug on the left hand injection pump. Allow fuel to flow freely at the opening until there are no air bubbles in evidence. Then replace the plug. Bleed the right hand pump in the same manner. Again operate the transfer pump primer lever to refill the secondary filter. Replace the bleed plug on the fuel filter. See the illustration BLEEDING THE FUEL SYSTEM.

NOTE: If the cam is on the high side the transfer pump will not operate. To correct, turn the crankshaft over one complete revolution. Leave the primer lever at the down position when through priming the fuel system. The pump will not operate with the lever at up position.

Bleeding procedure for "Spec F & G" models agrees with that above except "air accumulator tank" applies in place of secondary filter.

Models built prior to "Spec F" have no air accumulator tank nor bleeder plug on the secondary filter. Therefore, it is necessary to work the primer lever on the transfer pump during bleeding of each injection pump.

FUEL FLOW. - Fuel flow is from the fuel tank to the primary fuel filter, to the transfer pump to the secondary filter (air accumulator tank on Spec F and G), to the injection pumps, to the nozzles and to the combustion chambers. Fuel used to lubricate the nozzle pintle, drips back to the fuel tank through the return line.

STARTING THE PLANT

GENERAL L. - Starting instructions as described apply to starting at temperatures of 50°F. and above. Instructions for starting at lower temperatures are given under Abnormal Operating Conditions.

Check the entire installation to see that all connections and preparation have been made.

PRE-HEAT. - Hold the pre-heat switch at "ON" position up to two minutes if necessary.

CRANK. - Throw the momentary contact switch to START position and hold there until the engine is running fast enough to build up generator voltage. The engine will stop if the start switch is released too soon as current to the governor will be cut off. The engine cranks against compression and starts on compression. A sharp knock will be heard as the engine fires until it has warmed up. This is a normal condition. This sharp knock at starting diminishes as hours of operation rise.




FIG. 21 - CONTROL PANEL

CHECK. - Should the engine fail to fire within about 1 minute, release the start switch and check the fuel system before attempting to start the unit again. Check the heating elements. These elements are located in the intake manifold. The elements and glow plugs heat only when the start switch is at START position or the pre-heat switch at ON position. A glow plug is installed in each cylinder head on models beginning with "Spec'f".




FIG. 19 - BLEEDING THE FUEL SYSTEM (Units Prior to Spec. F)




FIG. 19A - BLEEDING THE FUEL SYSTEM (Spec F and Spec G Units)




FIG. 20 - BLEEDING THE FUEL SYSTEM (Units Beginning with Spec. H)

OPERATION

don't attempt to make repairs in the field. Install a new part.

OTHER CAUSES. - Refer to TROUBLES AND REMEDIES section.

POINTS TO CHECK AFTER STARTING THE PLANT

OIL PRESSURE. - The pressure reading on the gauge should be between 20 and 30 pounds at normal operating temperature. The reading will be higher than this with a cold engine but should fall to within these limits when it warms up. Should the oil pressure drop to 10 pounds or less, shut the plant off at once and determine the cause. Correct the trouble before restarting the plant. Before making any other tests, check the gauge. Beginning with "spec" plants, the low-oil pressure cut-off switch will automatically stop the plant when the oil pressure drops dangerously low.

OIL LEAKAGE. - If oil leakage occurs at the oil seals, check the breather tube check valve and the oil filler cap. The oil filler cap must be air tight.

BATTERY CHARGING RATE (AC PLANTS). - A two way switch permits the selection of a high rate of 5 amps, and low rate of 1 to 2 amps.

BATTERY CHARGING RATE (DC PLANTS). - Charge rate is controlled by a rheostat. To increase the charge rate, turn the rheostat clockwise. Follow battery manufacturer's specifications.

ENGINE SPEED. - Engine speed was set at the factory. Adjust only under Special Adjustment section.

BLACK SMOKY EXHAUST. - Black smoke coming from the exhaust outlet is an indication of trouble. Should this condition occur, shut the plant off at once and determine the cause. Correct the trouble before restarting the plant.

BATTERY CHARGING RATE (DC PLANTS). - Charge rate is controlled by a rheostat. To increase the charge rate, turn the rheostat clockwise. Follow battery manufacturer's specifications.

ENGINE SPEED. - Engine speed was set at the factory. Adjust only under Special Adjustment section.

BLACK SMOKY EXHAUST. - Black smoke coming from the exhaust outlet is an indication of trouble. Should this condition occur, shut the plant off at once and determine the cause. Correct the trouble before restarting the plant.

OPERATION

If the engine fires but fails to keep running, chances are that the fuel system has an air leak or air pocket in the suction line at some point or the start switch is being released too soon. Bleed the fuel system and check fuel connections for leakage. Then repeat the starting procedure, holding the start switch at START position until the engine picks up speed.

Fuel leakage may occur at the nozzle base when a new engine is being started the first few times after the initial start has been made. To correct, tighten the nozzle mounting nuts, or cap screws to the torque shown under Maintenance and Repair. NOTE:- Should trouble occur with the nozzle or injection pump, install a new part since a specialized repair is required.




FIG. 22 - TOP VIEW OF ENGINE

DISCHARGED BATTERY. - The battery must have sufficient charge to operate the heating elements and to crank the unit against compression. If the battery is in a well charged condition and the unit fails to crank when the start switch is thrown to ON position, check for loose connections.

FUEL SYSTEM. - Air pockets, air leaks and dirty fuel are three of the main causes of trouble in a diesel engine. When bleeding the fuel system, do a thorough job. When storing and handling fuel, use every precaution to keep it clean.

INJECTION PUMPS AND NOZZLES. - Very little trouble should be had with the injection pumps or nozzles unless dirty fuel is used. However, if trouble should occur,

Main causes of black smoke are overloading the generator, poor grade or dirty fuel, improper operation of an injection pump or nozzle or improper injection pump timing.

Black smoky exhaust is a normal condition with an overloaded generator. This condition can be easily remedied by simply reducing the load.

Black smoky exhaust at less than rated generator capacity indicates faulty combustion. Continued operation of the plant under this condition may result in stuck rings, blow-by at the rings, or premature blackening of the crankcase oil from carbon. Combustion is a direct result of loss of compression or faulty injection.

Also refer to the TROUBLES AND REMEDIES section for trouble diagnosis.

ENGINE RACES. - Stop the engine at once. This may require several steps. What usually happens when an engine races is that more fuel is drawn into the combustion chamber than can be safely burned. This extra fuel is usually drawn from the air cleaner because the cup was overfilled with oil or because the flapper valve in the breather tube is gummed up and not working properly allowing the oil to be drawn into the intake air stream. The first step in stopping the engine is to turn the governor arm toward idling position as far as it will go to cut off the normal fuel supply. Then remove the oil cup from both air cleaners. If necessary disconnect and remove the end of the hose at the breather tube. Another means of holding back engine speed is to apply a heavy electrical load to the generator. Disconnect this load when the engine has slowed down to a safe speed. Allow the engine to stop, determine what caused the engine to race and correct the trouble before starting the plant again.

VALVE CLEARANCE. - Check the valve clearance at the end of the first 50 hours of running time. Check only as needed thereafter. Refer to TABLE OF CLEARANCES under Maintenance and Repair.

FUEL KNOCK

Reference is made under starting instructions to a sharp knock that occurs when the engine is first started. This knock will usually diminish gradually as the engine warms up. However under such conditions as a cold engine, too much or too little fuel metered into the combustion chamber by the nozzle, an air leak in the suction side of the fuel system or to a change in the type of fuel used, the engine may continue to knock even after it is thoroughly warmed up. To remedy, proceed as follows:

FUEL SYSTEM. - Check for air leaks in the suction side of the fuel system. Any air leaks that are found should be corrected and the fuel system bled to remove all air from the system. The

transfer pump should be checked. The pump must provide a continuous supply of fuel at all times. Replace or repair pump if necessary.

INJECTION. - Adjust the nozzle for best operation for the type of fuel being used. Nozzles are adjusted at the factory according to the type of fuel used for the test run. The type of fuel used for test runs is changed from time to time in order to assure that these units will operate properly on any of the recommended fuels. Make the nozzle adjustment as described under the heading NOZZLE ADJUSTMENT under the Special Adjustments section of this manual.

VENTILATION. - Close ventilator openings as necessary during cold weather operation to allow the engine to warm up to normal operating temperature. Care should be taken not to close these ventilators too much. Even though the unit is installed in a room without heat it will generate a large amount of heat itself and may eventually overheat unless sufficient ventilation is provided. Readjust ventilator openings from time to time until the unit operates best without overheating. Best operating conditions are with room temperature of 50°F. to 70°F. for cold weather operation.

WHEN TO OPERATE THE PLANT

Alternating current plants supply current directly to the load and the plant must be operated whenever electricity is required.

The battery charging plant delivers current to the battery. The amount of electrical load which may be connected while the plant is not running will of course depend upon the capacity and charge condition of the battery. The amount of load which may be connected while the plant is running will be equal to the plant capacity plus the battery output. Operate the plant whenever it becomes necessary to recharge the battery or when a combined plant plus battery output is desired. To avoid possible damage to the generator, NEVER OPERATE THE PLANT WITHOUT THE BATTERY CONNECTED TO THE PLANT. CONTINUOUS OPERATION AT HIGH CHARGE RATE WHEN THE BATTERY IS FULLY CHARGED WILL "BURN UP" THE BATTERY. Check the battery specific gravity frequently while operating at high charge rate.

Most battery manufacturers recommend "cycling" the battery. This means a fully charged battery should be used without recharging until at least 85% discharged, then recharge fully. Repeat through complete cycles of charge and discharge for maximum life of the battery. Keeping a battery at a full state of charge at all times, without permitting it to cycle, may shorten its life by as much as 75%.

OPERATION

... PLANT

STOPPING THE PLANT

Reduce the at no load to allow the engine
utes at no load to allow the engine
ping the plant.

Throw the Start-stop operating solenoid off the fuel supply.

If for any reason the plant will not stop when the start-stop switch is thrown to STOP position, shutting off the governor arm to stop arm to stop position, pulling the governor arm to stop arm to stop position, stop the plant by pulling the governor arm to stop arm to stop position.

INSTRUCTIONS (AC PLANTS)

CONTROLS AND

[illegible]

gram, a better understanding will be gained. You will also be better prepared to operate the control circuits. This relay operates only while the start button is depressed. It closes the start position. It closes the stop position. It closes the stop position.

The circuit of the governor solenoid relay, the main purpose of which is to assure positive action of the glow plug relay, and the start solenoid. Its purpose is to assure positive action of a remote operate on battery current, especially when the unit is started from a remote station. Voltage loss from plant to station might otherwise affect the other relays.

GOVERNOR SOLENOID RELAY. - This relay operates only while the start switch is at the START position. Voltage loss from governor solenoid coil during cranking. The throttle opens and fuel is supplied. The start switch must be held in until generator voltage is built up. The start switch must be released.

[illegible]

MANIFOLD HEATER AND GLOW PLUGS

The manifold heaters, warming the intake air entering the engine, are connected to the glow plug circuit through the manifold heaters. Glow plugs are connected in the Manifold Heaters to aid starting. Glow plugs are connected in the "Spec F" models. Glow plugs, installed one in each cylinder head, help to ignite the fuel in the combustion chamber during the starting period. This relay operates whenever the starter switch is at START position or the heater switch is at ON position.

OPERATION

START SOLENOID. - This relay, mounted on the starting motor, completes the circuit from the battery to the field.

START DISCONNECT RELAY. - This relay operates to break the circuit through the start solenoid as the starter is cranked, cranking the unit. Current from the windings of the starter. Operates to stop the relay after the unit has gained speed. Operating current for the relay operates to stop the unit after the unit has gained speed.

This relay comes through the start switch to break the circuit to the governor. It also switches to stop cranking even though the start switch is held at stop.

STOP RELAY. - This relay operates to break the circuit to the engine fires. Throwing the start-stop switch open, and throwing the stop relay, its contacts open, the governor solenoid.

[illegible][illegible]

HIL-LO CHARGE SWITCH. - This switch regulates the starting battery by cutting resistance out of the circuit. - This switch permits the battery to be recharged.

11-120
 ance in or out of the circuit. - This switch permits manual operation of the glow plug heater and glow plug switch to starting.

MANIFOLD HEAD
tion of the heaters and glow plugs prior to starting.
meter indicates ampere rate of the starting battery.

CHARGE AMMETER. - The ammeter to or discharge from the start circuit at

START-STOP SWITCH. The terminal block facilitates installation of start-stop stations at any position.

REMOTE TERMINAL BLOCKS. lation of remote

BATTERY CHARGING PLANTS)

ATIONS (BATTERY CHARGING PLANTS)

ating Pilot

last points.

CONROLS AND THEIR FUNCTIONS (continued)

GENERAL - The Battery Charging plant does not use a Starting Pin-Relay; Start Disconnect Relay; Charge Relay; or Hi-Lo Charge Switch, and the engine is cranked by Generator Excitation In-

stead of a separate starter as used with the alternating current plants.

GOVERNOR SOLENOID RELAY. - This relay operates only while the start switch is depressed. Its purpose is to complete the circuit through the governor solenoid coil during cranking.

This releases the governor stop lever, allowing the governor to function, the throttle opens and fuel is supplied to the cylinders. The start switch must be held in until generator voltage is built up enough to operate the governor solenoid. Otherwise the plant will stop as soon as the start button is released.

MANFOLD HEATER AND GLOW PLUG RELAY. - This relay operates whenever the start switch is at START position or the heater switch is at ON position. This relay operates to complete the circuit through the manifold heaters and glow plugs. The manifold heaters warm the intake air stream to aid starting. The glow plugs, mounted one on each cylinder head, help ignite the fuel during the starting period. The glow plugs are resistance units and are connected in the manifold heater circuit. Current voltage at the glow plug, is reduced to 12 volts by first passing through the manifold heater. Don't operate the glow plug on voltage above 12 volts.

MANFOLD HEATER AND GLOW PLUG SWITCH. - This switch permits manual operation of the heaters and glow plugs prior to starting the plant.

START SOLENOID. - This solenoid completes the circuit from the battery to the series windings of the generator. Current from the battery causes the generator armature to rotate, cranking the unit. This Solenoid Switch operates only when the start switch is at START position.

STOP RELAY. - This relay operates to break the circuit to the governor solenoid. Depressing the stop switch to STOP position grounds out the coil of the stop relay, its contacts open and the circuit to the governor solenoid is broken releasing the governor stop lever. The governor stop spring pulls the stop lever against the governor arm, forcing the arm to close the throttle and stop the plant.

CHARGE AMMETER. - The ammeter indicates ampere rate of charge to the battery.

START-STOP SWITCH. - This switch completes the start circuit at START position and the stop circuit at STOP position.

300 AMPERE FUSE. - The fuse is used in the battery charge circuit to protect against overload.

RESISTORS. - Resistors are used to limit the voltage in the circuits to the Start Solenoid, the Stop Relay, and the Governor Solenoid.

FIELD RHEOSTAT. - The rheostat, connected in series with the shunt field windings of the generator, controls the output of the generator by varying the strength of the shunt field. This is done by varying the amount of resistance in the field circuit through different settings of the rheostat; the more resistance in the field circuit, the less the generator output.

SHUNT. - Shunt is used in the output circuit to permit use of the dc ammeter.

OPERATION CAUTION!

CARBON DEPOSITS IN THE EXHAUST SYSTEM MAY OCCUR IN ENGINES CONSISTENTLY OPERATED AT VERY LIGHT LOAD!

The recommended remedy is to apply a dummy load consisting of lights or heating elements to create a total load greater than 1/2 the rated generator capacity. An alternate recommendation is to operate the plant at full load for about 5 minutes just before stopping.

THE ENGINE LUBRICATING OIL PUMP SHOULD BE PRIMED BEFORE OPERATING AFTER EXTENDED PERIOD OF STORAGE!

Remove the oil by-pass cap, spring, and valve located near the oil pressure gauge and add about two ounces of oil. Note that the valve has a 3/8-16 internal thread to facilitate lifting it out. Reassemble, start, then check oil pressure immediately!

TING CONDITIONS

ABNORMAL OPERATING CONDITIONS

Keep fuel supplies free of water.

When bleeding the fuel system be sure to

Intervals of fuel injection are not restricted by sludge or wax crystals. Under extremely cold conditions, give more frequent attention to the filler and pour point, but as 30% and does not restrict the filler at all times.

Under extremely cold conditions, battery drops as much as 30% and does not restricted by all times. Under extremely cold conditions, battery drops as much as 30% and does not restricted by all times.

Keep the battery fully charged. A battery with a low terminal voltage of a battery cannot crank the engine fast enough to start the engine. Under conditions the terminal voltage of a cold engine is low, connected in parallel, not have power enough to crank a cold engine. Remove this booster and add a 12 volt battery, connected in parallel, to the cranking speed.

A temporary addition will improve crankshaft starting period will improve Crankshaft starting period will improve.

Check the charged condition of the batteries will freeze between temperatures depending on the state of charge. Watch the oil level and change the oil frequently. Watch the oil level and change the oil frequently.

Let the engine warm up carefully. Don't apply any load until the engine is at normal operating temperature.

HIGH TEMPERATURES - Keep the level of the oil in the engine pressure carefully. - Keep the level of the full mark at all crankcase at or near the full mark at all times. Provide ample ventilation so that radiated heat from the engine to overheats. Keep all cooling fans running if necessary. Keep all cooling fans running if necessary. Keep all cooling fans running if necessary.

more or larger areas. For the installation, follow the instructions for surfaces clean and free of dust, dirt, and grease. The installation agrees

BATTERY. - For a complete INSULATION. Batteries under insulation prepare the battery to insulate. Gravity.

[illegible]

Standard automotive type, and quickly when installed where ambient temperature is 70° F., such as in a boiler room. To length battery life, and electrolyte from a normal 1.275 reading at full charge to a 1.225 reading. If temperature is also reduced when electrolyte is

The cranking power of the engine is adjusted by diluting to reduce acid activity and temperature is consistently above 90°F. (32.2 C.) adjust the temperature as instructed below.

CONDITIONS

TEMPERATURES

COLD TEMPERATURES

Drain the crankcase oil while the engine is warm and refill the crankcase with heavy duty detergent SAE No. 5 oil. Start the engine and let it run for 1/2 hour. For heavy duty operation or continuous service, change to SAE No. 30 oil and provide some means of heating the space between the air cleaner and the engine to clean the air cleaner and

run for 1/2 hour. 30 oil and provide some change to SAE No. 5 oil. Cleaners tends to congeal, clean the air cleaner and in which the plant is located. SAE No. 5 oil. Con- SAE No. 5 oil. Con-

if the oil in the air cleaner to the level indicated on the dipstick. Refill the air cleaner to 5 oil until temperatures return to normal. heating the oil used in the air cleaners to be helpful. The oil should not be used in the engine. The oil should not be used in the engine.

In extremely cold weather, heating should be helpful.

Surround the boiling point of water cleaner cups. Heating should not damage the oil in the air cleaner as direct heat will damage the oil in the air cleaner.

The oil in the air cleaner should be heated while the oil is in the air cleaner and don't be attempted to clean until.

CAUTION: DON'T HEAT OR OVERHEAT IT.

Any other means of increasing the temperature of the combustion chamber will aid starting. Heating elements in the combustion chamber is ignited by the rise in temperature of the combustion chamber.

The fuel in the combustion chamber due to its temperature of the air before it enters the combustion chamber is provided to help ignite the mixture of the air and fuel. Glow plugs are connected in the starting circuit of Spec F models. Glow plugs are connected whenever the engine is started. Beginning with Spec F models, Glow plugs are connected whenever the engine is started. Beginning with Spec F models, Glow plugs are connected whenever the engine is started. Beginning with Spec F models, Glow plugs are connected whenever the engine is started.

divided so that the fuel is to be started the plant. Throw this fuel about 2 minutes just before the plant is to be started. BE SURE THE FUEL USED HAS A LOW POUR POINT (at least 10 degrees lower than the prevailing temperature) AND WILL FLOW FREELY AND NOT CONGEAL IN THE LINES. Fuel tends to form wax crystals and congeal in the filters and fuel lines at low temperatures. Stale and congeal in the filters, warm the fuel or change to a Diesel fuel having a lower pour point. The lowest temperature at which the fuel will flow through a pipe is known as the pour point or congealing point. Clogged screens interrupt the flow

**Keep all fuel tank screens clean.
of fuel and may cause air leaks.**

ABNORMAL OPERATING CONDITIONS

1. Fully charge the battery. DO NOT BRING AN OPEN FLAME OR BURNING CIGARETTE NEAR THE BATTERIES ON CHARGE BECAUSE THE GAS RELEASED DURING CHARGING IS VERY INFLAMMABLE.
2. While battery is on charge, use a hydrometer or filler bulb to siphon off all of the electrolyte above the plates in each cell. Don't attempt to pour off!! Dispose of the removed electrolyte. AVOID SKIN OR CLOTHING CONTACT WITH ELECTROLYTE.
3. Fill each cell with pure distilled water.
4. Recharge the batteries for one hour at a 4 to 6 ampere rate.
5. Use a reliable battery hydrometer, to test each cell. If the specific gravity is above 1.225, repeat steps number 2, 3, and 4 until the highest specific gravity reading of the fully charged battery is not over 1.225. Most batteries require repeating steps 2, 3 and 4 two times.

DUST AND DIRT

Check plant operation more often and service as needed.

Clean the air cleaners as often as necessary to assure a free passage of air to the combustion chambers.

Check the commutator and brushes of the generator and see that the brushes ride freely in their holders and make good contact. See GENERATOR under Maintenance and Repair for service instructions


Keep supplies of fuel and oil in air tight containers.

Keep the plant as clean as practicable.

SPECIAL PRIMING KIT FOR COLD WEATHER STARTING

37

- Compact
 - Easily installed
 - Simple to operate
- Incorporates using special starting fluid in capsule form by atomizing fluid into engine induction system.
- Permits starting if temperature permits cranking!
- Old engines no longer hesitate to start!



The ability to start a diesel engine in cold weather is limited by several factors among which are engine condition, fuel pour point, ability to pass fuel through filter and ability to crank.

The low kindling point fuel used with the primer permits starting at lower temperatures.

PERIODIC SERVICE

GENERAL. - Certain services must be performed periodically if your plant is to continue operating efficiently and economically. Service periods are based on hours of running time under normal operating conditions. For extreme conditions of load, temperature, dust, dirt, etc., service more often.

DAILY SERVICE

Perform the following services daily or at the end of each 8 hours of running time, whichever occurs first.

FUEL. - Check the fuel supply often enough to avoid running out of fuel. Use only recommended fuel.

CRANKCASE OIL LEVEL. - Check the oil level as indicated on the bayonet type gauge. Add recommended oil to replace the oil fill cap securely. Air leakage at this point may cause oil leakage at the seals and oil carry-over past the breather valve.

AIR CLEANER. - Check the oil level in the air cleaner cups. If necessary add oil of the same SAE No. as used in the engine crankcase.

CLEANING. - Keep the plant clean. A clean plant will give longer and more satisfactory service.

WEEKLY SERVICE

Perform the following services weekly or at the end of each 50 hours of running time, whichever occurs first.

CRANKCASE OIL. - Change the crankcase lubricating oil every 100 hours of running time. If sludge formation or condensation forms during cold weather operation, then change oil more often. Change the oil filter cartridge each time the crankcase oil is changed. Remove the drain plug from the oil filter and drain the old oil before installing the new cartridge.

GENERAL LUBRICATION. - If available, use only powdered graphite on the governor ball joint to promote best performance and longest wear. Otherwise, use light oil on all governor joints.

STARTING BATTERIES. - Check the fluid level in the starting batteries. Add distilled water to bring the fluid to 3/8" above the separators if necessary.

AIR CLEANERS. - Thoroughly clean the air cleaner cups in Diesel fuel and refill the cups to the level indicated on the cup with oil of the same SAE No. as used in the engine crankcase, except as noted under Abnormal Operating Conditions.

PERIODIC SERVICE

GENERAL INSPECTION. - Tighten all loose nuts, bolts, connections, etc.

VALVE CLEARANCE. - Check the valve clearance at the end of the first 50 hours of running time. Reset the valve clearance if necessary.

MONTHLY SERVICE

Perform the following services monthly or at the end of each 200 hours of running time, whichever occurs first.

GENERATOR. - Check the generator brushes. Brushes worn to 5/8" in length should be replaced.

Check the commutator and collector rings. A glossy brown color is normal. Brush surfaces must be smooth and cylindrical to assure good brush contact. See GENERATOR under the heading Maintenance and Repair for instructions.

FUEL FILTER. - Select and refer to the illustration SERVICING THE FUEL FILTER which applies. Be clean. Be thorough.

Intervals of necessary fuel filter service is dependent upon the cleanliness of the fuel used. Engine operation is the best indication of necessary filter service. The primary filter may have to be serviced several times before it is necessary to service the secondary filter (not used on Spec F and G). It is a good practice to have a spare secondary fuel filter cartridge on hand for use if trouble occurs. More damage may result, from dirt getting into the fuel system and clogging the injection pump or nozzle during periodic servicing of the filters, than might be gained by a periodic service aimed at preventing trouble.

To determine if plant failure is due to an air leak, try operating with the fuel supply raised above the level of the filter.


EXHAUST SYSTEM. - Inspect exhaust connections. Tighten or replace parts requiring it. Remove carbon deposits if condition exists.

ENGINE COMPRESSION. - Valve grinding is a service that must be performed periodically if your plant is to continue operating efficiently. There is no set period for performing this service. However, it is recommended that the following tests be made whenever the plant begins to lose power or consume an excessive amount of fuel or oil.

Insert the crank into the opening provided for this purpose at the front of the engine. Engage the crank dog and crank the engine over slowly. If compression is good it will require a lot of strength to crank the

BEST PROTECTION AGAINST FILTER TROUBLE IS THE USE OF CLEAN FUEL

Filters Should Be Cleaned Only When Necessary. The Primary Filter May Have To Be Cleaned Several Times Before It Becomes Necessary To Clean The Secondary Filter.



SECONDARY FILTER SERVICE (Don't Disassemble Unless Necessary)

DRAIN SLUDGE at Filter Base (1) (Each 6 Months or Often).

CARTRIDGE SERVICE Should Be Performed Only When Necessary. Failure to Pass Fuel, or Excessive Sludge Accumulation, Indicates a New Filter Cartridge Is Required.


Unscrew, but Don't Extract, the Large "Through" Screw (2) and Lift Off the Entire Body (3) Assembly From the Base (4). CLEAN the Filter Base and Body but Don't Allow Dirt to Enter the Passages to the Injection Pumps. Install a New Cartridge (5) Placing the End Marked "TOP" Toward the Filter Base, and Have All Gaskets (6, 7, 8, 9, 10) in Place, Using New Gaskets Where Needed. BLEED the System.

PRIMARY FILTER SERVICE

EMPTY WATER and SEDIMENT from Bowl (11) (Each 6 Months or 1200 Operating Hours). The Bowl Supports the Strainer Element and Gasket. CATCH THEM!

Bowl to Cover Gasket (12) Is Reusable with Successive Emptyings of Bowl. However, Renew Both Bowl to Cover Gasket (12) and Strainer to Cover Flare Gasket (13) with Each Cleaning of Brass Disc Strainer Element (14).

CLEAN Strainer ELEMENT (14) Only When It Won't Pass Fuel! Loosen Nuts (15) and Carefully Separate Discs. Submerge and Scrub in Clean Diesel Fuel or Suitable Solvent. Have Clean Hands! Rinse Thoroughly in Clean Fuel. Either Dry with Compressed Air or Leave Element Wet. Retighten Nuts. Prevent Dirt from Entering Internal Area of Discs.




WHEN CLEANING FUEL SYSTEM INTERNAL PARTS, "SWISH" THEM THOROUGHLY IN CLEAN DIESEL FUEL. DO NOT ATTEMPT TO WIPE DRY. HAVE HANDS CLEAN. BE THOROUGH!

FIG. 23 - SERVICING THE FUEL FILTER
(Units Beginning with "Spec H")

THE BEST PROTECTION AGAINST FILTER TROUBLE IS THE USE OF CLEAN FUEL

Note- FILTERS SHOULD BE CLEANED ONLY WHEN NECESSARY. THE PRIMARY FILTER MAY HAVE TO BE CLEANED SEVERAL TIMES BEFORE IT BECOMES NECESSARY TO CLEAN THE SECONDARY FILTER.



CLEAN FILTERS WITH COMPRESSED AIR IF AVAILABLE. BLOWING AIR FROM INSIDE OF ELEMENT TO THE OUTSIDE.

Caution

BE SURE AIR PRESSURE TANK AND LINES DO NOT CONTAIN WATER. ALWAYS OPEN NOZZLE TO CLEAR WATER FROM LINES BEFORE CLEANING FILTER ELEMENT. DO NOT DAMAGE SCREEN.

Gasket-

ALWAYS INSTALL A NEW GASKET WHENEVER THE FILTER BOWL IS REMOVED.



IF FILTER ELEMENT MUST BE CLEANED BY SUBMERGING OR SWISHING IN CLEAN DIESEL FUEL CLOSE TOP SO THAT SOLUTION CAN NOT GET INSIDE AND LEAVE SEDIMENT.

FIG. 24 - SERVICING THE FUEL FILTER
(Units Prior to "Spec F")

engine past the compression stroke. If compression is poor, the engine can be cranked past the compression stroke although not easily due to the high compression ratio of the engine.

Loss of compression may be due to a poor valve condition, worn or sticking piston rings, worn piston ring grooves or to worn cylinder walls. If an exhaust valve is leaking, it can be heard at the exhaust outlet on the plant. If the intake valve is leaking, a hissing noise will be heard at the air cleaner opening. A compression leak past the piston rings can be heard at the oil filler opening.

SEMI-YEARLY SERVICE

Perform the following services every six months or after each 1200 hours of running time, whichever occurs first.


GENERATOR BEARING. - Clean all dirt from around the generator bearing cover and remove the cover. On some models the cover is pressed into the bearing support and is removed by prying it out. Other models have a cover held in place by screws.

Lubricate the generator ball bearing at intervals determined by the type of grease used. Follow the paragraph of instructions below which agrees with the type of grease used. Avoid mixing different greases whenever practicable.


Lithium base type grease is used and recommended by the factory. This bearing grease is superior because it does not run, and will not become hard or caked when used at temperatures ranging from minus 90°F. to 125°F. With lithium base grease, service the generator ball bearing each 5,000 operating hours or each 2 years. Only a small quantity of this grease need be used. With a clean finger, remove as much as possible of the old grease. Force fresh grease into a 1/4 section of the bearing. DO NOT fill the entire bearing. Do not put a reserve of grease in the bearing recess nor in the bearing cover. If dirt has gotten into the bearing, remove the bearing and clean it in a good solvent. Dry the bearing thoroughly and reinstall it.

If ordinary good ball bearing grease is used, service the generator ball bearing each 1,200 operating hours or each 6 months. With a clean finger remove all the old lubricant and work approximately one tablespoonful of new bearing lubricant into the bearing. Again clean out the bearing, then refill about 1/2 full, packing the lubricant well into the lower half of the bearing.


TO FACILITATE FILTERING OF VERY COLD FUEL, WARM TO DISSOLVE WAX CRYSTALS.



REPLACE GASKET WHEN REMOVING FILTER CARTRIDGE. IT IS IMPORTANT THAT COVER FIT BOWL IN AN AIRTIGHT SEAL.



REPLACE FILTER CARTRIDGE EVERY 1000 HOURS OF OPERATION. (MORE FREQUENTLY IF DIRTY FUEL IS USED.)



CLEAN WATER AND SEDIMENT OUT OF BOWL

The best protection against filter trouble is the use of clean fuel.

FIG. 24A-SERVICING THE FUEL FILTER
("Spec F" and "Spec G" Units)




FIG. 25 - SERVICING THE GENERATOR BEARINGS

BRUSH RIG. - Check the generator brush rig to see that it has not shifted from its original position. Operation of the generator with the brushes out of neutral position causes rapid brush wear and excessive arcing of the brushes. Instructions for adjusting are described in the GENERATOR section of Maintenance and Repair.

GOVERNOR

GENERAL. - The governor is set at the factory to maintain a preferred regulation. Before attempting to make any adjustments on the governor it is recommended that the following paragraphs be carefully studied and that each point be checked in the order given.

LINKAGE, GOVERNOR ARM AND THROTTLE. - The linkage between the two throttle levers should be adjusted so that at full rated load both cylinders will pull equal load and at stop position still fully close the throttle of both pumps. Apply a load of about 5000 watts (4000 watts for 50 cycle units) and check the exhaust for a smoky condition. If one cylinder is getting too much fuel it will tend to smoke. Loosen the linkage adjusting turnbuckle lock nut and turn the turnbuckle a little at a time until smoky exhaust clears. Then tighten the lock nut. See the illustration **THROTTLE LEVER POSITIONS.** Remove all load and press the stop button on the plant. If the plant stops the setting is correct. If the plant does not stop, the adjustment made at full load probably holds one throttle open at stop position. If the throttle stops on both pumps do not touch the stop screw at the closed position and again at the wide open position, the arcs made by the throttle levers must be synchronized by adjusting one of the levers.

Check the governor arm, linkage and throttle levers for a binding condition and for excessive slack or wear at connection points. A binding condition at any point will cause the governor to act slowly and regulation will be poor. Excessive looseness will cause a hunting condition and regulation will be erratic. Work the arm back and forth several times by hand while the plant is idle. If either of these conditions exist, find out at which point the trouble lies and adjust or replace as required.

The linkage and the position of the governor arm must synchronize the travel of the governor arm and throttle levers so that the governor is wide open when the throttle levers are wide open and closed when the throttle levers are closed. The position of the governor arm is fixed and adjustment is made through the connecting linkage. Turn the governor arm away from the injection pump as far as it will go to place the governor shaft yoke against the governor cup. Then with the tension of the governor spring holding the arm at wide open position, adjust the linkage to hold the throttle levers at wide open position. See the illustration **GOVERNOR ADJUSTMENT.** Be sure there is no looseness or binding at any point.

Although the factory sealed position of the throttle lever stop on the injection pump is adjustable, the position should never be changed or altered in any manner as it fixes the position of the shaft which in turn determines the flow of fuel to the injection pump. If necessary to reset the stop, due to accidental loosening, refer to **RESETTING THE**

INJECTION PUMP THROTTLE STOP under Special Adjustments.

GOVERNOR SPRING. - Due to the fact that springs become fatigued and lose their original tension from long usage, it sometimes becomes necessary to install a new governor spring to get proper regulation. It is difficult to determine whether or not a spring is fatigued. Usually if all other adjustments have been properly made and regulation is still erratic, the trouble can be corrected by installing a new governor spring and resetting the sensitivity and speed adjusting screws.

SENSITIVITY ADJUSTMENTS. - The position of the sensitivity adjusting screw controls of the travel and leverage of the governor spring and determines the rpm between no load and full load. This rpm difference should not be more than 105 nor less than 45 rpm. Check with a tachometer. To increase rpm between no load and full load, turn the sensitivity screw out, to decrease, turn the screw in. See the illustration GOVERNOR ADJUSTMENT. Always recheck engine speed after making a sensitivity adjustment.

A hunting condition (engine alternately increasing and decreasing speed) may result from rpm between no load and full load being too close. Should this condition exist, turn the sensitivity screw out until the condition is corrected. Regulation is better with the end of the spring held closer to the governor shaft but the tendency to hunt is increased. Make the adjustment that gives the best regulation with no hunting. A more likely cause of the engine hunting is lack of fuel due to improper adjustment or blockage of the fuel system.

SPEED ADJUSTMENT. - The speed at which the engine operates is determined by the tension applied to the governor spring. Engine speed also determines current frequency and output voltage of the generator. Increasing spring tension increases engine speed and generator voltage. Decreasing spring tension decreases engine speed and generator voltage. Check engine speed with a tachometer. Check voltage with a voltmeter. Nominal engine speed and generator voltage should be as follows.

Speed and voltage tests should be made when the plant is warm, running for at least one hour before the test is made. Voltage limits for circuits of voltages other than shown below, will be multiples of those shown. Always check the voltage of each phase to detect an abnormal condition or fault. On 4 wire plants, the lower voltage (line to neutral) is always correct when regulation is correct for the higher rated voltage (line to line).

MAXIMUM NO LOAD ENGINE SPEED should not be more than 1920 rpm for 60 cycle units nor more than 1710 rpm for 50 cycle units.

TRANSFER PUMP. - A transfer pump of the diaphragm type is used to transfer fuel from the fuel tank through the filter and to the injection pumps. If fuel does not reach the filter, make the following checks before removing the transfer pump. Check the fuel tank to see that there is enough fuel in it and the shut-off valve is open. Disconnect the fuel line at the transfer pump outlet and work the lever on the pump. Fuel should spurt out of the pump outlet. If there is enough fuel in the tank, the shut-off valve open, the lines between the tank and pump are clear, but fuel does not spurt out of the pump outlet when working the primer, repair or replace the pump. Pump failure is usually due to a leaking diaphragm, a valve or valve gasket, a weak or broken spring or wear in the driving linkage. A 1/4 turn of the diaphragm will release the driving link.




FIG. 29 - TRANSFER PUMP LINKAGE

Should a new drive link be required, install as shown in the illustration TRANSFER PUMP LINKAGE.

ROCKER ARM REMOVAL. - Remove the blower housing, the valve compartment cover plates, and the oil feed lines from both heads.

Turn the flywheel until the valves of the left hand cylinder open and close and continue about 1/2 turn until the TC mark on the flywheel is aligned with the indicating pin or mark in the flywheel housing timing hole.

Back off the valve adjusting screws.

Remove the pin from the rocker arm shaft.

Use a brass rod and drive the rocker arm shaft out toward the blower housing end of the unit until the "O" ring can be removed from the shaft. Then remove the "O" ring and drive the shaft out toward the generator end of the unit. The rocker arms, springs and bushings can then be removed.

For right hand rocker arm removal, turn the flywheel over one complete revolution and again align the TC mark and the indicating pin or mark. Then repeat the above procedure except the direction of shaft removal is opposite.

ROCKER ARM INSTALLATION. - See that the TC mark on the flywheel and the indicator mark at the timing hole are aligned for the cylinder for which the rocker arms are being installed.

SPECIAL ADJUSTMENTS




FIG. 30 - ROCKER ARM INSTALLATION

Note that there is a small hole near one end of the rocker arm shaft. There is also a small hole in one of the shaft bosses in the cylinder head. Insert the end of the shaft having the drilled hole, into the shaft boss opposite the boss having the hole. Start the shaft so that holes in the shaft and boss will align when the shaft is in place. See the illustration ROCKER ARM INSTALLATION. Start the shaft by hand, keeping the holes in alignment.

Tap the shaft gently with a lightweight soft faced hammer and drive the shaft through the boss until about one inch extends beyond the boss on the inside.

Place the bushings on the shaft as needed to center the rocker arm over the push rod and then the rocker arm for the intake valve. Hold them in place and drive the shaft about half way through the valve compartment.

Place one bushing on the shaft, then the spacer spring, one more bushing, then the other rocker arm. Drive the shaft through just far enough to engage the rocker arm. Then insert bushings as needed between the rocker arm and the boss to center the arm over the push rod. These can be held in place by inserting a finger through the shaft boss until contact is made with the shaft.

Install an "O" ring on the shaft groove at the exposed end of the shaft and drive the shaft through the boss until the shaft groove on the other end of the shaft is in evidence on the opposite side of the head.

Install the other "O" ring on the shaft and drive the shaft back into the boss until the hole in the shaft and in the boss are aligned, then drop the pin into place.

Install the oil line fitting on the end of the shaft and connect the oil line. Make sure, on plants with glow plugs, that the oil line does not short out the glow plug.

Reset valve clearances.

SPECIAL ADJUSTMENTS

Replace the other parts removed to complete the installation in head.

For the other head, turn the flywheel over one complete revolution and again align the TC mark and the indicating mark. Then repeat the above procedure.

PUSH RODS. - The disassembly and assembly of the rocker arm push rods is self-evident. However, the tappets that operate the push rods will come out much easier if it is known that each tappet has a hole drilled part way down its length into which a bent wire can be inserted and the tappet lifted out.

NOZZLE ADJUSTMENT. - A nozzle adjustment is recommended only as a measure of correcting a fuel knock resulting from a change in the type of fuel used. Then both nozzles may require adjusting. Otherwise the original setting should not be disturbed. The adjustment is made as follows:

Start the unit and allow it to run until thoroughly warmed up. Then apply a full load.

Remove the top cover ① from the nozzle holder. See the illustration NOZZLE ADJUSTMENT.

Loosen the locknut ② just enough to allow the adjusting screw ③ to turn.

Insert a screwdriver into the screwdriver slot of the adjusting screw ③, hold a wrench on locknut ② and turn the screw ③ in the first one direction and then the other until fuel knock is least noticeable. CAUTION: Do not turn the adjusting screw ③ more than one turn in either direction from its original position.

Lock the adjusting screw locknut ② securely after making an adjustment. Then replace the cover ① securely, being sure the two thin washers are in place under the cover and locknut.

NOTE: Nozzles are adjusted at the factory to operate at 1750 to 1800 pounds (per sq. inch) pressure. Nozzle pressure should be the same for both nozzles. If necessary, have the nozzles checked on a nozzle tester to assure even pressure.

CORRECTING

INJECTION PUMP THROTTLE LEVER POSITION

Should it become necessary to remove the throttle lever from either pump or should the throttle lever work loose, use the template as shown to correctly position the throttle lever on its shaft. **NOTE:** If a new pump is being installed, always time the pump to the engine before positioning the throttle lever.

SPECIAL ADJUSTMENTS




FIG. 31 - NOZZLE ADJUSTMENT

LEFT HAND PUMP. - Remove mounting nuts and washers from injection pump.

Install template on studs and secure with pump mounting nuts.

Remove the ball joint stud from the throttle arm.

Loosen throttle lever lock screw just enough to permit turning and turn lever against throttle stop position (See the illustration THROTTLE LEVER POSITIONS reference 1) until hole in lever aligns with hole in template marked "L". Throttle lever stop must be hard against stop pin in stop position when holes align.

Insert the ball joint stud through throttle lever and template holes to hold alignment and secure the throttle lever to the shaft by tightening the locking screw.

Remove ball joint stud and template.

Secure pump with nuts and washers.

Connect ball joint stud on throttle lever.

RIGHT HAND PUMP. - Remove mounting nuts and washers from injection pump.

Install template on studs and secure with pump mounting nuts.

Remove the ball joint studs from both arms.

Loosen throttle lever lock screw just enough to permit turning and turn the lever against throttle stop position (See the illustration THROTTLE LEVER POSITIONS reference 2) until the hole in the second arm aligns with the hole in the template marked "R". Throttle lever stop must be hard against pin stop in stop position when holes align.

Insert governor linkage ball joint stud through throttle lever and template holes to hold alignment and secure the throttle lever to the shaft by tightening the locking screw.

Remove the ball joint stud and template.

Secure pump with nuts and washers.

Connect ball joint studs to throttle lever.

CORRECTING LENGTH OF THROTTLE ROD

Adjusting the throttle linkage between the two injection pumps may be necessary to smoothen out engine performance. If one pump supplies more fuel to its cylinder than the other pump, the cylinder receiving the most fuel will tend to carry more of the load and operation will be uneven. To smoothen out engine performance, adjust as follows:

Allow the engine to warm up thoroughly. Then apply almost a full load to the generator.

Loosen the turnbuckle locknut (See the illustration THROTTLE LEVER POSITIONS reference 2) and rotate turnbuckle slowly back and forth until engine performance is smoothest. CAUTION: DO NOT ROTATE TURNBUCKLE MORE THAN ONE TURN IN EITHER DIRECTION.

RESETTING INJECTION PUMP THROTTLE STOP

Should the throttle shaft stop lever ever work loose or be loosened accidentally, reset as follows:

Crank the engine over by hand until the TC mark on the flywheel and the mark on the flywheel housing are in line on the compression stroke of the left hand cylinder for adjustment of the left hand pump, or the compression stroke of the right hand cylinder for adjustment of the right hand pump. Then back up about 1/6 of a turn (60°) against rotation.

Disconnect the fuel line from the injection pump outlet.


Remove the valve from the injection pump outlet.

Remove the throttle lever and loosen the throttle stop socket head screw so the shaft will be free to turn.

Place a 0.030" feeler gauge over the throttle stop screw or pin and turn the throttle stop to the left (counterclockwise) until it rests against the gauge.


Align hole in lever with hole marked 'I' in template.

Put linkage stud through holes in both the lever and template before tightening lever lock screw. Then remove template.



CAUTION

WHEN POSITIONING ARM ON SHAFT, TURN THROTTLE LEVER IN A COUNTER CLOCKWISE DIRECTION ONLY STARTING FROM THE APPROXIMATE POSITION INDICATED BY BROKEN LINES.



Smooth engine performance by turning turnbuckle on linkage. Do not turn more than one turn in either direction.

Align hole in lever with hole marked 'R' in template. Put linkage stud through holes in both the lever and the template before tightening lever lock screw. Then remove template.

Have someone work the manual primer on the transfer pump. Use a steady motion so that the flow of fuel will be fairly steady.

Slowly turn the shaft to the right until fuel flows freely from the injection pump outlet.

Slowly turn the shaft to the left (counterclockwise) until fuel just stops flowing.

NOTE: If the flywheel has been turned too far or not far enough before TC mark, the fuel may not stop flowing at any point. If this happens turn the flywheel a few degrees one way or the other to correct the condition.

Without disturbing the position of the shaft, tighten the throttle-stop socket head screw securely to lock the shaft in place.

Replace the throttle lever and reset the position described in the illustration THROTTLE LEVER POSITIONS.

Replace the valve in the injection pump outlet and connect the fuel line to complete the job.




FIG. 33 - RESETTING THROTTLE STOP

FIG. 32 - THROTTLE LEVER POSITIONS

ENGINE

58

RUNNING TIME METER


Don't Guess - Know how many hours your plant runs, so that you can change oil and service the plant at proper intervals.

This meter will be an investment rather than an expense. Simple to connect. This meter runs only when the plant is operating.


PART NO.	USED WITH PLANT
302-68	60 Cycle, 115 V. A.C.
302-102	50 Cycle, 115 V. A.C.
304-99	Resistor - adding to either meter above makes it suitable for 230 V. use.

Meters listed above are 3-1/2 inch diameter, and are for flush mounting on panel; fit into 2-29/32 inch hole. For wall mounting, order separately.

301-500 Instrument Box



INSTRUMENT BOX



RUNNING TIME METER

GENERAL. - Certain new engines when leaving the factory have a .005" oversize cylinder bore. This oversize is indicated by the addition of a letter to the engine serial number. For example: Serial No. 48.382425E, the letter E indicating .005" oversize. The piston oversize is stamped on the top of the piston.

Pistons and rings are available in various oversizes for rebore jobs. Piston pins are also available in an oversize. Main bearings and connecting rods are available in an undersize. See the parts list. Before ordering any repair parts in an oversize or undersize and before doing any repair work on your unit, turn to the parts list and see if the parts needed are available in an oversize or undersize.

CYLINDER BLOCK INSPECTION. - The oil must be drained from the oil base and the oil base removed before the inner parts of the engine can be inspected. Visually inspect all parts in the block. Feel the fit of working parts. If your experience with engine is limited, your dealer or any good local mechanic should be able to help you decide on the need for repairs.

Always drain the oil whenever servicing bearings, timing gears, rods, pistons or rings. Thoroughly clean the oil pump suction screen and oil reservoir before reassembling the engine. Refill the crankcase with proper oil before attempting to start the engine.




FIG. 34 - CYLINDER BLOCK INSPECTION

CYLINDERS. - When making major repairs to your unit it is well to have the cylinders measured for wear. This requires the use of a dial gauge. Your dealer or any good local mechanic should be able to check the cylinders for wear. The cylinder bore of a new

MAINTENANCE AND REPAIR

engine is 3.5015" to 3.5025". If the cylinder bore measures more than .005" out of true, the cylinder should be refinished to use the next available oversize piston. Pistons are available in .010", .020", and .030" oversize. Piston rings are available in .010", .020", and .030" oversize. If the cylinders don't need refinishing, it is advisable to remove the ridge from the top of the cylinder walls before replacing pistons and rings. Also read the following on Piston and Piston Ring Service.

PISTON AND PISTON RING SERVICE. - Each piston has three (some early models used four) compression rings and two (models prior to "Spec F" used one) oil control rings. The top compression ring is chrome faced. Pistons are cam ground and taper ground. To measure the piston wear, or piston to bore clearance, piston must be measured at bottom of the skirt which is at right angle to the piston pin.

Inspect each ring carefully for fit in piston groove, for tension and for seating on the cylinder wall. If there is any doubt as to the condition of old piston rings, install new rings. It is advisable to roughen up the cylinder walls before installing new rings. The rings will seat much faster and better. The cylinder walls can be roughened with a wire brush or an abrasive such as emery cloth. Be very careful to remove all abrasive from the engine.

Clean all carbon from pistons, rings, cylinders, cylinder heads, valves, gaskets surfaces etc. before installing any parts.

Carefully inspect the pistons. If pistons are badly scored or burned, very loose in the cylinder, have badly worn ring grooves or are otherwise not in good condition, install new pistons. A new piston should also be installed if the old one is loose on the piston pin and an oversize pin will not correct the fit. Handle pistons carefully to avoid nicking the walls. Any raised surface of this type must be carefully dressed down with a fine stone. **CAUTION: BE CAREFUL NOT TO FLANGE END OF PISTON PIN WHEN REASSEMBLING THE PISTON AND ROD.**

When installing piston rings fit each ring singly to the cylinder from the top. See the illustration **PISTON AND PISTON RING SERVICE.** The correct ring gap while in the cylinder is between .010" and .015" for all rings except the top compression ring. The gap for this ring is from .010" to .020". Rings usually require some filing at the ends to obtain the right gap. Don't use rings that need a lot of filing at the ends to obtain the right gap as they will not seat properly on the cylinder walls. Install all rings on the piston before installing the piston in the cylinder. Coat cylinder walls with a thin coating of lubricating oil for cylinder lubrication when restarting the unit. Rings of the tapered type will be marked "TOP" or marked in some other manner and this mark must be placed nearer the top of the piston.




FIG. 35 - PISTON AND PISTON RING SERVICE

Chrome compression rings, when used, are used in the top groove. Compression rings fit into the three top grooves of the piston, the oil control rings in the bottom two grooves. The top compression ring is slightly heavier than the other two compression rings of each piston. This ring must be placed in the top piston groove. By inspecting the rings carefully you can tell which of the three are the thickest. Another means is by the ring gap. The heaviest ring will have a slightly wider gap when free. Space ring gaps 1/4 of the way around the piston from each other, being sure no ring gap is directly in line with the piston pin. Install the piston (assembled to the connecting rod) in the cylinder from the top. Compress each piston ring carefully so that it will enter the cylinder without damaging the ring. Don't use excessive force. Push the piston in until the top is flush with the block. Be sure the reference marks on the connecting rods and caps are aligned and face the oil base and that the rod fits easily into place on the crankshaft journal. See the illustration **CYLINDER BLOCK INSPECTION.** Coat the crankshaft bearing journals with oil before securing the rod. Apply oil liberally to the cylinder walls and rings.

CONNECTING RODS. - The connecting rods should be serviced at the same time as the pistons or piston rings as the rod must be removed with the piston. Observe and mark each rod and cap to assure reinstalling them together and to the same journal of the crankshaft. Then remove the cap screws, lockwashers and cap from

each rod and push the piston and rod assembly out through the top of the cylinder. Carefully hold the piston so that it doesn't hit against something as it clears the cylinder, resulting in damage to the piston or rings.

Two types of connecting rods have been used. For proper weight balance, use either both forged steel or both aluminum alloy rods.

The aluminum alloy connecting rod does not use separate bearings. Proper clearance between the rod bearing surface and the crankshaft bearing surface is obtained by dressing the connecting rod cap. See the illustration REDUCING CONNECTING ROD CLEARANCE. For correct clearance refer to Table of Clearances herein.

Place a small amount of suitable abrasive on a smooth flat surface such as a piece of plate glass. Set the connecting rod cap, ends down, on the abrasive material and carefully work the cap back and forth to dress the ends as needed. Be sure the cap is held perfectly straight. Remove all abrasive from the cap before installing it.




FIG. 36 - REDUCING CONNECTING ROD CLEARANCE

The forged steel rods use two bronze bushings at the piston pin end. The bushing ends must be installed flush with the sides of the rod to permit a 1/16" oil groove between the bushings. These bushings must be line reamed or bored to undersize or standard as desired. Make sure the oil passage through the rod is unrestricted. The tri-metal bearings in the crank end of the rod are precision size requiring no reaming. They are available in standard, .002" or .020" U.S. See the parts list. For clearance see the Table of Clearances in this book.

The connecting rod and cap for the left hand cylinder (facing the blower) are numbered 1, those for the right hand cylinder are numbered 2. Install connecting rods and caps with the numbers aligned, the cap toward the oil base. See that the rod is centered on the piston pin. Coat the crankshaft journal bearing surfaces with oil before installing and securing the rods. Turn the engine over by hand to see that the rods are free. If necessary, rap the rod cap sharply with a heavy soft hammer to set the rod square on the crankshaft. Check valves before replacing the heads. See VALVE SERVICE. Replace all parts removed.

VALVE SERVICE. - Valves are of the overhead type and are located in the cylinder heads. The blower housing, valve cover plates, fuel lines (pump to nozzle and return lines), exhaust outlet, air cleaners and air heater leads must all be removed before the cylinder heads can be removed. (CAUTION: Cover the openings of all fuel lines, oil lines, injector pumps and nozzles or trouble may result when restarting the unit. If the cylinder heads stick, rap sharply with a heavy soft hammer to loosen. Do not pry.

Remove the rocker arm, valve locks, retainer washers, valve springs and valves. Refer to paragraph **ROCKER ARM REMOVAL** under **Special Adjustments**. Mark each part so that it can be assembled in its original location.

Clean all carbon from the cylinders, heads, valves, valve seats, valve stems and valve guides. Clean gasket surfaces of cylinders and heads. Check all valves. Replace valves that are badly burned or pitted, have badly worn or warped stems, or that will have a very thin edge when refaced. Inspect valve guides for wear. Replace worn guides.




FIG. 37 - VALVE GRINDING

The valve **FACE** angle is 40°. The valve **SEAT** angle is 45°. This 10° interference angle results in a sharp seating surface between the valve and the top of the valve seat. The interference angle method of grinding valves minimizes face deposits and lengthens valve life.

The valves should not be hand lapped, if at all avoidable, since the sharp contact may be destroyed. This is especially important where stellite faced valves and seats are used. Valve faces should be finished in a machine to 40°. Valve seats should be ground with a 45° stone, and the width of the seat band should be 3/64 to 1/16 of an inch wide.

When installing a **NEW** exhaust valve insert seat, maintain a minimum clearance of 0.030" from the exhaust valve head to the face of cylinder head by grinding the seat.

Remove all grinding compound from engine parts and place each valve in the cylinder head. Check each valve for a tight seat, using an air pressure type testing tool. If such a tool is not available, make pencil marks at intervals across the valve face and observe if the marks rub off uniformly when the valve is rotated part of a turn against the seat.

Reassemble all parts removed and adjust the valve clearance.

VALVE ADJUSTMENT. - See ADJUSTING VALVE CLEARANCE under Special Adjustments.

FLYWHEEL REMOVAL. - The control box, the generator frame, the armature and the generator end of the adapter housing must be removed to expose the flywheel. If the generator leads marked A1 and A2 are disconnected inside the control box and the AC output leads disconnected and pulled back through the control box to the generator, the control box can be loosened from the generator and tilted forward making it unnecessary to disconnect other leads at the control. Turn to the section on GENERATOR For instructions on removing the generator. When the flywheel is exposed turn the



FIG. 38 - REMOVING THE FLYWHEEL

place a heavy punch against the crankshaft just above the keyway and hit the punch a hard blow with a heavy hammer. Repeat if necessary. See the illustration REMOVING THE FLYWHEEL.

RING GEAR INSTALLATION. - If removal of the ring gear is necessary, cut through the ring with a hacksaw. The ring will usually snap before the cut is very deep. If it does not, a few sharp raps with a cold chisel and heavy hammer should cause the ring to break.

Should the installation of a new ring gear become necessary, place it in an oven heated to 380 - 400°F. for 30 to 40 minutes. CAUTION: DO NOT HEAT WITH A TORCH. When heated properly the ring will fall into place on the flywheel. If it does not go on all the way by itself, drive into place with a hammer. Do it fast. The ring will contract rapidly and may shrink to the flywheel before it's in place. If this occurs, a new ring gear will be needed since the ring gear cannot be removed without damage. When using a hammer on the ring to drive it into place, be very careful not to damage the teeth.

FLYWHEEL INSTALLATION. - When installing a new flywheel the TC (top center) and PO (port opening) marks should be marked on the flywheel. A dial gauge should be used directly over the piston pin as shown in the illustration INSTALLING A NEW FLYWHEEL. Proceed as follows:

Install the flywheel on the crankshaft and turn the flywheel with rotation until the valves of the right cylinder open and close and continue about 1/2 turn until the piston of that cylinder is at the top of the cylinder.

Remove the right cylinder head and place the dial gauge (must read from 0 to 25 in thousandths) as shown in the illustration INSTALLING A NEW FLYWHEEL.




FIG. 39 - INSTALLING A NEW FLYWHEEL

Turn the flywheel slightly until the dial gauge needle indicates the piston is exactly on top center. Use a straight edge and a scratch awl and mark the flywheel at the indicating pin. This is the TC mark.

Turn the dial gauge until the 0 mark and the needle on the gauge are directly in line.

Turn the flywheel against rotation until the dial gauge needle points to 5-1/2 (.0055 inch). Again mark the flywheel at the indicating pin with a straight edge and scratch awl. This will be the PO mark. This is 40° before top center.

Remove the flywheel, deepen the marks with a chisel, and place identifying letters at each mark.

Install the flywheel (be sure the key is in place), remove the dial gauge and reassemble the unit.

NOTE: If a dial gauge is not available, use this alternate method. Make a chalk mark on the flywheel (opposite the indicating pin) at the point where the piston just reaches the top of the cylinder. Then continue to slowly turn the flywheel the same direction until the piston just begins to move downward and make another chalk mark on the flywheel opposite the indicating pin. Make a permanent mark across the flywheel with a scratch awl at a point half way between these two chalk marks. This is the TC mark. To locate the PO mark, measure exactly 15/32 to the right (with rotation) from the TC mark. Mark permanently with a scratch awl. This results in 4° BTC (before top center).

BLOWER. - The blower housing and crank dog must be removed before the blower can be removed. Then grasp the blower with both hands and work back and forth until free.

STARTER. - The starter can be removed by first removing the blower housing and air shroud.

The starter is an automotive type and repairs usually are minor such as replacing brushes or turning down the commutator.

To remove the starter from very early models, the flywheel must first be removed. Then disconnect leads from the starter and remove the starter and flywheel housing as a unit.

GEAR COVER. - All parts necessary to remove the blower, and the blower wheel itself, must be removed before the gear cover can be removed. Then disconnect the governor linkage. Remove the gear cover mounting screws, tap the gear cover gently with a soft hammer to loosen it and remove the gear cover.




FIG. 40 - REPLACING THE GEAR COVER

When installing the gear cover, select the instructions which apply to the model in question. Do not lose the governor-shaft-end-thrust ball.

On models of the later design, position the governor cup so that one of its three large holes will admit the stop pin located in the gear cover.

On engines of the earlier design, the governor cup stop pin is located on the governor cup and must fit into the slot in the governor shaft yoke, to permit smooth governor operation. Turn the governor cup to the position where its stop pin agrees with the 3 o'clock position on the face of a clock. Then turn the governor arm and shaft counterclockwise as far as it will go and hold it in this position until the gear cover is flush with the cylinder block. Turn the governor arm and shaft clockwise as far as it will go and hold or tie it in this position until the governor linkage is connected so that the governor stop pin will remain engaged with the yoke.

Be careful not to damage the gear cover oil seal.

GOVERNOR CUP. - With the gear cover removed the governor cup can be taken off by removing the snap ring from the camshaft center pin and sliding the cup off. Be sure to catch the flyballs (10 in all) as they will probably fall out when the cup is removed.

When installing a new governor cup, tip the plant upward from the blower end, place the flyballs in their places, and install the cup and snap ring on the center pin. The distance from the snap ring to the governor cup sleeve when the cup is flush against the flyballs must be exactly 7/32" for proper governor operation. See the illustration.



FIG. 41 - GOVERNOR CUP ASSEMBLY

The camshaft must be removed and the center pin carefully pressed in by means of an arbor press to allow 7/32" travel. Leave the cup and snap ring on the pin to measure by. Be very careful not to bend the center pin.

CRANKSHAFT GEAR. - With the gear cover removed

the crankshaft gear is easily removed after taking off the snap ring and special washer. The gear is recessed and a conventional gear puller having thin jaws can be used in removing the gear. Apply the puller carefully to avoid damaging the gear if reusable.

When installing a crankshaft gear, use a pipe that will fit over the crankshaft but will not hit the teeth of the gear and drive the gear on to the shoulder on the




FIG. 42 - REMOVING THE CRANKSHAFT GEAR

shaft. Be sure the woodruff key is in place.

Should it become necessary to replace the crankshaft gear, the camshaft gear must also be replaced as these gears are sold only as a matched set.

CAMSHAFT GEAR. - The camshaft and gear should be removed from the engine as an assembly. Before this can be done all parts necessary to expose the camshaft gear must be removed from the engine. In addition the transfer pump, valve tappets, injection pump tappets must be removed from the engine. Insert a screwdriver between the block and gear and apply a little pressure to loosen the camshaft.

If the gear is to be removed from the shaft, remove the snap ring from the center pin and then the governor cup and flyballs. Then place the camshaft and gear in an arbor press and remove the gear. Be very careful not to damage the center pin.

If the camshaft gear must be replaced, the crankshaft gear must also be replaced as they are sold only as a matched set. When pressing the camshaft gear into place on the shaft, be sure the key is in place and that the gear is straight on the shaft.

CRANKSHAFT AND CAMSHAFT ENDPLOY. - Crankshaft endplay is .015" to .020". This endplay and also the camshaft minimum endplay should be checked when installing the rear bearing plate. Use gaskets as needed behind the bearing plate to correct the endplay. Press the crankshaft all the way inward and insert a .015" feeler gauge between the rear bearing flange and the crankshaft thrust surface. The .015" gauge should pass freely between these surfaces but a .020" gauge should not.

When installing the camshaft and gear, be sure the thrust washer is in place behind the camshaft gear. The thrust washer provides for proper camshaft minimum endplay. Camshaft minimum endplay is .003" and is measured with a feeler gauge between the camshaft gear and the crankshaft gear washer while both gears are pressed all the way inward, as illustrated. A gap of less than .003" indicates excessive crankshaft endplay.




FIG. 43 - CHECKING CAMSHAFT ENDPLOY

MAINTENANCE AND REPAIR

TIMING GEAR MARKS. - The crankshaft camshaft gear serve to time the engine. These gears are matched and are sold only as a set. Both gears must be replaced at the same time. Timing marks must be aligned as shown in the illustration. TIMING GEAR MARKS, or the engine will be out of time.




FIG. 44 - TIMING GEAR MARKS

CRANKSHAFT. - The engine must be completely disassembled to remove the crankshaft. Whenever making major repairs on the engine always inspect the drilled passages of the connecting rods. Inspect crankshaft assure proper lubrication of the connecting rods. If they appear scored and cannot be smoothed out by dressing journals, the crankshaft should be ground down to accommodate .020" undersize main bearings and connecting rod bearings (or connecting rods complete if bearings are integral with rods) or a new crankshaft should be installed.

Correct crankshaft endplay is .015" to .020". Adjust as described under CHECKING CAMSHAFT AND CRANKSHAFT ENDPLOY.

BEARINGS. - Removal of the camshaft and crankshaft bearings require complete disassembly of the unit. Use a press or a suitable drive plug to remove bearings. Drive or press camshaft bearings from the inside toward the outside of the block. Drive or press the crankshaft bearings from the outside toward the inside of the block. Be careful not to damage the bearing boss when removing a bearing.

Coat bearings and bearing journals with light oil before installing.

Crankshaft main bearings are precision type and are available in standard size, 0.002" undersize for worn engines, and 0.020" undersize for remachined crankshaft journal. Precision type bearings DO NOT require line reaming. Use the crankshaft as a pilot and with a soft-faced hammer, tap the far end of the crankshaft to drive the crankshaft bearing carefully into place. Align the oil holes for bearing lubrication and align the notch in the bearing flange with the lock pin. A shouldered type bearing lock pin, as is furnished with the new precision type bearing, must be installed on those earlier engines not already having one.




FIG. 45 - BEARING INSTALLATION

When installing camshaft bearings, there are no holes to align, but to help return the oil, the oil groove in the front bearing should be centered at the top, and the notch in the rear bearing toward the inside and top of the cylinder block. Press or drive the front bearing in flush with the bearing boss and the rear bearing in flush with the Welch plug groove.

The camshaft bearings must be line bored or line reamed after being installed in the cylinder block. Any reliable machine shop should be able to perform this service. If equipment for line boring or reaming is not available locally, see the dealer from whom you purchased your unit or return it to the factory for repairs. Refer to the table of clearances. Replace the Welch plug.

OIL SEALS. - Oil seal removal and installation is easier when using a tool for expanding and driving the seals. Alternate methods are suggested below.

The gear cover must be removed to replace its oil seal. Drive the old seal out from the inside toward the outside of the gear cover.

The bearing plate must be removed before its oil seal can be removed. Drive the oil seal out from the inside toward the outside of the bearing plate.

When installing the gear cover oil seal, lay the gear cover on a board so that the bearing boss is supported, otherwise the gear cover may be distorted when installing the oil seal. Tap the oil seal into place until it is flush with the bore. Cover the crankshaft keyway with shim stock when installing the gear cover. Remove the shim stock when the gear cover is in place.




FIG. 46 - OIL SEAL INSTALLATION

When installing the bearing plate oil seal, drive the seal into the bearing plate until flush with the outer end of the bore. Use a piece of hollow pipe that will fit over the crankshaft and contact the oil seal near the outer edge. Drive the seal in evenly all the way around. A piece of shim stock placed over the crankshaft keyway will protect the seal from damage at this point.

OIL PUMP. - Remove all parts necessary to expose the gear cover. Also remove the oil base. Remove the stud or screw running through the intake cup bracket, turn the intake cup 1/4 turn to the left, remove other nuts and washers securing the oil base adapter, remove the adapter and turn the intake cup out. Then remove the oil pump assembly from the front of the engine.




FIG. 47 - OIL PUMP REMOVAL

Check the oil pump thoroughly for worn parts. Should any part need replacing, install a complete assembly. Oil pumps are sold only as a complete unit. See the parts list. When installing the oil pump, reverse the order of removal.




FIG. 48 - OIL INTAKE CUP LOCATION IN THE ADAPTER

FUEL SYSTEM. - Instructions for servicing various parts in the fuel system are given under Periodic Service and Special Adjustments. Whenever any part is disconnected from its line or mounting, protect it from getting dirty by wrapping it in clean paper or by plugging openings with cork. Never use waste or rags.

Lubricate the transfer pump linkage whenever the pump is removed for servicing or if a new pump is installed.

ROCKER ARM PUSH RODS AND PUSH ROD SHIELDS. - Push rod shields are a drive fit into the collars at the cylinder block and a loose fit into the cylinder head. "O" rings must be installed in the shields after the cylinder head is in place. Turn the crankshaft until the rocker arm lifts and press "O" rings into place with a blunt tool. Be careful not to scratch or tear "O" rings.

GASKETS. - Always use new gaskets when replacing any part that requires a gasket. Clean surfaces the gasket contacts before installing the gasket. Gaskets are listed singly and in kit form in the parts list.

ASSEMBLY TORQUES

Assembly torques as given here require the use of a torque indicating wrench. These assembly torques assure proper tightness without danger of stripping threads. If a torque indicating wrench is not available, you will have to estimate the degree of tightness necessary for the stud, nut or screw being installed and tighten accordingly. Be

careful not to strip threads. Check all studs, nuts and screws often. Tighten as needed.

CYLINDER HEAD STUDS AND NUTS. - 40 to 50 lbs. ft. torque.

CONNECTING ROD BOLTS. - 40 to 50 lbs. ft. torque.

ARMATURE DRIVE DISC SCREWS. - 35 to 40 lbs. ft. torque.

ARMATURE THRU STUD AND NUT (when used). - 45 to 50 lbs. ft. torque.

NOZZLE HOLDER SCREWS. - 15 lbs. ft. torque.

Tighten other studs and nuts just enough to assure tightness.

TABLE OF CLEARANCES

	MINIMUM	MAXIMUM
Valve Clearance - COLD (with steel push rods) - Beginning with Spec F Models ..		.015"
Valve Clearance - COLD (with aluminum push rods) - Prior to Spec F Models ..		.020"
Valve Stem Clearance in Guide ..	.003"	.0045"
Valve Seat Width ..	3/64"	1/16"
Crankshaft Main Bearing Clearance ..	.0025"	.004"
Crankshaft Rod Bearing Journal - Std. Size	2.7495"	2.7500"
Crankshaft Rod Bearing Journal - Std. Size	2.3745"	2.3750"
Crankshaft Endplay ..	.015"	.020"
Camshaft Bearing Clearance ..	.001"	.003"
Camshaft Endplay ..	.003"	
Connecting Rod Bearing Clearance ..		
Aluminum Alloy Rod with Brg. Integral ..	.003"	.004"
Forged Steel Rod with Precision Size Brg. Measured Parallel to Length of Rod ..		
Connecting Rod Endplay ..	.001"	.003"
Timing Gear Backlash ..	.002"	.011"
Oil Pump Gear Backlash ..	.001"	.006"
Piston Clearance in Cylinder (at bottom of skirt) ..	.003"	.005"
Piston Pin Clearance in Piston ..	.0035"	.0055"
Piston Pin Clearance in Piston - Tap Fit ..	.0000"	.0003"
Piston Pin Clearance in Rod (Aluminum Alloy Rod) ..	.0002"	.0006"
Piston Pin Clearance in Rod (Forged Steel Rod) ..	.0002"	.0007"
Top Compression Ring Gap - In Cylinder ..	.010"	.020"
Other Comp. Rings and Oil Rings Gap - In Cylinder ..	.010"	.015"
Injection Pump Tappet Setting ..	1.552"	± .002"
Injection Pump Timing - Port Opening ..		4°BTC
Exhaust Valve Head to Face of Cylinder Head (Maintain by grinding new seat) ..	.030"	
Cylinder Bore - Standard Size ..	3.5015	3.5025

GENERATOR

The generator normally needs little care other than proper lubrication of the armature ball bearing and a periodic check of the brushes, commutator and collector rings (A-C plants only). If a major repair job on the generator should become necessary, have the equipment checked by a competent electrician, one who is thoroughly familiar with the operation of electric generating equipment.

GENERATOR DISASSEMBLY. - The generator should be disassembled in the following manner and all leads that must be disconnected should be tagged and marked before removal.

Disconnect the battery to prevent accidental starting of the unit.

Remove the band from the end bell. On generators having constant-pressure type brush springs, remove all brushes and springs from their holders. On other generators lift each brush into its holder until the spring rests against its side and holds it in place. **NOTE:** On certain units built between serial #410955 and 447000, it is also necessary to remove the outer bearing cover and gasket and the three round head screws that retain the inner bearing cover before the generator can be disassembled.

Remove the cap nuts at the outboard end of the end bell, place a pinch bar against the generator adapter and pry against the generator frame until loose. Alternate from one side to the other if necessary.

Carefully slide the frame (together with collar, end bell and brush rig) off the studs, being careful not to let it rest or drag on the armature. Hold the end bell along with the frame as the end bell is loose on the frame.

FOR UNITS PRIOR TO "MODEL SPECIFICATION LETTER F" the armature is mounted with a through-stud, and driven by dowel pins in the flywheel. If the armature is to be removed, back the armature nut out 3 or 4 turns and hit the nut an endwise blow with a heavy soft hammer. Should the armature fail to come loose by this method, place a piece of brass rod against the armature shaft at the top, between the commutator (collector rings on a-c plants) and the bearing, and strike a sharp downward blow on the rod with a heavy soft hammer. Turn the armature over 1/2 turn if necessary to repeat.

FOR UNITS BEGINNING WITH "SPEC. LETTER F", the armature has a disc drive, and is removed by detaching at the flywheel.

If necessary to remove the brush rig, disconnect all leads necessary (be sure they are marked), remove the end bell from the frame assembly, remove the four cap screws that mount the brush rig ring and remove the brush rig.

SERVICING THE GENERATOR

BRUSHES. - Keep a close check on the generator brushes. Brushes worn to 5/8" should be replaced. If brushes appear to wear rapidly check the commutator and collector rings (a-c plants only). If they become pitted or rough or if the mica between the commutator bars comes in contact with the brushes, brush wear will be rapid. An improperly adjusted brush rig will also cause rapid brush wear.

NEUTRAL BRUSH POSITION. - The brush rig must be set at the neutral brush position, to prevent arcing at the brushes and rapid brush wear, to assure steady voltage and current, and to prevent overheating of the generator.

Markings were made at the factory to indicate the "neutral brush position".

The location of the "neutral brush position" mark, either yellow paint or chisel mark, on the brush rig ring should be flush with the brush rig mounting base as shown in the illustration **NEUTRAL BRUSH POSITION**. If it is not, loosen the brush rig mounting screws and shift the whole brush rig assembly as needed to align the mark. Tighten the mounting screws securely after making an adjustment.




FIG. 49 - NEUTRAL BRUSH POSITION & CONSTANT PRESSURE TYPE SPRINGS

If a new brush rig or armature is installed, the "neutral brush position" must be relocated and remarked. Full instructions for performing this service are included with all new armatures and brush rigs.

COLLECTOR RINGS (A.C. Plants Only). - If the collector rings become grooved or out of round, or the brush surface becomes pitted or rough so that good brush contact cannot be maintained, remove the armature and refinish the collector rings in a lathe. If the commutator appears to be in need of it, refinish it at the same time.




FIG. 50 - CUTAWAY VIEW OF GENERATOR

ARMATURE INSTALLATION. - When installing the armature, the run-out at the bearing end should not exceed .012". This runout can be checked by one of the methods shown in the illustration CHECKING THE GENERATOR BEARING RUNOUT. Excessive runout may be caused by a nick, foreign matter on the flange or disc surfaces. Take any steps necessary to correct.




FIG. 51 - CHECKING GENERATOR BEARING RUNOUT

COMMUTATOR. - The commutator bars wear down with usage so that the mica between them must be undercut. This should be done whenever the mica on any part of the commutator touches the brushes. A suitable undercutting tool can be made from a used hack saw blade. Use it as shown in the illustration CARE OF COMMUTATOR AND BRUSHES. Avoid injury to the surfaces of the commutator bars. Leave no burrs along the edges of the bars. The mica must also be undercut whenever the commutator is refinished.





FIG. 52 - CARE OF COMMUTATOR AND BRUSHES

TESTING WINDINGS. - A test lamp set and an armature growler are required for the various tests. Before making any tests, lift all brushes into their holders and disconnect the practice circuit wires from the plant. If the armature tests defective, the practical repair is to replace it. If a field coil tests defective, replace the entire coil assembly unless the trouble is in one of the external leads. Then it can be repaired as the nature of the trouble requires.



TEST LAMP

FOR TESTING FOR OPEN
CIRCUITS AND GROUNDS.

USE 3 OR 4 CANDLEPOWER
BULB.

WITH A 12 VOLT BATTERY
USE A 12 VOLT BULB.

WITH A 6 VOLT BATTERY
USE A 6 VOLT BULB.

FIG. 53 - TEST LAMP SET

TESTING ARMATURE WINDINGS FOR OPEN OR SHORT CIRCUITS.

This test requires the use of an armature growler. The armature assembly must be removed from the plant. Then follow the instructions given by the manufacturer of the armature growler.

TESTING ARMATURE WINDINGS FOR GROUNDS. - Use a test lamp set. Touch one test prod to the armature shaft and the other to the commutator. On an a-c plant, touch each collector ring in turn after checking the commutator. Be sure the test prods make good contact. If the lamp lights, the armature is grounded.

TESTING FIELD WINDINGS. - Use a test lamp set for all tests except a short circuit. Plants which do not have a separate starting motor, have a series field winding in addition to the shunt field winding. Disconnect all external leads of the coil assembly from the brush rig before testing. Tag and mark each lead before disconnecting to assure proper connections when reassembling.

TESTING FIELD WINDINGS FOR OPEN CIRCUIT. - To test a coil winding for an open circuit, disconnect its external leads and touch one test prod to the terminal of one coil lead and the other test prod to each of the other leads of the winding. If the lamp does not light the winding being tested is open. If the fault lies in a connection between coils or in a coil lead, the trouble can be repaired. If the trouble is inside the coil proper, replace the entire coil assembly.

TESTING FIELD WINDINGS FOR SHORT CIRCUITS. - If one coil is short circuited it will run cooler than the others and it may be possible to locate the short-circuited coil by placing your hand on the generator frame at each of the poleshoe positions and noting at which poleshoe position the frame is cooler than normal. A more definite test is a comparative resistance test or a comparative voltage drop test. If the coil windings are short-circuited, replace the entire coil assembly.

FIELD COIL INSTALLATION. - The generator frame assembly must be removed from the unit before the field coils can be removed from the poleshoes. Tag and mark all external leads before disconnecting to assure correct connections when reassembling. When removing the poleshoes and coils, be sure to keep the shims used under each poleshoe together to assure correct air gap when installing the coil assembly and poleshoes.

When installing a coil assembly, be sure it is in the original position in the frame. If it is not, the coil leads cannot be properly connected. Insert the poleshoe into the coil (be sure the poleshoe shims are in place) and secure the poleshoe to the frame. Tighten the poleshoe mounting screws securely. If they should work loose serious damage to the generator would result. Install each of the other coils and poleshoes in the same manner. Connect external leads as marked on the tags. If a new coil assembly is being installed, make the connections the same as marked for the old coil assembly.

POLESHOE INSTALLATION. - Follow the instructions given for FIELD COIL INSTALLATION.

GENERATOR ASSEMBLY. - Whenever installing a new armature, pole shoe, coil assembly or generator frame assembly, it is recommended that the field windings be repolarized to prevent a possible short circuit from occurring. If the polarity is not the same as the starting battery, the charge circuit will burn out. The field windings of the generator is polarized for a negative grounded starting system. This is done by lifting all generator brushes into their holders and momentarily touching the positive cable lug of a 12-volt battery to any positive brush terminal and the negative cable lug to the generator frame. This magnetizes the poleshoes with correct polarity

for a negative grounded starting system. The poleshoes retain this magnetism (residual) indefinitely although it is possible for the poleshoes to lose it. It is this residual magnetism in the poleshoes that starts the current flowing in the proper direction in the field windings when the generator starts to operate.

CONTROLS

If any of the control panel equipment fails to function properly, replace the defective part with a new part of the same kind rather than try to repair the old part. No attempt should be made to repair such parts as meters, fuses, switches, relays, or receptacles. Check all electrical connections and contacts whenever servicing control equipment.

Always disconnect the battery before servicing any control parts to avoid accidentally starting the unit. When removing any control part, tag and mark the connection point of each lead that has to be removed to assure correct connections when reassembling.

Feed through type condensers for radio frequency suppression are used at the ac output "hot" terminals, beginning with Spec H models. These condensers are not apt to fail. However, a shorted condenser may run hot, cause a severe voltage drop in that phase or circuit and should be replaced.

PREPARING UNITS FOR STORAGE OR EXTENDED OUT-OF-SERVICE PERIODS

Electrical generating plants are often taken out of service for extended periods of time. Plants remaining out-of-service more than 30 days should be protected against rust, corrosion, or the elements.

If the lubricating oil is dirty, drain it while hot, install a new filter element and attach a warning tag.

Remove the glow plug to pour two tablespoons of rust inhibitor oil (or SAE 50 as alternate) into the cylinder. Slowly crank the engine to lubricate the cylinder, then stop at top center. Replace the glow plug.

Wipe all exposed parts clean and coat with a film of grease all such parts liable to rust.

Disconnect the battery from the plant. An idle battery should be stored away from freezing temperatures and should be given a refreshing charge about every 40 days.

Clean generator brushes, brush holders, commutator and collector rings by wiping with a clean cloth. DO NOT coat with lubricant or other preservative.

The fuel supply and fuel system should be left filled but any possibility of fuel syphoning should be guarded against.

Plants being returned to service should be prepared according to preparation instructions for a new plant.

POSSIBLE CAUSE

REMEDIES

ENGINE CRANKS TOO STIFFLY

Load not disconnected from unit. Disconnect load from unit when starting.

Too heavy oil in crankcase. Use only recommended grades.

Engine stuck. Disassemble and repair.

ENGINE WILL NOT START WHEN CRANKED

Air in fuel system. Bleed the fuel system.

Lack of fuel or faulty injection caused by dirty fuel. Keep fuel tank filled. Keep fuel clean. Use only recommended fuels.

Clogged fuel filter. Keep supplies of fuel clean. Replace fuel filter element.

Poor fuel. Use only recommended grades.

Poor compression due to leaky gasket, loose head, worn valves or piston rings. Tighten cylinder head. Replace cylinder head gasket if necessary. Grind valves, replace if necessary.

Wrong injection pump timing. Check the injection pump timing.

ENGINE CRANKS SLOWLY OR WILL NOT CRANK

Defective or discharged battery. Replace or recharge battery.

Loose connections or broken wire in starter circuit. Tighten loose connections. Replace terminals or wire where necessary.

Corroded battery terminals. Clean corroded terminals. Replace cable if necessary.

Starter brushes worn excessively or making poor contact. Replace brushes. See that brushes make good contact.

Short circuit in generator or load circuit. Repair as needed.

Replace switch.

Dirty or corroded points in start solenoid switch.

ENGINE FIRES BUT FAILS TO KEEP RUNNING

Air in fuel system.

Bleed the fuel system. Check for air leakage. To help locate air leakage, raise the fuel supply 2 ft. above pump level, if practical.

Allow engine to gain running speed before releasing the start switch. Check for open circuit to stop solenoid.

Governor stop solenoid de-energized and closing the throttle.

<u>POSSIBLE CAUSE</u>	<u>REMEDIES</u>
ENGINE RUNS BUT VOLTAGE DOES NOT BUILD UP	
Poor brush contact.	See that brushes seal well on commutator and collector rings (where used), are free in holders, are not worn shorter than 5/8 inch and have good spring tension.
Open circuit, short circuit or ground in generator.	Check and repair or replace as described under GENERATOR in the Maintenance and Repair section.
VOLTAGE UNSTEADY BUT ENGINE NOT MISFIRING	
Speed too low.	Adjust governor to correct speed.
Injection pump fuel metering shaft not properly adjusted.	Adjust as instructed under SPECIAL ADJUSTMENTS.
Poor commutation or brush contact.	Refinish commutator or undercut mica if necessary. See that brushes are set well on commutator and collector rings (where used) are free in holders, are not worn shorter than 5/8" and have good spring tension.
Loose connections.	Tighten connections.
GENERATOR OVERHEATING	
Short in load circuit.	Correct short circuit.
Generator overloaded.	Reduce load.
Improper brush rig position.	Adjust to "neutral" position.
ENGINE OVERHEATING	
Improper lubrication.	See Low Oil Pressure.
Poor ventilation.	Provide ample ventilation at all times.
Dirty or oil cooling surfaces.	Keep the engine clean.
Retarded injection timing.	Retime.
Generator overloaded.	Reduce load.
VOLTAGE DROPS UNDER HEAVY LOAD	
Engine lacks power.	See Engine Misfires at Heavy Loads.

<u>POSSIBLE CAUSE</u>	<u>REMEDIES</u>
VOLTAGE DROPS UNDER HEAVY LOAD (CONT.)	
Poor compression.	Tighten cylinder head, grind or replace valves, replace piston rings as needed.
Faulty Injection.	Check fuel system. Dirty fuel is main cause. Use only recommended fuels.
Dirty air cleaner.	Clean. Refill with proper oil.
Dirty fuel filter.	Keep fuel clean. See SERVICING THE FUEL FILTER under Periodic Service.
Restricted exhaust line.	Clean or increase the size.
ENGINE MISFIRES AT LIGHT LOAD	
Faulty Injection.	Dirty fuel is main cause. Use only recommended fuels.
Poor compression.	Tighten cylinder head, grind or replace valves, replace piston rings as needed.
Poor grade of fuel.	Use only recommended fuels.
ENGINE MISFIRES AT HEAVY LOAD	
Faulty Injection.	Dirty fuel is main cause. Use only recommended fuels.
Dirty air cleaner.	Clean. Refill with proper oil.
Dirty fuel filters.	Refer to SERVICING FUEL FILTER under Periodic Service.
ENGINE MISFIRES AT ALL LOADS	
Leaky valves.	Refer to VALVE SERVICE under Maintenance and Repair.
Broken valve spring.	Replace.
Defective or dirty nozzle.	Install new nozzle.
LOW OIL PRESSURE	
Defective oil pressure gauge.	Replace.
Oil too light or diluted.	Drain. Refill with proper oil.
Oil too low.	Add oil.
Oil relief valve not closing.	Check by-pass. Clean or replace as needed.

POSSIBLE CAUSEREMEDIESLOW OIL PRESSURE (CONT.)

Badly worn bearing.

Replace.

Sludge on oil cup screen.

Remove and clean screen and oil reservoir.

Badly worn oil pump.

Replace.

HIGH OIL PRESSURE

Defective oil pressure gauge.

Replace.

Oil too heavy.

Drain. Refill with proper oil.

Clogged oil passage.

Clean all lines and passages.

Oil relief valve stuck.

Clean by-pass. Replace if needed.

EXCESSIVE OIL CONSUMPTION-LIGHT BLUE SMOKY EXHAUST

Poor compression. Usually due to worn piston, rings, or cylinder. Oil too light or diluted.

Refinish cylinder. Install oversize piston and rings.

Drain. Refill with proper oil.

Too large bearing clearance.

Replace bearings necessary.

Engine misfires. Usually due to leaky valve or broken valve spring.

Reseat or replace as needed.

Faulty injection timing.

Check injection pump timing.

Too much oil in cylinder block.

Drain excess oil.

Crankcase breather valve sticking.

Free up disc. Replace valve if necessary.

Air leak at oil filler cap gasket.

See that cap fits tightly and gasket is O. K.

BLACK, SMOKY EXHAUST - EXCESSIVE CONSUMPTION - POSSIBLE LACK OF POWER UNDER LOAD

Generator overloaded. Black smoky exhaust normal condition with overload.

Reduce load to within rated capacity. If smoky condition does not clear up, stop the unit at once and check for further trouble. Serious damage may result if trouble is not corrected.

Poor compression.

Tighten cylinder head, grind or replace valves, replace piston rings - as needed.

Poor grade or dirty fuel.

Use only clean recommended fuel.

POSSIBLE CAUSEREMEDIESBLACK, SMOKY EXHAUST - EXCESSIVE FUEL CONSUMPTION - POSSIBLE LACK OF POWER UNDER LOAD

Injection pump or nozzle not operating properly.

Install new nozzle or injection pump.

Faulty injection timing.

Check injection pump timing.

ENGINE RACES(STOP UNIT AT ONCE AND DETERMINE CAUSE)

Governor linkage disconnected.

Replace linkage. Tighten mounting nut securely.

Too much oil in air cleaner.

Correct oil level. Check breather tube check valve, free disc or replace valve.

ENGINE STOPS UNEXPECTEDLY

Empty fuel tank.

Refill fuel tank as often as needed to prevent running out of fuel.

Dirt in fuel system.

Use only recommended fuel. Refer to SERVICING FUEL FILTER under Periodic Service. Clean fuel tank. Fill with clean fuel. Bleed fuel system. Install new nozzle or injection pump if trouble not corrected.

Stop solenoid defective or open stop solenoid circuit.

Operate solenoid manually or repair, adjust, or replace parts needed.

Low oil pressure causing switch to operate.

See Low Oil Pressure.

Defective Oil Pressure Switch.

Replace Switch.

LIGHT POUNDING KNOCKNOTE: DO NOT CONFUSE WITH NORMAL KNOCK FROM FIRING OF FUEL.

Loose connecting rod.

Adjust clearance or replace.

Low oil supply.

Add oil. Change if necessary.

Oil badly diluted.

Drain. Refill with proper oil.

Low oil pressure.

See Low Oil Pressure.

REMEDIES

Install extra or larger wire or replace the load.

**VOLTAGE VARIES BETWEEN SINGLE PHASE CIRCUITS
OF 3 or 4 WIRE PLANTS**

Replace condenser.

Replace condenser.

RADIO INTERFERENCE


Replace.

FUEL NOZZLE FAILURE



Replace with new nozzle. If not scored and plunger can be freed up, continue in service.



Clean and continue in service, using cleaning tool set available through the dealer.



NOTE: Do not disassemble the nozzle and holder assembly unless necessary. Check all other possible causes of plant failure first. Finger marks cause corrosion of highly polished, impinged fit parts as found in the fuel nozzle and the fuel injection pump. Avoid corrosion by cleaning your hands and dipping your hands in clean diesel fuel when servicing those parts. To remove the nozzle, use a closed end type of wrench and remove the serrated nozzle nut from the combustion chamber end of the nozzle holder. Keep removed parts clean by placing them in a basin of clean diesel fuel and assembly them wet rather than try to wipe them dry.







WIRING DIAGRAM
SINGLE FRAME - TWO WIRE UNITS
PRIOR TO "SPEC H"












606862



WIRING DIAGRAM

115 VOLT DIRECT CURRENT
230 VOLT DIRECT CURRENT
NON-BATTERY CHARGING UNIT
BEGINNING WITH "SPEC J"