



Operator's Manual

DJB

DJC

DJE

GENERATOR SETS




Table of Contents

SECTION	TITLE	PAGE
	SAFETY PRECAUTIONS	iii, iv
1	INTRODUCTION	1-1
	About This Manual	1-1
	Safety Considerations	1-1
	How To Obtain Service	1-1
2	SPECIFICATIONS	2-1
3	INSTALLATION	3-1
	General	3-1
	Location	3-1
	Mounting	3-2
	Ventilation	3-4
	Exhaust	3-7
	Fuel Tank And Lines	3-8
	Injection Pump Adapter Assembly (DJE only)	3-10
	Oil Drain	3-10
4	ELECTRICAL PREPARATION	4-1
	General	4-1
	Transfer Switch	4-2
	Generator Voltage Connections	4-3
	Load Connection	4-5
	DC Wiring	4-6
	Battery Connections	4-7
5	CONTROL DESCRIPTION	5-1
	General	5-1
	Standard Control Components/Options	5-1
	Deluxe Control Panel Components	5-2
	Optional AC Meter Panel Components (Housed Units Only)	5-3

California

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

SECTION	TITLE	PAGE
6	OPERATION	6-1
	General	6-1
	Prestart Checks	6-2
	Pre-Heating And Starting	6-2
	Running	6-3
	Stopping	6-3
	Break-In	6-4
	No-Load Operation	6-4
	Exercising Unit	6-4
	Engine Ratings	6-5
	High/Low Operating Temperatures	6-5
	Dust And Dirt	6-5
	High Altitude	6-5
7	ADJUSTMENTS	7-1
	Output Voltage Adjustment (Optional)	7-1
	Governor	7-2
	Charge Rate Adjustment	7-2
	Valve Clearance Adjustments	7-3
	Centrifugal Switch	7-4
8	TROUBLESHOOTING	8-1
	Safety Considerations	8-1
9	MAINTENANCE	9-1
	General	9-1
	Generator Set Inspection	9-3
	Lubrication System	9-3
	Fuel System	9-6
	Air Cleaners	9-9
	Contractor Model Air Cleaner	9-9
	Governor Linkage	9-10
	Batteries	9-11
	Crankcase Breather	9-12
	Crankcase Breather Tube	9-12
	Torsional Washers	9-13
	Out-of-Service Protection	9-14
	Returning a Unit to Service	9-14
10	MAINTENANCE RECORD	10-1

Safety Precautions

Before operating the generator set, read the Operator's Manual and become familiar with it and the equipment. Safe and efficient operation can be achieved only if the equipment is properly operated and maintained. Many accidents are caused by failure to follow fundamental rules and precautions.

The following symbols, found throughout this manual, alert you to potentially dangerous conditions to the operator, service personnel, or the equipment.

DANGER *This symbol warns of immediate hazards which will result in severe personal injury or death.*

WARNING *This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.*

CAUTION *This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.*

FUEL AND FUMES ARE FLAMMABLE

Fire, explosion, and personal injury or death can result from improper practices.

- DO NOT fill fuel tanks while engine is running, unless tanks are outside the engine compartment. Fuel contact with hot engine or exhaust is a potential fire hazard.
- DO NOT permit any flame, cigarette, pilot light, spark, arcing equipment, or other ignition source near the generator set or fuel tank.
- Fuel lines must be adequately secured and free of leaks. Fuel connection at the engine should be made with an approved flexible line. Do not use copper piping on flexible lines as copper will become brittle if continuously vibrated or repeatedly bent.

- Be sure all fuel supplies have a positive shutoff valve.
- Be sure battery area has been well-ventilated prior to servicing near it. Lead-acid batteries emit a highly explosive hydrogen gas that can be ignited by arcing, sparking, smoking, etc..

EXHAUST GASES ARE DEADLY

- Provide an adequate exhaust system to properly expel discharged gases away from enclosed or sheltered areas and areas where individuals are likely to congregate. Visually and audibly inspect the exhaust daily for leaks per the maintenance schedule. Ensure that exhaust manifolds are secured and not warped. Do not use exhaust gases to heat a compartment.
- Be sure the unit is well ventilated.

MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Keep your hands, clothing, and jewelry away from moving parts.
- Before starting work on the generator set, disconnect battery charger from its AC source, then disconnect starting batteries, negative (-) cable first. This will prevent accidental starting.
- Make sure that fasteners on the generator set are secure. Tighten supports and clamps, keep guards in position over fans, drive belts, etc.
- Do not wear loose clothing or jewelry in the vicinity of moving parts, or while working on electrical equipment. Loose clothing and jewelry can become caught in moving parts. Jewelry can short out electrical contacts and cause shock or burning.
- If adjustment must be made while the unit is running, use extreme caution around hot manifolds, moving parts, etc.

ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Remove electric power before removing protective shields or touching electrical equipment. Use rubber insulative mats placed on dry wood platforms over floors that are metal or concrete when around electrical equipment. Do not wear damp clothing (particularly wet shoes) or allow skin surface to be damp when handling electrical equipment.
- Use extreme caution when working on electrical components. High voltages can cause injury or death. DO NOT tamper with interlocks.
- Follow all applicable state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag open switches to avoid accidental closure.
- DO NOT CONNECT GENERATOR SET DIRECTLY TO ANY BUILDING ELECTRICAL SYSTEM. Hazardous voltages can flow from the generator set into the utility line. This creates a potential for electrocution or property damage. Connect only through an approved isolation switch or an approved paralleling device.

GENERAL SAFETY PRECAUTIONS

- Coolants under pressure have a higher boiling point than water. DO NOT open a radiator or heat exchanger pressure cap while the engine is running. Allow the generator set to cool and bleed the system pressure first.

- Benzene and lead, found in some gasoline, have been identified by some state and federal agencies as causing cancer or reproductive toxicity. When checking, draining or adding gasoline, take care not to ingest, breathe the fumes, or contact gasoline.
- Used engine oils have been identified by some state or federal agencies as causing cancer or reproductive toxicity. When checking or changing engine oil, take care not to ingest, breathe the fumes, or contact used oil.
- Provide appropriate fire extinguishers and install them in convenient locations. Consult the local fire department for the correct type of extinguisher to use. Do not use foam on electrical fires. Use extinguishers rated ABC by NFPA.
- Make sure that rags are not left on or near the engine.
- Remove all unnecessary grease and oil from the unit. Accumulated grease and oil can cause overheating and engine damage which present a potential fire hazard.
- Keep the generator set and the surrounding area clean and free from obstructions. Remove any debris from the set and keep the floor clean and dry.
- Do not work on this equipment when mentally or physically fatigued, or after consuming any alcohol or drug that makes the operation of equipment unsafe.
- Substances in exhaust gases have been identified by some state or federal agencies as causing cancer or reproductive toxicity. Take care not to breathe or ingest or come into contact with exhaust gases.

KEEP THIS MANUAL NEAR THE GENSET FOR EASY REFERENCE

1. Introduction

ABOUT THIS MANUAL

This manual provides installation instructions, and information on operating, maintaining and adjusting the Onan® DJB, DJC, and DJE generator sets (gensets). Study this manual carefully and comply with each of its warnings and cautions. Using the genset properly and performing regular maintenance can result in longer genset life, better performance, and safer operation.

SAFETY CONSIDERATIONS

The generator set has been carefully designed to provide safe and efficient service when properly installed and operated. However, the overall safety and reliability of the complete system is dependent on many factors outside the control of the generator set manufacturer. To avoid possible safety hazards, make all mechanical and electrical connections to the generator set exactly as specified in this manual. All systems external to the generator (fuel, exhaust, electrical, etc.) must comply with all applicable codes. Make certain all required inspections and tests have been completed and all code requirements have been satisfied before certifying the installation is complete and ready for service.

HOW TO OBTAIN SERVICE

When the generator set requires servicing, contact your nearest dealer or distributor. Factory-trained Parts and Service representatives are ready to handle all your service needs.

If you are unable to locate a dealer or distributor, consult the Yellow Pages. Typically, our distributors are listed under:

GENERATORS-ELECTRIC or
ELECTRICAL PRODUCTS

For the name of your local Cummins®/Onan® or Onan-only distributor in the United States or Canada, call 1-800-888-ONAN (this automated service utilizes touch-tone phones only). By entering your area code and the first three digits of your local telephone number, you will receive the name and telephone number of the distributor nearest you.

For outside North America, call Onan Corporation, 1-612-574-5000, 7:30 AM to 4:00 PM, Central Standard Time, Monday through Friday. Or, send a fax to Onan using the fax number 1-612-574-8087.

When contacting your distributor, always supply the complete Model Number and Serial Number as shown on the generator set nameplate.

⚠ WARNING

INCORRECT SERVICE OR PARTS REPLACEMENT CAN RESULT IN SEVERE PERSONAL INJURY, DEATH, AND/OR EQUIPMENT DAMAGE. SERVICE PERSONNEL MUST BE QUALIFIED TO PERFORM ELECTRICAL AND/OR MECHANICAL SERVICE.



Page 1 of 1

Page 1 of 1



2. Specifications

TABLE 2-1. STANDARD SERIES SPECIFICATION

MODELS	4.5 DJB	6.0 DJB	4.5 DJE	6.0 DJE	9.0 DJC	12.0 DJC
GENERATOR DETAILS						
AC Output						
Frequency (Hertz)	50	60	50	60	50	60
Rating (AC output)	4.5kW	6.0kW	4.5kW	6.0kW	9.0kW	12.0kW
ENGINE						
Engine Speed	1500 RPM	1800 RPM	1500 RPM	1800 RPM	1500 RPM	1800 RPM
*Oil Capacity - qts (l)	3 (2.84)	3 (2.84)	3 (2.84)	3 (2.84)	6 (5.68)	6 (5.68)
Avg. Fuel Consumption						
gph (l/h) at: 1/4 load	0.27 (1.02)	0.33 (1.25)	0.33 (1.25)	0.33 (1.25)		0.55 (1.11)
1/2 load	0.38 (1.44)	0.43 (1.63)	0.35 (1.32)	0.43 (1.63)		0.72 (2.67)
3/4 load	0.45 (1.70)	0.53 (2.01)	0.42 (1.59)	0.53 (2.01)		0.88 (3.29)
Full load	0.53 (2.0)	0.64 (2.42)	0.52 (1.97)	0.64 (2.42)		1.05 (3.98)
ELECTRICAL SYSTEM						
Starting Voltage	12 Volts DC	12 Volts DC	12 Volts DC	12 Volts DC	12 Volts DC	12 Volts DC
Battery Charge Rate	2-5 Amps	2-5 Amps	2-5 Amps	2-5 Amps	2-5 Amps	2-5 Amps
Battery Requirements						
32° F (0° C) – Warmer	450 AMPS	450 AMPS	450 AMPS	450 AMPS	565 AMPS	565 AMPS
0° F (17° C) – Warmer	560 AMPS	560 AMPS	560 AMPS	560 AMPS	800 AMPS	800 AMPS
-25° F (-32° C) – Warmer	800 AMPS	800 AMPS	800 AMPS	800 AMPS	1080 AMPS	1080 AMPS
Below -10°F(-23°C)	5W30	5W30	5W30	5W30	5W30	5W30

* - Plus 1/2 quart (0.473 litre) for new filter.

TABLE 2-1. STANDARD SERIES SPECIFICATION (Cont'd)

MODELS	4.5 DJB	6.0 DJB	4.5 DJE	6.0 DJE	9.0 DJC	12.0 DJC
REQUIREMENTS						
Fuel Pump Inlet Thrd Size	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF
Fuel Pump Return Thrd Size	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF	7/16-24 NPTF
Fuel Pump Max. Lift - ft (m)	6 (1.83)	6 (1.83)	6 (1.83)	6 (1.83)	6 (1.83)	6 (1.83)
Exhaust Outlet (Pipe Tapped)	1.25 inch	1.25 inch	1.25 inch	1.25 inch	1.25 inch	1.25 inch
Maximum Exhaust Back Pressure - inch (mm) WC	27 (686)	27 (686)	27 (686)	27 (686)	27.2 (691)	27.2 (691)
Ventilation Required						
Engine - cfm (m³/min)	467 (13.2)	560 (15.9)	525 (14.9)	630 (17.8)	667 (18.9)	750 (21)
Generator - cfm (m³/min)	133 (3.8)	160 (4.53)	133 (3.8)	160 (4.53)	133 (3.8)	160 (4.53)
Combustion - cfm (m³/min)	21 (0.6)	25 (0.7)	25 (0.7)	29 (0.8)	44 (1.3)	52 (1.5)
Maximum Discharge Restriction - inch (mm) WC	0.25 (6.4)	0.25 (6.4)	0.25 (6.4)	0.25 (6.4)	0.25 (6.4)	0.25 (6.4)
DIMENSIONS						
Height - inch (mm)	28.94 (735)	28.94 (735)	26.12 (663)	26.12 (663)	26.06 (662)	26.06 (662)
Width - inch (mm)	21.75 (552)	21.75 (552)	18.38 (467)	18.38 (467)	19.50 (495)	19.50 (495)
Length - inch (mm)	36.69 (932)	36.69 (932)	33.44 (849)	33.44 (849)	46.81 (1189)	46.81 (1189)
Weight - pounds (kg)	485 (220)	485 (220)	485 (220)	485 (220)	710 (322)	710 (322)
ADJUSTMENT SPECS						
Cylinder Head Bolt Torque ft-lb (n•m) 44-46 (60-62)	44-46 (60-62)	37-40 (50-54)	37-40 (50-54)	44-46 (60-62)	44-46 (60-62)	10-15 (14-20)
Glow Plug Torque - ft-lb (n•m)	10-15 (14-20)	10-15 (14-20)	10-15 (14-20)	10-15 (14-20)	10-15 (14-20)	
Valve Clearances						
Intake - inch (mm)	.010 (.254)	.010 (.254)	.010 (.254)	.010 (.254)	.009 (.229)	.009 (.229)
Exhaust - inch (mm)	.007 (.178)	.007 (.178)	.007 (.178)	.007 (.178)	.007 (.178)	.007 (.178)
Centrifugal Switch Breaker Point Gap - inch (mm)	.020 (.508)	.020 (.508)	.020 (.508)	.020 (.508)	.020 (.508)	.020 (.508)

3. Installation

GENERAL

Most generator set installations must be designed so that the generator set will function properly under all anticipated operating conditions. Use these instructions as a general guide only. Follow the instructions of the consulting engineer when locating or installing any components.

Generator set installations must conform to local building codes, fire ordinances, and other local, state and federal regulation. For more detailed installation instructions, consult Onan Application Manual T-030, or contact an authorized Onan service representative.

Requirements to be considered prior to installation:

- Level mounting surface
- Adequate cooling air
- Adequate fresh induction air
- Discharge of circulated air

- Discharge of exhaust gases
- Electrical connections
- Fuel connections
- Accessibility for operation and servicing
- Noise levels
- Vibration isolation
- Electrical connections

LOCATION

Provide a location for the genset that is dry, clean, dust-free, well-ventilated, and protected from the weather.

The side of the generator set, where generator air is discharged, requires a minimum clearance of 3 inches (76 mm) from the wall, so the set can rock on its mounts. There should be at least 24 inches (610 mm) clearance around all other sides for service access.

MOUNTING

A permanent genset installation must have a sturdy, level mounting base of concrete, heavy wood or structural steel.

Plan for access to the genset for servicing and provide adequate lighting around the unit. For convenience in general servicing such as changing the crankcase oil, the surface of the mounting base should be at least 6 inches (152 mm) above the floor.

On all installations of non-housed generator sets, assemble the mounting cushions, washers and spacer bushing carefully. The spacer bushing prevents compression of the snubber (upper rubber cushion). Place the cushions (see Figure 3-1) under the engine and generator mounting feet. Use cushions with a higher number (part number is shown on cushion) on the heavier generator end. Space the mounting bolts in the floor or the base with distances between hole centers as shown in Figure 3-2 for either the DJB, DJC, or the DJE gensets.

⚠ CAUTION *The oil filter can be punctured easily by the end of the mounting bolt. For this reason, provide at least 1/2-inch (12.7 mm) clearance between the oil filter and the end of the mounting bolt, to avoid puncturing the filter.*




FIGURE 3-1. MOUNTING CUSHION INSTALLATION




FIGURE 3-2. MOUNTING BASE DIMENSIONS

VENTILATION

Air circulation is needed to dissipate heat produced by the engine and generator in normal operation. Outdoor installations can rely on natural circulation, but mobile, indoor or housed installations need proper size and positioned vents for required air flow. See *Specifications* section for air requirements.

Vent sizes depend on variable conditions:

- Size of enclosure
- Ambient temperature
- Electrical load
- Running time
- Restrictions imposed by screens, louvers, or filters
- Prevailing wind direction

The required volume of air must reach the unit, absorb the heat, and be discharged away from the installation.

Air Intake Requirements

DJB - Vacu-Flo® Cooling: On the DJB, the Vacu-Flo cooling inlet vent must be at least 1-1/3 square feet (1236 cm²) in area: the duct for discharged air should be at least as large as the scroll outlet. See *Specifications* section for air flow requirements for this set. See Figure 3-3.

DJE - Pressure Cooling: The pressure-cooled DJE needs an inlet vent with an unrestricted opening of at least 3-1/2 square feet (3252 cm²). See *Specifications* section for air flow requirements for this set. See Figure 3-4.

DJC - Pressure Cooling: The pressure-cooled DJC needs an inlet vent with an unrestricted opening of at least 5 square feet (4645 cm²). See *Specifications* section for air flow requirements for this set. See Figure 3-4.

Air Discharge Requirements

DJB, DJE and DJC Gensets: Install separate ducts for air discharge from the engine and generator (see exception) as follows:

1. The engine discharge duct must be the same size as the engine outlet:
 - DJB & DJE - 8 x 10 inches (203 x 254 mm).
 - DJC - 8 x 20 inches (203 x 508 mm).

If a screen is used in the duct, increase the duct size in proportion to the restriction. Consider installing the screen diagonally to limit the restriction, and increase duct size for runs over 9 feet (2.74 m). If bends are necessary, use large radius elbows. Use a canvas section at the set to absorb vibration and noise.

2. Generator outlet ducts must be used when units are installed in compartments too small for the operator to walk. Ducts are recommended for all other indoor installations. The air outlet is 5-5/8 x 3 inches (140 x 76 mm). Follow the same principles of duct design and installation as used for the engine duct. Engine and generator require separate ducts.

Auxiliary fans can be used to increase airflow to units installed in small, poorly ventilated rooms. The fan size and location should be such that the air inlet to the engine doesn't exceed 120° F (49° C) when running at full rated load.

Onan engine mounted thermostatically controlled shutters can be used to aid warm-up after starting and keep cold air out during shutdown. When the discharged air reaches 120° F (49° C), shutters begin to open; at 140° F (62° C), the shutters completely open.

⚠ CAUTION *Generator set overheating can result in engine damage. To avoid this, never operate the generator set with any of the cooling system components removed.*





FIGURE 3-3. DJB, TYPICAL INSTALLATION



M1880C

FIGURE 3-4. DJC AND DJE, TYPICAL INSTALLATION

EXHAUST

Pipe exhaust gases outside the enclosure. Locate the exhaust outlet far from the air inlet to avoid gases re-entering the enclosure. Use flexible seamless tubing to connect between the engine exhaust and any rigid pipe extension to prevent transmission of vibration.

⚠ WARNING *Inhalation of exhaust gases can result in severe personal injury or death. Modifying the exhaust system can allow poisonous exhaust gases to escape. Use only original equipment replacement parts when servicing the exhaust system. Unauthorized modifications will also void the warranty and cancel the UL Listing/CSA Certification. Liability for injury or damages due to unauthorized modifications becomes the responsibility of the person making the change.*

Because an exhaust system is subjected to detrimental conditions such as extreme heat, infrequent operation, and light operating load, inspect the exhaust system frequently to be sure that it remains fume-tight.

⚠ WARNING *Inhalation of exhaust gas presents the hazard of severe personal injury or death. Exhaust gas can easily leak from a faulty manifold. Do not use exhaust manifold heat to warm a room or compartment.*

An approved thimble must be used (Figure 3-5) to pass exhaust pipes through walls or partitions. Build this thimble according to code (see National Fire Protection Association bulletin, Volume 4, section 211 on "Standards for Chimneys, Fireplaces, and Vents").

As the exhaust pipe length and number of bends increases, a larger pipe is required to reduce excessive exhaust restriction and back pressure. Excessive exhaust back pressure will reduce the air-fuel ratio, resulting in reduced output, smoke, wasted power, high exhaust temperatures and reduced engine life.

Total back pressure of all system components must not exceed maximum back pressure limits. Note that any exhaust restriction, even if less than maximum, will affect performance.




FIGURE 3-5. EXHAUST PIPING

FUEL TANK AND LINES

⚠ WARNING Fuel tanks risk explosion and fire, which can cause severe personal injury or death. Because fuel leaks create fire hazards, always use flexible tubing between the engine and the fuel supply, to avoid leaks due to vibration and/or fuel line failure. Do not allow the fuel line to contact rough, sharp or hot surfaces.

Connect the fuel line to the fuel pump inlet as shown in Figure 3-6 for either the DJB, DJE or DJC generator set.

Use an approved flexible fuel line next to the engine. Diesel engines require a fuel supply line and a separate fuel return line. Install the fuel supply line from the supply tank to the inverted flare male elbow mounted in the inlet of the fuel pump. The pump is threaded 7/16-24 NPTF (American Standard Internal Tapered Pipe Thread).

Install fuel return line from the 7/16-24 size opening in the overflow fitting located on injection pump (where nozzle fuel return line is also connected) to the top of the fuel supply tank. Shield the line with

fire-retardant material if it passes through a combustible wall or partition.

⚠ WARNING Always use flexible tubing between engine and the fuel supply to avoid line failure due to vibration.

⚠ WARNING Never use galvanized or copper fuel lines, fittings or fuel tanks with diesel fuel systems. Condensation in the tank and lines combines with the sulfur in diesel fuel to produce sulfuric acid. The molecular structure of the copper or galvanized lines or tanks reacts with the acid and contaminates the fuel.

Carefully clean all fuel system components before putting the set into operation. Any dirt or contamination may cause major damage to the fuel injection system.

⚠ CAUTION Dirt in the system can severely damage both the injection pump and the injection nozzles. Dirty fuel is one of the major causes of engine failure. Even a tiny particle of dirt in the injection system may stop the engine. Because diesel injection systems have extremely precise tolerances, make certain that fuel is kept clean.




FIGURE 3-6. FUEL LINE CONNECTIONS

Separate Fuel Tanks

The fuel tank top must be lower than the fuel pump level to prevent putting a static head on the fuel pump inlet. If the fuel tank is shared with another engine, use separate fuel lines for both engines to avoid starving either one.

The following restrictions apply to separate fuel tank installation:

1. The bottom of the fuel tank must not be more than 6 feet (1.8 m) below the fuel transfer pump inlet, unless an auxiliary electric fuel pump is added. The maximum lift capacity of the transfer pump is six feet. See the Wiring Diagram for the connection.
2. If the tank is installed above the fuel pump inlet level without a supply line shutoff valve, a ruptured pump diaphragm could cause oil dilution, fuel loss, and fuel leakage to the crankcase.

3. If the maximum fuel lift must be exceeded on any installation, consult Onan Application Manual T-029 for information on installing a day tank and an electric solenoid shutoff valve.
4. Use an electric or manual shutoff valve if the minimum fuel level in the tank is higher than the pump inlet, to provide positive fuel shutoff when the engine is stopped. This valve also prevents loss of fuel from possible leaks between the tank and the fuel pump.

⚠ WARNING *Fuel leaks create the hazard of explosion and fire, which can cause severe personal injury or death. For these reasons, always use flexible tubing between the engine and the fuel supply, to avoid leaks due to vibration and/or fuel line failure. Make certain that the fuel system and the fuel tank location meet application local codes.*

INJECTION PUMP ADAPTER ASSEMBLY (DJE only)

A spring and plunger assembly on the side of the pump adapter (Figure 3-7) on the DJE generator set, limits the maximum power output of the engine for safe operation and permits maximum fueling during starting.

CAUTION Do not change the adjustment of this device unless absolutely required. The warranty may be voided if the fuel stop is intentionally altered to increase engine power.

OIL DRAIN

Extend the drain to suit the installation. The oil base has a 1/2-inch pipe size tapped hole.

WARNING Do not position the oil drain so that oil might drip onto the muffler, any exhaust components, or any other hot parts, causing a fire hazard. Fire presents the hazard of severe personal injury or death.




FIGURE 3-7. INJECTION PUMP ADAPTER ASSEMBLY

4. Electrical Preparation

GENERAL

The genset electrical system includes connecting the load, installing the control wiring and connecting the batteries. Connect the batteries last to avoid accidental starting of the unit during installation.

⚠ CAUTION *Always disconnect a battery charger from its AC source before disconnecting the battery cables. Otherwise, disconnecting the cables can result in voltage spikes high enough to damage the DC control circuits of the set.*

⚠ WARNING *Accidental starting of the generator set while working on it can cause severe personal injury or death. Prevent accidental starting by disconnecting the starting battery cables (negative [-] first).*

Arcing can ignite the explosive hydrogen gas given off by batteries, causing severe personal injury. Arcing can occur if the negative (-) battery cable is connected and a tool being used to connect or disconnect the positive (+) battery cable accidentally touches the frame or other grounded metal part of the set. To prevent arcing, always remove the negative (-) cable first, and reconnect it last.

The following paragraphs contain the procedures that are used to connect the electrical system of the genset.

⚠ WARNING *Each of the operations described in this section should be done only by persons trained and experienced in electrical maintenance. Improper procedures may result in property damage, bodily injury or death.*

Connecting the genset electrical system involves:

- Installation of transfer switch (standby service only)
- Generator voltage connections
- Load connection
- Control wiring
- Battery connection

Local regulations often require that wiring connections be made by a licensed electrician, and that the installation be inspected and approved before operation. All connections, wire sizes, materials used, etc. must conform to the requirements of electrical codes in effect at the installation site.

⚠ WARNING *Improper wiring can cause a fire or electrocution, resulting in severe personal injury or death and/or property and equipment damage.*

Before starting the genset, verify that all electrical connections are secure, and that all wiring is complete. Replace and secure any access panels that have been removed during installation. Check that the load cables from the genset are properly connected.

⚠ WARNING *Backfeed to utility system can cause electrocution or property damage. Do not connect to any building electrical system except through an approved device and after building main switch is opened.*

TRANSFER SWITCH

If the installation is for standby service, a transfer switch must be used for switching the load from the normal power source to the genset (see Figure 4-1). Either a manual or automatic transfer switch may be used. Follow the installation instructions provided with the transfer switch when connecting the load and control wiring.




FIGURE 4-1. TYPICAL LOAD TRANSFER FUNCTION

GENERATOR VOLTAGE CONNECTIONS

CAUTION Reconnecting factory connected generator sets to lower voltages may reduce set ratings, and also render line circuit breakers too small. Consult with your distributor before performing reconnection for different voltage.

The generator output voltages and maximum current rating are specified on the generator nameplate. Line-to-neutral voltage is always the lower voltage shown on the nameplate. Line-to-line voltage is the higher rating.

The factory ships special-order sets with control panels especially wired for the voltage specified by the customer. Standard sets without instruments are shipped with the T1-T4 or T1-T12 output leads separated in the output box. These single-phase and broad-range generators may be connected to provide any of the output voltages shown in the Reconnection Diagram (see Figure 4-3). **The Installer must always check the stator lead connections and perform any necessary reconnections to obtain the desired voltage.**

Refer to the Reconnection Diagram (see Figure 4-3) when reviewing the voltage connection infor-

mation, and use the electrical schematic supplied with your genset when actually performing load connections.

DANGER HAZARDOUS VOLTAGE Touching uninsulated live parts inside the AC control box can result in severe personal injury or death. Measurements and adjustments must be done with care to avoid touching uninsulated live parts.

For your protection, stand on a dry wooden platform or rubber insulating mat, make sure your clothing and shoes are dry, remove jewelry and use tools with insulated handles.

The AC control box (mounted above the control panel assembly) contains the automatic voltage regulator (AVR) printed circuit board. The AVR controls the output of the generator so that a constant voltage is maintained under varying load conditions. There are two types of AVR's available; one requiring jumper adjustments when connecting or changing load connections. If the genset contains the AVR shown in Figure 4-2, be sure to connect jumper W10 between terminal V4 (common) and V1, V2, or V3 as listed on the reconnection diagram.




FIGURE 4-2. AVR SELECTION JUMPERS (P/N 300-1540)

NAMEPLATE VOLTAGE CODE	VOLTAGE	PHASE	FREQUENCY	CONNECT W/O JUMPER WIRE FROM V4 TO:	GENERATOR CONNECTION	GENERATOR CONNECTION SCHEMATIC DIAGRAM	GENERATOR CONNECTION WIRING DIAGRAM
3C	120/240	1	60	V1		A	A
53C	120/240	1	50	V1		B	B
	115/230	1	50	V2		C	C
	110/220	1	50	V3			
18	120/208	3	60	V1	PARALLEL WYE		
	127/220	3	60	V2			
	139/240	3	60	V4			
518	110/190	3	50	V1			
	115/200	3	50	V2			
	120/208	3	50	V3			
	127/220	3	50	V4			
18	240/416	3	60	V1	SERIES WYE		
	254/440	3	60	V2			
	277/480	3	60	V4			
518	220/380	3	50	V1			
	230/400	3	50	V2			
	240/416	3	50	V3			
	254/440	3	50	V4			
18	120/240	3	60	V1	SERIES DELTA		
518	110/220	3	50	V1			
	115/230	3	50	V2			
	120/240	3	50	V3			
18	120/240	1	60	V1	DOUBLE DELTA		
518	110/220	1	50	V1			
	115/230	1	50	V2			
	120/240	1	50	V3			
18	120	1	60	V1	PARALLEL DELTA		
518	110	1	50	V1			
	115	1	50	V2			
	120	1	50	V3			
9X	347/600	3	60	V1	WYE		

FIGURE 4-3. GENERATOR VOLTAGE CONNECTIONS

LOAD CONNECTION

The output box (junction box) has knockout sections to accommodate load wires. Use flexible conduit and stranded load wires near the set to isolate vibration and permit movement. Use suitable size insulated wires for the load rating applied.

Connect each load wire to the proper generator output lead inside the output box. Insulate bare ends of ungrounded wires. Use bolt provided on the output box to connect the generator ground lead or earth wire. Install a fused main switch (or circuit breaker) between the generator and load. If a test-run indicates wrong rotation of 3 phase motors in the load circuit, switch the connections at any two of the generator terminals.

⚠ WARNING *Backfeed to utility system can cause electrocution or property damage. Do not connect to any building electrical system except through an approved device and after building main switch is opened.*

⚠ CAUTION *Phase rotation of the genset and utility must be the same. Equipment damage can occur. Check and reconnect as necessary.*

Check the rotation of 3-phase motors before loading and reconnect if necessary.

Balancing Loads

When connecting loads to the genset, balance the loads so that the current flow from each line terminal (L1, L2 and L3) is roughly the same. This is especially important if both single phase and three phase loads are connected. Any combination of single phase and three phase loading may be used as long as all line currents are about the same (within 10 percent of median value) and no line current exceeds the nameplate rating of the generator. Check the current flow from each load cable after connections are made, by observing the control panel ammeter if available.

Grounding

Grounding involves making a conducting connection between the metal parts of the generator set or one of its electrical circuits and the earth. The design and installation of a grounding system is affected by many factors such as the use of multiple transformers, ground fault protection requirements, and physical location of the generator. Follow the recommendations of the consulting engineer when installing the grounding system.

⚠ WARNING *Contact with electrical equipment can result in severe personal injury or death. Bonding and equipment grounding must be properly done. All metallic parts that could become energized under abnormal conditions must be properly grounded.*

DC WIRING

Remote Control Connections

Provisions are made inside the control box for adding optional remote starting, stopping, and preheating. Connections are made on the terminal block (TB11) located inside the control box. Connect the remote switches across the remote terminals and ground (TB11-1) terminal (Figure 4-3).

⚠ CAUTION *If the remote controller contains a preheat switch, remove jumper between terminals TB11-3 and TB11-H. If the jumper is not removed, the preheat switch will also start the genset.*

If a remote preheat switch is not used, do not remove the jumper. With the jumper installed, the remote start switch will energize the preheat circuitry during the start mode.

If the distance between the generator set and remote stations is less than 1000 feet (305 m), use 18 gauge stranded copper wire. If the distance is 1000 to 2000 feet (305 to 610 m), use 16 gauge stranded copper wire. Always run control circuit wiring in a separate conduit from the AC power cables to avoid inducing currents that could cause problems within the control.

Remote Monitor Connections

Provisions are made inside the control box for adding optional remote monitoring on gensets employing the deluxe control panel (three lamp panel). Connections are made on the terminal block (TB13) located inside the control box (Figure 4-3).




FIGURE 4-3. REMOTE CONTROL AND REMOTE MONITOR CONNECTIONS

BATTERY CONNECTIONS

Starting the unit requires 12 volt battery current. Use one, 12 volt battery for a normal installation (Figure 4-4). (Refer to Section 2, *Specifications* for battery type.)

Necessary battery cables and rack are on the unit. Service battery as necessary. Infrequent use (as in emergency standby service), may allow battery to self-discharge to the point where it cannot start the unit. If installing an automatic transfer switch that has no built-in charge circuit, connect a separate trickle charger. Onan automatic transfer switches can include an optional battery charging circuit.

⚠ WARNING *Ignition of explosive battery gases can cause severe personal injury. Always connect battery negative (-) last to prevent arcing.*

⚠ WARNING *Do not smoke or allow any other ignition source in area while servicing the battery. Explosive gases are emitted from batteries in operation. Ignition of these gases can cause severe personal injury.*




FIGURE 4-4. BATTERY CONNECTIONS



5. Control Description

GENERAL

This section covers a description of the controls for the standard control panel (Figure 5-1) the deluxe control panel (Figure 5-2) and the optional meter panel (Figure 5-3) used on housed gensets.

STANDARD CONTROL COMPONENTS/OPTIONS

Start / Stop Switch (S11): This switch is a single-pole, double-throw (SPDT) toggle type switch used for starting and stopping the generator set.

Holding the switch in the Start position will initiate engine cranking. When the engine reaches approximately 900 rpm, the starter motor will automatically disengage, preventing starter motor damage. The switch will automatically return to the center (Run) position when released.

Pushing the switch to the Stop position will initiate the stop function.

Preheat Switch (S13): Holding the switch in the Preheat position energizes the manifold heater and glow plugs for cold diesel engine starting.

DC Ammeter (M21): The DC ammeter indicates the rate in amperes at which the battery is being charged/discharged.

Running Time Meter (M12): This meter indicates the accumulated number of hours the set has run.

Common Fault Circuit Breaker (CB4): This fault circuit breaker shuts down the engine when any fault shutdown switch is energized. A fault shutdown is indicated when the breaker reset button extends out past normal. Push the button to restore operation (after reason for fault has been determined).

Fuse (F1): A 10-ampere fuse that provides protection to the control box wiring and remote wiring from short circuits or overload.

Exciter Field Circuit Breaker: Protects the exciter and the alternator if the voltage regulator malfunctions.

Voltage Adjust Rheostat (Optional): Rheostat providing approximately plus or minus five percent adjustment of the rated output voltage.

Oil Pressure Gauge: Indicates pressure of lubricating oil in engine. (Gauge is located on side of engine block.)




FIGURE 5-1. STANDARD CONTROL PANEL

DELUXE CONTROL PANEL COMPONENTS

The deluxe control panel (Figure 5-2) has the following fault indicators and circuit breakers in addition to the standard control panel controls.

Start / Stop / Test Switch (S11): In addition to the Start / Stop function provided on the standard control panel, a test position is provided on the deluxe control panel. In the Stop / Test position, this switch will light all fault indicator lamps on the deluxe control panel and remote annunciator panel. (Replace lamps that do not light.)

Individual Fault Circuit Breakers (CB4, CB5, CB6): An individual fault circuit breaker is provided in connection with each fault shutdown switch to shut down the engine when the contacts of a fault switch close. Each breaker is identified according to fault by the fault indicator above it on the panel.

Fault shutdown is indicated when the fault indicator lights and the breaker reset button extends out past normal. Push the button to restore operation (after the reason for the fault has been serviced).

Fault Indicator Lamps: An individual fault lamp is provided in connection with each fault shutdown switch to indicate the following fault conditions.

- **Low Oil Pressure:** This lamp indicates that the engine oil pressure is abnormally low (less than 14 psi ± 2 psi).
- **High Air Engine Temperature:** This lamp indicates that engine air temperature is abnormally high (greater than 375° F [190.5° C]).
- **Overspeed:** This lamp indicates that the engine shut down because of overspeed (60 Hz units at 2100 ± 90 r/min, and 50 Hz at 1850 ± 50 r/min).




FIGURE 5-2. DELUXE CONTROL PANEL

OPTIONAL AC METER PANEL COMPONENTS (HOUSED UNITS ONLY)

The optional AC meter panel (Figure 5-3) used on housed units only (DJC and DJE), has the following components:

AC Voltmeter (M1): The voltmeter indicates output voltage for the phase selected.

Voltmeter Phase Selector Switch (S1): Selects the phase of the generator output voltage to be measured.

Running Time Meter (M5): This meter indicates the accumulated number of hours the set has run.

Frequency Meter (M6): Indicates the frequency of the output voltage in hertz. It can be used to check engine speed (30 rpm-produces one hertz).

AC Ammeter (M2, M3, M4): The ammeter indicates output amperage for each phase. Ammeter M2 is used on three phase units only.

Line Circuit Breaker (CB1): Protects generator from line overloads.




FIGURE 5-3. AC METER PANEL



1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 2679, 26

22



6. Operation

⚠ WARNING

EXHAUST GAS IS DEADLY!

Exhaust gases contain carbon monoxide, an odorless and colorless gas. Carbon monoxide is poisonous and can cause unconsciousness and death. Symptoms of carbon monoxide poisoning can include:

- **Dizziness**
- **Nausea**
- **Headache**
- **Weakness and Sleepiness**
- **Throbbing in Temples**
- **Muscular Twitching**
- **Vomiting**
- **Inability to Think Coherently**

IF YOU OR ANYONE ELSE EXPERIENCE ANY OF THESE SYMPTOMS, GET OUT INTO THE FRESH AIR IMMEDIATELY. If symptoms persist, seek medical attention. Shut down the unit and do not operate until it has been inspected and repaired.

Protection against carbon monoxide Inhalation also includes proper installation and regular, frequent visual and audible inspections of the complete exhaust system.

GENERAL

This section covers prestart checks, starting and stopping and operating the generator set. Each operator should read through this entire section before attempting to start the set. It is essential that the operator be completely familiar with the set for safe operation.

⚠ CAUTION **Always disconnect a battery charger from its AC source before disconnecting the battery cables. Otherwise, disconnecting the cables can result in voltage spikes high enough to damage the DC control circuits of the set.**

⚠ WARNING **Accidental starting of the generator set while working on it can cause severe personal injury or death. Prevent accidental starting by disconnecting the starting battery cables (negative [-] first).**

Arcing can ignite the explosive hydrogen gas given off by batteries, causing severe personal injury. Arcing can occur if the negative (-) battery cable is connected and a tool being used to connect or disconnect the positive (+) battery cable accidentally touches the frame or other grounded metal part of the set. To prevent arcing, always remove the negative (-) cable first, and reconnect it last.

PRESTART CHECKS

Before starting, be sure the following checks have been made and the unit is ready for operation. Refer to the *Maintenance* section for the recommended procedures.

Mechanical Checks

Before the generator set is activated, check all components for mechanical integrity. If an abnormal condition, defective part, or operating difficulty is detected, repair or service the genset as required. Keep the generator set free of dust, dirt, and spilled oil or fuel.

Lubrication

Check the engine oil level. Keep the oil level near as possible to the dipstick high mark without overfilling.

Fuel

Make sure the fuel tank has sufficient fuel and that the fuel system is primed.

DC Electrical System

CAUTION *Always disconnect a battery charger from its AC source before disconnecting the battery cables. Otherwise, disconnecting the cables can result in voltage spikes high enough to damage the DC control circuits of the set.*

With the genset off, check the terminals on the battery for clean and tight connections. Loose or corroded connections create resistance that can hinder starting. Clean and reconnect the battery cables if loose. Always connect the negative battery cable last.

WARNING *Ignition of explosive battery gases can cause severe personal injury. Do not permit any flame, cigarette, pilot light, spark, arcing switch or equipment or other ignition source near the battery.*

PRE-HEATING AND STARTING

WARNING *Do not use ether as a cold weather starting aid. The heat from the glow plugs or manifold heater may cause a sudden ignition of the ether vapor. This can result in personal injury and damage to the engine.*

CAUTION *Phase rotation of the genset and utility must be the same. Equipment damage can occur. Check and reconnect as necessary.*

Check the rotation of 3-phase motors before loading and reconnect if necessary.

1. Engage the Preheat switch for 60 seconds when the ambient temperature is 55° F (13° C) and lower, or 30 seconds when the temperature is above 55° F (13° C).

CAUTION *Preheating the engine longer than one minute in moderate ambient temperatures before cranking the engine can destroy the manifold heater and glow plugs, because there is no incoming air flow to cool them. For this reason, do not exceed the one minute preheat periods (unless ambient temperature is below 5° F), to prevent heater burnout and conserve the battery.*

2. Engage the Start switch. Continue to hold the Preheat switch until engine comes up to operating speed. When the engine reaches approximately 900 rpm, the starter motor will automatically disengage with the switch held in the Start position, preventing starter motor damage. The switch will automatically return to the center (Run) position when released.
3. If the engine fails to start after 15-20 seconds of cranking, repeat Steps 1 and 2 above. Absence of blue/white exhaust smoke during cranking indicates no fuel being delivered. Determine cause.
4. Release the Preheat switch after the engine reaches speed. In extreme cold below 32° F (0° C) it may be necessary to maintain preheating for two minutes after the engine starts to obtain firing or smooth out cylinders, especially at no load or light loads.
5. Check the oil pressure gauge: it should read at least 20 psi (138 kPa).

CAUTION *Do not apply overvoltage to the starting circuit at any time. Overvoltage will destroy the glow plugs and air heater in 2 to 3 seconds. If it becomes necessary to use an additional source of power to start the set, use a 12 volt battery connected in parallel.*

RUNNING

With the genset running, listen for any unusual noises that may indicate mechanical problems and check the oil pressure frequently. Investigate anything that indicates possible mechanical problems.

Before operating the genset under load, make certain the genset will perform correctly by checking the following areas.

Exhaust System

⚠ WARNING *Inhalation of exhaust gases can result in severe personal injury or death. Inspect exhaust system audibly and visually for leaks daily. Repair any leaks immediately.*

Inspect the entire exhaust system including the exhaust manifold, muffler and exhaust pipe. Visually and audibly check for leaks at all connections, welds, gaskets, and joints. Make sure exhaust pipes are not heating surrounding area. If any leaks are detected, have them corrected immediately.

Fuel System

⚠ WARNING *Leaking fuel will create a fire hazard that can result in severe personal injury or death if ignited by a spark. If any leaks are detected, have them corrected immediately.*

Inspect the fuel supply lines, filters, and fittings for leaks. Check any flexible sections for cuts, cracks, and abrasions and make sure they are not rubbing against anything that could cause breakage.

Engine Gauges

Check the following while the genset is operating.

Oil Pressure Gauge: The oil pressure should be at least 20 psi (138 kPa).

DC Ammeter: The DC ammeter indicates the rate in amperes at which the battery is being charged. The charge rate should be approximately 2 amperes.

Generator AC Meters (Optional)

Check the following meters while the genset is operating.

Frequency Meter: The generator frequency should be stable and the reading should be the same as the nameplate rating (50 Hz - 1500 RPM, 60 Hz - 1800 RPM $\pm 5\%$).

AC Voltmeter: On three phase gensets, turn the phase selector switch to each line-to-line phase selection shown on the volts scale (L1-L2, L2-L3, and L1-L3). At no load, the line-to-line voltage should be the same as the genset nameplate rating. If the reading is incorrect, refer to the *Adjustment* section for the correct procedure.

AC Ammeter: At no load, the current readings should be zero. With a load applied, each line current should be approximately the same, and no line current should exceed the genset nameplate rating.

STOPPING

Run the generator set at no load for three to five minutes before stopping. This allows the lubricating oil to carry heat away from the combustion chamber and bearings.

1. Push the Start / Stop switch to the Stop position.
2. If the stop circuit fails, push governor arm down to shut off fuel injection pump.

Engine Monitor Indicator Lamps (Optional)

With the genset stopped, briefly engage the Stop / Test switch. All indicator lamps should light. Verify all of the lamps are on and then release the switch. Contact an Onan distributor if any lamps require replacement.

Mechanical Checks

With the genset stopped, check for leaking fittings and gaskets, and for any signs of mechanical damage. If any problems are found, have them corrected immediately.

BREAK-IN

Observe the following schedule for genset break-in:

1. One half hour at 1/2 load.
2. One half hour at 3/4 load.
3. Full load.

During the first few hundred hours of operation, the genset load should be at least 1/2 to full load. Continuous operation below this load recommendation can result in poor piston ring seating, causing higher-than-normal oil consumption and blowby.

Drain and replace the crankcase oil after the first 50 hours of operation on new gensets. Refer to the *Maintenance* section of this manual for the recommended procedures.

NO-LOAD OPERATION

Periods of no-load operation should be held to a minimum. If it is necessary to keep the engine running for long periods of time when no electric output is required, best engine performance will be obtained by connecting a "dummy" electrical load. Such a load could consist of a heater element, etc.

EXERCISING UNIT

⚠ CAUTION *Improper exercising may cause more damage than no exercising at all.*

Significant amounts of water and raw fuel will remain in the lubrication oil if the unit is run at a low operating temperature. Also, operating the engine at no load or at low temperatures causes carbon buildup and exhaust system fouling. Continued operation in this manner may cause starting failure and/or engine damage. Exercising a generator set without exercising its associated controls and switchgear does not test the operation of the controls and switchgear. If the control systems are not fully functional, the system may fail to provide power when required.

Infrequent use of the generator set can cause it to deteriorate. The following can occur:

- Condensation in the fuel and lubrication system, causing contamination and/or corrosion
- Loss of protective oil film on moving engine parts
- Loss of engine fuel prime due to drain-back and/or evaporation
- Battery discharge due to internal and external current leakage
- Breakdown of generator insulation due to water absorption

Proper exercising does the following:

- Elevates engine oil temperature to at least 180° F (82.2° C)
- Evaporates water from engine lubrication system
- Re-establishes a protective oil film on engine parts
- Recharges battery to full normal potential
- Brings generator to normal operating temperature through load application

The generator set should be exercised at least once each week. The engine oil temperature should be held at 180° F (82.2° C) for at least 30 minutes during this exercise.

To exercise the generator set, do the following:

1. Perform all required maintenance checks, start the unit, and apply a load (50 percent or more) by creating a simulated power failure*. This exercises the control and switchgear systems.
2. After the genset has reached its normal operating temperature, allow the genset to run an additional 30 minutes.
4. Shut the unit down by simulating the return of normal power*. Run the set for approximately three to five minutes with no load to allow the engine to cool down.

* This applies to a standby genset only. Other units should be started and loaded by control and load application systems normally associated with operation of the unit.

After each exercise period, refill the fuel tank and check the engine for leaks and overall condition. Locate the cause of any leaks and correct.

ENGINE RATINGS

Ratings apply to altitudes up to 1000 feet (305 m), gensets using standard cooling, normal ambient temperatures and with No. 2 Diesel fuel. Consult the nearest authorized Onan service center for operating characteristics under other conditions.

HIGH/LOW OPERATING TEMPERATURES

The generator set has been designed to operate satisfactorily in both high (above 100° F) and low (below 0° F) temperatures. Use the oil recommended in the *Maintenance* section of this manual for the expected temperature conditions.

High Operating Temperatures

1. See that nothing obstructs air flow to and from the set.
2. Keep cooling fins clean. Cylinder air housings should be properly installed and undamaged.

Low Operating Temperatures

1. Use correct viscosity oil for temperature conditions. Change oil only when engine is warm. If an unexpected temperature drop causes an emergency, move the set to a warm location or apply heated air (never use open flame) externally until oil flows freely.

2. Use fresh fuel. Protect against moisture condensation.
3. Keep fuel system clean, and batteries in a well charged condition.
4. Partially restrict cool air flow but use care to avoid overheating.
5. Use additional preheating during cold starts.

DUST AND DIRT

1. Keep the generator set and the cooling system clean.
2. Service the air cleaner as frequently as necessary.
3. Change the crankcase oil every 100 operating hours.
4. Keep oil and fuel in dust-tight containers.
5. Keep governor linkage clean.

HIGH ALTITUDE

Maximum power is reduced approximately 4 percent for each 1000 feet (305 m) altitude above sea level after the first 1000 feet (305 m).



7. Adjustments

⚠ CAUTION Always disconnect a battery charger from its AC source before disconnecting the battery cables. Otherwise, disconnecting the cables can result in voltage spikes high enough to damage the DC control circuits of the set.

⚠ WARNING Accidental starting of the generator set while working on it can cause severe personal injury or death. Prevent accidental starting by disconnecting the starting battery cables (negative [-] first).

Arcing can ignite the explosive hydrogen gas given off by batteries, causing severe personal injury. Arcing can occur if the negative (-) battery cable is connected and a tool being used to connect or disconnect the positive (+) battery cable accidentally touches the frame or other grounded metal part of the set. To prevent arcing, always remove the negative (-) cable first, and reconnect it last.

OUTPUT VOLTAGE ADJUSTMENT (OPTIONAL)

Output voltage can be adjusted plus or minus five percent of nominal voltage by the adjustment screw (output voltage trimmer) located above the control panel (Figure 7-1). Call your distributor if the required voltage cannot be obtained by this adjustment.

⚠ WARNING Use extreme caution when working on electrical components. High voltages can cause injury or death. Stand on rubber mat or wooden platform. Do not wear jewelry, damp clothing (particularly wet shoes) or allow skin surface to be damp when handling electrical equipment.




FIGURE 7-1. OUTPUT VOLTAGE ADJUSTMENT

GOVERNOR

The governor controls engine speed. On a 4 pole generator, engine speed equals frequency multiplied by 30. Thus 1800 rpm generates 60 hertz. Preferred engine speed does not vary more than 3 hertz from no-load to full-load operation. Be sure that the throttle, linkage, and governor mechanism operate smoothly.

Speed Adjustment

To change the governor speed, change the spring tension by turning the governor speed adjusting nut (Figure 7-2). Turn the nut clockwise (more spring tension) to increase rpm, or counterclockwise to reduce governed speed. Use a stroboscope or a frequency meter to make this adjustment.

Sensitivity Adjustment

To adjust governor sensitivity (no-load to full-load speed droop), turn the sensitivity adjusting ratchet. Turning the ratchet counterclockwise provides more sensitivity (less speed drop when full load is applied), and turning it clockwise provides less sensitivity (more speed drop).

If the governor is too sensitive, a rapid hunting condition occurs (alternate increasing and decreasing speed). Adjust the governor for maximum sensitivity without hunting. After making the sensitivity adjustment, readjust the speed.




FIGURE 7-2. ADJUSTING GOVERNOR

CHARGE RATE ADJUSTMENT

The adjustable resistor slide tap (Figure 7-3) in the charging circuit is set to produce a 2 ampere charging rate. This resistor is found in the generator air outlet. For applications requiring frequent starts, check the battery specific gravity periodically. If necessary, increase the charging rate slightly (move the slide tap up). Adjust this slide tap only when the engine is stopped.

⚠ WARNING Batteries present the hazard of explosion, which can result in severe personal injury. Because batteries produce explosive gas, do not smoke or allow any flame, sparks, or arc-producing devices in the battery area.

Avoid overcharging the battery. Make small increments of change until the proper rate has been determined to keep the battery charged.




FIGURE 7-3. CHARGING RESISTOR

VALVE CLEARANCE ADJUSTMENTS

Check the valve clearance when the engine is at room temperature, about 70° F (21° C).

CAUTION *Incorrect valve clearance adjustment can lead to irrevocable damage to the generator set. Make certain that only qualified personnel perform this adjustment.*

1. Turn the flywheel until the cylinder which is to have its valve adjusted is on its compression stroke. On engines without a hand crank, use a socket wrench on the flywheel hex head screw. To determine if the cylinder is in its compression stroke, observe the push rods as the engine is rotated in a clockwise direction. The exhaust valve push rod will be in its lowest position, and the intake valve push rod will be moving downward. As the piston reaches top dead center, the flywheel timing mark should be aligned with the timing pointer, and the valve push rods should be stationary.
2. Turn the flywheel an additional 10 to 45 degrees clockwise (estimated). When the piston is in this position, it is in its power stroke, with both valves completely closed.
3. Check cylinder head-bolt torque prior to valve clearance adjustment. Torque values are listed in the *Specifications* section. Adjust valve clearance with the locknut which secures the rocker arm to the cylinder head (Figure 7-4). Loosen this locknut to increase clearance, tighten it to reduce clearance.
4. Using a feeler gauge, check the clearance between the rocker arm and the valve (Figure 7-5). Increase or decrease the clearance until the proper gap is established. Valve clearances are listed in the *Specifications* section.




FIGURE 7-4. VALVE CLEARANCE ADJUSTMENTS




FIGURE 7-5. CHECK VALVE CLEARANCE

CENTRIFUGAL SWITCH

The start-disconnect centrifugal switch (Figure 7-6) is located on the side of the engine, above the oil filter. The switch opens when the engine stops, and closes when engine speed reaches 900 rpm. If necessary, loosen the stationary contact and adjust the point gap to 0.020 inch (51 mm). Replace burned or faulty points.

⚠WARNING *High voltage, which can cause severe personal injury or death, is present at the breaker point gap. For this reason, disconnect the battery cable, negative (-) terminal first, before setting the breaker point gap.*




FIGURE 7-6. CENTRIFUGAL SWITCH
ADJUSTMENT

8. Troubleshooting

The generator set has sensors that continuously monitor the engine for low oil pressure, high engine temperature and overspeed. If an abnormal condition occurs, the fault circuit breaker will trip, (optional fault lamp will light) and the engine shuts down. After the problem is corrected, reset the fault circuit breaker to restart the generator set.

Table 8-1 describes the operation of the fault condition system (including optional features) and lists troubleshooting procedures.

SAFETY CONSIDERATIONS

High voltages are present within the control box and generator output box when the generator is running. Do not open the control box or generator output box while the set is running.

⚠ WARNING *Contacting high voltage components can cause severe personal injury or death. Keep control and output box covers in place during troubleshooting.*

Generator set installations are normally designed for automatic starting or remote starting. When troubleshooting a set that is shut down, make certain the generator set cannot be accidentally restarted. To prevent accidental starting, always re-

move the negative battery cable from the set starting battery.

⚠ WARNING *Accidental starting of the generator set during troubleshooting can cause severe personal injury or death. Prevent accidental starting by disconnecting the starting battery cables (negative [-] first).*

Arcing can ignite the explosive hydrogen gas given off by batteries, causing severe personal injury. Arcing can occur if the negative (-) battery cable is connected and a tool being used to connect or disconnect the positive (+) battery cable accidentally touches the frame or other grounded metal part of the set. To prevent arcing, always remove the negative (-) cable first, and reconnect it last.

⚠ CAUTION *Always disconnect a battery charger from its AC source before disconnecting the battery cables. Otherwise, disconnecting the cables can result in voltage spikes high enough to damage the DC control circuits of the set.*

When a fault condition occurs during operation, follow the procedures in Table 8-1 to locate and correct the problem. If a major problem is indicated, contact an Onan Distributor for service.

TABLE 8-1. TROUBLESHOOTING

⚠WARNING Many troubleshooting procedures present hazards that can result in severe personal injury or death. Only qualified service personnel with knowledge of fuels, electricity, and machinery hazards should perform service procedures. Review safety precautions on pages iii and iv..

SYMPTOMS	CHECKS AND CORRECTIVE MEASURES
1. The engine will not crank.	<p>1a. Indicates possible fault with control or starting system. Check for the following conditions:</p> <ul style="list-style-type: none"> a. Fuse F1 has blown. Replace the fuse with one of the same type and amp rating. b. Fault circuit breaker has tripped. Service the fault, and re-set the circuit breaker. c. Poor battery cable connections. Clean the battery terminals and tighten all connections. <p>1b. Indicates insufficient battery voltage due to:</p> <ul style="list-style-type: none"> a. Batteries not charged. b. Battery connections loose or dirty. c. Insufficient battery charging voltage (contact an Onan distributor for assistance). d. Contact an Onan distributor for assistance if none of the above.
2. The engine cranks, but does not start or starts and then shuts down.	<p>2. Indicates possible fuel system problem.</p> <ul style="list-style-type: none"> a. Check for empty fuel tank, fuel leaks, or plugged fuel lines and correct as required. b. Check for dirty fuel filter and replace if necessary (see <i>Maintenance</i> section). c. Check for dirty or plugged air filter and replace if necessary (see <i>Maintenance</i> section). d. Contact an Onan distributor for assistance if none of the above.
3. Engine runs and then shuts down (fault circuit breaker trips and optional OVER-SPEED lamp lights.	<p>3. Indicates engine has exceeded normal operating speed.</p> <ul style="list-style-type: none"> a. Check the governor-throttle linkage. See <i>Adjustments</i> section. b. Reset the tripped fault circuit breaker. c. Contact an Onan distributor for assistance if none of the above.

TABLE 8-1. TROUBLESHOOTING (Continued)

⚠ WARNING *Many troubleshooting procedures present hazards that can result in severe personal injury or death. Only qualified service personnel with knowledge of fuels, electricity, and machinery hazards should perform service procedures. Review safety precautions on pages iii and iv.*

SYMPTOMS	CHECKS AND CORRECTIVE MEASURES
4. Engine runs and then shuts down (fault circuit breaker trips and optional HI ENG TEMP lamp lights).	4. Indicates engine has overheated. Allow engine to cool down completely before proceeding with the following checks: a. Check for obstructions to cooling airflow and correct as necessary. Keep cooling fins clean. b. Incoming air is too hot. Open doors or windows in generator area to increase ventilation. c. Overloaded. Disconnect as many non-critical loads as possible so that the engine will run cooler. d. Reset fault circuit breaker after locating and correcting problem. Contact an Onan distributor for assistance if none of the above.
5. Engine runs and then shuts down (fault circuit breaker trips and optional LO OIL PRES lamp lights).	5. Indicates engine oil pressure has dropped below 20 psi (138 kPa). Check oil level, lines and filters. If oil system is okay but oil level is low, replenish. Reset fault circuit breaker. Contact an Onan distributor for assistance if oil pressure is not 20 psi or above.
6. Fault lamp lights but no fault exists. Engine gauges show oil pressure.	6. Engine sensor is faulty. Contact an Onan distributor for assistance.
7. Fault lamp(s) does not light when Alarm Test switch is engaged.	7. Replace defective lamp(s).
8. No AC output voltage because the line circuit breaker (if provided) or the field circuit breaker has tripped.	8. Determine the cause (overload or short circuit) and clear the fault. Reset the line circuit breaker and/or the field circuit breaker. Contact an Onan distributor if voltage buildup causes breaker to trip.



9. Maintenance

GENERAL

Establish a maintenance/service schedule based on the type of application, and on the severity of the environment. The Table 9-1 lists the recommended service intervals. In extreme operating conditions, reduce the service intervals accordingly. Factors that affect the maintenance schedule include the following:

- Use for continuous duty (prime power)
- Extremes in ambient temperature
- Exposure to elements
- Exposure to salt water
- Exposure to windblown dust or sand

Consult with an authorized service center if the set is subject to extreme operating conditions, and determine a suitable maintenance schedule. Perform all service at the time period indicated, or after the number of operating hours indicated, whichever comes first. Use Table 9-1 to determine the required maintenance. Refer to this section for maintenance procedures.

⚠ CAUTION *Always disconnect a battery charger from its AC source before disconnecting the battery cables. Otherwise, disconnecting the cables can result in voltage spikes high enough to damage the DC control circuits of the set.*

⚠ WARNING *Accidental starting of the generator set while working on it can cause severe personal injury or death. Prevent accidental starting by disconnecting the starting battery cables (negative [-] first).*

Arcing can ignite the explosive hydrogen gas given off by batteries, causing severe personal injury. Arcing can occur if the negative (-) battery cable is connected and a tool being used to connect or disconnect the positive (+) battery cable accidentally touches the frame or other grounded metal part of the set. To prevent arcing, always remove the negative (-) cable first, and reconnect it last.

TABLE 9-1. MAINTENANCE SCHEDULE

HOURS OF OPERATION	MAINTENANCE TASK
8	<ul style="list-style-type: none">• Inspect exhaust system• Inspect generator set• Check fuel supply; See Note 1• Check oil level
50	<ul style="list-style-type: none">• See Note 2• Check air cleaner; See Note 3
100	<ul style="list-style-type: none">• Clean governor linkage• Change crankcase oil (or annually); See Note 3• Clean sediment bowl and filter on fuel transfer pump; See Note 1• Replace oil filter• Check battery condition
200	<ul style="list-style-type: none">• Clean crankcase breather
500	<ul style="list-style-type: none">• Check start-disconnect circuit• Check valve clearances; See Note 4• Clean crankcase breather tube
600	<ul style="list-style-type: none">• Change primary fuel filter
1500	<ul style="list-style-type: none">• Check torsional washers for corrosion; See Note 5
2000	<ul style="list-style-type: none">• Grind valves (if required); See Note 4• Check nozzle spray pattern; See Note 4• Clean generator
3000	<ul style="list-style-type: none">• Change secondary fuel filter
5000	<ul style="list-style-type: none">• General overhaul (if required); See Note 4

1. Water or foreign material in fuel can ruin the injection system. If daily inspection shows water or excessive dirt in sediment bowl, fuel handling and storing facilities should be checked and situation corrected. Primary and secondary fuel filters can be replaced following correction of fuel contamination problem.
2. Tighten head bolts and adjust valve clearance after first 50 hours on new and overhauled engines, and then adjust valve clearance each 500 hours thereafter.
3. Perform more often in extremely dusty conditions.
4. Contact an authorized service center for service.
5. Check yearly on non-commercial sets.

GENERATOR SET INSPECTION

During operation, be alert for mechanical problems that could create unsafe or hazardous conditions. Section 6 of this manual covers the areas that should be frequently inspected for continued safe operation.

LUBRICATION SYSTEM

The engine oil was drained from the crankcase before shipment. Before the initial start, the lubrication system must be filled with oil of the recommended classification and viscosity. Refer to *Specifications* section for the lubricating oil capacity.

Oil Recommendations

The use of quality engine lubricating oils combined with appropriate oil drain and filter change intervals are critical factors in maintaining engine performance and durability.

Use SAE 30 oil that meets the American Petroleum Institute (API) Classification CC/CD, CD/SG or CE/SG. Table 9-2 shows the preferred oil grades for ambient temperatures indicated.


CC/CD or CD/SG engine oils can be used in areas where CE oil is not yet available, but the oil change interval must be reduced to one half the interval given in the Maintenance Schedule.

Oil consumption may be higher with a multigrade oil than with a single-grade oil. For this reason, single grade oils are preferable unless wide temperature variations are anticipated.

CAUTION Limited use of low viscosity oils, such as 5W-30 may be used for easier starting and providing sufficient oil flow at ambient temperatures below 23° F (-5° C). However, continuous use of low viscosity oils can decrease engine life due to wear. Refer to the accompanying chart.

In extremely dusty or dirty conditions, oil should be changed more frequently. When adding oil between changes, use the same brand as already in the engine. Various brands of oil may not be compatible when mixed.

TABLE 9-2. OIL VISCOSITY/TEMPERATURE CHART



* PREFERRED SUMMER

Engine Oil Level

⚠ CAUTION *Do not operate the engine with the oil level below the LOW mark or above the FULL mark. Overfilling can cause foaming or aeration of the oil while operation below the ADD mark can cause loss of oil pressure.*

Check the engine oil level during engine shutdown periods at the intervals specified in the Maintenance Schedule. The oil dipstick and oil fill are located on the side of the engine (Figure 9-1). The dipstick is stamped with FULL and LOW to indicate the level of oil in the crankcase. For accurate readings, shut off the engine and wait approximately 10 minutes before checking the oil level. This allows oil in the upper portion of the engine to drain back into the crankcase.

Keep the oil level as near as possible to the FULL mark on the dipstick. Remove the oil fill cap and add oil of the same quality and brand when necessary.




FIGURE 9-1. OIL LEVEL INDICATOR

Oil Change

⚠WARNING *Hot crankcase oil can cause burns if it is spilled or splashed on skin. Keep fingers and hands clear when removing the oil drain plug and wear protective clothing.*

Change the oil and filter at the intervals recommended in the Maintenance Schedule.

Stop the engine and drain the crankcase oil while the engine is still hot. Place a pan under the drain outlet and remove the oil drain plug or open the oil drain valve. After the oil is completely drained, replace the drain plug or close the drain valve. Replace oil filter if necessary before adding oil.

Refill with oil of the correct API designation and SAE viscosity grade for the temperature conditions (refer to Table 9-2).

Check the oil level indicator after every 8 hours of operation, and maintain the oil level at the FULL mark (Figure 9-3). Refer to the *Specifications* section for crankcase and filter capacity.

Oil Filter Change

⚠WARNING *Hot crankcase oil can cause burns if it is spilled or splashed on skin. Keep fingers and hands clear when removing the oil drain plug and wear protective clothing.*

Place a container under the oil filter and remove the filter by turning it counterclockwise. Clean the filter mounting area. Oil filter gasket with clean oil. To install the new filter, turn the filter on clockwise until the gasket touches the mounting base, then tighten 1/2 turn.

FUEL SYSTEM

Use only high-quality fuel in this generator set. Fuel quality is important in obtaining dependable performance and satisfactory engine life. Fuel must be clean, completely distilled, well refined, and non-corrosive to fuel system parts.

⚠ WARNING *Ignition of fuel can cause severe personal injury or death by fire or explosion. Do not permit any flame, cigarette, spark, pilot light, arcing equipment or other igniter near the fuel system.*

Fuel Recommendations

Use ASTM 2-D (No. 2 Diesel) or ASTM 1-D (No. 1 Diesel) fuel with a minimum Cetane number of 45. Number 2 diesel fuel gives the best economy and performance under most operating conditions. Use number 1 diesel fuel when ambient temperatures are below 0° C (32° F), or during long periods of light engine load.

The fuel's viscosity must be kept above 1.3 cSt to provide adequate fuel system lubrication.

Fuels with Cetane numbers higher than 45 may be needed in higher altitudes or when extremely low ambient temperatures are encountered to prevent misfires and resultant excessive smoke.

Use low-sulfur-content fuel with a cloud point at least 10 degrees below the lowest expected fuel

temperature. (Cloud point is the temperature at which wax crystals begin to form in diesel fuel.)

Fuel Handling Precautions

Take appropriate precautions to prevent the entrance of dirt, water or other contaminants into the fuel system. Filter or strain the fuel as the tank is filled.

⚠ CAUTION *Due to the precise tolerances of diesel injection systems, dirt or water in the fuel can cause severe damage to both the injection pump and injector nozzles. Take special precautions to keep the fuel clean and free of water.*

To avoid condensation problems, keep fuel tanks as full as possible. In cold weather, warm fuel returning from the engine heats the fuel in the supply tank. If the fuel level is low, condensation tends to form in the upper portion of the tank. In warm weather, the fuel and the tank will both be warm during the daytime. At night, cool air lowers the temperature of the tank more rapidly than the temperature of the fuel. If the fuel level is low, the upper portion of the tank will cool more rapidly and condensation will tend to form.

Condensation (water) can clog fuel filters as well as causing freezing problems. Also, water mixing with the sulfur in the fuel forms acid which can corrode and damage engine parts.

Fuel Filters

The filters are spin-off, throw-away units. A water drain is situated at the bottom of the filter case (Figure 9-2). This should be used to drain off moisture either daily or at the end of every exercise period, depending on unit application.

The drain plug on the fuel filter can tolerate only a limited amount of torque. Use two wrenches in combination for breaking the plug loose and for final tightening.

Change the primary and secondary fuel filters at the intervals recommended in the Maintenance Schedule. Change the fuel filters by removing the washer and capscrew on top of the fuel filter body.




FIGURE 9-2. DUAL FUEL FILTERS

Fuel Pump Sediment Bowl

Remove the sediment bowl from the fuel filter body (Figure 9-3). Clean out any contaminants from sediment bowl. When re-installing the sediment bowl, make sure that gasket and screen are in place.




FIGURE 9-3. FUEL PUMP SEDIMENT BOWL

Priming the Fuel System


The fuel system must be primed before initial startup or after the engine has run out of fuel. Prime the fuel system as follows.

Disconnect the fuel return line (Figure 9-4). Operate the hand priming lever on the fuel transfer pump until the fuel following from the fuel return line is free of air bubbles. Then reconnect the fuel return line.

Cranking the engine should expel trapped air from the injection pump.

If the pump lobe of the camshaft is up, crank the engine one revolution to permit hand priming. When finished, return priming lever inward (disengaged position) to permit normal pump operation.

WORK TRANSFER PUMP
PRIMING LEVER UNTIL FUEL
FLOWS FROM RETURN LINE
OF INJECTION PUMP




ALWAYS RETURN
PRIMER LEVER TO
LOWEST POSITION

INJECTION
PUMP RETURN
LINE FITTING

DJB & DJC FUEL SYSTEM BLEEDING

FS1777



ALWAYS RETURN
PRIMER LEVER TO
LOWEST POSITION

WORK TRANSFER PUMP
PRIMING LEVER UNTIL FUEL
FLOWS FROM RETURN LINE
OF INJECTION PUMP

RETURN LINE

DJE FUEL SYSTEM BLEEDING

FS1854C

FIGURE 9-4. FUEL SYSTEM

AIR CLEANERS

⚠ CAUTION *Filters should be handled with care to prevent damage. If the filter does become damaged, install recommended replacement part.*

After every 50 hours of operation, remove and clean the filter element (Figure 9-5). After washing the element in solvent, dip the element in engine oil and squeeze it as dry as possible.




FIGURE 9-5. POLYURETHANE FOAM AIR CLEANER

CONTRACTOR MODEL AIR CLEANER

1. Remove pre-cleaner (Figure 9-6) and wash out dirt. Dry and reinstall.
2. Loosen clamp and remove end cover.
3. Remove thumbscrew and take out element. Wash element in detergent and water (use new element after 6 washings). Dry and reinstall.
4. Remove air cleaner baffle from cover, wash out dirt, and reinstall in cover.
5. Install cover with "TOP" up and tighten clamp.




FIGURE 9-6. CONTRACTOR MODEL AIR CLEANER

GOVERNOR LINKAGE

Every 100 hours, carefully pull the neoprene governor ball joints apart and clean them. Do not lubricate these joints. See Figure 9-7.

⚠ CAUTION *Some solvents can damage the neoprene governor ball joints. Read the manufacturer's recommendations before using any lubricants or solvents near the ball joints.*




FIGURE 9-7. GOVERNOR BALL JOINT

BATTERIES

⚠ WARNING *Ignition of explosive battery gases can cause severe personal injury. Do not smoke or allow any source of ignition while servicing batteries.*

Check the condition of the starting battery at the interval specified in the maintenance schedule. To prevent dangerous arcing, always disconnect the negative ground strap from the battery before working on any part of the electrical system or the engine. Disregard the sections on Checking Specific Gravity and Checking Electrolyte Level if using a "maintenance-free" battery.

⚠ WARNING *Arcing can ignite the explosive hydrogen gas given off by batteries, causing severe personal injury. Arcing can occur if the negative (–) battery cable is connected and a tool being used to connect or disconnect the positive (+) battery cable accidentally touches the frame or other grounded metal part of the set. To prevent arcing, always remove the negative (–) cable first, and reconnect it last.*

⚠ CAUTION *Always disconnect a battery charger from its AC source before disconnecting the battery cables. Otherwise, disconnecting the cables can result in voltage spikes high enough to damage the DC control circuits of the set.*

Cleaning Batteries

Keep the batteries clean by wiping them with a damp cloth whenever dirt appears excessive.

If corrosion is present around the terminal connections, remove battery cables and wash the terminals with an ammonia solution or a solution consisting of 1/4 pound of baking soda added to 1 quart of water.

Be sure the vent plugs are tight to prevent cleaning solution from entering the cells.

After cleaning, flush the outside of the battery and surrounding areas with clean water.

Keep the battery terminals clean and tight. After making connections, coat the terminals with a light application of petroleum jelly or non-conductive grease to retard corrosion.

Checking Specific Gravity

Use a battery hydrometer to check the specific gravity of the electrolyte in each battery cell.

Hold the hydrometer vertical and take the reading. Correct the reading by adding four gravity points (0.004) for every ten degrees the electrolyte temperature is above 80° F (27° C). A fully charged battery will have a corrected specific gravity of 1.260. Charge the battery if the reading is below 1.215.

Checking Electrolyte Level

⚠ CAUTION *Do not add water in freezing weather unless the engine will run long enough (two to three hours) to assure a thorough mixing of water and electrolyte.*

Check the level of the electrolyte (acid and water solution) in the batteries at least every 200 hours of operation.

Fill the battery cells to the bottom of the filler neck. If cells are low on water, add distilled water and recharge. If one cell is low, check case for leaks. Keep the battery case clean and dry. An accumulation of moisture will lead to a more rapid discharge and battery failure.

CRANKCASE BREATHER

Clean the crankcase breather at the intervals recommended in the Maintenance Schedule.

To clean the crankcase breather, remove hose clamp, breather hose, breather cap clamp and insulator halves to release breather cap and valve assembly (Figure 9-8). Wash cap, valve assembly and baffle in suitable solvent. Dry and reinstall.




FIGURE 9-8. CRANKCASE BREATHER

CRANKCASE BREATHER TUBE

Clean the crankcase breather tube at the intervals recommended in the Maintenance Schedule.

To clean the crankcase breather tube, remove both rocker covers (Figure 9-9). The breather tube itself is installed with a sealant on the threads to prevent oil leakage into the intake manifold; it should NOT be removed. A small wire, nail or drill bit inserted through from the top can be used to clean out the breather hole. The breather hole seldom needs cleaning. A 500 hour interval coincides with the valve lash adjustments, because the rocker box covers must also be removed at that time.




FIGURE 9-9. CLEANING BREATHER

TORSIONAL WASHERS

Four torsional washer assemblies are bolted inside the flywheel pulley hub (Figure 9-10). When functioning properly, they react to relieve torsion

stresses on the crankshaft. Inspect the assemblies periodically for movement of washers and freedom from corrosion (1500 hours commercial, yearly non-commercial). If condition is questionable, contact an Onan service center or distributor.




FIGURE 9-10. TORSION WASHER ASSEMBLY

OUT-OF-SERVICE PROTECTION

The inherent lubricating qualities of No. 2 diesel fuel normally should protect the cylinders of a diesel engine for at least 30 days when the unit is not in service. To protect an engine that will be out of service for more than 30 days, proceed as follows:

1. Exercise the generator set as described in the *Operation* section until the engine is up to operating temperature.
2. Shut down the engine. Disconnect battery and store in a cool, dry place. Connect battery to a charger every 30 days to maintain it at full charge.
3. Drain the oil base while it is still warm. Refill and attach a warning tag indicating the viscosity of oil used.
4. Service the air cleaner.
5. Clean throttle and governor linkage and protect by wrapping with a clean cloth.
6. Plug the intake and exhaust outlets to prevent entrance of moisture, bugs, dirt, etc.
7. Clean and wipe the entire unit. Coat parts susceptible to rust with a light coat of grease or oil.
8. Provide a suitable cover for the entire unit after unit has cooled down.

RETURNING A UNIT TO SERVICE

1. Remove the cover and all protective wrapping. Remove the plug from the intake and exhaust outlet.
2. Check the warning tag on the oil base and verify that the oil viscosity is still correct for the existing ambient temperature.
3. Clean cooling fin areas.
4. Clean and check the battery. Measure the specific gravity (1.260 at 80° F [27° C]) and verify that the level is at the split ring. If the specific gravity is low, charge until the correct value is obtained. If the level is low, add distilled water and charge until the specific gravity is correct. **DO NOT OVERCHARGE.**

⚠ WARNING *Ignition of explosive battery gases can cause severe personal injury. Do not smoke or allow any ignition source while servicing batteries.*

5. Connect the starting battery (ground terminal last).
6. Prime the fuel system.
7. Remove all loads before starting the engine.
8. Start engine and observe oil pressure gauge and charge rate ammeter.
After engine has started, excessive blue smoke will be exhausted until the rust inhibitor or oil has burned away.
9. After start, apply load to at least 50 percent of rated capacity.
10. Unit is ready for service and load may be applied.

2

Refer to the Maintenance Schedule in Section 8 for the time interval between maintenance procedures. Record the name and address of your Onan service center and keep all of your service receipts.

[illegible]

1



Onan Corporation
1400 73rd Avenue N.E.
Minneapolis, MN 55432
Telex: 275477
Fax: 612-574-8087

Onan is a registered trademark of Onan Corporation
Cummins is a registered trademark of Cummins Engine Company