


The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.

Onan

**Parts
Catalog**
JC Series
GenSet



Onan Service Parts

967-0220
9-89 (Spec A-AB)
Replaces 8-84 (Spec A-AB)
Printed in U.S.A.

SAFETY PRECAUTIONS

The following symbols are used in Onan manuals to alert users to the potentially dangerous conditions relating to maintenance of the equipment and replacement parts. Please read and observe.

⚠ DANGER *This symbol warns of immediate hazards which will result in severe personal injury or death.*

⚠ WARNING *This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.*

⚠ CAUTION *This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.*

MODEL IDENTIFICATION

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO., and SERIAL NO. from the Onan nameplate.

For handy reference, insert your nameplate information in the spaces below:

MODEL AND SPEC NO.

SERIAL NO.

PRODUCT SAFETY PRECAUTIONS

⚠ WARNING

Contact with USED ENGINE OILS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking or changing engine oils take all necessary precautions not to ingest, breathe the fumes or contact the used oil.

⚠ WARNING

Contact with ASBESTOS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When handling engine gaskets take all necessary precautions not to ingest, breathe or contact the dust from the gaskets! Use adequate ventilation and wear protective gloves, masks and clothing!

⚠ WARNING

Contact with BENZINE and LEAD, found in gasoline, fuel additives and solvents has been identified by a United States federal agency and some USA agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking, draining or adding gasoline and fuel additives, or using solvents take all necessary precautions not to ingest, breathe the fumes, or contact the liquids. Use adequate ventilation and wear protective gloves, masks and clothing.

Supplement: 967-2003
Date: 10-94
Insert With-
Title: "J" Series Gas/Gasoline Parts Catalog
Spec Advance
Number: As Listed Below

This Supplementary Parts List Spec advances specific "J" series gas/gasoline generator sets as shown:

"J" Series Models	New Spec Advance Letter	Catalog Number
JB Generator Spec AD to	E	967-0223
JC Generator Spec AB to	C	967-0220


(The former JC model letter designation is now being changed to new model letter designations beginning with the Spec advance to letter C as shown above. Model JCA is a 12.5 kW, 60 hertz version and model JCB is a 12.5 kW, 50 hertz or a 15.0 kW, 60 hertz version.)

Note that these models are being Spec advanced to a single letter due to limited computer space. Models JB and JC were first manufactured in the early 1960's beginning with the single Spec letter A. The Spec letters advanced through the alphabet (A to B, B to C.....Z to AA, AA to AB, etc.) due to manufacturing changes and are now advanced to a single Spec letter as shown in the middle column above. Use caution when ordering service replacement parts for these models. Do not confuse 1994 single letter production models with 1960's single letter production models. Example: When the parts catalog lists three part number choices based on Spec letter differences such as "Spec A through H", "Spec J through S" and "Begin Spec T", use the "Spec A through H" part number for 1960's single Spec letter production and the "Begin Spec T" part number for 1994 single Spec letter production. The following may also be used as a guide: The 1960's production generator set nameplates used a number(s) and letter(s) combination (i.e.: 3CR, 4R, 18R, 53CR, 57XR, 518R, etc.) for the voltage code and is shown near the center of the complete model and Specification number (i.e.: 7.5JB-9XR/8066E). With the 1994 production generator set nameplates the voltage code is no longer used (i.e.: 7.5JB8066E). When in doubt, obtain the complete model and serial number and consult the factory.

This "J" series gas/gasoline supplement covers the change for the "J" series product line standardization program. Some low usage feature options were made obsolete and some high usage features were made standard. The following pages reflect these changes. Of special note, this supplement lists two field replacement carburetor kits that are suitable for all known JB and JC engines and generator sets. Although not part of this supplemental spec advance, these kits also apply to model RJC Spec A through AC generator sets. Carburetor kit 141-0970, as shown on page 4, is the replacement for all straight gas carburetors now in the field. This kit contains the new standardized carburetor without the autochoke plus instructions, gaskets, fittings and components to disable the choke plate for straight gas usage (a choke shaft and plate are still part of the new carburetor). Carburetor kit 141-0967, as shown on page 5, is the replacement for all straight gasoline or dual gas/gasoline carburetors now in the field. This kit contains the new standardized complete autochoke carburetor, instructions, gaskets, fittings and other applicable components.

In addition, the generator page for each catalog has an expanded parts list for the generator and rotor through studs that were not completely covered in prior issues of the parts catalogs.


Air Cleaner Heavy Duty



140-2929

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	140-0584	1	Gasket	12	862-0015	4	Nut, Hex (5/16-18)
2	140-0740	1	Tube, Air Intake	13	850-0045	4	Washer, Lock - Spring (5/16")
3	140-0645	1	Adapter, Air Cleaner	14	503-0330	1	Hose, Connector
4	140-0721	1	Cleaner Assembly, Air (Includes Element and Baffle)	15	526-0018	1	Washer, Flat (1/4")
5	140-0765	1	Element	16	800-0007	1	Screw, Cap - Hex Head (1/4-20 x 1")
6	140-1267	1	Baffle	17	800-0015	1	Screw, Cap - Hex Head (1/4-20 x 3")
7	140-0722	2	Band, Air Cleaner Mounting	18	850-0040	1	Washer, Lock - Spring (1/4")
8	503-0365	4	Clamp, Hose	19	140-0723	1	Pre-Cleaner, Air Cleaner
9	503-0419	1	Elbow, Rubber - Moulded				
10	140-1271	1	Bracket, Mounting				
11	800-0024	4	Screw, Cap - Hex Head (5/16-18 x 1-1/2")				

High Air Temperature Switch




309-0644

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	309-0195	1	Bracket, Mounting
2	309-0206	1	Switch, High Air Temperature (S5)
3	508-0127	1	Insulator, Sleeving
4	332-0876	1	Terminal, Ground


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
5	856-0006	1	Washer, Lock - EIT (1/4")
6	526-0021	1	Washer, Flat (1/4")
7	508-0126	4	Washer, Insulating
8	862-0001	1	Nut, Hex (1/4-20)
9	338-3197	1	Harness, Wiring - Switch (46")

Replacement Carburetor Kit
Straight Gaseous Fueled Generator Sets
JB Generators Spec A Through AD
JC Generators Spec A Through AB




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	141-0970	1	Kit, Carburetor - Replacement - Gaseous Fuel (Includes Instruction Sheet and All Parts Listed Below)	5	517-0273	1	Plug, Pipe
2	141-0961	1	Carburetor, Gaseous Fuel (See Separate Page For Components)	6	517-0313	1	Cap, Inlet - Gas Fuel
3	517-0317	1	Cap, Vacuum Tube	7	503-1445-04	1	Clamp
4	502-0065	1	Elbow, Pipe - Brass (45 Deg)	8	154-0733	1	Gasket, Intake Manifold
				9	141-0281	1	Gasket, Carburetor Flange
				10	140-0921	1	Gasket, Carburetor Air Horn
				11	143-0231	1	Spring, Choke Lock
				12	524-0723-01	1	Tube, Repair - Zinc Plating (1/16 Fluid Oz)

Replacement Carburetor Kit
Straight Gasoline or Dual Gas/Gasoline Fueled Generator Sets
JB Generators Spec A Through AD
JC Generators Spec A Through AB



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	141-0967	1	Kit, Carburetor - Replacement - Straight Gasoline or Dual Gas/Gasoline Fuel (Includes Instruction Sheet and All Parts Listed Below)	6	503-1445-04	1	Clamp
2	141-0962-07	1	Carburetor, Straight Gasoline or Dual Gas/Gasoline Fuel (See Separate Page For Components)	7	226-4627	1	Lead (5")
3	502-0065	1	Elbow, Pipe - Brass (45 Deg)	8	154-0733	1	Gasket, Intake Manifold
4	517-0273	1	Plug, Pipe	9	141-0281	1	Gasket, Carburetor Flange
5	517-0313	1	Cap, Inlet - Gas Fuel	10	140-0921	1	Gasket, Carburetor Air Horn
				11	143-0231	1	Spring, Choke Lock
				12	153-0680	1	Cover, Insulator - Used on JB Vacu-Flo Cooled Gas/Gasoline Fueled Generator Sets
				13	524-0723-01	1	Tube, Repair - Zinc Plating (1/16 Fluid Oz)


Carburetor Components **141-0962-07**



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	141-0961	1	Carburetor, Replacement - Straight Gasoline or Dual Gas/ Gasoline Fuel (See Separate Page For Components)	10		1	*Lever, Choke
2	153-0667-02	1	Bracket, Choke	11		1	*Spring, Return - Choke Arm
3	815-0340	2	Screw, Self-Locking - Hex Washer Head - Thread Forming (#10-32 x 3/8")	12		1	*Collar, Choke (Plastic)
4	815-0844	5	Screw, Pan Head - Cross Recessed - Thread Forming (#8-32 x 3/8")	13		1	*Ring, Clamp
5	815-0845	1	Screw, Pan Head - Cross Recessed - Thread Forming (#6-32 x 3/8")	14		1	*Arm, Bimetal
6	153-0668-02	1	Lever, Choke	15		1	*Lever, Bimetal
7	153-0672	1	Bushing, Shaft	16		3	*Washer, Link
8	153-0677	1	Package, Choke Parts (Includes Parts Marked *)	17		1	*Clip, "E"
9		2	*Screw, Set - Lever	18		1	*Pin, Cotter
				19		1	*Rod, Choke
				20		1	*Hose, Vacuum
				21	153-0684	1	Diaphragm, Pulloff
				22	153-0670	2	Washer, Thrust
				23	153-0676	1	Cover, Bimetal
				24	146-0639	1	Backplate
				25	153-0685	1	Gasket, Bimetal

* - Parts Included in 153-0677 Choke Parts Package

Carburetor Components
141-0961
JB Generators Begin Spec E
JCA, JCB Generators Begin Spec C




141-0961/0720

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	141-0747	1	Package, Repair (Includes Parts Marked *)
2	141-0748	1	Kit, Gasket (Includes Parts Marked #)
3	141-0698	4	Screw and Washer - Choke and Throttle Plate Mounting
4	141-0793	1	Plate, Throttle
5	141-0713	1	Needle, Idle Adjusting - Gas Fuel
6	141-0710	1	Spring, Idle Needle - Gas Fuel
7	141-0830	1	*Seat Assembly - Fuel Valve
8	145-0693	1	Tube, Vacuum
9	141-0703	1	*Shaft, Float
10	141-0702	1	Float
11	141-0701	1	*#Gasket - Bowl to Body
12	141-0700	1	Screw, Throttle Stop
13	141-0711	1	Spring, Throttle Stop
14	141-0713	1	Needle, Idle Adjusting - Gasoline Fuel

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
15	141-0710	1	Spring, Idle Needle - Gasoline Fuel
16	141-0077	1	*#Washer, Main Jet Assembly
17	141-0942	1	Jet Assembly, Main (Adjustable)
18	141-0963	1	Shaft, Choke
19	141-0969	1	Shaft, Throttle
20	141-0733	1	Spring, Main Gas Needle
21	141-0734	1	Needle, Main Gas Adjusting
22	141-0799	1	*Spring, Float
23			Gasket
	141-0281	1	# Carburetor Mounting
	154-0733	1	*# Intake Manifold
24	141-0708	1	Bowl, Fuel
25	141-0965	1	Plate, Choke

* - Parts Included in 141-0747 Repair Package
- Parts Included in 141-0748 Gasket Kit

**Governor Linkage
JCA, JCB Generators Begin Spec C**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	150-2505	1	Linkage Assembly, Governor (Includes Parts Marked *)
1	150-2501	1	*Rod, Governor Control
2	870-0053	2	*Nut, Hex (#10-32)
3	150-1081	2	*Joint, Ball

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
4	870-0131	2	Nut, Hex - W/ET (#10-32)

* - Parts Included in 150-2505 Governor Linkage Assembly

Vacuum Switch




179-2711

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0367	1	Switch, Vacuum (Includes Mounting Nut and Terminals) (S9)
2	502-0313-01	1	Elbow - 90 Deg (1/8" Pipe to 3/16" Hose)
3	153-0677-12	1	Hose, Vacuum
4	815-0844	1	Screw, Pan Head - Cross Recessed (#8-32 x 3/8")

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
5	815-0340	4	Screw, Self-Locking - Hex Washer Head - Thread Forming (#10-32 x 3/8")
6	153-0667-02	1	Bracket, Mounting - Choke
7	148-1011-02	1	Bracket, Mounting - Switch

Exhaust




155-2838

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-2355-13	1	Tube, Exhaust (18")
2	505-0036	1	Coupling, Reducer - Pipe (1-1/2" to 1-1/4")

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
3	505-0177	1	Nipple, Close - Pipe (1-1/2")
4	505-0032	1	Coupling, Pipe (1-1/2")


Vacu-Flo Cooling



134-5058

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	134-1436	1	Scroll, Blower	6	812-0076	2	Screw, Machine - Round Head (#8-32 x 5/16")
2	895-0098	-	Stripping, Seal - Bulk (3/8" Wide x 5/16" Thk) (Order by the foot - 4 feet required)	7	870-0221	2	Nut, Hex - W/ET (#8-32)
3	134-3081	1	Guard, Scroll Outlet	8	508-0002	1	Grommet (Fits 1/2" Hole)
4	815-0421	4	Screw, Sheet Metal - Hex Head W/ET (#10-16 x 1/2")	9	338-3197	1	Harness, Wiring - Switch (2 Wire, 44")
5	309-0171	1	Switch, High Air Temperature (S5)				


Resistor Generator Air Outlet



304-0824

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	232-2399	1	Bracket, Resistor Mounting	7	856-0003	1	Washer, Lock - EIT (#10)
2	304-0500	1	Resistor, Tapped - Adjustable (2 Ohm, 150 Watt)	8	871-0010	1	Nut, Hex - Brass (#10-32)
3	800-0004	2	Screw, Cap - Hex Head (1/4-20 x 5/8")	9	812-0169	1	Screw, Machine - Round Head (1/4-20 x 5-1/2")
4	850-0040	2	Washer, Lock - Spring (1/4")	10	853-0013	1	Washer, Lock - ET (1/4")
5	304-0006	2	Washer, Centering	11	357-0067	1	Rectifier (6 Amp, 400 Volt)
6	811-0098	1	Screw, Machine - Round Head (Brass) (#10-32 x 3/8")				


Generator Begin Spec AA



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Stud, Generator Through (3/8" Diameter) JB
	520-0795	4	8-1/4" Long
	520-0796	4	8-13/16" Long
			JC, JCA, JCB
	520-0797	4	9-15/16" Long
	520-0798	4	10-5/8" Long
	520-0799	4	11-3/8" Long
	520-0800	4	12-5/8" Long

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
2			Stud, Rotor Through (7/16" Diameter) JB
	520-0787	1	14-1/8" Long
	520-0788	1	14-11/16" Long
			JC, JCA, JCB
	520-0789	1	15-9/16" Long
	520-0790	1	16-1/4" Long
	520-0791	1	17" Long
	520-0792	1	18-1/4" Long

Control



612-6640/6642

Control

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Panel, Control	27	323-1624	1	*#Wedge, Connector (Used in P1)
	319-2035-03	1	Without Indicator Lights	28	357-0030	1	*#Rectifier (6 Amp) (CR12)
	319-2035-04	1	With Indicator Lights	29	332-0604	1	*#Block, Terminal (5 Place) (TB11)
2	307-0845	1	Relay, Solenoid - Start (K11)	30	332-0706	1	#&Block, Terminal (8 Place) (TB13)
3			Breaker, Circuit	31	305-0880	1	#&Rectifier, Bridge - 20 Amp (CR7)
	320-1706-14	1	Without Indicator Lights (CB4)	32	332-1043	1	#Jumper - Terminal Block (Sets With Indicator Lights)
	320-1824-02	3	With Indicator Lights (CB4,5,6)	33	301-1962	1	Box, Control
4			Light, Indicator	34	332-3223	1	&Strip, Marker
	322-0108	1	Low Oil Pressure (DS4)	35	812-0065	2	&Screw, Machine - Round Head (#6-32 x 5/8")
	322-0109	1	High Engine Temp (DS5)	36	332-0052	1	Clip, Wire
	322-0111	1	Overspeed (DS6)	37	508-0001	1	Grommet
5	302-0885	1	Meter, Time Totalizing (M12)	38			Harness, Wiring - Engine to Control (Includes Parts Marked @)
6	302-0446	1	Ammeter, DC (M21)		338-2945	1	JB
7	321-0175	1	Holder, Fuse		338-2944	1	JCA, JCB
8	321-0146	1	Fuse - 10 Amp (F1)	39	871-0010	4	Nut, Hex - Brass (#10-32)
9	332-0616	1	Strip, Marker	40	850-0030	2	Washer, Lock - Spring (#10)
10	309-0270	1	&Thermostat (S8)	41	526-0049	4	Washer, Flat (#10)
11	518-0049	2	&Screw, Machine - Round Head W/ET (#8-32 x 1/4")	42	821-0040	8	Screw, Self-Locking - Hex Washer Head (#10-32 x 5/16")
12	821-0004	4	Screw, Self-Locking - Hex Washer Head (#10-32 x 5/16")	43	301-0856	1	Cover, Output Box
13	821-0008	1	Screw, Self-Locking - Hex Washer Head (1/4-20 x 5/16")	44	301-3683	1	Saddle, Control Mounting
14	815-0544	2	&Screw, Machine - Round Head - Cross Recessed W/IT (#6-32 x 1/2")	45	301-3682	1	Box, Output
15	815-0385	2	Screw, Machine - Round Head (#6-32 x 1/2")	46	402-0070	4	Dampner, Vibration
16			Nut, Hex - W/ET (#6-32)	47	337-0036	1	Strap, Ground
	870-0183	3	Sets Without Indicator Lights	48	856-0008	8	Washer, Lock - EIT (5/16")
	870-0183	5	Sets With Indicator Lights	49	815-0236	7	Screw, Hex Head - Thread Forming (5/16-18 x 5/8")
17	815-0550	2	&Screw, Pan Head - Cross Recessed W/ET (#6-32 x 3/8")	50	821-0014	8	Screw, Self-Locking - Hex Washer Head (5/16-18 x 1/2")
18	815-0539	2	Screw, Machine - Round Head - Cross Recessed W/IT (#8-32 x 5/8")	51	508-0183	1	Grommet
19	810-0153	1	Screw, Machine - Round Head - Brass (1/4-20 x 1")	52	357-0030	1	@Rectifier (6 Amp) (CR1) (Used on 338-2945 Engine Wiring Harness)
20	856-0006	3	Washer, Lock - W/EIT (1/4")	53	323-1491	6	@ Pin, Contact (Used in J1)
21	871-0016	2	Nut, Hex - Brass (1/4-20)	54	323-1626	1	@Wedge, Connector (Used in J1)
22			Harness, Wiring - Control	55	323-1625	1	@Connector, Receptacle (J1)
	338-2921-01	1	Sets Without Indicator Lights (Includes Parts Marked *)	56	812-0065	1	Screw, Machine - Round Head (#6-32 x 5/8")
	338-2922-01	1	Sets With Indicator Lights (Includes Parts Marked #)	57	517-0132	1	Plug, Hole
23	323-1492	6	*#Socket, Contact (Used in P1)				
24			Switch, Toggle (S11)				
	308-0345	1	* Start/Stop (Sets Without Indicator Lights)				
	308-0329	1	# Start/Stop/Test (Sets With Indicator Lights)				
25			Relay				
	307-2817-01	3	*# K12, K14, K15 (Mounted on right side facing panel front)				
	307-2594	1	# K17 (Sets With Indicator Lights) (Mounted on left side facing panel front)				
26	323-1623	1	*#Connector, Plug (6 Place) (P1)				


& - Parts Used on Sets With Indicator Lights

* - Parts Included in 338-2921-01 Control Wiring Harness

- Parts Included in 338-2922-01 Control Wiring Harness

@ - Parts Included in 338-2945 and 338-2944 Engine to Control Wiring Harnesses

AC Meter Panel



612-6638

AC Meter Panel

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Ammeter, AC (Quantity Used: 2 for Sets With 2-Pole Breakers, 3 for Sets With 3-Pole Breakers) (M3,M4 - Sets With 2-Pole Breakers, M2,M3,M4 - Sets With 3-Pole Breakers)	3			Meter, Time Totalizing (M1 - Sets With 2-Pole Breakers, M5 - Sets With 3-Pole Breakers)
	302-0460	1	Scale Reads 0-20		302-0468	1	Sets With 2-Pole Breakers 50 Hertz
	302-0418	1	Scale Reads 0-30		302-0465	1	60 Hertz
	302-0444	1	Scale Reads 0-35				Sets With 3-Pole Breakers 50 Hertz
	302-0419	1	Scale Reads 0-50		302-0468	1	Under 300 Volts AC
	302-0458	1	Scale Reads 0-80		302-0469	1	Over 300 Volts AC
2			Breaker, Circuit (CB1)				60 Hertz
			Two Pole Breakers		302-0465	1	Under 300 Volts AC
			50 Hertz		302-0466	1	Over 300 Volts AC
	320-1841-02	1	15 Amp	4			Meter, Frequency (M5 for Sets With 2-Pole Breakers, M6 for Sets With 3-Pole Breakers)
	320-1841-03	1	20 Amp		302-1338	1	Sets With 2-Pole Breakers
	320-1841-04	1	25 Amp				Sets With 3-Pole Breakers
	320-1841-05	1	30 Amp		302-1338	1	Under 300 Volts AC
	320-1841-08	1	45 Amp		302-1340	1	Over 300 Volts AC
	320-1841-12	1	65 Amp				Voltmeter, AC (M2 for Sets With 2-Pole Breakers, M1 for Sets With 3-Pole Breakers)
			60 Hertz	5			Scale Reads 0-300
	320-1841-03	1	20 Amp		302-0421	1	Scale Reads 0-500
	320-1841-04	1	25 Amp		302-0612	1	
	320-1841-05	1	30 Amp	6	303-0076	1	Knob, Rotary Switch
	320-1841-06	1	35 Amp	7	308-1021-02	1	Switch, Rotary (S1)
	320-1841-07	1	40 Amp	8			Panel, Meter
	320-1841-09	1	50 Amp		301-2288	1	Sets With 2-Pole Breakers
	320-1841-11	1	60 Amp		319-2233-02	1	Sets With 3-Pole Breakers
	320-1841-13	1	70 Amp				Nut, Hex - W/ET (#4-40)
			Three Pole Breakers	9			Sets With 2-Pole Breakers
			50 Hertz		870-1220	15	Sets With 3-Pole Breakers
			Under 300 Volts AC		870-1220	18	Sets With 3-Pole Breakers
	320-1827-03	1	20 Amp	10	870-0221	5	Nut, Hex - W/ET (#8-32)
	320-1827-04	1	25 Amp	11			Washer, Lock - Spring (#6)
	320-1827-06	1	35 Amp		850-0020	4	Sets With 2-Pole Breakers
	320-1827-07	1	40 Amp		850-0020	6	Sets With 3-Pole Breakers
	320-1827-09	1	50 Amp	12	812-0076	5	Screw, Maching - Round Head (#8-32 x 5/16")
	320-1827-10	1	55 Amp				Screw, Machine - Round Head (#6-32 x 3/8")
			Over 300 Volts AC	13			Sets With 2-Pole Breakers
	320-1827-01	1	10 Amp		812-0061	4	Sets With 3-Pole Breakers
	320-1827-02	1	15 Amp	14			Plug, Hole
	320-1827-03	1	20 Amp		517-0131	1	Fits 3/8" Hole
	320-1827-04	1	25 Amp		517-0132	1	Fits 7/16" Hole
	320-1827-05	1	30 Amp	15	322-0004	2	Bulb, Panel Light (DS1, DS2)
	320-1827-08	1	45 Amp	16	322-0072	2	Socket, Panel Light
	320-1827-09	1	50 Amp	17			Switch, Toggle
	320-1827-11	1	60 Amp		308-0002	1	Panel Light (S1)
			Over 300 Volts AC		308-0154	1	Start/Stop (S2)
	320-1827-02	1	15 Amp	18			Harness, Wiring - Remote Control to Output Box (4 Wire, 36") (W1)
	320-1827-03	1	20 Amp		338-0495	1	Control to Start/Stop Switch (3 Wire, 50") (W2)
	320-1827-04	1	25 Amp		338-0305	1	
	320-1827-05	1	30 Amp				
	320-1827-06	1	35 Amp				

INDEX

INTRODUCTION	2
GENERATOR SET DATA TABLE	2, 2A
STANDARD PARTS SECTION	
Base, Oil	12
Block, Cylinder	4
Camshaft	6
Carburetor Parts	18
Spec A Through Q	19
Begin Spec R	20
Choke	38
Control	7
Crankshaft	27
Distributor Parts	32
Exciter, Generator - Spec A Through Z	21
Exhaust System	7
Flywheel	16
Fuel System (Gasoline)	13
Gearcase	30
Generator	36
Spec A Through Z	14
Begin Spec AA	8
Governor	15
Head, Cylinder	28
Heater, Carburetor Air - Begin Spec P (Gasoline Sets)	22
Housing, Air	10
Ignition System	3
Oil System	40
Piston and Rod	41
Regulator, Voltage - Begin Spec AA	24
Service Kits and Miscellaneous	25
Starter	44
Starter Parts	44
SPECIAL PARTS SECTION - Pennsylvania Approved Sets	
Base, Oil - Begin Spec K	42
Control - Spec A through Z	42
Crankshaft - Spec A Through Q	44
Flywheel - Spec A Through Q	42
Fuel System (Gas, Gas-Gasoline and LPG)	42
Gearcase - Spec A Through Q	42
Starter - Spec A Through Q	43
Starter Parts - Spec A Through Q	47
OPTIONAL PARTS SECTION	
Cleaner, Air	46
Contractor	64
Oil Bath	53
Control, Switchboard (Unhoused Sets)	55
Cooling, Vacu-Flo	56
Duct, Air	61
Duct and Shutter, Air (Housed Sets)	50
Filter, Voltage Regulator	51
Fuel System (Gas, Gas-Gasoline and LPG)	60
Fuel System (LPG and Natural Gas)	58
Heater, Carburetor Air - Spec A through N (Gasoline Sets)	66
Housing and Skid Base	66
Miscellaneous Optional Parts	
Filter Oil (Heavy Duty)	66
Heater	66
Generator Space - Begin Spec AA	66
Oil Base	66
Muffler, Critical (Housed Sets)	66
Switch	66
Low Oil Pressure	66
Overspeed	66
Vacuum - Begin Spec B (Gas and Gas-Gasoline Sets)	66
Thermostat, Low Engine Temperature	62
Panel, AC Meter (Housed Sets)	60
Skid and Battery Rack	52
Switch, High Air Temperature	48
Tank	49
Day	
Fuel (Housed Sets)	

Introduction

This catalog applies to the standard JC Generator Sets as listed in the Generator Set Data Table. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Unless otherwise mentioned in the description or page heading, parts are interchangeable between models. Parts illustrations are typical. Using the model and specification number from your generator set nameplate, select parts that apply to your set. Left and right sides are determined by facing the engine end (front) of the set.

Generator Set Data Table

MODEL AND SPECIFICATION	ELECTRICAL DATA				
	WATTS	VOLTS	HERTZ	WIRE	PHASE
10.0JC-3CR/*	10,000	120/240	60	**	1
10.0JC-4R/*	10,000	120/208	60	4	3
10.0JC-4XR/*	10,000	277/480	60	4	3
10.0JC-5DR/*	10,000	120/240	60	4	3
12.5JC-3CR/*	12,500	120/240	60	**	1
12.5JCJ#	12,500	120/240	60	**	1
12.5JC-3R/*	12,500	120/240	60	3	1
12.5JCB#	12,500	120/240	60	3	1
12.5JC-4R/*	12,500	120/208	60	4	3
12.5JCC#	12,500	120/208	60	4	3
12.5JC-4XR/*	12,500	277/480	60	4	3
12.5JCG#	12,500	277/480	60	4	3
12.5JC-5DR/*	12,500	120/240	60	4	3
12.5JCD#	12,500	120/240	60	4	3
12.5JC-9XR/*	12,500	347/600	60	4	3
12.5JCH#	12,500	347/600	60	4	3
12.5JC-18R/*	12,500	@	60	12	3
12.5JCL#	12,500	@	60	12	3
12.5JC-53CR/*	12,500	120/240	50	**	1
12.5JC-53R/*	12,500	120/240	50	3	1
12.5JC-55DR/*	12,500	120/240	50	4	3
12.5JC-57R/*	12,500	220/380	50	4	3
12.5JC-57XR/*	12,500	240/416	50	4	3
12.5JC-518R/*	12,500	@	50	12	3
12.5JCZ#	12,500	@	50	12	3
15.0JC-1R/	15,000	120	60	3	1
15.0JC-3CR/*	15,000	120/240	60	**	1
15.0JCJ#	15,000	120/240	60	**	1
15.0JC-3R/*	15,000	120/240	60	3	1
15.0JCB#	15,000	120/240	60	3	1
15.0JC-4R/*	15,000	120/208	60	4	3
15.0JCC#	15,000	120/208	60	4	3
15.0JC-4XR/*	15,000	277/480	60	4	3
15.0JC-5DR/*	15,000	120/240	60	4	3
15.0JCD#	15,000	120/240	60	4	3
15.0JC-9XR/*	15,000	347/600	60	4	3
15.0JCH#	15,000	347/600	60	4	3
15.0JC-18R/*	15,000	@	60	12	3
15.0JCL#	15,000	@	60	12	3
10JC-53R17/*†	10,000	120/240	50	**	1
12JC-3R17/*†	12,500	120/240	60	**	1
(These are X-ray models and are identified by the number 17 in the model.)					
PENNSYLVANIA APPROVED SETS	These sets are recognized by the numbers 30 (Gasoline Fuel), 31 (Gaseous Fuel), or 131 (Liquified Petroleum Fuel) appearing in the model just before the diagonal line (/). (Example: 15.0JC-18R31/1AA). For replacement parts, refer first to the Special Parts Section for Pennsylvania Approved Generator Sets. Parts not in that section refer to the Standard Parts Section. When referring to the Standard Parts Section reference to Specification Letter and Voltage also applies to these sets.				

NOTE: Prior to 1969 production, a V was used in the model to designate sets with Vacu-Flo cooling and the C designation (3CR, 53CR, etc.) was not used in the models. Also, the model designation did not use a decimal in the KW rating (EXAMPLE: 12.5JC was formerly 12JC (12-1/2 KW) and 15.0JC was formerly 15JC).

****** - These generators have four load wires which are reconnectible for 120 volt, 2 wire service or 240 volt, 2 wire service or 120/240 volt, 3 wire service.

@ - Broad range reconnectible sets, refer to connection diagram inside outlet box cover.

***** - Spec A through May, 1988 Spec AB production, the diagonal line (/) in the model and specification number separates generator set characteristics from the specification number and letter(s). The specification number denotes customer requested options or deviations from a standard (1A, 1B...1AA,1AB) model. The specification letter advances (A to B, B to C...Z to AA, AA to AB) with major manufacturing changes.

- Beginning with April, 1988 JC generator production during Spec AB, the complete model identifying characters changed. The dash (-), the diagonal line (/) and the first letter (A) of the double letter following the specification number are no longer used. Also, a letter is now used in the model to indicate the voltage code and replaces the corresponding number(s) and letter(s) designation as listed in the Generator Set Data Table (EXAMPLE: Code 3CR is now J; Code 4R is now C). Listed below are Spec AB samples of two variations of the identical generator set showing the change in model identifying characters:


12.5JC-3CR/12927AB ... Used prior to April, 1988 production - number and letters (3CR) are used for voltage code. Order Spec AB service parts as shown in this catalog.

12.5JCJ12927B Used beginning with April, 1988 production - the dash, diagonal line and the letter A are no longer used. In this sample, a letter (J) is used for the voltage code. To order service parts, add the letter A between the specification number and letter making it Spec AB and order service parts as shown in this catalog.

STANDARD PARTS SECTION


This section contains standard parts applicable to models listed in the generator set data table.

PISTON AND ROD



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	RING SET, PISTON		
	113-0107	4	Standard
	113-0107-10	4	.010" Oversize
	113-0107-20	4	.020" Oversize
	113-0107-30	4	.030" Oversize
	PISTON KIT (Includes Pin and Retaining Rings)		
2	Gasoline, Gas-Gasoline, LPG and Standard Natural Gas Sets		
	112-0172	4	Standard
	112-0172-10	4	.010" Oversize
	112-0172-20	4	.020" Oversize
	112-0172-30	4	.030" Oversize
3	Natural Gas Sets With High Compression Pistons		
	112-0174	4	Standard
	112-0174-10	4	.010" Oversize
	112-0174-20	4	.020" Oversize
	112-0174-30	4	.030" Oversize
4	112-0085	8	Ring, Retaining
5	114-0163	4	Rod Assembly, Connecting
6	BEARING HALF, CONNECTING ROD		
	114-0164	8	Standard
	114-0164-02	8	.002" Undersize
	114-0164-10	8	.010" Undersize
	114-0164-20	8	.020" Undersize
	114-0164-30	8	.030" Undersize
7	114-0170	8	Bushing Half, Piston Pin - Connecting Rod
8	805-0012	8	Bolt, Place (Special)
9	112-0086	4	Pin, Piston

CYLINDER BLOCK




CYLINDER BLOCK

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	110-1328	1	Block Assembly, Cylinder (Includes Tappets and Parts Marked *)
2	101-0337	1	*Plate, Rear Bearing
3	101-0386	1	*Gasket and Shim Kit, Rear Bearing Plate - Kit Includes Bearing Plate Mounting Washers
4	BEARING, MAIN - FRONT AND REAR		
	101-0359	2	*Standard
	101-0359-02	2	.002" Undersize
	101-0359-10	2	.010" Undersize
	101-0359-20	2	.020" Undersize
	101-0359-30	2	.030" Undersize
5	516-0072	4	*Screw, Drive - Crankshaft Thrust Washers
6	104-0420	2	*Washer, Crankshaft Thrust
7	101-0363	1	*Bearing, Camshaft - Front
8	101-0365	1	*Bearing, Camshaft - Rear
9	*TUBE, CRANKCASE OIL		
	120-0586	1	Front
	120-0585	1	Rear
10	517-0053	1	*Plug, Expansion - Rear Camshaft Opening
11	123-1168	1	*Cap, Breather - Begin Spec T
12	509-0086	1	Seal, Crankshaft - Rear
13	805-0019	6	*Bolt, Rear Bearing Plate (Special)
14	123-0649	1	Tube, Oil Fill

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
15	123-0667	1	Gasket, Oil Fill
16	123-0698	1	Cap & Indicator
17	123-0191	1	Gasket, Cap
18	CAP, BREATHER TUBE		
	123-0458	1	Spec A through H
	123-0787	1	Spec J through S
19	123-0645	1	*Tube, Breather - Spec A through S
20	850-0045	2	Washer, Lock - Spring (5/16")
21	123-0865	1	Filter, Breather Tube - Spec A through S
22	800-0026	2	Screw, Cap - Hex Head (5/16-18 x 3/4")
23	526-0035	2	*Washer, Flat (17/32 ID x 7/8 OD x 1/8" Thk)
24	526-0245	6	Washer, Flat (.391 ID x .625 OD x .010 Thk)
25	BEARING HALF, MAIN - CENTER		
	101-0361	2	*Standard
	101-0361-02	2	.002" Undersize
	101-0361-10	2	.010" Undersize
	101-0361-20	2	.020" Undersize
	101-0361-30	2	.030" Undersize
26	101-0342	2	*Bolt, Center Bearing Housing
27	516-0141	2	*Pin, Gearcase Locating
28	516-0149	2	*Pin, Center Bearing Housing
29	101-0364	1	*Bearing, Camshaft - Center

* - Parts Included in 110-1328 Cylinder Block Assembly.

CAMSHAFT




C-1029-1

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	CAMSHAFT (Includes Center Pin)		
	105-0240	1	Spec A through N
	105-0275	1	Begin Spec P
2	515-0001	2	Key, Camshaft Gear and Distributor Drive Gear
3	150-0075	1	Pin, Center
4	105-0205	1	Washer, Thrust
5	105-0218	1	Gear Assembly, Camshaft - Begin Spec B (Includes Parts Marked *)
6	FLYBALL, GOVERNOR		
	510-0046	12	Spec A
	510-0046	10	Begin Spec B
7	150-0857	1	Cup, Governor
8	150-0078	1	Ring, Center Pin
9	166-0302	1	Gear, Distributor Drive
10	518-0195	1	Ring, Distributor Drive Gear
11	105-0465	1	*#Gear, Camshaft - Begin Spec B
12	150-0773	1	*#Plate, Governor Flyball - Begin Spec B
13	150-1842	1	*#Spacer Kit, Governor Flyball - Begin Spec B (Includes Mounting Screws)
14	815-0506	3	*Screw, Spacer Mounting (Special) Begin Spec B
15	150-0859	1	Washer, Thrust - Governor Yoke - Begin Spec B
16	105-0223	1	Gear, Camshaft (Includes Spacer and Plate) Spec A

* - Parts Included in 105-0218 Camshaft Gear Assembly.

- Camshaft Gear Assemblies With Rivets, Begin Spec B, Order 105-0218 Camshaft Gear Assembly.

CRANKSHAFT AND FLYWHEEL



CT 1043


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	104-1362	1	Crankshaft Kit (Includes All Keys)	13	526-0185	1	Washer, Flat (15/32" ID x 1-1/2" OD x 3/8" Thk)
2	104-0418	1	Gear, Crankshaft	14	515-0153	1	Key, Crankshaft to Flywheel
3	104-0416	1	Washer, Retainer	15	854-0017	4	Washer, Lock-IT (5/16")
4	518-0188	1	Ring, Lock	16	134-1401	1	*Hub, Flywheel - Begin Spec H
5	515-0006	1	Key, Crankshaft to Generator Fan	17	526-0187	4	*#ΔWasher, Flat - Hub to Flywheel
6	134-1406	1	Flywheel Assembly - Begin Spec H (Replaces Flywheel Assembly Used Spec A-G) Includes Parts Marked *)	18	104-0543	4	*#ΔSpacer and Washer - Hub to Flywheel
7	821-0014	4	Screw, Locking Head (5/16-18 x 1/2")	19	870-0352	4	*#ΔNut, Locking - Hub to Flywheel (Special)
8	104-0423	1	*ΔGear, Ring	20	104-0572	1	Flywheel Assembly - Sets With Vacu-Flo Cooling (Includes Parts Marked Δ)
9	800-0500	1	Screw, Flywheel Mounting (Special)	21	104-0557	1	ΔHub, Flywheel - Sets With Vacu-Flo Cooling
10	515-0001	1	Key, Crankshaft to Gear	22	134-1431	1	Wheel, Blower - Sets With Vacu-Flo Cooling
11	801-0054	4	*#ΔScrew, Flywheel Hub Mounting (3/8-24 x 2")	23	134-0988	1	Plate, Blower Wheel - Sets With Vacu-Flo Cooling
12	134-3960	1	Hardware Kit, Hub Mounting - Begin Spec H for Sets Without Vacu-Flo Cooling (Includes Parts Marked #)	24	850-0055	1	Washer, Lock - Spring (7/16")

* - Parts Included in 134-1406 Flywheel Assembly.

- Parts Included in 134-3960 Hardware Kit.

Δ - Parts Included in 104-0572 Flywheel Assembly.

CYLINDER HEAD



CYLINDER HEAD

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	HEAD, CYLINDER			22	115-0155	16	Washer, Spring Retaining
	110-1313	2	With Values Gasoline Sets (Includes Parts Marked *)	23	115-0146	8	Spring, Shield Retainer
	110-1388	2	Gas and Gas-Gasoline Sets (Includes Parts Marked Δ)	24	COVER ASSEMBLY, ROCKER		
			Without Values		115-0134	2	Gasoline Sets (Includes Parts Marked **)
	110-1439	2	* Gasoline Sets (Includes Parts Marked +)		115-0179	2	Gas and Gas-Gasoline Sets (Includes Parts Marked #)
	110-1440	2	Δ Gas and Gas-Gasoline Sets (Includes Parts Marked £)	25	LINE, OIL - ROCKER COVER		
2	110-1223	2	Gasket, Head		120-0628	2	**Gasoline Sets
3	GUIDE, VALVE				120-0626	2	#Gas and Gas-Gasoline Sets
			Gasoline Sets - Intake and Exhaust	26	115-0130	2	Gasket, Rocker Cover
	110-1501	8	+ Standard	27	110-1225	10	Screw, Cylinder Head (3/8-16 x 4-3/4") Special
	110-1501-01	8	.001" Oversize	28	110-0815	8	Screw, Cylinder Head (3/8-16 x 2") Special
	110-1501-05	8	.005" Oversize	29	110-1282	4	Screw, Cylinder Head (3/8-16 x 4") Special
			Gas and Gas-Gasoline Sets	30	520-0626	2	Stud, Cylinder Head (3/8" x 2-5/8") Spec A through H
			Intake	31	526-0174	12	Washer, Flat (.406 ID x .781 OD X .1345 Thk) Cylinder Head
	110-1501	4	£ Standard	32	520-0338	4	*ΔStud, Intake Manifold
	110-1501-01	4	.001" Oversize	33	520-0608	8	*ΔStud, Exhaust Manifold (Special)
	110-1501-05	4	.005" Oversize	34	505-0274	1	*Δ+£Plug, Pipe - Countersunk Hex Head (1/8")
			Exhaust	35	403-0690	1	Bracket, Lifting - Begin Spec J
	110-1392	4	£ Standard	36	403-0620	2	Nut, Extension - Spec A through H
	110-1392-01	4	.001" Oversize				Bar Assembly, Lifting - Spec A through H (For Replacement Order (1) 403-0690, (2) 800-0009 and (2) 850-0060)
	110-1392-05	4	.005" Oversize	37			
4	INSERT, VALVE SEAT			38	815-0562	2	**#Screw, Machine - Cross Recessed Pan Head (#10 x 5/16")
			Intake	39	110-1312	2	*ΔBaffle, Fuel Distributing
			Gasoline Sets	40	800-0039	2	Screw, Cap - Hex Head (5/16-18 x 3-1/2")
	110-1214	4	+ Standard	41	850-0045	10	Washer, Lock - Spring (5/16")
	110-1214-02	4	.002" Oversize	42	526-0100	2	Washer, Flat (9/16" ID x 1-3/8" OD x 7/64" Thk) Begin Spec J
	110-1214-05	4	.005" Oversize	43	526-0130	2	**#Washer, Flat (17/64" ID x 1" OD x 1/16" Thk)
	110-1214-10	4	.010" Oversize	44	862-0015	1	Nut, Hex (5/16-18) Begin Spec J
	110-1214-25	4	.025" Oversize	45	402-0361	2	Cushion, Vibration - Begin Spec J
			Gas and Gas-Gasoline Sets	46	403-0890	1	Brace, Lifting Bracket - Begin Spec J
	110-1287	4	£ Standard	47	403-0826	1	Spacer, Lifting Bracket - Begin Spec J
	110-1287-02	4	.002" Oversize	48	402-0362	2	Bushing, Spacer - Begin Spec J
	110-1287-05	4	.005" Oversize	49	123-1169	2	Adapter, PCV Valve - Begin Spec T
	110-1287-10	4	.010" Oversize	50	123-1170	2	Valve, PCV - Begin Spec T
	110-1287-25	4	.025" Oversize	51	800-0030	8	Screw, Cap - Hex Head (5/16-18 x 1-1/4")
			Exhaust	52	800-0094	2	Screw, Cap - Hex Head (1/2-13 x 2") Begin Spec J
	110-1215	4	+£ Standard	53	800-0025	1	Screw, Cap - Hex Head (5/16-18 x 5/8") Begin Spec J
	110-1215-02	4	.002" Oversize	54	800-0038	1	Screw, Cap - Hex Head (5/16-18 x 3-1/4") Begin Spec J
	110-1215-05	4	.005" Oversize				
	110-1215-10	4	.010" Oversize				
	110-1215-25	4	.025" Oversize				
5	VALVE, INTAKE						
	110-1218	4	*Gasoline Sets				
	110-1286	4	ΔGas and Gas-Gasoline Sets				
6	110-1219	4	*ΔValve, Exhaust				
7	110-1221	8	*ΔSpring, Valve				
8	110-1220	8	*ΔRetainer, Valve Spring				
9	110-0858	16	*ΔLock, Valve Spring Retainer				
10	110-0859	8	Cap, Valve Stem				
11	509-0090	4	*ΔSeal, Oil - Intake Valve				
12	ARM, ROCKER						
	115-0128	4	Exhaust				
	115-0129	4	Intake				
13	115-0189	4	*Δ+£Stud Package, Rocker Arm (Package Includes Two Studs and One Lock)				
14	115-0127	8	Ball, Rocker Arm				
15	115-0150	8	Locknut, Rocker Arm				
16	115-0184	4	*Δ+£Lock, Stud				
17	115-0145	8	Rod, Valve Push				
18	TAPPET, VALVE						
	115-0132	8	Spec A through N				
	115-0195	8	Begin Spec P (Included in Cylinder Block Assembly)				
19	115-0196	2	Guide, Push Rod				
20	115-0137	8	Shield, Push Rod				
21	509-0084	16	Seal, Push Rod Shield				

* - Parts Included in 110-1313 Cylinder Head.

Δ - Parts Included in 110-1388 Cylinder Head.


+ - Parts Included in 110-1439 Cylinder Head.

£ - Parts Included in 110-1440 Cylinder Head.

** - Parts Included in 115-0134 Rocker Cover Assembly.

- Parts Included in 115-0179 Rocker Cover Assembly.

OIL SYSTEM




OIL SYSTEM

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	120-0547	1	Pump, Oil
2	120-0580	1	Gasket Kit, Oil Pump
3	CUP, OIL PUMP INTAKE		
	120-0756	1	Spec A through G (This 120-0756 Cup Kit Replaces the Intake Cup With the Straight Tube Used During Spec A through G) Includes Parts Marked *
	120-0601	1	*Begin Spec H (Curved Tube)
4	122-0185	1	Filter, Oil (4-3/8" Long)
5	122-0188	1	Gasket, Adapter
6	122-0182	1	Adapter, Oil Filter
7	193-0006	1	Gauge, Oil Pressure
8	ELBOW, STREET — 45°		
	502-0053	1	Sets Without Low Oil Pressure Switch
	502-0053	2	Sets With Low Oil Pressure Switch
9	505-0057	1	Plug, Pipe (1/8") Sets Without Low Oil Pressure Switch
10	ELBOW, INVERTED MALE — Oil Line to Filter Adapter		
	502-0019	1	Gasoline Sets — Spec A through N
			Gas and Gas-Gasoline Sets
	502-0019	1	Spec A through Serial Number 698177 During Spec N
	502-0037	1	Begin Serial Number 698178 During Spec N
	502-0037	1	Begin Spec P (All Fuels)
11	LINE, FILTER ADAPTER TO CYLINDER HEAD		
			Gasoline Sets
	120-0562	1	Spec A through N
	120-0637	1	Spec P through S
			Gas and Gas-Gasoline Sets
	120-0562	1	Spec A through Serial Number 698177 During Spec N
	120-0606	1	Begin Serial Number 698178 During Spec N through Spec S
	120-0707	1	Begin Spec T (All Fuels)
12	502-0242	1	Tee, Restricted - Front Cylinder Head - Spec A through S
13	120-0539	1	Value, Oil By-Pass
14	120-0555	1	Spring, By-Pass Value
15	505-0274	1	Plug, Pipe - Countersunk (1/8") Oil By-Pass

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
16	120-0602	1	*Bracket, Oil Pump Intake Cup — Begin Spec H
17	850-0045	1	*Washer, Lock - Spring (5/16") Begin Spec H
18	CONNECTOR, INVERTED MALE — Rear Cylinder Head		
			Gasoline Sets
	502-0097	1	Spec A through N
	502-0274	1	Spec P through S (Restricted)
			Gas and Gas-Gasoline Sets
	502-0097	1	Spec A through Serial Number 698177 During Spec N
	502-0274	1	Begin Serial Number 698178 During Spec N through Spec S (Restricted)
19	LINE, TEE TO REAR CYLINDER HEAD		
	120-0575	1	Spec A through N
	120-0635	1	Spec P through S
20	502-0097	1	Connector, Inverted Male - Tee to Rear Cylinder Head Line - Spec A through S
21	CONNECTOR, INVERTED MALE — Adapter Oil Line to Tee		
			Gasoline Sets
	502-0030	1	Spec A through N
	502-0097	1	Spec P through S
			Gas and Gas-Gasoline Sets
	502-0030	1	Spec A through Serial Number 698177 During Spec N
	502-0097	1	Begin Serial Number 698178 During Spec N through Spec S
22	120-0695	2	Line, Oil - Cylinder Head - Begin Spec T
23	502-0373	1	Tee, Inverted Flare - Begin Spec T
24	502-0394	2	Connector, Inverted Male Cylinder Head - Begin Spec T
25	850-0045	5	Washer, Lock - Spring (5/16")
	SCREW, CAP — HEX HEAD		
26	800-0030	2	5/16-18 x 1-1/4"
27	800-0028	3	5/16-18 x 1"
28	800-0025	1	*5/16-18 x 5/8" — Begin Spec H

* - Parts Included in 120-0756 Oil Pump Intake Cup Kit.

OIL BASE




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	BASE, OIL 102-0476	1	Spec A through J Begin Spec K
	102-0539	1	Sets Without Oil Base Heater
	102-0549	1	Sets With Oil Base Heater (3/8 NPSF)
	102-0622	1	Sets With Oil Base Heater (1/2 NPSF)
2	102-0475	1	Gasket, Oil Base
3	800-0072	10	Screw, Cap - Hex Head (7/16-14 x 1-1/4")
4	850-0055	10	Washer, Lock - Spring (7/16")
5	505-0056	1	Plug, Pipe - Square Head (1/2") Sets Without Housing or Skid Mounting
6	NIPPLE, PIPE 505-0100 505-0002	2 2	Close (1/2") Housed Sets Long (1/2" x 3") Skid Mounted Sets
7	504-0011	1	Valve, Oil Drain - Housed or Skid Mounted Sets
8	503-0197	1	Clamp, Hose - Housed or Skid Mounted Sets
9	503-0316	1	Hose, Oil Drain - Housed or Skid Mounted Sets
10	HARDWARE PACKAGE, MOUNTING - Begin Spec K 402-0291	4	Sets Without Housing, Skid Mounting or Vacu-Flo Cooling (Hardware Package for 1 Mount) Includes Parts Marked *
	402-0327	1	Sets With Housing, Skid Mounting or Vacu-Flo Cooling (Hardware Package for 4 Mounts) Includes Parts Marked #
11	862-0004	4	*#Nut, Hex (7/16")
12	SUPPORT — Vacu-Flo Cooled Sets Spec A through J		
	403-0706	1	Engine End
	403-0648	1	Generator End
	403-0710	2	Begin Spec K
13	850-0055	4	*#Washer, Lock - Spring (7/16")

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
14	526-0014	4	*#Washer, Flat (29/64" ID x 1-1/2" OD x 1/8" Thk) Use With Cone Shaped Cushions
15	526-0198	8	*#Washer, Flat (5/8" ID x 1-1/2" OD x 1/16" Thk) Use With Cone Shaped Cushions (Use as Required)
16	402-0282	4	*#Snubber - Begin Spec K
17	BUSHING, SPACER 402-0046 402-0290	4 4	Spec A through J *#Begin Spec K
18	CUSHION, VIBRATION - Cone Shaped (Begin Spec K) 402-0285	2	Engine End Generator End
	402-0287	2	Spec K through Z
	402-0286	2	Begin Spec AA
19	526-0195	4	*#Washer, Flat (29/64" ID x 3-1/4" OD x 1/8" Thk) Use With Cone Shaped Cushions
20	816-0212	4	*Bolt, Carriage (7/16-14 x 5-1/2") Sets Without Housing, Skid Mounting or Vacu-Flo Cooling
21	800-0082	4	#Screw, Cap - Hex Head (7/16-14 x 3-3/4") Sets With Housing, Skid Mounting or Vacu-Flo Cooling
22	402-0036	4	Mount, Upper Vibration (Cylindrical Shaped) Spec A through J
23	MOUNT, LOWER VIBRATION (Cylindrical Shaped) Spec A through J 402-0038 402-0251	2 2	Engine End Generator End

* - Parts Included in 402-0291 Mounting Hardware Package.
- Parts Included in 402-0327 Mounting Hardware Package.

GEARCASE




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	GEARCASE ASSEMBLY (Includes Parts Marked*)		
	103-0277	1	Spec A through E (Also Order 103-0251 Gasket)
	103-0277	1	Begin Spec F
2	ARM. GOVERNOR		
	150-0836	1	Spec A through Q
	150-1091	1	Begin Spec R
3	516-0111	1	*Pin, Governor Cup Stop
4	150-0777	1	*Yoke, Governor
5	518-0129	1	*Ring, Yoke Retaining
6	509-0088	1	*Seal, Governor Shaft
7	510-0048	1	*Bearing, Shaft - 1/2" Shaft
8	510-0082	1	*Bearing, Shaft - 1/4" Shaft
9	BALL, GOVERNOR SHAFT THRUST		
	510-0014	1	Spec A through E (3/16")
	510-0043	1	*Begin Spec F (5/16")
10	509-0087	1	*Seal
11	GASKET, GEARCASE		
	103-0219	1	Spec A through E (Cast Iron Cover)
	103-0251	1	Begin Spec F (Die Cast Cover)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
12	103-0218	1	Gasket, Backplate
13	103-0271	1	Backplate, Gearcase (To Replace One-Piece Backplate Used on Early Models Also Order 134-1532 Baffle)
14	134-1532	1	Baffle, Backplate (Not Used on Early Models)
15	SCREW, CAP - HEX HEAD		
	110-0879	4	Special
	800-0028	1	5/16-18 x 1"
16	800-0026	1	Screw, Cap - Hex Head (5/16-18 x 3/4")
17	815-0347	2	Screw, Machine - Flat Head - Socket Drive (1/4-20 x 1/2")
18	850-0045	6	Washer, Lock-Spring (5/16")
19	526-0115	5	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)
20	850-0025	1	*Washer, Lock-Spring (#8)
21	815-0176	1	*Screw, Machine - Hex Head (#8-32 x 1/2")
22	150-0838	1	*Shaft, Governor

* - Parts Included in 103-0277 Gearcase Assembly.

GOVERNOR




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	SPRING, GOVERNOR		
		1	#Spec A
	150-0861	1	Spec B through Q
	150-0862	1	Spec A through Q
			Vacu-Flo Cooled Sets
	150-1085	1	Begin Spec R
2	STUD, GOVERNOR ADJUSTING		
		1	#Spec A
	150-0863	1	Spec B through Q
			Begin Spec R
	150-1083	1	Pressure Cooled Sets
	150-1082	1	Vacu-Flo Cooled Sets
3	NUT, ADJUSTING		
			Pressure Cooled Sets
	104-0091	1	Spec A through Q
	862-0003	1	Begin Spec R
			Vacu-Flo Cooled Sets
	150-0937	1	Spec A through Q
	150-1112	1	Begin Spec R
4	BRACKET, GOVERNOR		
			Pressure Cooled Sets
	150-0814	1	Spec A through Q
	150-1110	1	Begin Spec R
			Vacu-Flo Cooled Sets
	150-0812	1	Spec A through Q
	150-1107	1	Begin Spec R
5	LINK, GOVERNOR		
	150-0841	1	Spec A through Q
	150-1069	1	*Begin Spec R
6	JOINT, BALL		
	150-0974	1	Spec A through Q
	150-1081	2	*Begin Spec R
7	870-0131	2	Nut, Hex - ET (#10-32)
8	NUT, LOCK - Sets Without Vacu-Flo Cooling		
	870-0130	1	Spec A through Q (3/8-24)
	870-0133	1	Begin Spec R (3/8-16)
9	516-0036	1	Key, Cotter — Spec A through Q
10	870-0053	2	*Nut, Hex - Begin Spec R (#10-32)
11	800-0005	2	Screw, Cap - Hex Head (1/4-20 x 3/4")
12	850-0040	2	Washer, Lock - Spring (1/4")
13	150-1070	1	Linkage Assembly, Governor - Begin Spec R (Includes Parts Marked *)

- For Spec A Replacement Order 1 each of 150-0861 Governor Spring and 150-0863 Governor Adjusting Stud.

* - Parts Included in 150-1070 Governor Linkage Assembly.

CARBURETOR AIR HEATER-BEGIN SPEC P (GASOLINE SETS)




XFS 1396

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	HEATER KIT, CARBURETOR AIR (Complete Replacement for All Specs)		
			Pressure Cooled Sets
	140-0894	1	Without Duct or Duct and Shutters
	140-0893	1	With Duct or Duct and Shutters
	140-0892	1	Vacu-Flo Cooled Sets
1	133-0187	1	Adapter, Hose - Air Outlet - Pressure Cooled Sets with Duct or Duct & Shutter and Vacu-Flo Cooled Sets
2	133-0192	1	Plenum, Manifold Heater - Pressure Cooled Sets without Duct or Shutters
3	140-0788	1	Control Assembly, Temperature (Includes Parts Marked*)
4	140-0785	1	*Housing, Temperature Control
5	140-0782	1	*Shutter, Temperature Control
6	140-0786	1	*Spring, Shutter Control
7	140-0784	1	*Plunger, Temperature Control
8	140-0808	1	*Spacer, Vernatherm
9	140-0787	1	*Spring, Vernatherm
10	518-0205	2	*Ring, Retaining
11	870-0195	1	*Nut, Locking - Vernatherm (5/16-24)
12	309-0181	1	*Vernatherm, Temperature Control

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
13	140-0789	1	Shield, Air Outlet Hose - Pressure Cooled Sets with Duct or Duct & Shutter
14	140-0790	1	Cover, Air Cleaner
15	140-0791	1	Pan, Air Cleaner
16	140-0821	2	Clamp, Temperature Control Support - Pressure Cooled Sets
17	140-0822	1	Support, Temperature Control - Pressure Cooled Sets
18	CLAMP, HOSE		
	503-0311	2	Pressure Cooled Sets
	503-0311	4	Vacu-Flo Cooled Sets
19	HOSE, CONTROL TO AIR CLEANER		
	503-0475	1	Pressure Cooled Sets
	503-0477	1	Vacu-Flo Cooled Sets
20	HOSE, PLENUM TO CONTROL		
	503-0476	1	Pressure Cooled Sets
	503-0039	1	Vacu-Flo Cooled Sets
21	813-0105	2	Screw, Machine - Round Head (10-32 x 1")
22	854-0010	2	Washer, Lock - IT (#10)
23	808-0032	2	Screw, Machine - Round Head Sheet Metal (#10 x 1/2")
24	800-1005	2	Screw, Cap - Hex Head (1/4-20 x 3/4")

* - Parts Included in 140-0788 Temperature Control Assembly.

FUEL SYSTEM (GASOLINE)



XFS 1392

FUEL SYSTEM (GASOLINE)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	CARBURETOR - Includes Mounting Gasket (See Separate Group for Components)		
	141-0759	1	Spec A through Q (Spec A through K Also order 153-0430 Thermo-Magnetic Choke Kit When Originally Equipped With Electric Choke)
	141-0876	1	Begin Spec R
2	141-0281	1	Gasket, Carburetor
3	502-0002	2	Elbow, Inverted Male (90°) Fuel Pump Inlet and Outlet
4	ADAPTER, AIR CLEANER (Includes Tube)		
	140-0647	1	Spec A through Q
	140-0933	1	Begin Spec R
5	HOSE, BREATHER		
	503-0389	1	Spec A through H
	503-0416	1	Spec J through S
	503-0471	1	Begin Spec T
6	PAN, AIR CLEANER		
	140-0595	1	Spec A through N
	140-0791	1	Begin Spec P
	140-0595	1	Gas and Gas-Gasoline Sets
7	140-1907	1	Element and Retainer
8	COVER, AIR CLEANER		
	140-0594	1	Spec A through N
	140-0790	1	Begin Spec P
	140-0594	1	Gas and Gas-Gasoline Sets
9	140-0584	1	Gasket, Air Cleaner
10	GASKET, ADAPTER TO CARBURETOR		
	140-0585	1	Spec A through Q
	140-0921	1	Begin Spec R
11	520-0621	2	Stud, Air Cleaner (1/4" x 3")
12	865-0020	2	Nut, Wing (1/4-20)
13	ELBOW, INVERTED MALE (Carburetor Inlet)		
	502-0002	1	Spec A through K (90°)
	502-0065	1	Begin Spec L (45°)
14	LINE, PUMP TO CARBURETOR		
	159-0744	1	Spec A through K
	149-1016	1	Spec L through Q
	149-1099	1	Begin Spec R

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
15	149-1787	1	Pump Kit, Fuel - Includes Mounting Gasket
	149-1048	1	Repair Kit, Fuel Pump
16	149-0792	1	Gasket, Fuel Pump
17	149-0463	1	Screen, Fuel Pump
18	149-0517	1	Gasket, Bowl
19	MANIFOLD, INTAKE		
	154-0724	1	Spec A
			Begin Spec B
	154-0749	1	Gasoline Sets
			Gas and Gas-Gasoline Sets
	154-0749	1	Sets Without Vacuum Switch
	154-1224	1	Sets With Vacuum Switch
20	154-0733	2	Gasket, Intake Manifold
21	520-0526	2	Stud, Carburetor Mounting (5/16" x 1-1/4")
22	123-0732	1	Tube, Nylon
23	BAIL, FUEL PUMP (Measure for Correct Length)		
	149-1006	1	3-5/8" Long
	149-1169	1	2-7/8" Long
24	BOWL, FUEL PUMP (Measure for Correct Length)		
	149-0116	1	2-3/8" Long
	149-1168	1	1-5/8" Long
25	800-0027	2	Screw, Cap - Hex Head (5/16-18 x 7/8")
26	526-0241	2	Washer, Flat (#10)
27	850-0030	2	Washer, Lock - Spring (#10)
28	503-0171	2	Clamp, Breather Hose
29	149-1307	2	Stiffener, Fuel Pump Mounting
30	141-0727	1	Rod, Carburetor Adjusting
31	868-0002	2	Nut, Jam - Hex Head (5/16-24)
32	870-0137	4	Nut, Hex - Self-Locking (5/16-24)
33	854-0017	2	Washer, Lock - IT (5/16")
34	813-0108	2	Screw, Machine - Round Head (#10-32 x 1-1/2")
35	505-0098	1	Nipple, Close - Pipe (1/8" x 3/4") Gas and Gas-Gasoline Sets With Vacuum Switch
36	502-0053	1	Elbow, Street - Brass (45°) Gas and Gas-Gasoline Sets With Vacuum Switch

CARBURETOR PARTS — SPEC A THROUGH Q

(Note Replacement Carburetor are same as
used on units beginning with spec R)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
CARBURETOR REPLACEMENT KITS			
		1	Gasoline Sets - Kit 141-0759 (Includes carburetor 141-0876)
		1	Gas-Gasoline Sets - Kit 141-0758 (Includes carburetor 141-0886)
		1	Gas Sets - Kit 141-0757 (Includes carburetor 141-0889)
	143-0241	1	Repair Kit (Includes Parts Marked *)
	143-0201	1	*Gasket Kit (Includes Parts Marked #)
	141-0281	1	*#Gasket, Carburetor Mounting
1	143-0202	1	Valve, Throttle
2	SHAFT AND LEVER, THROTTLE		
	145-0301	1	Spec A
	143-0234	1	Begin Spec B
3	143-0204	1	Valve, Choke
4	143-0235	1	*Needle, Idle Jet and High Speed Adjusting
5	143-0237	1	*Nozzle (Not Used on Gas Only Carburetor)
6	SHAFT, CHOKE		
	143-0207	1	Spec A through K
	143-0315	1	Spec L through Q
	143-0232	1	Spec A through K
	143-0316	1	Spec L through Q
7	143-0208	1	Screw and Gasket, Bowl
8	143-0015	1	#Gasket, Fuel Inlet Valve
9	143-0209	1	#Gasket
10	143-0105	1	Float and Lever ((Not Used on Gas Only Carburetor)
11	143-0210	1	Bowl
12	143-0077	1	#Gasket, Bowl Ring
13	141-0703	1	*Pin, Float (Not Used on Gas Only Carburetor)
14	143-0341	1	*Valve, Fuel Inlet
15	143-0213	1	Screw, Idle Adjusting (2 for Gas-Gasoline Carburetor)
16	812-0014	4	*Screw, Machine - Round Head (#3-48 x 3/16")
17	143-0110	1	Plug, Expansion
18	143-0214	1	Spring, Throttle Adjusting
19	143-0112	1	Spring, Idle Adjusting (2 for Gas-Gasoline Carburetor)
20	143-0114	1	Spring, High Speed Adjusting
21	143-0215	1	Screw, Throttle Adjusting
24	145-0308	1	Tube, Gas Inlet - Gas and Gas-Gasoline Sets
25	145-0309	1	Needle, Gas Adjusting - Gas and Gas-Gasoline Sets
26	148-0010	1	Spring, Gas Adjusting - Gas and Gas-Gasoline Sets
27	143-0231	1	Wire, Choke Lock - Gas-Gasoline Sets
28	505-0008	1	Plug (1/8") - Gas Sets
29	510-0075	1	Bearing, Needle - Throttle Shaft - Spec A
30	510-0076	1	Bearing, Needle - Throttle Shaft - Spec A



* - Parts Included in 143-0241 Repair Kit.
- Parts Included in 143-0201 Gasket Kit.

CARBURETOR PARTS — BEGIN SPEC R


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	CARBURETOR (Includes Mounting Gasket)		
	141-0876	1	Gasoline Sets
	141-0886	1	Gas-Gasoline Sets
	141-0889	1	Gas Sets
	141-0747	1	Repair Package (Includes Parts Marked *)
	141-0748	1	Gasket Kit (Includes Parts Marked #)
	141-0281	1	*#Gasket, Carburetor Mounting
1	141-0708	1	Bowl, Fuel
2	141-0860	1	Plate, Choke (Not Used on Gas Only Carburetor)
3	141-0698	4	Screw and Washer, Choke and Throttle Plate Mounting (Two Used on Gas Only Carburetor)
4	141-0793	1	Plate, Throttle
5	141-0705	1	*Retainer, Seal
6	141-0661	1	*#Seal, Rubber
7	141-0830	1	*Valve Seat Assembly, Fuel (Not Used on Gas Only Carburetor)
8	141-0811	1	*#Washer, Fuel Valve Seat (Not Used on Gas Only Carburetor)
9	141-0703	1	*Shaft, Float (Not Used on Gas Only Carburetor)
10	141-0702	1	Float Assembly (Not Used on Gas Only Carburetor)
11	141-0701	1	*#Gasket, Bowl to Body
12	141-0700	1	Screw, Throttle Stop
13	141-0711	1	Spring, Throttle Stop
14	NEEDLE, IDLE ADJUSTING		
	141-0713	1	Gasoline and Gas Only Carburetor
	141-0713	2	Gas-Gasoline Carburetor
15	SPRING, IDLE NEEDLE		
	141-0710	1	Gasoline and Gas Only Carburetor
	141-0710	2	Gas-Gasoline Carburetor
16	141-0077	1	*#Washer, Main Jet Assembly
17	141-0712	1	Jet Assembly, Main (Adjustable) Not Used on Gas Only Carburetor
18	141-0679	1	Shaft, Choke (Not Used on Gas Only Carburetor)
22	141-0735	1	Shaft and Lever, Throttle
23	141-0733	1	Spring, Main Gas Needle - Gas and Gas-Gasoline Carburetor
24	141-0734	1	Needle, Main Gas Adjusting - Gas and Gas-Gasoline Carburetor
25	141-0736	1	Nut, Bowl - Gas Only Carburetor
26	141-0737	1	Plug, Pipe (1/8") Gas Only Carburetor
27	141-0738	1	Screw - Gas Only Carburetor
28	141-0739	1	Washer - Gas Only Carburetor
29	141-0799	1	*Spring, Float



* - Parts Included in 141-0747 Repair Package.

- Parts Included in 141-0748 Gasket Kit.

CHOKE




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	153-0430	1	Choke Kit - Replacement for Sets Originally Equipped With Thermo-Magnetic Choke
1		1	*Adapter - Spec A through K
2	153-0324	1	Bracket - Spec A through K
3		1	*Element - Spec A through K
4	153-0325	1	Cover Assembly, Choke - Spec A through K
5	153-0385	1	Plate, Mounting - Begin Spec L
6	153-0386	1	Body - Begin Spec L
7	153-0389	1	Cover - Begin Spec L
8	153-0391	1	Core, Solenoid - Begin Spec L
9	153-0395	1	Armature - Begin Spec L
10	307-1203	1	Coil, Solenoid Assembly - Begin Spec L
11	153-0392	1	Frame, Solenoid - Begin Spec L
12	SPRING		
	153-0387	1	Spec L through R
	153-0425	1	Begin Spec S
13	153-0390	1	Lever, Thermostat - Begin Spec L
14	526-0018	1	Washer, Flat (17/64 ID x 5/8 OD x 1/16" Thk) - Begin Spec L
15	870-0134	1	Palnut (1/4-20) - Begin Spec L
16	153-0399	2	Insulator - Begin Spec L

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
17	HEATER ASSEMBLY		
	153-0400	1	Spec L through R
	153-0422	1	Begin Spec S
18	518-0129	1	Ring, Retaining - Begin Spec L
19	332-0876	1	Terminal Ground - Begin Spec L
20	LEAD		
	334-0028	1	Choke to Coil - Spec A through K
	334-0028	1	Choke Solenoid to Ground - Begin Spec L
21	338-0332	1	Harness, Choke - Begin Spec L
22	SCREW, FLATHEAD - CHOKE PLATE MOUNTING		
	815-0161	2	Late Models (#10-32 x 3/8")
	815-0266	2	Early Models (#8-32 x 3/8")
23	813-0107	1	Screw, Round Head (#10-32 x 1-1/4")
24	812-0076	2	Screw, Round Head (#8-32 x 5/16")
25	526-0008	1	Washer, Flat (13/64" ID x 7/16 OD x 1/32" Thk)
26	526-0022	1	Washer, Flat (21/64" ID x 9/16 OD x 1/16 Thk)
27	850-0030	1	Washer, Lock - Spring (#10)
28	854-0007	2	Washer, Lock - IT (#8)
29	854-0017	1	Washer, Lock - IT (5/16")
30	862-0015	1	Nut, Hex (5/16-18)

* - Parts Not Available - Order Replacement Choke Kit 153-0430.


EXHAUST SYSTEM



EXS 1066

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	154-0714	1	Manifold, Exhaust	5	505-0032	1	Coupling, Pipe (1-1/2")
2	154-0463	4	Gasket - Exhaust Manifold				Unhoused and Skid Mounted
3	MUFFLER						Sets
	155-0077	1	Unhoused and Skid Mounted	6	154-0738	1	Gasket, Exhaust Outlet
			Sets	7	155-0782	1	Flange, Exhaust Outlet
	155-0456	1	Housed Sets	8	505-0043	2	Elbow, Pipe (1-1/2 x 90°)
4	TUBE, EXHAUST - FLEXIBLE						Housed Sets
	155-0493	1	Unhoused and Skid Mounted	9	526-0174	2	Washer, Flat (13/32" ID x
			Sets (36")				25/32" OD x 9/64" Thk)
	155-0841	1	Housed Sets (9-3/4")	10	800-0052	2	Screw, Cap - Hex Head (3/8-16
	155-0949	1	Housed Sets With 155-0360				x 1-1/2")
			Critical Muffler (10-5/8")	11	110-0445	8	Nut, Hex (Special)
				12	154-1665	4	Tab, Lock

IGNITION SYSTEM




IGNITION SYSTEM

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	862-0001	2	Nut, Hex (1/4-20)
2	166-0279	1	Clamp, Coil
3	166-0278	1	Coil, Ignition
4	160-0558	6	Nipple, Ignition Cable
5	CABLE KIT, SPARK PLUG — Includes Suppressor		
	167-1596	3	13"
	167-1595	1	24"
6	CABLE, COIL TO DISTRIBUTOR (Includes Suppressor)		
	167-1426	1	Pressure Cooled Sets
	167-1425	1	Vacu-Flo Cooled Sets
7	314-0006	1	Suppressor, Ignition Coil - Begin Spec G (Also Usable on Spec A through F)
8	334-0028	1	Lead, Coil to Distributor
9	509-0096	1	"O" Ring
10	332-0052	1	Clip, Spark Plug Cables
11	PLUG, SPARK		
	167-0241	4	Non-Resistor Type
	167-0237	4	Resistor Type
12	160-0721	1	Gasket, Breaker Plate
13	191-0395	1	Plate Assembly, Start-Disconnect
14	160-1224	1	Plate Only, Start-Disconnect
15	309-0134	1	Switch Assembly, Start-Disconnect
16	309-0140	1	Plunger, Start-Disconnect
17	160-0382	1	Diaphragm, Start-Disconnect
18	160-0720	1	Spacer, Timing Control
19	160-0707	1	Gear and Shaft Assembly
20	160-0806	1	Disc, Thrust

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
21	160-0711	2	Spring, Timing Weight
22	160-0773	1	Spring, Thrust Plunger
23	160-0774	1	Plunger, Thrust
24	520-0347	1	Stud, Plate Cover
25	160-0719	1	Cover, Breaker Plate
26	338-0261	1	Harness, Wiring - Switchplate to Control
27	DISTRIBUTOR - See Separate Group for Components		
	166-0307	1	Sets Without Vacu-Flo Cooling
	160-1300	1	Sets With Vacu-Flo Cooling
28	312-0193	1	Condenser, Ignition Coil - Begin Spec G (Also Usable on Spec A through F)
29	160-0886	1	Bracket, Coil Mounting - Vacu-Flo Cooled Sets
30	166-0286	1	Screw, Round Head Machine - Coil Clamp
31	812-0148	1	Screw, Round Head Machine (1/4-20 x 1/2")
32	800-0002	2	Screw, Hex Head Cap (1/4-20 x 3/8")
33	800-0052	2	Screw, Hex Head Cap (3/8-16 x 1-1/2")
34	850-0040	1	Washer, Lock (1/4")
35	850-0050	2	Washer, Lock (3/8")
36	526-0015	2	Washer, Flat (9/32 ID x 9/16 OD x 1/16" Thk)
37	526-0026	2	Washer, Flat (13/32 ID x 3/4 OD x 1/16" Thk)
38	854-0014	2	Washer, Lock - IT (1/4")
39	853-0008	1	Washer, Lock - ET (#10)
40	865-0011	1	Nut, Wing (#10-32)


STARTER



ES-1129

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	800-0051	2	Screw, Cap - Hex Head (3/8-16 x 1-1/4")
2	850-0050	2	Washer, Lock - Spring (3/8")
3	800-0054	2	Screw Cap - Hex Head (3/8-16 x 2")
4	850-0050	3	Washer, Lock - Spring (3/8")
5	800-0052	1	Screw, Cap - Hex Head (3/8-16 x 1-1/2")
6	850-0050	1	Washer, Lock - Spring (3/8")
7	191-0311	1	Spacer, Starter
8	191-0512	1	Flange, Starter
9	800-0046	1	Screw, Cap - Hex Head (3/8-16 x 1/2")
10	864-0003	1	Nut, Hex (3/8-16)
11	856-0010	1	Washer, Lock - EIT (3/8")
12	191-0365	1	Bracket, Starter
13	191-0324	1	Starter (See Separate Group for Components)
14	CABLE, BATTERY		
	416-0021	2	Sets Without Housing or Skid Mounting (20-1/2")
	416-0037	2	Sets With Housing or Skid Mounting (48")
15	416-0133	1	Cable, Battery Jumper
16	416-0096	1	Clamp, Battery Cable
17	338-0262	1	Harness, Wiring

STARTER PARTS




ES-1098


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	191-0324	1	Starter
1	191-0712	1	Armature
2	191-0432	1	Clutch
3	191-1023	1	Head Assembly, Commutator End
4	191-1024	1	Coil Package, Field
5	191-1025	1	Plate Assembly, Brush
6	191-1020	1	Spring Set, Brush (Set of 4)
7	191-1263	1	Connector Package
8	191-0497	1	Bearing (Bronze), Drive End
9	191-1027	1	Spring, Plunger
10	191-1028	1	Core Assembly, Moving
11	191-0433	1	Switch, Solenoid
12	191-1029	1	Yoke Parts Package
13	191-1030	1	Stop and Lock Ring Package, Pinion
14	191-1031	1	Thrust Washer Package, Armature (Use as Required)
15	191-0434	1	Brush Set, Service
16	191-1032	1	Yoke
17	191-0468	1	Cover, Solenoid
18	191-1134	1	Boot, Rubber - Part of Moving Core Assembly

DISTRIBUTOR PARTS

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
DISTRIBUTOR ASSEMBLY			
	166-0307	1	Pressure Cooled Sets
	160-1300	1	Vacu-Flo Cooled Sets
1	166-0235	1	Cap
2	166-0234	1	Rotor
3	166-0297	1	Plate, Breaker
4	166-0245	1	Point Set, Breaker
5	166-0061	1	Nut, Lock - Contact Screw
6	166-0606	1	Spring Set, Governor Weight
7	166-0607	1	Wick Package
8	166-0608	1	Terminal Stud and Parts Package
9	166-0310	1	Condenser
10	166-0609	1	Weight Set, Governor
11	509-0096	1	Seal, Base
12	166-0303	1	Gear, Drive
13	518-0216	1	Ring, Retaining
14	166-0610	1	Shaft, Drive
15	166-0611	1	Cam and Stop Plate
16	166-0612	1	Bearing and Parts Package
17	166-0623	1	Arm, Ignition Advance




AIR HOUSING



AIR HOUSING

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	HOUSING, BLOWER			25	854-0010	2	Washer, Lock - IT (#10)
	134-1087	1	Pressure Cooled Sets	26	815-0235	1	Screw, Cap - Hex Head (1/4-20 x 5/8")
	134-1433	1	Vacu-Flo Cooled Sets	27	853-0013	1	Washer, Lock - ET (1/4")
2	134-1048	1	Housing, Cylinder Air - Front	28	800-0024	2	Screw, Cap - Hex Head (5/16-18 x 1/2")
3	134-1051	1	Housing, Cylinder Air - Rear	29	850-0045	2	Washer, Lock - Spring (5/16")
4	134-1418	1	Panel, Cylinder Air - Bottom	30	813-0098	2	Screw, Machine - Round Head (#10-32 x 3/8")
5	COVER, CYLINDER AIR HOUSING			31	853-0008	2	Washer, Lock - ET (#10)
	134-1119	1	Spec A	32	800-0007	3	Screw, Cap - Hex Head (1/4-20 x 1")
	134-1785	1	Spec B through P	33	850-0040	3	Washer, Lock - Spring (1/4")
			Begin Spec R	34	526-0115	3	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)
	134-1785	1	Gasoline Sets	35	812-0165	1	Screw, Machine - Round Head (1/4-20 x 4-1/2")
	134-1910	1	Gas and Gas-Gasoline Sets	36	854-0014	1	Washer, Lock - IT (1/4")
6	PANEL, AIR HOUSING DOOR			37	104-0528	1	Pointer, Timing - Vacu-Flo Cooled Sets
	134-1096	1	Spec A	38	134-1415	1	Cover, Access Hole - Vacu-Flo Cooled Sets
	134-1202	1	Begin Spec B	39	FITTING		
7	134-1089	2	Bracket, Air Housing Door		508-0117	1	Grommet, Rubber - Spec A through AA
8	134-1373	2	Screw, Door Panel		517-0108	1	Plug, Cap - Begin Spec AB
9	134-1180	4	Washer, Door Panel	40	134-1109	1	Shroud - No. 1 Cylinder (Front) Vacu-Flo Cooled Sets
			(NOTE: Some early models used 8 for top cover)	41	134-1337	1	Shroud - No. 4 Cylinder (Rear) Vacu-Flo Cooled Sets
10	CLIP, RETAINER			42	134-1434	1	Cover, Cylinder Shroud - Vacu-Flo Cooled Sets
	870-0194	6	Pressure Cooled Sets (U Type)	43	134-1435	1	Wrapper, Cylinder Shroud - Vacu-Flo Cooled Sets
	870-0178	8	Vacu-Flo Cooled Sets (J Type)	44	134-0944	4	Spring, Cylinder Shroud Wrapper - Vacu-Flo Cooled Sets
11	SUPPORT, BLOWER HOUSING			45	517-0035	1	Plug, Dot Button (1-1/16" Hole) Vacu-Flo Cooled Sets
	134-1088	1	Pressure Cooled Sets	46	134-1427	1	Baffle, Front - Vacu-Flo Cooled Sets
	134-1085	1	Vacu-Flo Cooled Sets	47	134-1428	1	Baffle, Rear - Vacu-Flo Cooled Sets
12	134-1178	1	Grille	48	134-1430	1	Baffle, Center - Vacu-Flo Cooled Sets
13	134-1092	3	Retainer, Grille	49	134-1472	1	Panel, Cylinder Air - Vacu-Flo Cooled Sets
14	134-1097	1	Baffle, Cylinder (Carburetor Side)	50	134-1429	1	Bracket, Cylinder Shroud - Vacu-Flo Cooled Sets
15	134-1098	1	Baffle, Cylinder (Opposite Carburetor Side)				
16	508-0002	2	Grommet, Rubber (1/2" Hole) Bottom Cylinder Air Panel				
17	800-0004	4	Screw, Cap - Hex Head (1/4-20 x 5/8")				
18	850-0040	4	Washer, Lock - Spring (1/4")				
19	526-0021	4	Washer, Flat (17/64" ID x 3/4" OD x 1/16" Thk)				
20	815-0235	6	Screw, Cap - Hex Head (1/4-20 x 5/8")				
21	854-0014	6	Washer, Lock - IT (1/4")				
22	815-0235	2	Screw, Cap - Hex Head (1/4-20 x 5/8")				
23	854-0014	2	Washer, Lock - IT (1/4")				
24	813-0097	2	Screw, Machine - Round Head (#10-32 x 5/16")				

GENERATOR—SPEC A THROUGH Z




XG 1138

GENERATOR—SPEC A THROUGH Z

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	ADAPTER, GENERATOR			15	870-0177	1	#Nut, Speed (#10)
	231-0099	1	Spec A through J	16	304-0500	1	Resistor, Tapped Adjustable
	231-0111	1	Begin Spec K	17	232-1565	1	Bracket, Resistor Mounting
	231-0112	1	Mobile Electric Power Plants	18	304-0006	2	Washer, Resistor Centering
2	205-0064	1	*Fan, Generator	19	520-0620	1	Stud, Resistor Mounting
3	515-0103	1	*Key, Fan to Rotor	20	866-0001	1	Nut, Acorn (1/4-20)
4	234-0162	1	Baffle, Generator Air	21	NUT, ROTOR THROUGH STUD		
5	ROTOR ASSEMBLY, GENERATOR (Includes Parts Marked *)				232-1567	1	Spec A through D (7/16-14)
	201-1121	1	10.0 - 12.5 kw 60 Hz		870-0203	1	Begin Spec E (7/16-20)
	201-1122	1	All others	22	232-0200	1	Washer - Cone Shaped (Special) Rotor through Stud
6	510-0047	1	*Bearing, Rotor	23	GROMMET, RUBBER		
7	232-0596	1	Clip, Bearing Stop		508-0095	1	Air Baffle
8	STATOR, GENERATOR				508-0112	1	Lead Outlet
	220-0594	1	Single Phase 10.0 kw 60 Hz	24	204-0061	1	*Ring, Collector
			Three Phase 10.0 - 12.5 kw 60 Hz	25	516-0138	2	Pin, Roll (3/16" x 9/16") Alignment
	220-0594	1	120/208 Volt	26	332-0050	1	Clip - Brush Wires
	220-0628	1	120/240 Volt	27	SCREW, CAP — HEX HEAD		
	220-0673	1	277/480 Volt		800-0050	2	3/8-16 x 1"
			50 Hertz 12.5 kw		800-0051	2	3/8-16 x 1-1/4"
	220-0667	1	Single Phase	28	850-0050	4	Washer, Lock - Spring (3/8")
	220-0668	1	Three Phase	29	850-0055	1	Washer, Lock - Spring (7/16")
			60 Hertz 15.0 kw	30	862-0015	4	Nut, Hex (5/16 - 18)
	220-0601	1	Single Phase	31	850-0045	4	Washer, Lock - Spring (5/16")
			Three Phase	32	811-0098	1	Screw, Machine - Round Head Brass (#10-32 x 3/8")
	220-0595	1	120/208 Volt	33	856-0002	4	Washer, Lock - EIT (#8)
	220-0632	1	120/240 Volt	34	809-0046	1	#Screw, Sheet Metal - Round Head (#10 x 3/4")
	220-0655	1	277/480 Volt	35	813-0098	5	Screw, Machine - Round Head (#10-32 x 3/8")
	220-0651	1	347/600 Volt	36	850-0040	1	Washer, Lock - Spring (1/4")
	220-0651	1	600 Volt	37	812-0150	1	Screw, Machine - Round Head (1/4-20 x 5/8")
			X-Ray Applications	38	850-0040	1	Washer, Lock - Spring (1/4")
	220-0667	1	50 Hertz	39	856-0003	1	Washer, Lock - EIT (#10)
	220-0601	1	60 Hertz	40	850-0030	5	Washer, Lock - Spring (#10)
9	BELL, END			41	871-0010	1	Nut, Hex - Brass (#10-32)
	211-0138	1	Spec A through D	42	811-0098	1	Screw, Machine - Round Head Brass (#10-32 x 3/8")
			Begin Spec E	43	812-0085	4	Screw, Machine - Round Head (#8-32 x 1-1/8")
	211-0138	1	Sets Without Overspeed Switch	44	526-0049	4	Washer, Flat (13/64" ID x 7/16" OD x 1/32" Thk)
	211-0152	1	Sets With Overspeed Switch	45	856-0002	4	Washer, Lock - EIT (#8)
10	STUD, GENERATOR THROUGH			46	812-0086	4	Screw, Machine - Round Head (#8-32 x 1-1/4")
			10.0 - 12.5 kw 60 Hz	47	856-0003	1	Washer, Lock - EIT (#10)
	520-0607	4	Spec A through D				
	520-0638	4	Begin Spec E				
			All others				
	520-0460	4	Spec A through D				
	520-0640	4	Begin Spec E				
11	STUD, ROTOR THROUGH						
	520-0613	1	10.0 - 12.5 kw 60 Hz				
	520-0615	1	All others				
12	212-1064	2	Block, Collector Ring Brush				
13	214-0059	4	Brush, Collector Ring				
14	234-0163	1	Cover Assembly, Air Outlet (Includes Parts Marked #)				

* - Parts Included in Generator Rotor Assemblies.
- Parts Included in 234-0163 Cover Assembly.

GENERATOR EXCITER - SPEC A THROUGH Z



NOTE: 02SX1N1A used on all 60 hertz sets Spec A and B.
 06SX1N1A used on all 60 hertz sets Spec C and D.
 06SX1N1B used on all 60 hertz sets Spec E through M.
 06SX1N1B used on 120/240 volt, 120/208 volt and 600 volt, 3 phase, 60 hertz sets begin Spec P.
 06SX1N3B used on all 60 hertz sets (except 120/240 volt, 120/208 volt and 600 volt, 3 phase sets) begin Spec P.
 06SX51N1A used on all 50 hertz sets Spec A through D.
 06SX51N1B used on all 50 hertz sets Spec E through M.
 06SX51N1B used on 120/240 volt, 120/208 volt and 600 volt, 3 phase, 50 hertz sets begin Spec P.
 06SX51N3B used on all 50 hertz sets (except 120/240 volt, 120/208 volt and 600 volt, 3 phase sets) begin Spec P.

Check your set nameplate for correct magneciter number. Select the correct Part Number column that applies to your set.

GENERATOR EXCITER - SPEC A THROUGH Z

REF NO.	PART NUMBER	PART DESCRIPTION	QUANTITY USED										
			A	B	C	D	E	F	G	H	J	K	
		02SX1N1A Use Column A	X										
		04SX1N1A Use Column B		X									
		04SX1N1B Use Column C			X								
		04SX1N3B Use Column D				X							
		06SX1N1A Use Column E					X						
		06SX1N1B Use Column F						X					
		06SX1N3B Use Column G							X				
		06SX51N1A Use Column H								X			
		06SX51N1B Use Column J									X		
		06SX51N3B Use Column K										X	
	209-0001	Exciter, Complete (Less Cover)	1										
	209-0002	Exciter, Complete (Less Cover)		1									
	209-0003	Exciter, Complete (Less Cover)			1								
	209-0005	Exciter, Complete (Less Cover)				1							
	209-0007	Exciter, Complete (Less Cover)					1						
	209-0008	Exciter, Complete (Less Cover)						1					
	209-0010	Exciter, Complete (Less Cover)							1				
	209-0011	Exciter, Complete (Less Cover)								1			
	209-0012	Exciter, Complete (Less Cover)									1		
	209-0013	Exciter, Complete (Less Cover)										1	
1	234-0154	• Cover, Exciter	1	1			1			1			
1	234-0185	• Cover, Exciter			1	1		1	1		1	1	
2	234-0153	Panel Only, Exciter	1	1			1			1			
2	234-0188	Panel Only, Exciter			1	1		1	1		1	1	
3	315-0084	Reactor, Gate	2										
3	315-0099	Reactor, Gate		2	2	2							
3	315-0102	Reactor, Gate					2	2	2				
3	315-0104	Reactor, Gate								2	2	2	
4	232-1553	Gasket, Gate Reactor Mounting - Outer	2	2	2	2		2	2		2	2	
4	232-1608	Gasket, Gate Reactor Mounting - Outer					2			2			
5	232-1551	Gasket, Gate Reactor Mounting - Inner	2	2	2	2	2	2	2	2	2	2	
6	232-1552	Retainer, Gate Reactor	2	2	2	2		2	2		2	2	
6	234-0191	Retainer, Gate Reactor					2			2			
7	520-0211	Stud, Gate Reactor Mounting	1	1			1			1			
8	800-0013	Screw, Cap - Hex Head (1/4-20 x 2-1/2")			2	2							
8	800-0015	Screw, Cap - Hex Head (1/4-20 x 3")						2	2		2	2	
9	305-0259	Rectifier Assembly (Includes Parts Marked †)	1	1	1								
9	305-0387	Rectifier Assembly (Includes Parts Marked Δ)				1							
9	305-0264	Rectifier Assembly (Includes Parts Marked *)					1	1		1	1		
9	305-0388	Rectifier Assembly (Includes Parts Marked £)							1			1	
10	305-0238	†Δ*£ Rectifier Only, Power Field (Negative)	2	2	2	2	2	2	2	2	2	2	
11	305-0239	†Δ*£ Rectifier Only, Power Field (Positive)	2	2	2	2	2	2	2	2	2	2	
12	305-0239	Δ£ Rectifier Only, Field Flash				1			1			1	
13	305-0240	†Δ*£ Rectifier, Voltage Control	4	4	4	4	4	4	4	4	4	4	


GENERATOR EXCITER - SPEC A THROUGH Z

REF NO.	PART NUMBER	PART DESCRIPTION	QUANTITY USED									
			A	B	C	D	E	F	G	H	J	K
14	304-0476	†ΔResistor (500-Ohm, 5 Watt)	1	1	1	1						
14	304-0512	*£Resistor (150-Ohm, 50 Watt)					1	1	1	1	1	1
15	304-0498	†Δ*£Clip, Resistor Mounting	1	1	1	1	1	1	1	1	1	1
16	332-0697	†Δ*£Stud, Terminal (Flat Head)	2	2	2	2	2	2	2	2	2	2
17	332-0698	†Δ*£Stud, Terminal (Extended Slotted Head)	1	1	1	1	1	1	1	1	1	1
18	870-0196	†Δ*£Fastener (Compression Type)	2	2	2	2	2	2	2	2	2	2
19	332-0699	Block, Terminal (6 Place)	1	1			1			1		
19	332-0745	Block, Terminal (7 Place)			1	1		1	1		1	1
20	332-0746	Strip, Block Marker (7 Place)			1			1			1	
20	332-0925	Strip, Block Marker (7 Place)				1			1			1
21	304-0489	Resistor, Fixed (200-Ohm, 50 Watt)	1									
21	304-0511	Resistor, Tapped - 500-Ohm (425 Fixed, 75 Adj.)		1			1			1		
21	304-0527	Resistor, Tapped - 500-Ohm (425 Fixed, 75 Adj.)			1	1		1	1		1	1
22	304-0015	Washer, Centering - Resistor	2	4	4	4	4	4	4	4	4	4
23	232-1473	Spacer, Resistor Mounting	2				2			2		
23	232-1550	Spacer, Resistor Mounting		2								
23	232-1474	Spacer, Resistor Mounting			2	2		2	2		2	2
24	315-0085	Reactor, Voltage Control	1									
24	315-0100	Reactor, Voltage Control		1	1	1	1	1	1			
24	315-0105	Reactor, Voltage Control								1	1	1
25	232-1548	Gasket, Voltage Control Reactor	2	2	2	2	2	2	2	2	2	2
26	307-0584	Relay, Field Build-Up	1									
27	520-0641	Stud, Tapped Resistor Mounting	1		1	1		1	1		1	1
27	812-0116	Screw, Tapped Resistor Mounting (RHMS #10-24 x 4-1/2")		1			1			1		
28	332-0050	Clip, Loop	1	1			1			1		
28	332-0052	Clip, Loop			1	1		1	1		1	1
29	508-0008	Grommet, Rubber (For 7/8" Hole)	1	1	1	1	1	1	1	1	1	1
30	307-0643	Cover, Field Relay	1									
31	304-0510	Resistor, Fixed (250-Ohm, 25 Watt)		1	1	1	1	1	1	1	1	1
32	813-0112	Screw, Fixed Resistor Mounting (RHSMS #10-32 x 2-1/2")		1	1	1	1	1	1	1	1	1
33	308-0175	Switch, Residual Reset			1			1			1	
34	305-0238	Rectifier, Power Field - Negative				1			1			1
35	526-0173	Washer, Retainer - Voltage Control Reactor	1	1	1	1	1	1	1	1	1	1
ASSOCIATED HARDWARE (NOT ILLUSTRATED)												
		SCREW, MACHINE - ROUND HEAD										
	812-0156	1/4-20 x 1-1/2"										
	813-0101	#10-32 x 9/16"										
	811-0098	#10-32 x 3/8" (Brass)										
	813-0098	#10-32 x 3/8"										
	815-0190	#8-32 x 3/8"										
	815-0198	#8-32 x 5/8"										
	815-0001	Screw, Machine - Binder Head (Brass) (#6-32 x 1/4")										

GENERATOR EXCITER - SPEC A THROUGH Z

REF NO.	PART NUMBER	PART DESCRIPTION	QUANTITY USED									
			A	B	C	D	E	F	G	H	J	K
		WASHER, FLAT										
	526-0003	11/64" ID x 3/8" OD x 1/32" Thk						As Required				
	526-0048	.172" ID x 3/8" OD x 1/32" Thk						As Required				
	526-0049	.200" ID x 7/16" OD x 1/32" Thk						As Required				
	526-0179	7/32" ID x 5/8" OD x 1/16" Thk						As Required				
		WASHER, LOCK - SPRING										
	850-0030	#10						As Required				
	850-0040	1/4"						As Required				
	853-0005	Washer, Lock - ET (#8)						As Required				
		WASHER, LOCK - IT										
	854-0007	#8						As Required				
	854-0010	#10						As Required				
	854-0014	1/4"						As Required				
		NUT, HEX										
	860-0008	#8-32						As Required				
	860-0011	#10-24						As Required				
	862-0001	1/4-20						As Required				
	870-0053	#10-32						As Required				
	871-0005	#6-32 (Brass)						As Required				
	871-0007	#8-32 (Brass)						As Required				
	871-0010	#10-32 (Brass)						As Required				
		• - Use 234-0223 cover for housed sets.										
		† - Parts included in 305-0259 Rectifier Assembly.										
		Δ - Parts included in 305-0387 Rectifier Assembly.										
		* - Parts included in 305-0264 Rectifier Assembly.										
		£ - Parts included in 305-0388 Rectifier Assembly.										

GENERATOR - BEGIN SPEC AA



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	STATOR, GENERATOR		
			50 Hertz
	220-2024	1	10 kw 53,53C
	220-2049	1	10 kw 55D,57,57X,518
	220-2050	1	10 kw 55D,57,57X,518 (Extended Stack)
	220-2677	1	10 kw 53, 53 (Environmentally Protected)
	220-2659	1	10 kw 55D,57,57X,518 (Environmentally Protected)
	220-2025	1	12.5 kw 53,53C
	220-2050	1	12.5 kw 55D,57,57X,518,Z
	220-2051	1	12.5 kw 55D,57,57X,518 (Extended Stack)
	220-2678	1	12.5 kw 53,53C (Environmentally Protected)
	220-2660	1	12.5 kw 55D,57,57X,518 (Environmentally Protected)
	220-2026	1	15.0 kw 53,53C
	220-2051	1	15.0 kw 55D,57,57X,518
	220-2052	1	15.0 kw 55D,57,57X,518 (Extended Stack)
	220-2679	1	15.0 kw 53,53C (Environmentally Protected)
	220-2661	1	15.0 kw 55D,57,57X,518 (Environmentally Protected)


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			60 Hertz
	220-2016	1	10.0 kw 3,3C
	220-2041	1	10.0 kw 4,4X,5D,18
	220-2284	1	10.0 kw 9X
	220-2042	1	10.0 kw 4,4X,5D,18 (Extended Stack)
	220-2669	1	10.0 kw 3,3C (Environmentally Protected)
	220-2651	1	10.0 kw 4,4X,5D,18 (Environmentally Protected)
	220-2017	1	12.5 kw 3,3C,8,J
	220-2042	1	12.5 kw 4,4X,5D,18,C,D,G,L
	220-2285	1	12.5 kw 9X,H
	220-2043	1	12.5 kw 4,4X,5D,18 (Extended Stack)
	220-2670	1	12.5 kw 3,3C (Environmentally Protected)
	220-2652	1	12.5 kw 4,4X,5D,18 (Environmentally Protected)
	220-2018	1	15.0 kw 3,3C,8,J
	220-2043	1	15.0 kw 4,4X,5D,18,C,D,L
	220-2286	1	15.0 kw 9X,H
	220-2044	1	15.0 kw 4,4X,5D,18 (Extended Stack)
	220-2671	1	15.0 kw 3,3C (Environmentally Protected)
	220-2653	1	15.0 kw 4,4X,5D,18 (Environmentally Protected)

GENERATOR - BEGIN SPEC AA

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
2	ROTOR			19	509-0094	1	Seal, Bearing ("O" Ring)
			50 Hertz	20	STUD, GENERATOR THROUGH		
	201-2156	1	10 kw 53,53C,55D,57,57X,518		520-0798	4	50 Hertz Sets
	201-2157	1	10 kw 55D,57,57X,518				60 Hertz Sets
			(Extended Stack)		520-0797	4	12.5JC Sets
	201-2311	1	10 kw 53,53C,55D,57,57X,518		520-0798	4	15.0JC Sets
			(Environmentally Protected)	21	850-0050	4	Washer, Lock - Spring (3/8")
	201-2157	1	12.5 kw 53,53C,55D,57,57X,518,2	22	850-0040	2	Washer, Lock - Spring (1/4")
			(Extended Stack)	23	850-0040	2	Washer, Lock - Spring (1/4")
	201-2158	1	12.5 kw 55D,57,57X,518	24	850-0055	1	Washer, Lock - Spring (7/16")
			(Extended Stack)	25	853-0013	1	Washer, Lock (1/4" ET)
	201-2312	1	12.5 kw 53,53C,55D,57,57X,518 (Environmentally Protected)	26	870-0177	1	Nut, Speed (#10)
			(Extended Stack)	27	862-0011	4	Nut, Hex (3/8-16)
	201-2158	1	15.0 kw 53,53C,55D,57,57X,518	28	870-0203	1	Nut, Hex (7/16-20)
			(Extended Stack)	29	871-0010	1	Nut, Hex - Brass (#10-32)
	201-2159	1	15.0 kw 55D,57,57X,518	30	526-0260	2	Washer, Flat (Special)
			(Extended Stack)	31	232-0200	1	Washer - Cone Shaped
	201-2313	1	15.0 kw 53,53C,55D,57,57X,518 (Extended Stack)	32	853-0013	2	Washer, Lock (1/4" ET)
				33	809-0046	1	Screw, Sheet Metal - Round Head (#10 x 3/4")
			60 Hertz	34	856-0003	1	Washer, Lock (#10 EIT)
	201-2156	1	10 kw 3,3C,4,4X,5D,18	35	800-0004	2	Screw, Cap - Hex Head (1/4-20 x 5/8")
	201-2156	1	10 kw 9X				
	201-2157	1	10 kw 4,4X,5D,18	36	SCREW, MACHINE - ROUND HEAD (End Bell Cover Mounting)		
			(Extended Stack)				Sets Without Housing
	201-2311	1	10 kw 3,3C,4,4X,5D,18		812-0165	2	Sets Without Overspeed Switch (1/4-20 x 4-1/4")
			(Environmentally Protected)		812-0167	2	Sets With Overspeed Switch (1/4-20 x 6")
	201-2157	1	12.5 kw 3,3C,4,4X,5D,18,B,C,D,G,J,L		812-0165	2	Sets With Housing (1/4-20 x 4-1/2")
	201-2157	1	12.5 kw 9X,H	37	815-0194	6	Screw, Hex Head - Thread Cutting with ET (#10-32 x 3/8") Board (2) and Baffle (4) Mounting
	201-2158	1	12.5 kw 4,4X,5D,18				
			(Extended Stack)	38	800-0004	2	Screw, Cap - Hex Head (1/4-20 x 5/8")
	201-2312	1	12.5 kw 3,3C,4,4X,5D,18	39	812-0169	1	Screw, Machine - Round Head (1/4-20 x 5-1/2")
			(Environmentally Protected)	40	811-0098	1	Screw, Machine - Round Head (Brass) (#10-32 x 3/8")
	201-2158	1	15.0 kw 3,3C,4,4X,5D,18,B,C,D,J,L	41	STUD, ROTOR THROUGH		
	201-2158	1	15.0 kw 9X,H		520-0790	1	50 Hertz Sets
	201-2159	1	15.0 kw 4,4X,5D,18				60 Hertz Sets
			(Extended Stack)		520-0789	1	12.5JC Sets
	201-2313	1	15.0 kw 3,3C,4,4X,5D,18		520-0790	1	15.0JC Sets
			(Environmentally Protected)	42	234-0462	1	Baffle, Air
3	510-0112	1	*Bearing, Rotor	43	508-0112	1	Grommet, Rubber - Generator Adapter
4	232-2398	1	*Spacer, Bearing	44	508-0095	1	Grommet, Rubber - Air Baffle
5	201-2151	1	*Rotor, Exciter	45	515-0103	1	*Key, Fan to Rotor
6	515-0094	1	*Key, Exciter Rotor	46	232-2418	1	Board, Connection
7	870-0284	1	*Nut, Exciter Rotor Locking	47	231-0161	1	Adapter, Generator
8	205-0105	1	*Fan, Generator	48	234-0493	1	Cover Assembly, Air Outlet
10	526-0008	12	*Washer, Flat (13/64" ID x 7/16" OD x 1/32" Thk)	49	304-0500	1	Resistor, Tapped - Adjustable
11	870-0131	8	*Nut, Hex (#10-32)	50	232-2399	1	Bracket, Resistor Mounting
12	358-0069	1	*Rectifier Assembly - Positive	51	304-0006	2	Washer, Centering - Resistor Mounting
13	358-0070	1	*Rectifier Assembly - Negative				
14	853-0008	4	*Washer, Lock - ET (#10)				
15	813-0100	4	*Screw, Machine - Round Head (#10-32 x 1/2")				
16	211-0237	1	Bell, End				
17	220-2009	1	Stator, Exciter				
18	COVER, END BELL						
			Sets Without Housing				
	234-0185	1	Sets Without Generator Space Heater or Overspeed Switch				
	234-0498	1	Sets With Overspeed Switch				
	234-0542	1	Sets With Generator Space Heater				
	234-0543	1	Sets With Generator Space Heater and Overspeed Switch				
			Sets With Housing				
	234-0223	1	Sets Without Generator Space Heater				
	234-0541	1	Sets With Generator Space Heater				

* - Parts Included in Generator Rotor Assemblies.

CONTROL




XES 1133-2

CONTROL

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	301-1962	1	Box, Control	30	815-0236	4	Screw, Self Tapping - Hex Head (5/16-18 x 5/8")
2	PANEL, CONTROL			31	856-0008	4	Washer, Lock - EIT (5/16")
	301-1961	1	Sets Without Indicator Lamps	32	HARNES, WIRING		
	301-2376	1	Sets With 1 or 2 Indicator Lamps	338-0305	1	Control to Housing Start/Stop (Housed Sets)	
	301-3567	1	Sets With 3 Indicator Lamps	338-0495	1	Control to Output Box (Housed Sets)	
3	301-3683	1	Saddle, Control Box - Begin Spec AA	338-0337	1	High Air Temperature Switch (Sets With Vacu-Flo Cooling)	
4	WASHER, FIBER - Resistor Mounting			33	RELAY, LATCHING		
	508-0015	2	Sets Without Low Oil Pressure Switch	307-1129	1	Sets With High Air Temperature Switch or Overspeed Switch (Includes Leads)	
	508-0015	4	Sets With Low Oil Pressure Switch	307-1519	1	Sets With High Air Temperature Switch and Overspeed Switch (Includes Two Relays With Leads)	
5	RESISTOR, FIXED			34	PLUG, DOT BUTTON		
	304-0032	1	15 Ohm, 10 Watt	517-0019	1	1/2" Hole	
	304-0217	1	1 Ohm, 10 Watt - Sets with Low Oil Pressure Switch — Begin Spec G	517-0012	1	5/8" Hole	
6	307-0623	1	Relay, Ignition	517-0139	1	11/16" Hole	
7	RELAY, START SOLENOID			35	332-0052	1	Clip, Wire - Begin Spec AA
	307-1046	1	Spec A through Z	36	322-0072	2	Socket, Panel Light - Housed Sets
	307-0845	1	Begin Spec AA	37	321-0175	1	Holder, Fuse - Use Began Serial Number B780304257 During Spec AA
8	GROMMET, RUBBER - Output Box			38	321-0146	1	Fuse - 10 Amp - Use Began Serial Number B780304257 During Spec AA
	508-0117	1	Spec A through Z (1-3/8" Hole)	39	322-0069	As Req	Holder, Indicator Lamp - Sets With Indicator Lamp
	508-0183	1	Begin Spec AA (1-3/4" Hole)	40	322-0004	As Req	Lamp, Indicator - Sets With Indicator Lamp
9	308-0154	1	Switch, Start/Stop (Housed and Unhoused Sets)	41	308-0002	1	Switch, Panel Light - Housed Sets
10	308-0002	1	Switch, Selector (Manual or Electric Start)	42	322-0004	2	Lamp, Panel Light - Housed Sets
11	302-1366	1	Ammeter Kit, Charge (5-0-5) Includes Mounting Hardware	43	307-0597	1	Relay, Ignition Start - Spec A through Z
12	305-0673	1	Kit, Rectifier	44	BRACKET, CONTROL BOX MOUNTING (Left Hand) Spec A through Z		
13	305-0254	1	Bracket, Rectifier Mounting	301-1979	1	Unhoused Sets Without Switchboard Control	
14	337-0036	1	Strap, Ground - Control Box (Begin Spec AA)	301-1965	1	Unhoused Sets With Switchboard Control	
15	402-0078	4	Mount, Rubber - Control Box	45	301-1964	1	Bracket, Control Box Mounting (Right Hand) Spec A through Z
16	332-0537	1	Block, Terminal (4 Place)	46	332-0750	1	Kit, Polarity Marker - Used on Early Models
17	332-0566	1	Strip, Marker (4 Place)	47	416-0096	2	Clamp, Harness Support
18	332-0706	1	Block, Terminal (8 Place)	48	305-0197	1	Rectifier, Full Wave - Sets With Low Oil Pressure Switch (Spec A through F)
19	332-0739	1	Strip, Marker (8 Place)	49	308-0091	1	Switch, Reset - Sets With Low Oil Pressure Switch (Spec A through F)
20	320-0104	1	Limiter, Cranking - Sets With Low Oil Pressure Switch (Begin Spec G)	50	307-0614	1	Relay, Latching - Sets With Low Oil Pressure Switch (Spec A through F)
21	REGULATOR, VOLTAGE - Begin Spec AA (See Separate Group for Components)						
	305-0589	1	Sets Without Voltage Adjustment				
	305-0590	1	Sets With Voltage Adjustment				
22	815-0350	8	Screw, Hex Washer Head - Tapping (#10-32 x 3/8")				
23	COVER						
	301-1963	1	Control Box - Spec A through Z				
	301-3714	1	Voltage Regulator - Begin Spec AA				
24	BOX, OUTPUT						
	301-1978	1	Spec A through Z				
	301-3682	1	Begin Spec AA				
25	301-0856	1	Cover, Output Box				
26	508-0001	1	Grommet, Rubber (1-1/16" Hole)				
27	800-0024	4	Screw, Cap - Hex Head (5/16-18 x 1/2")				
28	850-0045	4	Washer, Lock - Spring (5/16")				
29	526-0115	4	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)				

VOLTAGE REGULATOR—BEGIN SPEC AA



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	REGULATOR, VOLTAGE		
	305-0589	1	Without Voltage Adjustment (Includes Parts Marked *)
	305-0590	1	With Voltage Adjustment (Includes Parts Marked #)
1	300-1540	1	*#Board, Voltage Regulator - Begin Spec AB (Replaces 300-1006 Board Used Begin Spec AA through Serial Number F760142041 During Spec AA and 300-1404 Board Begin Serial Number F760142042 During Spec AA Until Spec AB) Refer to Printed Circuit Board Parts Catalog Number 900-0234 for Board Components
2	815-0190	4	*#Screw, Tapping - Round Head (#8-32 x 3/8")
3	853-0005	4	*#Washer, Lock - ET (#8)
4	320-0505	1	*#Breaker, Circuit
5	812-0070	4	*#Screw, Machine - Round Head (#6-32 x 1-1/4")

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
6	870-0183	4	*#Nut, Hex - With ET (#6-32)
7	315-0391	1	*#Reactor
8	315-0386	1	*#Transformer, Voltage
9	517-0045	1	*#Plug, Dot Button
10	812-0027	1	*#Screw, Machine - Round Head (#4-40 x 1/4")
11	853-0001	1	*#Washer, Lock - ET (#4)
12	860-0003	1	*#Nut, Hex (#4-40)
13	812-0063	2	*#Screw, Machine - Round Head (#6-32 x 1/2")
14	870-0183	2	*#Nut, Hex - With ET (#6-32)
15	332-1647	1	*#Block, Terminal
16	301-3713	1	*#Panel, Mounting
17	HARNESS, WIRING - Voltage Regulator to Exciter Stator		
	338-0744	1	Sets Without Overspeed Switch
	338-0917	1	Sets With Overspeed Switch
18	332-0942	8	*#Tie, Cable
19	303-0103	1	#Rheostat
20	303-0194	1	#Knob

* - Parts Included in 305-0589 Voltage Regulator Without Adjustment.

- Parts Included in 305-0590 Voltage Regulator With Adjustment.

SERVICE KITS AND MISCELLANEOUS


NOTE: For other kits refer to the related group.

PART NO.	QTY. USED	PART DESCRIPTION
98-1100	1	Decal Kit
168-0084	1	Gasket Kit, Generator Set
OVERHAUL KIT, GENERATOR SET		
522-0199	1	Spec A through Q
522-0235	1	Begin Spec R
PAINT, TOUCH-UP (13 oz. Pressurized Can)		
525-0137		Metallic Green
525-0305		Non-Metallic Green
525-0454		Greige - Enamel

SPECIAL PARTS SECTION

PENNSYLVANIA APPROVED GENERATOR SETS


CRANKSHAFT AND FLYWHEEL - SPEC A THROUGH Q



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	104-0477	1	Crankshaft
2	134-1446	1	Flywheel Assembly - Includes Hub and Mounting Hardware



GEARCASE - SPEC A THROUGH Q

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	103-0252	1	Gearcase Assembly
2	103-0231	1	Gasket, Gearcase
3	103-0225	1	Backplate, Gearcase



STARTER - SPEC A THROUGH Q


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	191-0453	1	Starter - Includes Pinion Gear and Pin (See Separate Group for Components)
2	191-0342	1	Base and Shaft, Idler Gear
3	518-0196	1	Ring, Retaining - Idler Gear
4	526-0175	1	Washer, Thrust - Idler Gear
5	191-0457	1	Gear Assembly, Idler
6	191-0354	1	Gear and Clutch Assembly, Crankshaft
7	509-0093	1	Seal, "O" Ring - Starter Mounting
8	338-0335	1	Harness, Starter to Control



SPECIAL PARTS SECTION

PENNSYLVANIA APPROVED GENERATOR SETS

STARTER PARTS - SPEC A THROUGH Q




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	191-0453	1	Starter
1	191-0452	1	Armature
2	191-1017	1	Coil Assembly, Field
3	191-0513	1	Brush Set, Service
4	191-1018	1	Head Assembly, Commutator End
5	191-1020	1	Spring, Brush (Set of 4)
6	191-1021	1	Washer, Armature Thrust (Package) Use as required.
7	191-1022	1	Stud, Terminal (Package)
8	191-0450	1	Gear, Pinion
9	516-0154	1	Pin, Pinion Gear
10	191-0451	1	Spacer, Armature to Adapter
11	191-0448	1	Adapter
12	191-0329	1	Bushing, Adapter
13	509-0092	1	Seal, Oil Armature Shaft - Front
14	509-0093	1	Seal, "O" Ring Starter Motor Mounting

SPECIAL PARTS SECTION

PENNSYLVANIA APPROVED GENERATOR SETS

CONTROL - SPEC A THROUGH Z



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	307-0773	1	Relay - Start Disconnect and Ignition
2	308-0005	1	Switch
3	307-0860	1	Relay, Field Build-up
4	323-0321	1	Socket, Relay
5	307-0778	1	Spring, Hold-down - Relay

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
6	332-0751	1	Block, Terminal (10 Place)
7	332-1235	1	Strip, Marker (10 Place)
8	307-0845	1	Solenoid, Start - Begin Spec L
9	306-0195	1	Bracket, Solenoid Mounting
10	332-0052	1	Clip, Tinnerman

OIL BASE - BEGIN SPEC K



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	CUSHION, VIBRATION (Cone Shaped) Generator End		
	402-0287	2	Vacu-Flo Cooled Sets and Sets not Housed or Skid Mounted
	402-0286	2	Housed and Skid Mounted Sets


FUEL SYSTEM (GAS, GAS-GASOLINE AND LPG) (NOT ILLUSTRATED)

PART NO.	QTY. USED	PART DESCRIPTION
149-0558	1	Strainer
307-0312	1	Valve, Fuel
416-0325	1	Hydrometer

OPTIONAL PARTS SECTION


This section contains illustrated parts listings of factory installed options. Options may not be applicable to all models; for field conversions additional parts are usually required.

OIL BATH AIR CLEANER — OPTIONAL



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	140-0500	1	Cleaner, Air
2	140-0519	1	Band, Air Cleaner
3	503-0274	2	Clamp, Hose
4	503-0444	1	Hose, Air Cleaner
5	140-0645	1	Adapter, Air Cleaner
6	800-0003	2	Screw, Cap - Hex Head (1/4-20 x 1/2")
7	850-0040	2	Washer, Lock - Spring (1/4")
8	862-0001	2	Nut, Hex (1/4-20)
9	800-0015	1	Screw, Cap - Hex Head (1/4-20 x 3")
10	800-0007	1	Screw, Cap - Hex Head (1/4-20 x 1")
11	850-0040	1	Washer, Lock - Spring (1/4")
12	140-0584	1	Gasket, Adapter Mounting
13	526-0108	1	Washer, Flat (17/64" ID x 7/16" OD x 1/32" Thk)


CONTRACTOR AIR CLEANER - OPTIONAL



FS 1264

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	140-0645	1	Adapter, Air Cleaner Hose
2	800-0015	1	Screw, Cap - Hex Head (1/4-20 x 3")
3	526-0108	1	Washer, Flat (17/64" ID x 7/16" OD x 1/32" Thk)
4	800-0007	1	Screw, Cap - Hex Head (1/4-20 x 1")
5	850-0040	1	Washer, Lock - Spring (1/4")
6	503-0274	4	Clamp, Hose
7	503-0330	1	Hose, Connector (Rubber) - 2" Long
8	140-0740	1	Tube, Air Induction
9	503-0419	1	Elbow (Rubber)
10	140-0721	1	Cleaner, Air (Includes Element and Baffle)
11	140-0722	2	Band, Air Cleaner Mounting
12	140-1271	1	Bracket, Air Cleaner Mounting
13	140-0723	1	Pre-Cleaner, Air Cleaner
14	140-0765	1	Element, Air Cleaner
15	800-0024	4	Screw, Cap - Hex Head (5/16-18 x 1/2")
16	850-0045	4	Washer, Lock - Spring (5/16")
17	862-0015	4	Nut, Hex (5/16-18)
18	140-1267	1	Baffle, Air Cleaner


DAY TANK — OPTIONAL



FS 1394

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	TANK, DAY			8	502-0053	2	Elbow, Male - 45° (Brass) Solenoid Valve to Carburetor Line (1) and Day Tank to Fuel Pump Line (1)
	159-0294	1	One Quart				
	159-0746	1	Two Quart	9	502-0082	1	Nipple, Hex - 1/8" (Brass)
2	159-0705	1	Reducer, Restricted	10	505-0057	2	Plug, Pipe - Square Head (1/8")
3	BRACKET, MOUNTING			11	502-0002	2	Elbow, Inverted Flare - 90° (Brass) Fuel Pump and Carburetor Inlet - Begin Spec J
	159-0759	1	One Quart				
	159-0826	1	Two Quart	12	504-0007	1	Valve, Fuel Pump Inlet
4	BAND, MOUNTING			13	800-0005	2	Screw, Cap - Hex Head (1/4-20 x 3/4")
	159-0121	1	One Quart				
	159-0825	1	Two Quart	14	850-0040	2	Washer, Lock - Spring (1/4")
5	159-0761	2	Spacer, Mounting - Bracket to Rocker Cover	15	860-0013	2	Nut, Hex (1/4-20)
6	307-0565	1	Valve, Solenoid	16	800-0039	2	Screw, Cap - Hex Head (5/16-18 x 3-1/2")
7	LINE, FUEL			17	850-0045	2	Washer, Lock - Spring (5/16")
	501-0005	1	Main Tank to Day Tank				
	501-0008	2	Day Tank to Fuel Pump (1) and Day Tank to Carburetor (1)				

FUEL TANK (HOUSED SETS) — OPTIONAL




FS 1395

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	159-0799	1	Tank Assembly, Fuel - Complete (Includes All Listed Parts)
1	159-0788	1	Tank, Fuel - 15 Gallon
2	159-0786	2	Strap, Mounting
3	159-0789	2	Bracket, Support
4	159-0787	2	Strap, Hold-down
5	159-0512	1	Cap and Indicator
6	504-0004	1	Valve, Shutoff
7	501-0007	1	Line, Fuel - Flexible (24")
8	159-0751	1	Gasket, Fuel Cap
9	307-0565	1	Valve, Fuel Solenoid
10	336-1424	1	Lead - Control to Fuel Solenoid Valve
11	332-0050	1	Clip, Fuel Line
12	502-0082	1	Nipple, Hex - 1/8" (Brass)
13	505-0057	1	Plug, Pipe (1/8")
	HARDWARE, MOUNTING - Not Illustrated		
	800-0009	4	Screw, Cap - Hex Head (1/4-20 x 1-1/2")
	821-0010	8	Screw, Locking Head (1/4-20 x 7/8")
	850-0040	4	Washer, Lock - Spring (1/4")



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
8	505-0128	1	Bushing, Reducer (1-1/4" x 3/8") Algas Regulator
9	148-0107	1	Vent, Regulator
10	504-0007	1	Valve, Fuel Pump Inlet - Gas- Gasoline Sets
11	307-0615	1	Primer Assembly, Solenoid (Algas Regulator)
12	149-0638	1	Plate, Fuel Pump Hole - Gas and LPG Sets
13	505-0057	1	Plug, Pipe - Square Head (1/8") Garretson Regulator
14	143-0231	1	Spring, Wire - Choke Stop (Gas - Gasoline Sets)
15	502-0020	1	Elbow, Street (90°) Brass (Fuel Pump Inlet) Gas - Gasoline Sets
16	502-0002	1	Elbow, Inverted Male - Brass (Fuel Pump Outlet) Gas - Gasoline Sets


FUEL SYSTEM (LPG AND NATURAL GAS) - OPTIONAL



865C

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0626	1	Valve, Control (Propane Inlet)	14	148-0311	1	Regulator, Gas
2	148-0627	1	Switch, Pressure	15	502-0002	1	Elbow, Inverted Male (1/4" Tube x 1/8" Pipe)
3	505-0007	2	Reducer (1/4" to 1/8")	16	503-1559	1	Hose, Gas Fuel (1/2" ID x 43")
4	505-0020	1	Reducer (3/4" to 1/4")	17	501-0005	1	Hose, Fuel (3/16" ID x 18-1/2")
5	505-0302	1	Nipple, Half (1/4" x 1-1/2")	18	508-0071	1	Grommet, Rubber (7/8" Hole)
6	505-0017	1	Reducer (3/8" x 1/4")	19	821-0018	2	Screw, Self-Locking - Hex Washer Head (1/4-20 x 5/8")
7	505-0166	2	Tee, Pipe (3/4")	20	870-0212	4	Nut, Locking (1/4-20)
8	110-0810	1	Bracket	21	821-0011	2	Screw, Self-Locking - Hex Washer Head (1/4-20 x 7/8")
9	505-0129	1	Reducer (1" x 3/4")	22	140-1753	1	Bracket, Mounting
10	307-0312	2	Valve, Magnetic - 12 VDC	23	503-0183	1	Clamp, Hose (#10)
	307-0829	1	Kit, Coil - Replacement (For above valve)	24	370-4008	2	Spacer
11	505-0102	5	Nipple, Pipe (3/4" x 1-3/8")	25	502-0020	1	Elbow, Street - 90° (1/8")
12	505-0132	1	Elbow - 90° (3/4")				
13	505-0120	2	Elbow, Street - 90° (3/8")				

HIGH AIR TEMPERATURE SWITCH - OPTIONAL




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	SWITCH, HIGH AIR TEMPERATURE 309-0196	1	*Sets Without High Air Temperature Indicator Lamp
	309-0206	1	*Sets With High Air Temperature Indicator Lamp
2	309-0195	1	*Bracket, Mounting
3	508-0126	4	*Washer, Insulating
4	508-0127	1	*Insulator, Sleeving
5	526-0021	1	*Washer, Flat (17/64" ID x 3/4" OD x 1/16" Thk)
6	856-0006	1	*Washer, Lock - EIT (1/4")
7	862-0001	1	*Nut, Hex (1/4-20)
8	332-0876	1	*Terminal, Ground
9	812-0076	2	#Screw, Machine - Round Head (#8-32 x 5/16")
10	870-0221	2	#Nut, Hex - With ET (#8-32)
11	338-0337	1	#Harness, Wiring
12	SWITCH, HIGH AIR TEMPERATURE 309-0162	1	‡Used on Air Duct and Shutter - Spec A through K (External Springs) Used on Vacu-Flo Cooling Scroll
	309-0162	1	# Sets Without High Air Temperature Indicator Lamp
	309-0171	1	# Sets With High Air Temperature Indicator Lamp

* - Sets with Switch Mounted on Exhaust Manifold.

- Sets with Switch Mounted on Vacu-Flo Cooling Scroll.

‡ - Sets with Switch Mounted on Air Duct and Shutter - Spec A through K (External Springs).


VACU-FLO COOLING — OPTIONAL



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	CONVERSION KIT, FIELD — Vacu-Flo Cooling		
	134-1832	1	Spec A through Q
	134-1939	1	Begin Spec R
1	134-1521	1	Scroll Assembly (Includes Parts Marked *)
2	895-0126	1	*Stripping, Seal
3	134-3081	1	*Guard, Scroll Outlet
4	815-0421	4	*Screw, Sheet Metal - Hex Head With ET (#10-16 x 1/2")
5	508-0002	1	Grommet, Rubber (1/2" Hole) High Air Temperature Switch Leads
6	517-0112	2	Plug, Plastic (1" Hole)
7	508-0117	1	Grommet, Rubber (1" Hole) Governor Adjust Opening
8	517-0021	3	Plug, Dot Button (7/8" Hole) Scroll Mounting Opening
9	517-0150	1	Plug, Nylon (1-3/16" Hole) Scroll Center Opening

* - Parts Included in 134-1521 Scroll Assembly.

AIR DUCT — OPTIONAL





M 1153-1

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	134-3756	1	Duct Kit, Air (Includes Parts Marked *)
2	870-0178	3	*Nut, Speed - Sheet Metal (1/4-20)
3	853-0013	3	*Washer, Lock - ET (1/4")
4	815-0235	3	*Screw, Cap - Hex Head, Pointed End (1/4-20 x 5/8")
5	508-0002	1	*Grommet, Rubber (1/2" Hole)
6	154-0738	1	*Gasket, Exhaust
7	134-1375	1	*Plate, Exhaust
8	850-0050	2	*Washer, Lock - Spring (3/8")

* - Parts Included in 134-3756 Air Duct Kit.

AIR DUCT AND SHUTTER (HOUSED SETS) — OPTIONAL



AIR DUCT AND SHUTTER (HOUSED SETS) — OPTIONAL

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	134-3754	1	Duct and Shutter Kit, Air - Complete Replacement for Sets With Air Duct and Shutter Assembly With External or Internal Springs (Includes Parts Marked *)	22	815-0194	8	*Screw, Cap - Hex Head With ET (#10-32 x 3/8")
2	134-3756	1	*Duct Kit, Air (NOTE: Cannot be used on early model shutter assembly with external shutter pivot springs) Includes Parts Marked #.	23	813-0097	2	*Screw, Machine - Round Head (#10-32 x 5/16")
3	134-2411	2	*Bracket and Pivot, Shutter	24	821-0010	4	*Screw, Cap - Hex Head Locking (1/4-20 x 1/2")
4	134-1802	1	*Bracket and Pivot, Shutter and Rod	25	526-0113	1	*Washer, Flat - Actuating Arm Bearing
5	134-1801	1	*Bracket and Pivot, Shutter and Spring	26	853-0008	2	*Washer, Lock - ET (#8)
6	SHUTTER, AIR OUTLET			27	853-0016	1	*Washer, Lock - ET (5/16")
	134-1237	2	+Spec A through K	28	856-0006	4	*Washer, Lock - EIT (1/4")
	134-1614	2	*£Begin Spec L	29	862-0015	1	*Nut, Hex (5/16-18)
7	150-1358	1	*£Joint, Ball	30	870-0131	9	*Nut, Hex - ET (#10-32)
8	134-1606	1	*£Rod, Shutter Control (Upper)	31	526-0175	2	*Washer, Flat (41/64" ID x 29/32" OD x 1/16" Thk) Vernatherm Element to Spring
9	134-1607	1	*£Rod, Shutter Control (Lower)	32	870-0053	1	*Nut, Hex (#10-32)
10	BEARING			33	815-0235	3	*Screw, Cap - Hex Head (1/4-20 x 5/8")
			Sets With Internal Shutter Springs	34	853-0013	3	*Washer, Lock - ET (1/4")
	134-2900	4	* Shutter	35	870-0178	3	*Nut, Speed (1/4-20)
	134-1248	2	* Actuating Arm	36	BRACKET AND PIVOT - Sets With External Shutter Springs		
			Sets With External Shutter Springs		134-1242	3	+Spec A through K Begin Spec L
	134-1248	4	+ Spec A through K		134-1242	2	£ Without Control Rod Bracket
	134-1248	6	£ Begin Spec L		134-1612	1	£ With Control Rod Bracket
11	BRACKET AND GUIDE, VERNATHERM			37	BRACKET, SHAFT AND PIN - Sets With External Shutter Springs		
	134-1244	1	+Spec A through K		134-1238	1	Spec A through K
	134-1610	1	*£Begin Spec L		134-1611	1	Begin Spec L
12	134-0656	1	*£+Spring, Vernatherm Element	38	134-1247	1	+Rod, Shutter Control
13	309-0085	1	*£+Element, Vernatherm	39	134-1437	2	£+Spring, External - Shutter Pivot
14	134-0658	1	*£+Spring, Shutter Return - Lower	40	850-0050	2	*Washer, Lock - Spring (3/8") Engine Air Outlet Duct
15	134-1817	1	*Spring, Shutter Return - Upper	41	508-0002	1	*Grommet, Rubber (1/2" Hole) Air Duct
16	CLIP, ROD END						
	518-0004	1	*£+Right Side				
	518-0006	2	*£Left Side - Begin Spec L				
17	134-1605	1	*£Shaft, Actuating Arm				
18	134-1604	1	*£Arm, Actuating				
19	WASHER, FLAT - Begin Spec L						
	526-0213	1	*21/64" ID x 1" OD x 1/8" Thk - Sets With Internal Shutter Springs				
	526-0045	1	*£21/64" ID x 5/8" OD x 1/8" Thk - Sets With External Shutter Springs				
20	134-1375	1	*£#Plate, Exhaust Outlet				
21	154-0738	1	*£#Gasket, Exhaust Outlet Plate				


* - Parts Included in 134-3754 Air Duct and Shutter Kit (With Internal Shutter Springs)

- Parts Included in 134-3756 Air Duct Kit

+ - Parts that apply to Air Duct and Shutter Assembly with External Shutter Springs used Spec A through K. For complete replacement order 134-3754 Air Duct and Shutter Kit.

£ - Parts that apply to Air Duct and Shutter Assembly with External Shutter Springs used begin Spec L until the use of Air Duct and Shutter Assembly with internal shutter springs. For complete replacement order 134-3754 Air Duct and Shutter Kit.

HOUSING AND SKID BASE — OPTIONAL




M 1353

HOUSING AND SKID BASE — OPTIONAL

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	HOUSING KIT, CONVERSION		
	405-2248	1	With Duct, Without Meter Panel
	405-2249	1	With Duct and Shutters, Without Meter Panel
	405-2247	1	With Duct and Meter Panel
	405-2255	1	With Duct and Shutters, and Meter Panel
1	403-0661	1	Base, Skid
2	PANEL, FRONT - UPPER (Engine End)		
	405-1323	1	Sets Without Oil Bath Air Cleaner
	405-1651	1	Sets With Oil Bath Air Cleaner
3	405-1333	1	Panel, Front - Lower (Engine End)
4	PANEL, REAR (Generator End)		
	405-1322	1	Sets WITHOUT Meter Panel
	405-1331	1	Sets WITH Meter Panel
5	PANEL, DOOR - REAR END		
	405-1329	1	Sets WITHOUT Meter Panel
	405-1332	1	Sets WITH Meter Panel
6	405-1330	1	Panel, Generator Access
7	405-1326	1	Panel, Top
8	PANEL, RIGHT SIDE		
	405-1342	1	Sets WITHOUT Shutters
	405-1352	1	Sets WITH Shutters
9	405-1325	1	Panel, Left Side
10	405-1327	1	Rail, Stiffener - Right Side
11	405-1328	1	Rail, Stiffener - Left Side
12	405-1341	2	Bracket, Stiffener Rail
13	416-0501	2	Bracket, Battery Support
14	416-0502	1	Frame, Battery Hold-down
15	406-0002	1	Knob, Rear End Door Panel
16	406-0105	2	Fastener, Housing Hold-down
17	405-1138	2	Pin, Shoulder - Rear End Panel
18	405-1139	2	Spring, Shoulder Pin - Rear End Panel
19	526-0115	2	Washer, Flat (11/32" ID x 11/16 OD x 1/16" Thk)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
20	516-0039	2	Pin, Cotter (3/32 x 5/8")
21	520-0490	2	Stud, Battery Hold-down (5/16 x 8-13/16")
22	DUCT, EXHAUST MANIFOLD (See Separate Group for Components)		
	134-3756	1	Sets Without Shutters
	134-3754	1	Sets With Shutters
23	405-1181	2	Stop, Door
24	503-0423	1	Hose, Flexible - Generator Air Duct
25	336-0476	1	Strap, Ground - Engine to Frame
26	895-0104	1	Stripping, Foam Weather - (76")
27	BAND, MUFFLER		
	140-0631	2	Used for Mounting 155-0456 (Standard) Muffler
	140-0078	2	Used for Mounting 155-0360 (Critical) Muffler
28	SCREW, CAP - HEX HEAD		
	800-0003	5	1/4-20 x 1/2"
	800-0025	12	5/16-18 x 5/8"
	821-0010	32	1/4-20 x 1/2" (Self-Locking)
	815-0181	14	#10-32 x 1/2" (Thread Cutting With ET)
29	862-0015	18	Nut, Hex (5/16-18)
30	WASHER, LOCK - SPRING		
	850-0045	14	5/16"
	850-0040	5	1/4"
	850-0030	20	#10
31	526-0115	10	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)
32	813-0098	20	Screw, Machine - Round Head (#10-32 x 3/8")
33	870-0110	24	Nut, Speed (1/4-20)
34	405-1674	1	Shield, Rain
35	134-1375	1	Plate, Exhaust Outlet Cover

SKID AND BATTERY RACK — OPTIONAL




M-1134

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	403-0661	1	Skid
2	416-0502	1	Frame, Battery
3	526-0115	2	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)
4	520-0490	2	Stud, Battery Frame
5	850-0045	2	Washer, Lock - Spring (5/16")
6	862-0015	6	Nut, Hex (5/16-18)


CARBURETOR AIR HEATER (SPEC A THROUGH N) — OPTIONAL (GASOLINE SETS)

NOTE: For complete replacement refer to Carburetor Air Heater Group Begin Spec P — Order by carburetor air heater kit number.



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	815-0048	4	Screw, Round Head - Self Tapping (#10-32 x 3/8")
2	140-0650	1	Cover, Air Cleaner (Hot Air)
3	140-0654	1	Box, Air Outlet (Shutter)
4	140-0658	1	Cover, Air Cleaner Pan
5	503-0004	2	Clamp, Hose
6	503-0397	1	Hose, Hot Air
7	854-0010	4	Washer, Lock - IT (#10)


VOLTAGE REGULATOR FILTER - OPTIONAL



ES1130

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	813-0098	6	Screw, Machine - Round Head (#10-32 x 3/8")	12	304-0292	2	Insulator, Resistor
2	850-0030	6	Washer, Lock - Spring (#10)	13	870-0053	2	Nut, Hex (#10-32)
3	232-2463	1	Cover, Housing	14	304-0120	2	Resistor, Fixed (2 Ohm, 25 Watt)
4	815-0001	4	Screw, Machine - Binding Head Brass (#6-32 x 1/4")	15	812-0079	4	Screw, Machine - Round Head (#8-32 x 1/2")
5	853-0003	4	Washer, Lock - ET (#6)	16	850-0025	4	Washer, Lock - Spring (#8)
6	860-0006	4	Nut, Hex (#6-32)	17	860-0008	4	Nut, Hex (#8-32)
7	332-1279	4	Terminal, Lug	18	312-0198	2	Bracket, Mounting - Capacitor
8	338-1165	1	Harness, Wiring	19	312-0197	1	Capacitor
9	508-0071	1	Grommet, Rubber	20	232-2462	1	Housing, Filter
10	813-0112	2	Screw, Machine - Round Head (#10-32 x 2-1/2")	21	332-0942	2	Tie, Cable
11	304-0015	4	Washer, Centering		625-1304	—	Diagram, Wiring


AC METER PANEL (HOUSED SETS) — OPTIONAL



AC METER PANEL (HOUSED SETS) — OPTIONAL

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	PANEL, METER — Begin Spec AA (Spec A through Z Supply Complete Model, Specification Number and Serial Number)			6	BREAKER, CIRCUIT (Select According to Existing Breaker)		
			120/208 Volt				Single Pole
	301-2088	1	Sets Without Frequency Meter and Running Time Meter	320-0150	As Req.	20 Amp, 480 Volt	
	301-2204	1	Sets With Frequency Meter and Running Time Meter	320-0019	As Req.	25 Amp, 120/240 Volt	
			120/240 Volt	320-0151	As Req.	25 Amp, 480 Volt	
			Single Phase Sets	320-0020	As Req.	35 Amp, 120/240 Volt	
	301-1554	1	Sets Without Frequency Meter and Running Time Meter	320-0153	As Req.	40 Amp, 120/240 Volt	
	301-2288	1	Sets With Frequency Meter and Running Time Meter	320-0198	As Req.	45 Amp, 120/240 Volt	
			Three Phase Sets	320-0052	As Req.	50 Amp, 120/240 Volt	
	301-2088	1	Sets Without Frequency Meter and Running Time Meter	320-0195	As Req.	55 Amp, 120/240 Volt	
	301-2204	1	Sets With Frequency Meter and Running Time Meter	320-0021	As Req.	60 Amp, 120/240 Volt	
			220/380 Volt	320-0366	As Req.	65 Amp, 120/240 Volt	
	301-2373	1	Sets Without Frequency Meter and Running Time Meter	320-0148	As Req.	70 Amp, 120/240 Volt	
	301-2308	1	Sets With Frequency Meter and Running Time Meter	320-0367	As Req.	75 Amp, 120/240 Volt	
			240/416 Volt	320-0251	As Req.	100 Amp, 120/240 Volt	
	301-2308	1	Sets With Frequency Meter and Running Time Meter				Three Pole Companion
			277/480 Volt	320-0514	As Req.	15 Amp, 600 Volt	
	301-2373	1	Sets Without Frequency Meter and Running Time Meter	320-0486	As Req.	20 Amp, 480 Volt	
	301-2308	1	Sets With Frequency Meter and Running Time Meter	320-0459	As Req.	20 Amp, 600 Volt	
			347/600 Volt	320-0487	As Req.	25 Amp, 480 Volt	
	301-3736	1	Sets With Frequency Meter and Running Time Meter	320-0488	As Req.	30 Amp, 480 Volt	
			Broad Range Sets	7	AMMETER, AC (Select According to Scale)		
	301-3732	1	Sets With Frequency Meter and Running Time Meter	302-0460	As Req.	Scale Reads 0-20	
2	308-0012	1	Switch, Selector - Voltmeter (3 Phase Sets)	302-0418	As Req.	Scale Reads 0-30	
3	303-0076	1	Knob, Selector Switch - 3 Phase Sets	302-0444	As Req.	Scale Reads 0-35	
4	RESISTOR, FIXED			302-0419	As Req.	Scale Reads 0-50	
	304-0305	1	277/480 Volt Sets (45,000 Ohm, 10 Watt)	302-0458	As Req.	Scale Reads 0-80	
	304-0536	1	600 Volt Sets (9,000 Ohm, 50 Watt)	302-0410	As Req.	Scale Reads 0-150	
5	BAR, CIRCUIT BREAKER TIE			8	VOLTMETER, AC (Select According to Scale)		
	320-0187	1	Sets With 3 Circuit Breakers	302-0420	1	Scale Reads 0-150	
	320-0202	1	Sets With 2 Circuit Breakers	302-0421	1	Scale Reads 0-300	
				302-0612	1	Scale Reads 0-500	
				302-0422	1	Scale Reads 0-600	
				302-0423	1	Scale Reads 0-750	
				9	METER, FREQUENCY (Check Meter Face for Part Number)		
							50 Hertz
				302-0234	1	100-150 Volt	
				302-0256	1	200-250 Volt	
				302-0825	1	480 Volt	
				302-0788	1	600 Volt	
							60 Hertz
				302-0213	1	100-150 Volt	
				302-0221	1	200-250 Volt	
				302-0716	1	480 Volt	
				302-0717	1	600 Volt	
				10	METER, RUNNING TIME (Check Meter Face for Part Number)		
							50 Hertz
				302-0468	1	120 Volt	
				302-0469	1	240 Volt	
				302-0470	1	480 Volt	
							60 Hertz
				302-0465	1	120 Volt	
				302-0466	1	240 Volt	
				302-0467	1	480 Volt	
				11	301-2395	1	Bracket, Panel Stop - Broad Range Sets
				12	301-2727	1	Handle, Control Panel - Broad Range Sets
				13	322-0044	2	Light, Neon Pilot - Red Lens (Indicates 1 Phase or 3 Phase in Operation) Broad Range Sets
				14	308-0203	1	Switch, Selector - Output Phase (Broad Range Sets)
				15	302-0448	1	Plate, Meter Face (Used on Early Style Round Meters)

SWITCHBOARD CONTROL (UNHOUSED SETS) — OPTIONAL




SWITCHBOARD CONTROL (UNHOUSED SETS) — OPTIONAL

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	PANEL, INSTRUMENT - Begin Spec AA (Spec A through Z Supply Complete Model, Specification Number and Serial Number)		
	301-8776		120 Volts
			120/208 Volts
	301-2077	1	Sets Without Frequency Meter and Running Time Meter
	301-2099	1	Sets With Frequency Meter and Running Time Meter
			120/240 Volt
			Single Phase Sets
	301-2085	1	Sets Without Frequency Meter and Running Time Meter
	301-2086	1	Sets With Frequency Meter and Running Time Meter
			Three Phase Sets
	301-2077	1	Sets Without Frequency Meter and Running Time Meter
	301-2099	1	Sets With Frequency Meter and Running Time Meter
	301-2116	1	220/380 Volts
	301-2116	1	277/480 Volts
	301-2681	1	347/600 Volts
	301-3741	1	Broad Range Sets
2	BOX, INSTRUMENT		
	301-2027	1	All Except Broad Range Sets
	301-2304	1	Broad Range Sets
3	BOX ASSEMBLY (Meter or Circuit Breaker) (Not used on all models)		
	301-0500	1	Sets With One Meter (Includes Parts Marked *)
	301-0994	1	Sets With Two Meters (Includes Parts Marked *)
	320-0458	1	Sets With Circuit Breaker Enclosure
4	508-0008	1	*Grommet, Rubber (13/16" Hole)
5	850-0030	2	*Washer, Lock - Spring (#10)
6	811-0098	2	*Screw, Machine - Round Head Brass (10-32 x 3/8")
7	508-0009	1	Grommet, Rubber (1-3/8" Hole)
8	304-0536	1	Resistor - Running Time Meter (600 Volt Sets) 9000 Ohm, 50 Watt
9	308-0012	1	Switch, Selector - Voltmeter (3 Phase Sets)
10	301-2076	1	Bracket, Mounting - Instrument Box (Bottom) Spec A through Z
11	322-0044	2	Light, Neon Pilot — Red Lens (Indicates 1 Phase or 3 Phase in Operation) Broad Range Sets
12	308-0203	1	Switch, Selector - Output Phase (Broad Range Sets)
13	BAR, CIRCUIT BREAKER TIE		
	320-0187	1	Sets With 3 Circuit Breakers
	320-0202	1	Sets With 2 Circuit Breakers

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
14	AMMETER, AC (Select According to Scale)		
	302-0460	As Req.	Scale Reads 0-20
	302-0418	As Req.	Scale Reads 0-30
	302-0444	As Req.	Scale Reads 0-35
	302-0419	As Req.	Scale Reads 0-50
	302-0458	As Req.	Scale Reads 0-80
	302-0410	As Req.	Scale Reads 0-150
15	METER, FREQUENCY (Select According to Hertz and Volts)		
			50 Hertz
	302-0234	1	100-150 Volt
	302-0256	1	200-250 Volt
	302-0893	1	208 Volt
	302-0825	1	480 Volt
	302-0788	1	600 Volt
			60 Hertz
	302-0213	1	100-150 Volt
	302-0221	1	200-250 Volt
	302-0809	1	208 Volt
	302-0716	1	480 Volt
	302-0717	1	600 Volt
16	VOLTMETER, AC (Select According to Scale)		
	302-0420	1	Scale Reads 0-150
	302-0421	1	Scale Reads 0-300
	302-0612	1	Scale Reads 0-500
	302-0422	1	Scale Reads 0-600
	302-0423	1	Scale Reads 0-750
17	METER, RUNNING TIME (Check Existing Meter for Part Number)		
			50 Hertz
	302-0468	1	120 Volt
	302-0469	1	240 Volt
	302-0470	1	480 Volt
			60 Hertz
	302-0465	1	120 Volt
	302-0466	1	240 Volt
	302-0467	1	480 Volt
18	BREAKER, CIRCUIT (Select According to Existing Breaker)		
			Single Pole
	320-0020	As Req.	35 Amp, 120/240 Volt
	320-0153	As Req.	40 Amp, 120/240 Volt
	320-0198	As Req.	45 Amp, 120/240 Volt
	320-0052	As Req.	50 Amp, 120/240 Volt
	320-0195	As Req.	55 Amp, 120/240 Volt
	320-0021	As Req.	60 Amp, 120/240 Volt
	320-0366	As Req.	65 Amp, 120/240 Volt
	320-0148	As Req.	70 Amp, 120/240 Volt
	320-0367	As Req.	75 Amp, 120/240 Volt
	320-0251	As Req.	100 Amp, 120/240 Volt
	320-0357	As Req.	125 Amp, 120 Volt
			Three Pole Companion
	320-0514	As Req.	15 Amp, 600 Volt
	320-0486	As Req.	20 Amp, 480 Volt
	320-0459	As Req.	20 Amp, 600 Volt
	320-0487	As Req.	25 Amp, 480 Volt
	320-0488	As Req.	30 Amp, 480 Volt
19	303-0076	1	Knob, Selector Switch - 3 Phase Sets
20	302-0079	1	Transformer (120V, 1 Phase Sets)

* - Parts Included in Meter Box Assemblies.

MISCELLANEOUS OPTIONAL PARTS



M 1142-1

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	309-0270	1	Thermostat, Low Engine Temperature
2	155-0360	1	Muffler, Critical - Housed Sets
3	102-0558	1	Heater, Oil Base
4	331-0041	2	Nut, Lock (1/2") Begin Spec AA
5	333-0184	1	Heater, Generator Space - Begin Spec AA
6	148-0367	1	Switch, Vacuum - Gas and Gas-Gasoline Sets Begin Spec B
7	SCREW 813-0100	2	Machine - Round Head (#10-32 x 1/2") Spec A through Z
	800-0003	2	Cap - Hex Head (1/4-20 x 1/2") Begin Spec AA

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
8	WASHER, LOCK - SPRING 850-0030	2	#10 - Spec A through Z
	850-0040	2	1/4" - Begin Spec AA
9	SWITCH, OVERSPEED 150-0956	1	60 Hertz Sets
	150-1661	1	50 Hertz Sets
10	868-0004	1	Nut, Jam - Hex Head (7/16-20)
11	BRACKET AND POINT ASSEMBLY 150-0958	1	Spec A through Z
	150-1446	1	Begin Spec AA
12	122-0193	1	Filter, Oil - Heavy Duty (5-3/4")
13	SWITCH, LOW OIL PRESSURE 309-0064	1	Spec A through F
	309-0169	1	Begin Spec G