

HARVESTORE[®]FARMSTEAD PRODUCTS w/PrintOr AUTOMATED FEEDING FOUNDATED AUTOMATED FEEDING EQUIPMENT

	MODEL
	40PTO-1
	40PTO-3
· ·	55PTO-1
	55PTO-3
SPECIFICATIONS PAGE	STANDBY POWER ALTERNATOR
	OPERATOR'S MANUAL
	INSTALLATION
	OPERATION
	MAINTENANCE
	PARTS CATALOG
	FILE COP



HEIGHTS, ILLINOIS 60005 Remove this I

PART NO. 19871-40 PRINTED IN U.S.A.

MMG 23092.0 9/15/70

RETURN TO FILE

TECH. PUB. DEPT.

SECTION

· Ja Internal Distribution I each to Bill Kiewel Bob Westrum Paul Mockanhaupt Lloyd Friend .. Wayne Clemens WI Bud Stand

Date Ordered _____8-70; Ref. No._____ Date Required _____ Form No. _97/-_ Date Completed _ NAMIA Description _ 40-50KW ast Revised 9-15-70 New Rerun 800 Stock OSM Stock _ PAPFR Color Color No. of Impressions No. of Copies_ 81/2 Running Size ____ Cut Size de f Color of Ink -18 Rl No. Plates 230 un-Date Total Running Time_ Folding Time ____ Gathering _____ Stapling ____ Trimming_ Drilling ____ Padding_ Total Time Distribute To: Distribution per Bill Kiewel . OF My Sales Internal distribution a monty Card page index. heon Remarks: -res sur ster bront mple along O.K.'d. by Dend (lloon

ONAN

, <u> </u>		1			••••••••••••••••••••••••••••••••••••••				•	· · · ·
. •		ON		OF ONAN CORPORATION	_	ENGINE	ERING CH	IANGE NOT	ICE	ECN #
	ECN	# Issue Da	te Effective D	ate Requested by	Issued by	Eff. Ser. 4	EII. Spec.	Series	Page U	ECN #
	1682	7-12-73	7-12-73	Ertl	Ertl	I .	1	UR	1 of 1	1682
	Dispos & Com	sition of Stoc iments:	Model, Regard Change, oil ca Reason: incorr gear boxes in center line of ck,oil level check in maintaining (SAE 90 Multi	ling tractor drive apacity. The book tect. Inasmuch as the past, they skill the oil level cl the oil level cl k plugs located g insufficient oil Purpose Gear Lube	e generator g as and some a sour oil lev hould be disp neck plug is below the l in the gean e) should be	gear boxes, the lrawings have vel check plug regarded as a located 3" be center line of rbox. changed at lo	here has been shown this t gs have been means of che elow the cent of the gearca	confusion reg to be 1-1/2 pin incorrectly lo ecking oil leve ter line of the use are too low rvals. On thos	arding cor ts and thi cated on t l unless t gearcase. and will c e gear box	rect is is the the Those result 011 ces
	Repair	r Jobs - Cha	nge? Charge?:		Intorchan		DARTS			
	Per .	PA	RIS ADDED	. •	New w/Ol	d Per			•	
• •	Unit	Part No.	Name (Indent)	parts within assy.) Old w/N	ew Unit Par	t No. Na	me (Indent par	ts within a	assy.)
		having the interval, d 190-0316 an would be th	oil level check cain the oil and d 190-0327. On e 190-0303 and 1	plug in the inco i refill with 5-1, those gear boxes .90-0328.	rect location 2 pints on with 540 RPM	on, if the oi those boxes w i input, the p	l level is in with 1000 RPM proper oil ca	doubt during input. This pacity is 2-1/	the 100 hc would be t 2 pints.	our he This
-			 							· · · · · · · · · · · · · · · · · · ·
		ţ								
- -		-								
•		-								
	01500 1440								Γ, Ι	ECN. NO 1682

ECN. NO. 1682

HARVESTORE FARMSTEAD PRODUCTS -

POWER ALTERNATOR WARRANTY REGISTRATION CARD

The A. O. Smith Harvestore Products, Inc. warranty can be applied only if this form is properly filled out and mailed within 30 days from original installation and/or delivery date of the following Farmstead Products - Standby Power Alternator.

Consistent with the warranty on my Harvestore Standby Power Alternator, this is to apprise you of the following information: (PLEASE PRINT)

Purchaser or Original User's Name,

Installation Address_

ō

HIS

City and State

Dealer's Name (Print)_

Installation and/or Delivery Date_____

___Model No.

I have read the Harvestore Farmstead Products - Standby Power Alternator Warranty and understand its terms and conditions and that these are the sole warranties expressed or implied that are provided by A. O. Smith Harvestore Products, Inc. and upon which I rely.

-

Date Signed, Purchaser or Original User

IMPORTANT

Please return this Warranty Card

NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 234, ARLINGTON HEIGHTS, ILLINOIS

HARVESTORE[®] PRODUCTS, INC.

550 W. ALGONQUIN ROAD Arlington Heights, Illinois 60005

HARVESTORE[®] FARMSTEAD PRODUCTS

This certificate constitutes a warranty by and between A. O. SMITH HARVESTORE PRODUCTS, INC., and the purchaser and/or original user of the equipment herein referred to. No Harvestore warranty extends to any subsequent purchaser or any person, firm or corporation except as set forth herein.

If within one year after the installation of the Farmstead Products, any part thereof shall prove defective in material or workmanship upon examination by A. O. Smith Harvestore Products, Inc. (hereinafter referred to as the "Corporation"), the Corporation will supply an identical or substantially similar replacement part f.o.b. the Corporation's factory, or the Corporation, at its option, will repair or allow credit for such part. Where applicable, this warranty is subject to the following restrictions: (1) Electric motors and gas or diesel industrial engines are warranted by the motor manufacturer and must be serviced at an approved motor service station; (2) The Corporation does not consider as defects excessive depreciation or wear attributable to the installation and use of its equipment in areas having abnormally abrasive soil conditions. Except for repair or replacement parts, the warranty for the Harvestore Farmstead Products shall commence with the date of installation and/or delivery. In order to make this warranty effective, the Warranty Registration Card executed by the purchaser or original user, as the case may be, shall be received by the Corporation within thirty (30) days from original date of installation and/or delivery. Any repair or replacement part provided hereunder shall be warranted against defects in material or workmanship during the unexpired portion of the warranty period applicable to the Harvestore Farmstead Products.

This warranty shall be applicable only if the Harvestore Farmstead Products shall still be the property of the original purchaser and shall have been properly installed, used, operated and maintained in accordance with the Harvestore Farmstead Products installation and Operators Manual. This warranty shall not be applicable if the Harvestore Farmstead Products have been subject to any accident, misapplication, alteration, abuse or misuse.

No other warranty, either express or implied, has been or will be made by or in behalf of the Corporation or by operation of law with respect to the Harvestore Farmstead Products or its installation, use, operation, replacement or repair. The Corporation shall not be liable by virtue of this warranty or otherwise for any special or consequential loss or damage resulting from the use or loss of use of the Harvestore Farmstead Products and will make no allowance for repair or alterations made without its consent. The Corporation makes no warranty with respect to the installation of the Harvestore Farmstead Products, accessories or related equipment by the Harvestore Dealer, who is an independent contractor, or by any other independent contractor. The only obligation of the Corporation shall be the replacement or repair of a defective part, and the Corporation shall not be liable for drayage or labor costs, except as provided above.

> A. O. SMITH HARVESTORE PRODUCTS, INC. Arlington Heights, Illinois

7/7/70

TABLE OF CONTENTS

General Information	
Introduction	23094.0
Description	23094.0
Optional Accessories MMG	23094.0
Specifications	23094.0
Installation	
Location	23095.0
Mounting the Alternator	23095.0
Connecting the Alternator Wires MMG	23096.0
Installing the Load Transfer Switch MMG	23096.0
Power Return Signal	23096.0
Operation	
Starting	23097.0
Operating	23097.0
Service and Maintenance	
Periodic Service and Inspection MMG	23097.0
Gear Box Lubrication MMG	23097.0
Power Take-Off Shaft	23097.0
Slip Rings MMG	23097.0
Brushes	23097.0
Bearing	23097.0
Exciter-Voltage Regulator	23098.0
Fuse Replacement	23098.0
Wiring Diagrams	
40PTO-1, 55PTO-1 MMG	23098.0
40PTO-3, 55PTO-3 MMG	23099.0
Parts Catalog	23100.0

MMG 23093.0 9/15/70



GENERAL INFORMATION

INTRODUCTION

This manual contains information for the proper installation, operation and maintenance of your alternator. We suggest you keep this book handy so it can be referred to when necessary.

If you wish to contact your dealer regarding this equipment, be sure to supply the complete MODEL NUMBER and the full SERIAL NUMBER of your equipment. This information is necessary to identify your equipment among the many units manufactured.

DESCRIPTION

Harvestore Models 40 PTO and 55 PTO are revolving field, two bearing alternators. AC output voltage is generated in the stator and controlled by an exciterregulator system. The exciter-regulator produces DC for field excitation and regulates the AC output.

The rotor consists of four inter-connected coils spaced symmetrically on a steel shaft. Slip rings on the shaft transmit excitation voltage to the field coils. The shaft is supported at both ends by prelubricated ball bearings. A centrifugal blower on the drive end of the alternator draws air through the alternator for cooling.

The complete alternator includes an exciter-regulator system, mounting feet, lifting eye, mounted gear box with splined shaft and control box.

Exciter-Regulator System: The exciter and voltage regulator work together to control the AC output voltage over a wide range of load conditions. This system is factory-set to provide the proper voltage.

Control Box: The control box includes a frequency meter, a fused, 120 volt, duplex receptacle, an exciter circuit breaker (alternator protection) and a load (line) circuit breaker and convenient load connection terminals.

The load circuit breaker can be used as a disconnect switch, however a transfer switch is recommended.

Gear Box: The gear box is secured to the alternator's rear adapter and has two gears. A pinion gear is pressed onto the splined alternator rotor shaft. It meshes with a larger spur gear which is pressed onto the splined gear reduction shaft. Two roller bearings support the shaft.

The gear box oil capacity is 1-1/2 pints; the gear ratio is 3.33 to 1.



UTION } This alternator cannot be belt driven.

OPTIONAL ACCESSORIES

Power Take-Off Shaft: Telescoping, shielded, heavy duty power take-off shafts, recommended for use with PTO powered, Harvestore gear drive alternators provide maximum safety for the operator. The splined universal joint with snap ring type shield and quick disconnect feature, fits a 1-3/8 inch tractor PTO drive. PTO shaft operating lengths are: minimum 41 inch, maximum 57 inch; weight 65 pounds. Six spline universal for 540 rpm PTO.

SPECIFICATIONS

	40PTO-1	40PTO-3	55PTO-1	55PTO-3
Watts	40,000	40,000	55,000	55,000
Volts	120/240	120/240	120/240	120/240
Phase	1	3	. 1	3
Cycles	60	60	60	60
Running Current (Amperes)	-208 / 66	120	287 2 30	166
Alternator Speed (RPM)	1800	1800	1800	1800.
Tractor Speed (RPM)	540	540	540	540
Minimum Horsepower Required, Driving Source	73	. 73	100	100
Gear Ratio	3.33-1	3.33-1	3.33-1	3.33-1
Gear Box Oil Capacity, Pints	11/2	. 11/2	11/2	11/2
Recommended Gear Lubricant	SAE 90	SAE 90	. SAE 90	SAE 90
Weight (Approximate)	1075	940	1300	1100
Power Factor	0:8-1.D	0.8	0.8. 1. 6	0.8
Max KVA (0.0 P.F.) (Kilo-Volt Amperes)	163	103	218	140
Run KVA (Kilo-Volt Amperes)	50	50	68.75	68.75
Run KW (Kilowatts)	40	40	55	55

Per Bull Water 8-27-73

.

INSTALLATION

LOCATION

Figure 1 shows dimensions of the alternator and bolthole centers for installation. Select a site for the alternator with the following points in mind.

- 1. Ventilation: The alternator creates considerable heat when operating under load. It is important that this heat be dissipated by proper ventilation. If the alternator is installed inside a small room or compartment, provide a vent for exhausting the air heated by the alternator. Locate the exhaust vent above the inlet vent. Heated air is discharged from the drive-shaft end of the alternator.
- 2. Convenience to Driving Power: Locate the alternator for easy connection to the tractor. Align the power take-off to the alternator. Stay within the limits of the power take-off shaft.
- 3. Dusty or Damp Conditions: Avoid dusty or damp conditions as much as possible. Alternator should be mounted under cover or inside a building to protect it against the weather.
- 4. Servicing Convenience: Allow at least 24 inches of space on all sides of the alternator.
- 5. Wiring Convenience: Do not locate the alternator in a location difficult to service or which would have poor ventilation, to save a few feet of wiring. Install the alternator as close to the load transfer switch as possible. Do not move the load transfer switch to the alternator. Refer to INSTALLING THE LOAD TRANSFER SWITCH.

MOUNTING THE ALTERNATOR

Figure 2 shows the recommended mounting base and bolthole centers to use for the alternator. The top surface must be level and flat so the mounting brackets will not be sprung when tightened down. After securing alternator with lockwashers and nuts, the shaft should turn freely by hand.

Be sure that the alternator is properly aligned with the driving mechanism and that it will stay in alignment.

CAUTION To develop 40 and 50 KW requires 73 and 100 horsepower respectively at the power take-off. The torque will flip the alternator over unless secured to a strong substructure. DO NOT MOUNT THIS ALTERNATOR ON A TRAILER.



FIGURE 2. RECOMMENDED MOUNTING BASE



MMG 23095.0 9/15/70



FIGURE 3. TYPICAL FARM STANDBY, SINGLE PHASE

CONNECTING THE ALTERNATOR WIRES

Connect the load wires to the large circuit breaker inside of the control box before operating the alternator. Fasten with large allen screws as shown in Figures 4 and 5. Connect the grounded wire to the neutral bar located near the circuit breaker.

Connect the circuit breaker leads to the load transfer switch using flexible conduit.

WARNING Personnel connecting the alternator and any such auxiliary equipment must be fully qualified and understand wiring diagrams, circuits, etc.

120/240 Volt, 1 Phase, 3 Wire Alternator: Terminal post L0 is the grounded (neutral) terminal. For 120 volt current, connect the "hot" load wire to either the L1 or L2 terminal. Connect the neutral load wire to the L0 terminal. Two 120 volt circuits are thus available, with not more than 1/2 the alternator's rated capacity available on each circuit. Balance the load as closely as possible.

For 240 volt current, connect one load wire to terminal L1 and the second load wire to terminal L2. Terminal L0 is not used for 240 volt service.

If using both 120 and 240 volt current at the same time, use care not to overload either circuit.



FIGURE 4. 120/240 VOLT, SINGLE PHASE

120/240 Volt, 3 Phase, 4 Wire Delta Connected Alternator: The 3 phase Delta connected unit is designed to supply 120 volt, 1 phase current and 240 volt, 3 phase current. For 3 phase operation, connect the three load wires to the three terminals L_1 , L_2 , and L_3 - one wire to each terminal. For 3 phase operation the L0 terminal is not used.

For 120/240 volt, 1 phase, 3 wire operation, terminals L1 and L2 are the "hot" terminals. The L0 terminal is the neutral, which can be grounded if required. For 120 volt service, connect the "hot" (black) load wire to either the L1 or L2 terminal. Connect the neutral (white) wire to the L0 terminal. Two 120 volt circuits are available.

Any combination of 1 phase and 3 phase loading can be used at the same time as long as no terminal current exceeds the NAMEPLATE rating of the alternator. If no 3 phase output is used, usable 1 phase output is 2/3 of 3 phase KVA.



FIGURE 5. 120/240 VOLT, THREE PHASE

INSTALLING THE LOAD TRANSFER SWITCH

Before using the alternator for emergency purposes, install a DOUBLE THROW LOAD TRANSFER SWITCH. The switch must have an ampere rating large enough to carry the total load when the main source of power is in use. Follow the local electrical code. The load transfer switch should always be installed close to the main line switch, and between the main line switch and the load. When properly installed, the load transfer switch in one position will connect the electrical load to the highline. When the load transfer switch is thrown to the other position, the load is first disconnected from the main source of power, and then connected to the standby alternator. Using the load transfer switch makes it impossible to connect the alternator to the main source of power. The load lines must connect to the center terminals of the transfer switch. The alternator leads and the main power source leads must be connected at OPPOSITE ends of the switch.

POWER RETURN SIGNAL

When using the alternator for emergency applications, install a pilot light or alarm signal to indicate when the power is restored and the alternator can be disconnected. Connect a signal light across the regular power line, just ahead of the load transfer switch. Install an on-off switch and a fuse for the signal light. When a power failure occurs, snap the signal switch to the ON position before putting the alternator into operation. When the normal power returns, the signal will operate and the alternator can then be disconnected.





OPERATION

STARTING

When a power failure occurs, the alternator should be ready to run and to take over the load. Set up the tractor and properly install the power take-off shaft. Before engaging power take-off, proceed as follows in the order shown.

- 1. Alternator line circuit breaker must be in the OFF position.
- 2. Throw transfer switch to connect load to alternator.
- 3. Turn power return signal ON if one has been installed.
- 4. Engage power take-off and bring PTO shaft speed to 540 rpm. The alternator speed at this time will be 1800 rpm. The frequency meter on the alternator control box should read approximately 59-61 cycles.
- 5. Exciter breaker on.



FIGURE 7. TRACTOR CONNECTION

OPERATING

With alternator running, throw the alternator line disconnect switch to the ON position. The various electrical loads can then be connected. When motor loads are connected, connect one at a time, allowing each to reach running speed before connecting the next one. Motors require four to five times more current for starting than for running at normal speed. If several motors are started at the same instant, the total electrical load may overload the alternator, causing the circuit breaker to operate.

If the alternator frequency is not at the proper value, it may be necessary to advance or retard the engine throttle control. In some cases, it may be necessary to change the engine throttle setting when large changes in the electrical load are made.

CAUTION Keep the alternator load within its nameplate rating. If the alternator is seriously overloaded the circuit breaker will automatically trip, disconnecting the entire electrical load. Reduce the load before throwing the circuit breaker back to the ON position.

If the tractor engine has very little reserve power, use care when operating the alternator. For example, if a 100.horsepower (at the power take-off) engine is used to drive a 55,000 watt alternator, the engine throttle will be wide open at full alternator load. If most of the electrical load is suddenly removed, the governor cannot act quickly and smoothly enough to prevent a surge of speed and high voltage. Any electrical equipment left connected may be damaged by the resulting high voltage.

When disconnecting large portions of the load, disconnect one piece of equipment at a time, or first disconnect that part of the load which will be left on. Then remove the rest of the load. Wait until the alternator speed has stabilized and then reconnect that part of the load which will be left on. The alternator speed will remain relatively stable, and the tractor engine speed will not change or surge enough to cause any damage if this procedure is followed.

SERVICE AND MAINTENANCE

PERIODIC SERVICE AND INSPECTION

Follow a definite schedule of inspection and servicing. Make a good visual check before, during, and after alternator operation; look for loose or broken leads and bad connections.

GEAR BOX LUBRICATION

Drain the gear box after the first 100 hours of operation and refill with fresh lubricant of the recommended grade. Use only SAE 90 multi-purpose gear lubricant. Repeat this procedure every six months thereafter, or every 100 hours.

Maintain the proper oil level between changes. Overfilling will cause foaming, which can lead to an oil leak due to overheating. Remove the filler plug on top of the case and the oil level plug from the face of the gear case. Fill the case until the oil just begins to flow from the oil level plug hole. Gear box holds 1-1/2pints U. S. Measure. Replace both plugs. See Figure 8.



FIGURE 8. GEAR BOX LUBRICATION

POWER TAKE-OFF SHAFT

Grease the universal joints at least every 25 operating hours. Under adverse conditions, grease the joints as required, possibly every 4 to 8 hours. Never operate the alternator with the shield removed from the power take-off shaft.

WARNING

PTO.

Be extremely careful when working near a running unit. Avoid wearing loose clothing which could get caught in the revolving

SLIP RINGS

Slip rings must be clean and free of scratches and burrs (do not remove the dark brown film). If necessary to use an abrasive on the slip rings, use No. 00 sandpaper, never emery cloth or other conducting abrasives.

If rings are grooved, out of round, pitted, or rough so brushes seat poorly, remove rotor and refinish rings in a lathe. Remove or shield the bearing during refinishing.

BRUSHES

To examine the brushes, brush springs, and collector rings, remove the grille section below the control box. There is a direct access to the brushes through the large openings in the endbell.



FIGURE 9. BRUSH REPLACEMENT

Replace brushes when worn to approximately 5/8" long, or when the brush is wearing into the stamped name (Figure 9). Do not attempt to remove the brush without first removing its spring and brackets as shown. Never bend a spring back over its bracket doing so will put a kink in it and require its replacement. Do not use a substitute brush that may look identical but may have entirely different electrical characteristics. Be sure the brush is installed so that the short side of its taper is toward the spring and its bracket (Figure 10).

ALTERNATOR BEARING

The alternator bearing is double-sealed and prelubricated. Inspect the bearing for rotation every 1000 hours while the alternator is running.

If alternator is used for "prime power", replace the bearing every 10,000 hours or two years. If the alternator is used as "standby", replace the bearing every five years. Deterioration of the bearing grease, due to oxidation, makes this replacement necessary.



FIGURE 10. BRUSH REMOVAL

EXCITER VOLTAGE REGULATOR

This system contains no moving parts. Occasionally blow out dust, etc. with clean, filtered air. Check thoroughly to assure that all components are mechanically secure and that all electrical connections are tight.

FUSE REPLACEMENT

A fused, 120 volt duplex receptacle provides for convenient load connections up to 15 amps. If exceeding this load, fuse will blow and will require replacement. To change fuse, unlatch top panel of control box and lift open. Twist fuse holder as shown in Figure 11 and replace with Buss ABC 15 or equivalent.



FIGURE 11. FUSE REPLACEMENT

OUTPUT VOLTAGE

A voltage adjusting potentiometer located on the printed circuit board inside the control box, provides for a \pm 3% adjustment of the output voltage. This potentiometer is preset at the factory and should not require readjustment unless replacing printed circuit board. Refer to Parts Catalog, Printed Circuit Board Assembly Group, Item 36.

NATURE OF TROUBLE	PROBABLE CAUSE					
No Output Voltage	 Check load circuit breaker for a tripped position; an external short or overload may have caused this condition. Remove part of the load before resetting breaker. Check exciter circuit breaker for a tripped posi- tion. Correct problem before resetting. Check tractor PTO speed - should be 540 rpm. 					
No Output Voltage From 120Volt Duplex Receptacle	 Blown fuse - Open control box cover and replace fuse with Buss ABC 15 or equivalent. 					
Low Frequency - Alternator Will Not Maintain 60 Cycles	1. Check engine PTO speed - Should be 540 rpm.					
Alternator Overheats	 Overloaded - Remove part of load. Poor ventilation - Check alternator's air intake and outlet for restrictions. 					

ALTERNATOR OPERATIONAL GUIDELINES

NOTE: If alternator does not produce current after making these checks, contact your nearest A. O. Smith Harvestore (B) dealer.



FIGURE 12. WIRING DIAGRAM FOR MODELS 40PTO-1 AND 55PTO-1, SINGLE PHASE



FIGURE 13. WIRING DIAGRAM FOR MODELS 40PTO-3 AND 55PTO-3, THREE PHASE

MMG 23099.0 9/15/70

PARTS CATALOG

Always give the MODEL and SERIAL NO.

For parts or service, contact the dealer from whom you purchased this equipment.

To avoid errors or delay in filling your parts order, please furnish all information requested.

MODEL	ALWAYS MENTION MODEL & SERIAL No.)]
AC VOLTS AMPS PH EXCITER	KVA PF CYCLES RPM DC VOLTS AMPS	

NO.	NO.	USED	DESCRIPTION	<u>NO.</u>	<u>NO.</u>	USED	DESCRIPTION
1	82134-1	I	Rotor Assembly, Wound - 40 KW, I Phase	26	82134-26	4	Stud, Alternator Through - 40 KW, I Phase
2,	82134-2	ŀ	Rotor Assembly, Wound - 40 KW, 3 Phase	27	82134-27	.4	Stud, Alternator Through - 40 KW, 3 Phase
3	82134-3	I	Rotor Assembly, Wound - 55 KW, Phase	28	82134-28	4	Stud, Alternator Through - 55 KW, I Phase
4	82134-4	. 1	Rotor Assembly, Wound - 55 KW, 3 Phase	29	82134-29	4	Stud, Alternator Through - 55 KW, 3 Phase
5	82134-5	1	Blower	: 30	82 34-30	2	Spacer, Voltage Regulator
6	82134-6	1	Bearing				Chassis Mounting
7	82134-7	I	Stator Assembly, Wound - 40 KW, I Phase	31	82134-31		Chassis Assembly, Voltage Regulator (Includes Parts
8	82134-8	I	Stator Assembly, Wound -				Marked *) - 3 Phase
			40 KW, 3 Phase	· 32	82134-32	1	Chassis Assembly, Voltage
9	82 34-9	I	Stator Assembly, Wound -				Regulator (Includes Parts Marked +) - I Phase
10	82134-10	1	Stator Assembly Wound -	33	82134-33	1	*+Chassis, Voltage Regulator
	02134-10		55 KW, 3 Phase	34	82134-34	I	*+Rectifier, Silicon (Avalanche)
11	82 34-11	1	Brushes and Springs)	35	82134-35	2	*+Rectifier, Gate Control (SCR)
12	82 34- 2	4	Spring, Brush		02124.24	2	Negative
13	82134-13	4	Brush	36	82134-36	2	- Negativo
14	82134-14	I	Bell, End	27	62134-37	3	*+Heat Sink Rectifier
15	82134-15	l l	Screen, Alternator	3/	92134-39	2	*+lumper Terminal Board
16	82134-16		Base, Alternator Mounting	30	82134-39	2	*+Grommet Reactor Leads
17	82134-17	I	Ring, Collector	40	82134-40	<u> </u>	*+Block Terminal
18	82134-18		Adapter, Alternator	40	82134-41	1	*ABeactor Assembly
19	82134-19	I	Grille, Alternator Air Inlet	42	82134-47	i	ABeactor Assembly
20	82134-20	1	Wrapper, Alternator End Bell	42	82134-43	6	*Linsulator Heat Sink Mounting
21	82134-21	l i	Seal, 'O' Ring - Bearing		87134-44	ĩ	Evebolt Lifting
22	82134-22	1	Washer, Bearing Retainer	(02131-11	•	L'rebolt, Elling
23	82134-23	I .	Screw, Bearing Retainer	<u>۰</u>	Included in 8	2134-31 0	hassis Assembly
24	82134-24	4	Spacer, Brush Rig Mounting		Included in 9	2134-37 0	hassis Assembly
25	82134-25	4	Washer, Brush Rig Mounting		mended in o	4139 JZ C	and as a semility.



GEAR DRIVE BOX

REF. NO.	PART NO.	QTY. USED	PART	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	82135A	<u> </u>	Gear Box - Complete	. 16	82135-16	I I	Seal
1.	82135-1	I	Case (Less Pipe Plugs)	17	82135-17	I	Plate, Open End
2	82135-2	1	Case (Includes Pipe Plugs	18	82135-18	18	Screw, Cap
3	82135-3	1.1	Gasket	19	82135-19	I.	Gear
4	82135-4	1	Flange	20	82135-20	16	Screw, Cap .
5	82135-5	2	Bearing, Cup	21	82135-21	16	Nut
6	82135-6	2	Bearing, Cone	22	82135-22	2	Bushing, Lineup
7	82135-7	Ī	Shaft & Gear	23	82135-23	I	Plate, Closed End
Ŕ	82135-8	2	Seal	24	82135-24	6	Screw, Cap
9	82135-9	Ī	Plate, Open End	25	. 82135-25	6	Washer, Lock
ιÓ	82135-10	As Rea.	Shim, .001 "Thick (Clear)	26	82135-26	1	Plug
iĭ	82135-11	As Reg.	Shim, .003 "Thick (Green)	27	82126-20	2	Plug, Drain
12	82135-12	As Rea.	Shim, .005 "Thick (Blue)	28	82135-28	2	Screw, Cap
ÎĨ	82135-13	2	Bearing, Cup	29	82135-29	2	Washer, Lock
14	82135-14	2	Bearing, Cone	30	82135-30	1	Cap, Vent
15	82135-15	ī	Shaft, Splined				



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART
1	82136-1	I	Chassis, Control	16	82136-16	I.	Board Assembly, Printed
2	82 36-2	1	Panel, Control Chassis				Circuit (See Separate Group
3	82136-3	1	Cover, Control Chassis				For Components)
4	82136-4	I	Holder, Cover	17	82136-17	1	Breaker, Circuit (15 Amp) -
5	82 36-5	1	Block, Terminal - 12 Place				40 KW, 1 & 3 Phase
· 6	82136-6	ł	Strip, Marker - 12 Place	18	82136-18	1	Breaker, Circuit (20 Amp) -
7	82136-7	1	Meter, Frequency				55 KW, 1 & 3 Phase
8	82136-8	l I	Receptacle, Duplex	19	82136-19	I	Breaker, Circuit (125 Amp) -
9	82136-9	1	Holder, Fuse	· ·			40 KW, 3 Phase
10	82136-10	I	Fuse, 15 Amp	20	82136-20	1	Breaker, Circuit (175 Amp) -
11	82136-11	I	Saddle, Control Chassis				55 KW, 3 Phase
			Mounting	21	82136-21	I	Breaker, Circuit (225 Amp) -
12	82136-12	1	Resistor, Fixed - 1740-Ohms,				40 KW, I Phase
			1/4 Watt	22	82136-22	1	Breaker, Circuit (300 Amp) -
i 13	82136-13	1	Transformer, Voltage				55 KW, I Phase
14	82136-14	1	Bar Assembly, Neutral -	23	82136-23	1	Bracket, Circuit Breaker Mtg
			55 KW, 1 Phase	-			40 KW, I Phase and 40 KW &
15	82136-15	I	Bar Assembly, Neutral -				55 KW, 3 Phase
			40 KW, 1 & 3 Phase	24	82136-24	1	Bracket, Circuit Breaker Mtg
			and 55 KW, 3 Phase	}			55 KW, I Phase
				L .	•		

MMG 23102.0 9/15/70



PRINTED CIRCUIT BOARD ASSEMBLY GROUP

4-5-6

REF.	PART	QTY.	PART	REF.	PART	QTY.	
<u>NO.</u>	<u>NO.</u>	USED	DESCRIPTION	<u> </u>	- <u>- NO.</u>	USED	DESCRIPTION
1	82136-16	1	Board Assembly, Printed	24	82137-24	1.	Resistor (2 Watt, 4.7 Megohm)
			Circuit - Complete	25	82137-25	12	Resistor, Fixed (10 Watt,
2	82137-2	1	Block, Terminal (12 Place)				270-Ohm)
3	82137-3	5	Terminal, Standoff	26	82 37-26	I	Resistor, Fixed (15 Watt,
4	82137-4	2	Screw, Rd. Head Machine				5,000-Ohm)
			(#8-32 × 5/8)	27	82137-27	1	Resistor (1/2Watt, 3,000-Ohm)
5	82137-5	2	Washer, E.T. Lock (#8)	28	82137-28	2	Resistor (1/2 Watt, 300,000-Ohm)
6	82137-6	2	Nut, Hex (#8-32)	29	82137-29	2	Resistor (1/2Watt, 33,000-Ohm)
7	82137-7	3	Pad, Transistor Mounting	30	82137-30	1	Resistor, Fixed (5 Watt, 15,000-
8	82137-8	1	Capacitor (.47 Mfd., 100 Volt)				Ohm)
9	82137-9	2	Capacitor (.22 Mfd., 200 Volt)	31	82137-31	I	Resistor (2 Watt, 13,000-Ohm)
10	82137-10	2	Capacitor (.47 Mfd., 400 Volt)	32	82137-32	I I	Resistor (2 Watt, 6,800-Ohm)
11	82137-11	l I	Capacitor (.47 Mfd., 200 Volt)	33	82137-33	1 -	Resistor (1/2 Watt, 220,000-Ohm)
12	82137-12	2	Capacitor (1 Mfd., 100 Volt)	34	82137-34	L	Resistor (1/2 Watt, 100,000-Ohm)
13	82 37- 3	1	Capacitor (. Mfd., 200 Volt)	35	82137-35	i	Resistor, Metal Film (1/4 Watt,
14	82137-14	I	Capacitor (.047 Mfd., 200 Volt)				12,100-Ohm)
15	82137-15	8	Rectifier, Silicon	36	82137-36	I	Potentiometer
16	82137-16	1	Diode, Zener	37	82137-37	2	Resistor, Metal Film (1/4Watt,
17	82137-17	I	Diode, Zener				28,000-Ohm)
18	82137-18	I	Diode, Zener	38	82137-38	1	Resistor, Metal Film (1/4 Watt,
19	82137-19	1	Relay, Magnetic Reed				5,110-Ohm)
20	82137-20	2	Transistor, Silicon NPN	39	82137-39	1	Resistor, Metal Film (1/4 Watt,
21	82137-21	1	Transistor, Unijunction				8,870-Ohm)
22	82137-22	2	Resistor (1/2 Watt, 47-Ohm)	40	82137-40	1	Diode, Zener
23	82137-23	2	Resistor (1/2 Watt, 33-Ohm)	41	82137-41	I.	Capacitor (100 Mfd., 10 Volt)

• . <u>.</u> •