


OPERATOR'S MANUAL

FOR
DYG
SERIES

ELECTRIC GENERATING SETS



SAFETY PRECAUTIONS

The following symbols in this manual signal potentially dangerous conditions to the operator or equipment. Read this manual carefully. Know when these conditions can exist. Then, take necessary steps to protect personnel as well as equipment.

ONAN recommends that you read your manual and become thoroughly acquainted with it and your equipment before you start your unit. These recommendations and the following safety precautions are for your protection.

Fuels, electrical equipment, batteries, exhaust gases and moving parts present potential hazards that could result in serious, personal injury. Take care in following these recommended procedures.

WARNING Onan uses this symbol throughout this manual to warn of possible serious personal injury.

CAUTION This symbol refers to possible equipment damage.

General

- Keep your electric generating set and the surrounding area clean and free from obstructions. Remove any debris from set and keep the floor clean and dry.
- Provide appropriate fire extinguishers and install them in convenient locations. Consult your local fire department for the correct type of extinguisher to use. Do not use foam on electrical fires. Use extinguisher rated ABC by NFPA.
- Make sure that all fasteners on the generating set are secure. Tighten supports and clamps, keep guards in position over fans, driving belts, etc.
- Do not wear loose clothing in the vicinity of moving parts, or jewelry while working on electrical equipment. Loose clothing and jewelry can become caught in moving parts. Jewelry can short out electrical contacts; cause shock or burning.
- If adjustment *must* be made while the unit is running, use extreme caution around hot manifolds, moving parts, etc.
- Do not work on this equipment when mentally or physically fatigued.
- Coolants under pressure have a higher boiling point than water. DO NOT open a radiator or heat exchanger pressure cap while the engine is running. Bleed the system pressure first.

Protect Against Moving Parts

- Keep your hands away from moving parts.

- Before starting work on the generating set, disconnect batteries. This will prevent starting the set accidentally.

Fuel System

- DO NOT fill fuel tanks while engine is running, unless tanks are outside engine compartment. Fuel contact with hot engine or exhaust is a potential fire hazard.
- DO NOT SMOKE OR USE AN OPEN FLAME in the vicinity of the generator set or fuel tank. Internal combustion engine fuels are highly flammable.
- Fuel lines must be of steel piping, adequately secured, and free from leaks. Piping at the engine should be approved flexible line. Do not use copper piping on flexible lines as copper will work harden and become brittle.
- Be sure all fuel supplies have a positive shutoff valve.

Guard Against Electric Shock

- Remove electric power before removing protective shields or touching electrical equipment. Use rubber insulative mats placed on dry wood platforms over floors that are metal or concrete when around electrical equipment. Do not wear damp clothing (particularly wet shoes) or allow skin surfaces to be damp when handling electrical equipment.
- Use extreme caution when working on electrical components. High voltages cause injury or death. DON'T tamper with interlocks.
- Follow all state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag open switches.
- DO NOT SMOKE while servicing batteries. Lead acid batteries emit a highly explosive hydrogen gas that can be ignited by electrical arcing or by smoking.

Exhaust Gases Are Toxic

- Provide an adequate exhaust system to properly expel discharged gases. Check exhaust system regularly for leaks. Ensure that exhaust manifolds are secure and not warped. Do not use exhaust gases to heat a compartment.
- Be sure the unit is well ventilated.

Keep the Unit and Surrounding Area Clean

- Make sure that oily rags are not left on or near the engine.
- Remove all oil deposits. Remove all unnecessary grease and oil from the unit. Accumulated grease and oil can cause overheating and subsequent engine damage and may present a potential fire hazard.

TABLE OF CONTENTS

UNLESS INDICATED, ALL SECTIONS WILL
APPLY TO 150, 175 AND 200 kW SETS

TITLE	PAGE
Safety Precautions.....	Inside Cover
Introduction	1
Specifications (150, 175 kW).....	4
Specifications (200 kW).....	5
Description.....	8
Installation	13
Electrical (150, 175 kW)	18
Electrical (200 kW)	22
Operation	26
General Maintenance	31

WARNING

TO AVOID POSSIBLE PERSONAL INJURY OR
EQUIPMENT DAMAGE, A QUALIFIED ELECTRI-
CIAN OR AN AUTHORIZED SERVICE
REPRESENTATIVE MUST PERFORM IN-
STALLATION AND ALL SERVICE.

INTRODUCTION

FOREWORD

This manual is applicable to the DYG Series electric generating set, driven by an Allis Chalmers, 6138-LT turbocharged diesel engine. The 150.0 and 175.0 kW set consists of a UR Series Generator, while the 200.0 kW set consists of a YB Series generator.

Information is provided on installation, operation, troubleshooting and parts ordering for the DYG set. The manual should be used in conjunction with the Allis-Chalmers engine manual, as your specific engine may have variations due to optional equipment available.

MODEL IDENTIFICATION

Identify your model by referring to the MODEL and SPECIFICATION NO. as shown on the Onan nameplate. Electrical characteristics are shown on the lower portion of the nameplate.

150.0	DYG	15R	/	1	G
1	2	3		4	5

1. Indicates Kilowatt rating.
2. Factory code for SERIES identification.
3. Indicates voltage code.
15 indicates 60 Hz reconnectable.
R indicates remote electric start.
4. Factory code for designating optional equipment.
5. Specification letter. (Advances when factory makes production modifications.)

If it is necessary to contact a dealer or the factory regarding the set, always mention the complete Model, Spec No. and Serial No. as given on the Onan nameplate. This nameplate information is necessary to properly identify your unit among the many types manufactured. Refer to the engine nameplate when requesting information from its manufacturer. The Onan nameplate is located on the right side of the generator; the Allis-Chalmers nameplate is on the right side, on the engine block.

WARNING

ENGINE EXHAUST GAS (CARBON MONOXIDE) IS DEADLY!

Carbon monoxide is an odorless, colorless gas formed by incomplete combustion of hydrocarbon fuels. Carbon monoxide is a dangerous gas that can cause unconsciousness and is potentially lethal. Some of the symptoms or signs of carbon monoxide inhalation are:

- Dizziness
- Intense Headache
- Weakness and Sleepiness
- Vomiting
- Muscular Twitching
- Throbbing in Temples

If you experience any of the above symptoms, get out into fresh air immediately.

The best protection against carbon monoxide inhalation is a regular inspection of the complete exhaust system. If you notice a change in the sound or appearance of exhaust system, shut the unit down immediately and have it inspected and repaired at once by a competent mechanic.


FLAMMABLE LIQUIDS

Carelessness is a deadly habit when handling electric generating sets.

The ingredients of an explosion are simple—a combustible mixture and a means of igniting it. Internal combustion engines operate on natural gas, manufactured gas, gasoline and diesel oil fuel. Liquid fuels alone will not burn. Air has to be mixed with the fuel so that it reaches what is called a “fume state.” Only then will a liquid fuel ignite. So it is good to remember that—

IF YOU CAN SMELL FUMES, YOU HAVE HALF THE INGREDIENTS FOR AN EXPLOSION.

With a combustible mixture, all that is needed is a way of igniting the fumes. There are many: faulty engine-ignition insulation, arcing relays or brushes, welding, dropping a steel wrench on a concrete floor, and of course a cigarette.



The following example is a very real possibility: A loose connection in a fuel line, or dirt in a solenoid valve allows fuel vapors to escape.

An operator smoking a cigarette is in the vicinity of the escaping fuel. Now, coal at the cigarette end has a temperature of 1000° F, and rises up to 1175° F (538° C to 635° C) when air is drawn through it. That coal is hot enough to ignite a fuel vapor mixture.

Could the explosion have been prevented? The answer is obviously “yes.” This accident happened because a Planned Maintenance Program was either non-existent, or was not being followed. Most accidents happen because some individual does not follow the simple fundamental rules of safety.

MOST ACCIDENTS CAN BE PREVENTED!

SPECIFICATIONS

150.0 Kilowatts

175.0 Kilowatts

ENGINE DETAILS

Engine Manufacturer
 Engine Series
 Number of Cylinders.....
 Displacement.....
 BHP @ 1800 RPM
 Compression Ratio
 Bore
 Stroke
 Fuel
 Battery Voltage.....
 Battery Group (Two 12-Volt, 225 A.H.).....
 Starting Method
 Governor Regulation.....
 Battery Charging Current

Allis-Chalmers
 6138-LT
 6
 844-inch³ (13.8 lit)
 276 (206 kW)
 15.1:1
 5.25-inches (133.35 mm)
 6.50-inches (165.10 mm)
 ASTM No 2 Diesel
 24 VDC
 8D
 Solenoid Shift
 5% Maximum
 35 Amperes

GENERATOR DETAILS

Type.....

UR 15 60 Hz
 UR 515 50 Hz
 UR 9X 60 Hz

Rating (Watts)

60 Hertz Continuous Standby
 50 Hertz Continuous Standby

150,000 175,000
 125,000 145,000

AC Voltage Regulation.....

60 Hertz RPM
 50 Hertz RPM

± 2%

1800

1500

Output Rating

0.8 PF

AC Frequency Regulation.....

3 Hz Max. No load—Full load

CAPACITIES AND REQUIREMENTS

Cooling System (Including Radiator)

Engine Oil Capacity (Filter, Lines, Crankcase).....

Exhaust Connection (inches pipe thread)

16.5-Gallons (62.5 lit)
 45-Quarts (42.58 lit)
 6 (Female)

AIR REQUIREMENTS (1800 RPM)

Engine Combustion.....

Radiator Cooled Engine.....

Total for Radiator Cooled Model

Alternator Cooling Air (1800 RPM)

(1500 RPM)

640-ft³ (18.13 m³/min.) 690-ft³ (19.54 m³/min)
 18,400-ft³ (521 m³/min)
 20,040-ft³ (568 m³/min) 20,090 ft³(569 m³/min)
 1000-ft³(28.32 m³/min)
 833-ft³ (23.6 m³/min)

Fuel Consumption at Rated Load

ASTM No. 2 Diesel

11.5-GPH (43.5 lit/hr) 13.5-GPH (51.1 lit/hr)

GENERAL

Height

Width

Length

Weight (Approximate)

66.00-inches (1.68 m)
 44.00-inches (1.11 m)
 120.00-inches (3.04 m)
 5820-lb (2653.5 kg) 6000-lb (2721 kg)

SPECIFICATIONS

200 kW

ENGINE DETAILS

Engine Manufacturer	Allis-Chalmers
Engine Series	6138-LT
Number of Cylinders	6
Displacement	844-inch ³ (13.8 lit)
BHP @ 1800 RPM	310 (231.2 kW)
Compression Ratio	15.4:1
Bore	5.25-inches (133.35 mm)
Stroke	6.50-inches (165.10 mm)
Fuel	ASTM No 2 Diesel
Battery Voltage	24 VDC
Battery Group (Two 12-Volt, 225 A.h)	8D
Starting Method	Solenoid Shift
Governor Regulation	5% Maximum
Battery Charging Current	35 Amperes

GENERATOR DETAILS

Type	YB 17/1 (60 Hz) YB 517/1 (50 Hz)
Rating (Watts)	
60 Hertz Continuous Standby	200,000
50 Hertz Continuous Standby	153,000
AC Voltage Regulation	±2%
60 Hertz RPM	1800
50 Hertz RPM	1500
Output Rating	0.8 PF
AC Frequency Regulation	3 Hz Max. No load—Full load

CAPACITIES AND REQUIREMENTS

Cooling System (Including Radiator)	16.5-Gallons (62.5 lit)
Engine Oil Capacity (Filter, Lines, Crankcase)	15-Gallons (56.8 lit)
Exhaust Connection (inches pipe thread)	6 (Female)

AIR REQUIREMENTS (1800 RPM)

Engine Combustion	670-ft ³ /min (18.76 m ³ /min)
Radiator Cooled Engine	18,400-ft ³ /min (521 m ³ /min)
Total for Radiator Cooled Model	20,070-ft ³ /min (562 m ³ /min)
Alternator Cooling Air (1800 RPM)	1000-ft ³ /min (28.32 m ³ /min)
(1500 RPM)	833-ft ³ /min (23.6 m ³ /min.)
Fuel Consumption at Rated Load	
ASTM No. 2 Diesel	15.7-GPH (59.5 lit/hr.)

GENERAL

Height	70.00-inches (1778 mm)
Width	44.00-inches (1118 mm)
Length	109.00-inches (2768 mm)
Weight (Approximate)	6200-lbs. (2814.8 kg)

150 & 175 kW




FIGURE 1. STANDARD CONTROL PANEL (ONE FAULT LAMP)

150 & 175 kW




FIGURE 2. OPTIONAL CONTROL PANEL (FIVE FAULT LAMPS)

200 KW




FIGURE 3. CONTROL PANEL




FIGURE 4. CONTROL PANEL INTERIOR

DESCRIPTION

GENERAL

An Onan DYG series electric generating set is a complete unit consisting of an engine driven AC generator, with controls and accessories as ordered.

ENGINE

The engine on the DYG is an Allis-Chalmers 6138-LT as described in the engine manual. Basic measurements and requirements will be found under *Specifications*. However, the engine used for your unit may have variations due to optional equipment available, therefore the Allis-Chalmers manual should be consulted.

AC GENERATOR

The generator is an Onan Type UR (150 & 175 kW) or YB (200 kW). It is a 12 lead, 4 pole revolving field, reconnectable brushless unit. Alternating current is generated in the stator winding. The alternator rotor, attached directly to the engine flywheel turns at engine speed. Therefore, the speed at which the rotor turns, determines generator output frequency. The 60 hertz set operates at 1800 rpm and the 50 hertz at 1500 rpm. Excitation is achieved by feeding AC output to a voltage regulator, where it is compared with a reference voltage, rectified and returned to the field of the exciter. Current induced in the exciter rotor is rectified and fed to the generator rotor. This induces a current in the generator stator which is applied to load. The generator is available in 3-phase and single phase. Excitation and regulation are the same for either unit.

CONTROL PANEL

The following is a brief description of each of the standard controls and instruments located on the face of the panel. See Figure 1 and 3.

DC Panel

Panel Light and Switch: Illuminates control panel.

Oil Pressure Gauge: Indicates pressure of lubricating oil in engine (wired to a sensor unit located on the engine).

Water Temperature Gauge: Indicates temperature of circulating coolant in engine. (Wired to a sensor unit located on the engine.)

Battery Charge Rate DC Ammeter: Indicates battery charging current.

Run-Stop/Reset-Remote Switch: Starts and stops the unit locally or from a remote location. Resets engine monitor relay in Stop/Reset position.

Warning Light: Indicates "Fault" in engine operation.

AC Panel

AC Voltmeter: Indicates AC generator output voltage. Dual range instrument: measurement range in use shown on indicator light.

AC Ammeter: Indicates AC generator output current. Dual range in use shown on indicator lights.

Voltmeter-Ammeter Phase Selector Switch: Selects the phases of the generator output to be measured by the AC voltmeter and AC ammeter.

Voltage Regulator: Rheostat, provides approximately plus or minus 5% adjustment of the rated output voltage.

Exciter Circuit Breaker: Provides generator exciter and regulator protection from overheating in the event of certain failure modes of the generator, exciter and voltage regulator.

Running Time Meter: Registers the total number of hours, to 1/10th that the unit has run. Use it to keep a record for periodic servicing. Time is accumulative, meter cannot be reset.

Frequency Meter: Indicates the frequency of the generator output in hertz. It can be used to check engine speed. (Each hertz equals 30 rpm.)

OPTIONAL EQUIPMENT

DC Panel

Warning Lights: Eliminates the one "Fault" light and substitutes five indicator lights to give warning of—

- a. Overcrank
- b. Overspeed
- c. Low oil pressure
- d. High engine temperature
- e. Low engine temperature

Operation of these lights will be discussed in conjunction with engine monitor panel.

Reset Switch: Manual reset for engine monitor after shut-down.

Lamp Test: Press to test warning lamp bulbs (when engine is running only).

CONTROL PANEL INTERIOR

The only equipment discussed in this section will be that which the operator may have reason to adjust or inspect for service.

Terminal Board (TB) 21

Connection of wire W12 to terminals H3, H4, H5, and H6 is made at this point, to change reference voltage when reconnecting generator for different voltages. Refer to Figure 16.

Voltage Regulator

Solid state unit, consisting of printed circuit board VR21; an SCR bridge CR21, with a commutating reactor L21 are located in the control panel as part of the voltage regulator system. AC output from generator is controlled at predetermined level regardless of load; regulation is plus or minus 2 percent from no load to full load, at 0.8 PF.

Engine Monitor

Printed circuit plug-in modules provide the following functions:

1. A 75 second cranking period.
2. Approximately a 12.5-second time delay for oil pressure buildup.
3. An external alarm contact to light a fault lamp and shut down the set for alarm conditions such as:
 - a. Overcrank (failed to start after cranking 75 seconds).
 - b. Low oil pressure 14 psi (96.5 kPa).
 - c. High engine temperature 215° F (102° C).

CAUTION

High Engine Temperature Cutoff will shut down engine in an overheat condition only if coolant level is sufficiently high to physically contact shutdown switch. Loss of coolant will allow engine to overheat without protection of shutdown device, thereby causing severe damage to the engine. It is therefore imperative that adequate engine coolant levels be maintained, to ensure operational integrity of cooling system and engine coolant overheat shutdown protection.

On standard control panels, all four alarms are wired into one common fault lamp; on units with five fault lamps, four have shutdown alarms, the fifth (low engine temperature) lights a fault lamp only. Refer to Table 3.

Standard Cranking Module

Limits engine cranking time to 75 seconds. If engine fails to start after 75 seconds the engine monitor lights a fault lamp and opens the cranking circuit.

OPTIONAL MODULES

Cycle Cranker

Plug-in module replaces standard cranking circuit. Automatically provides a 15-second crank time and a 10-second rest time for three ON and two OFF cycles in 65 seconds. If engine fails to start, after 75 seconds the engine monitor lights a fault lamp and opens the cranking circuit. The ON and OFF cycle times are nominal and can be adjusted at potentiometers on the cranker module board.

Pre-Alarm

Gives advance warning for low oil pressure or high engine temperature. Requires two sensors each for engine temperature and oil pressure.

TABLE 1. FAULT LAMP OPTIONS

SYSTEM	FAULT	FAULT LAMP	STOP ENGINE	EXTERNAL ALARM	PRE-ALARM
PENN STATE SINGLE LIGHT	Overcrank Overspeed Low Oil Pressure High Engine Temperature	x x x x	x x	x x x x	
STANDARD SINGLE LIGHT	Overcrank Overspeed Low Oil Pressure High Engine Temperature	x x x x	x x x x	x x x x	
5 LIGHT	Overcrank Overspeed Low Oil Pressure High Engine Temperature Low Engine Temperature	x x x x x	x x x x	x x x x	
5 LIGHT PRE-ALARM	Overcrank Overspeed Low Oil Pressure High Engine Temperature Low Engine Temperature	x x x x x	x x * * 	x x x x	 x x

* - With additional optional sensors.


EXHAUST SYSTEM

Exhaust fumes are noxious. Inhalation can cause death.

Carbon monoxide (CO) is an odorless, colorless gas formed by incomplete combustion of hydrocarbon fuels. Design and installation of an exhaust system is important for two reasons: one is fume evacuation; the other reason is the high temperatures the materials must withstand. The gauge or size of materials used is determined by the maximum allowable back pressure, and length of the exhaust system. In cases where an engine is exhausted through the roof of a building, it may be necessary to use an exhaust booster fan to aid fume evacuation, and keep back pressure within specified limits. The pipe attached to the exhaust manifold should be flexible enough to compensate for thermal expansion, contraction. It should also be able to absorb vibrations. This is extremely important on turbo-charged units where a rigid piece of exhaust pipe could impart enough stress and weight to severely damage both turbo-charger and housing.

Where pipe is joined, make sure the joint welds are leak-free. Exhaust ducting which is run along a combustible wall should be far enough from the wall to prevent heat or fire damage. Where pipe is run through a wall, a thimble should be installed which will adjust for thermal movement and also prevent exhaust heat from damaging the wall. Sharp bends should be avoided, but where this is not possible, a condensation trap should be installed. Drain this trap frequently. Do not terminate an exhaust pipe in the vicinity of ventilating air inlet duct or venturi, otherwise exhaust gases will be pulled back into the building.

EXHAUST FUMES ARE DEADLY!






FIGURE 5. A TYPICAL STANDBY INSTALLATION

INSTALLATION

GENERAL

Installations must be considered individually. Use these instructions as a general guide. Meet regulations of local building codes, fire ordinances, etc., which may affect installation details. See Figure 5.

Installation points to consider include:

1. Level mounting surface.
2. Adequate cooling air.
3. Adequate fresh induction air.
4. Discharge of circulated air.
5. Discharge of exhaust gases.
6. Electrical connections.
7. Fuel connections.
8. Water connections.
9. Accessibility for operation and servicing.
10. Vibration isolation.
11. Noise levels.

LOCATION

Provide a location that is protected from the weather and is dry, clean, dust free and well ventilated. If practical, install inside a heated building for protection from extremes in weather conditions.

MOUNTING

Generating sets are mounted on a rigid skid base which provides proper support. Install vibration isolators between skid base and foundation. For convenience in draining crankcase oil and general servicing, mount set on raised pedestals (at least 6-inches [150 mm] high). If mounting in a trailer, or for other mobile applications, bolt securely in place. Extra support for the vehicle flooring may be necessary. Bolting down is recommended for stationary installations.

VENTILATION

Generating sets create considerable heat which must be removed by proper ventilation. Outdoor installations rely on natural air circulation but mobile and indoor installations need properly sized and positioned vents for the required air flow. See *Specifications* for the air required to operate with rated load under normal conditions at 1800 rpm.

Radiator set cooling air travels from the rear of the set to the front end. Locate the room or compartment air inlet where most convenient, preferably to the rear of the set. Make the inlet opening at least as large as the radiator area (preferably 1-1/2 times larger).

Engine heat is removed by a pusher fan which blows cooling air out through the front of the radiator. Locate the cooling air outlet directly in front of the radiator and as close as practical. The opening size should be at least as large as the radiator area. Length and shape of the air outlet duct should offer minimum restriction to air flow. Use a duct of canvas or sheet metal between the radiator and the air outlet opening. The duct prevents recirculation of heated air.

Provide a means of restricting the air flow in cold weather to keep the room or compartment temperature at a normal point.

A shelter housing with electrically operated louvres is available as an option. Transformers connected across the generator output supply current to the motors.

When the generator is operating, current in the transformers actuate the motors and open the louvres. The louvres are held open for the duration of the set operation, then are closed by return springs when the set is shut down.

City water cooled sets do not use the conventional radiator. A constantly changing water flow cools the engine. Ventilation is seldom a problem, but sufficient air movement and fresh air must be available to properly cool the generator, disperse heat convected off the engine and support combustion in the engine.

For small compartments, a duct of equal or larger area than generator outlet is recommended to remove the heated air from the generator air outlet to the outside atmosphere. Limit bends and use radius type elbows where needed. A larger, well ventilated compartment or room does not require a hot air duct.

Installations made in a small room may require installation of an auxiliary fan (connected to operate only when the plant is running) of sufficient size to assure proper air circulation.

CITY WATER COOLING

An optional method of engine cooling, in place of the conventional radiator and fan, uses a constant pressure water supply. This is referred to as CITY WATER COOLING. There are two varieties of city water cooling; the HEAT EXCHANGER SYSTEM and STANDPIPE SYSTEM. See Figures 6 and 7.




FIGURE 6. TYPICAL HEAT EXCHANGER SYSTEM

The HEAT EXCHANGER provides for a closed engine cooling system. Engine coolant flows through a tubed chamber, keeping the coolant separate from the cool "raw" water supply. The coolant chamber must be filled for operation, as for a radiator cooled set.




FIGURE 7. TYPICAL STANDPIPE SYSTEM

The STANDPIPE SYSTEM uses a mixing or tempering tank. Cooling water that circulates through the engine mixes with a source of cool "raw" water. The "raw" water supply must be free of scale forming lime or other impurities.

On both systems use flexible pipe for connecting water supply and outlet flow pipes to engine. Pipe the outlet flow to a convenient drain. Install an electric solenoid valve and a rate of flow valve in the water supply line. The electric solenoid valve opens and allows water flow through the system only when the plant operates. The rate of flow valve, either automatic or manual, provides for the proper flow rate to the engine. Adjust the flow to maintain water temperature between 165° F and 195° F (73.9° C and 90.6° C) while viewing the water temperature gauge.

Before filling cooling system check all hardware for security. This includes hose clamps, capscrews, fittings and connections. Use flexible coolant lines with heat exchanger, standpipe or remote mounting radiator.

WATER JACKET HEATER (Optional)

This heater is installed to maintain an elevated engine temperature in lower ambient temperature applications. It heats and circulates engine coolant, and is thermostatically controlled.

EXHAUST

WARNING

Inhalation of exhaust gases can result in death.

Engine exhaust gas must be piped outside building or enclosure. Do not terminate exhaust pipe near inlet vents or combustible materials. An approved thimble (Figure 8) must be used where exhaust pipes pass through walls or partitions. Pitch exhaust pipes downward or install a condensation trap (Figure 9) at the point where a rise in the exhaust system begins. Avoid sharp bends; use sweeping long radius elbows. Provide adequate support for mufflers and exhaust pipes. Refer to Figure 5 for a typical exhaust installation. Shield or insulate exhaust lines if there is danger of personal contact. Allow at least 9-inches (230 mm) of clearance if the pipes run close to a combustible wall or partition. Use a pipe at least as large as the 6-inch (152 mm) pipe size outlet of the engine with a flexible portion between the engine and the muffler.




FIGURE 8. EXHAUST THIMBLE




FIGURE 9. EXHAUST CONDENSATION TRAP

Do not connect a flexible line to the exhaust manifold. Minimum diameters and maximum lengths of pipe are as follows:

Single Exhaust system:

5-inch (127 mm) pipe	50 feet (15 m)
6-inch (152.4 mm) pipe	150 feet (46 m)
8-inch (203.2 mm) pipe	500 feet (152 m)

Maximum permissible exhaust restriction (back pressure) is 2-inches Hg. (6754 N/m²).




FIGURE 10. DAY TANK INSTALLATION

FUEL SYSTEM

Allis-Chalmers engines used on the DYG sets are designed for use with ASTM No. 2 Diesel fuel. They will however, operate on diesel fuels within the specifications delineated in the Allis-Chalmers engine manual.

FUEL CONNECTIONS

Check local regulations governing the installation of a fuel supply tank.

In any diesel engine installation, fuel system cleanliness is of utmost importance. Make every effort to prevent entrance of moisture or contaminants of any kind. Do not use lines or fittings of galvanized material.

A fuel lift in excess of 8 feet (2.44 m) is not recommended without a day tank installation, because of fuel drainage. Horizontal run, if the supply tank is level with the fuel pump, should not exceed 25-feet (7.6 m). However, a day tank is again recommended.

The fuel inlet is to the transfer pump and is threaded for 3/8-inch pipe. Injectors' return line requires a 1/4-inch low pressure hose connection.

DAY TANK

Generator set installations may be equipped with an optional separate fuel day tank. A float operated valve controls fuel flow into the fuel tank. The correct level is maintained to assure a constant source of fuel. It is necessary to install an overflow line between the day tank and the main fuel tank. Refer to the installations included with the tank. See Figure 10 for an example of a day tank installation.

BATTERY

Starting the unit requires 24-volt battery current. Use two 12-volt (see *Specifications*) batteries for a normal installation. Connect the batteries in series (negative post of first battery to positive post of second) as in Figure 11. Necessary battery cables are on unit. Service the batteries as necessary. Infrequent unit use (as in emergency standby service) may allow the batteries to self-discharge to the point where they cannot start the unit. If installing an automatic transfer switch that has no built-in charge circuit, connect a separate trickle charger. Onan automatic transfer switches include such a battery charging circuit.

WARNING Do not smoke while servicing batteries. Lead acid batteries give off explosive gases while being charged.




FIGURE 11. BATTERY CONNECTION

BATTERY, HOT LOCATION

Batteries will self discharge very quickly when installed where the ambient temperature is above 90° F (32° C), such as a boiler room. To extend battery life dilute the electrolyte from its normal 1.260 specific gravity at full charge to a 1.225 reading. The cranking power will be slightly reduced, but, in ambient temperatures above 90° F (32° C) this should not be noticed. The lengthened battery life will be worth the effort.

Reduce the specific gravity as follows:

WARNING Do not smoke or operate electrical equipment in the vicinity while servicing batteries. Explosive gases are emitted from batteries in operation, ignition of these gases can cause severe personal injury.

1. Fully charge the battery.
2. With the battery still on charge, draw off the electrolyte above the plates in each cell. DO NOT ATTEMPT TO POUR OFF; use a hydrometer or filler bulb and dispose of the acidic electrolyte in a safe manner. Avoid skin or clothing contact with the electrolyte.
3. Refill each cell with distilled water to the normal level.
4. Continue charging for 1 hour at a 4-6 ampere rate.
5. Test each cell. If the specific gravity is still above 1.225, repeat steps 2,3 and 4 until the reading is reduced to 1.225. Usually repeating steps twice is sufficient.

ELECTRICAL

150 kW AND 175 kW

REMOTE CONTROL CONNECTIONS

Provision is made for addition of remote starting. This is accomplished on a 4 place terminal block situated within the control box. Connect one or more remote switches across remote terminal and B+ terminal as shown in Figure 12. If the distance between the set and remote station is less than 1000-feet (305 m), use No. 18 AWG wire; between 1000- and 2000-feet (305 m and 610 m), use No. 16 AWG wire.





FIGURE 12. REMOTE STARTING

If the installation is for standby service, a double throw transfer switch must always be used. Connect this switch (either automatic or manual) so that it is impossible for commercial power and generator current to be connected to the load at the same time. Instructions for connecting an automatic load transfer control are included with such equipment.



NOTE: SHOWN WITH LINE CONNECTED TO LOAD.

FIGURE 13. LOAD TRANSFER SWITCH

WIRING CONNECTIONS

Most local regulations require that wiring connections be made by a licensed electrician and that the installation be inspected and approved before operation. All connections, wire sizes, etc. must conform to requirements of electrical codes in effect at the installation site.





FIGURE 14. CONTROL BOX (SIDE PANEL REMOVED)


Control Box Connections: The factory ships these 12 lead generators with load connection wires. NOT connected together in the control box. These 12 wires are labeled T1 through T12 and must be brought together before making load connections. Proceed as follows:

1. Remove either right, left or top panel from control box. See Figure 14.
2. Connect wires together as shown on panel and in Figure 15 according to voltage desired..

120/240 VOLT, 1 PHASE, 60 HERTZ



347/600 VOLT, 3 PHASE, 60 HERTZ



THIS DIAGRAM APPLIES TO 12 LEAD GENERATORS ONLY

NAMEPLATE VOLTAGE CODE	VOLTAGE	PHASES	HERTZ	CONNECT LEAD FROM TERMINAL 63 TO:	GENERATOR CONNECTION	GENERATOR CONNECTION SCHEMATIC DIAGRAM	GENERATOR CONNECTION WIRING DIAGRAM (WITH CURRENT TRANSFORMERS WHEN USED)
15	120/240	1	60	H5	DOUBLE DELTA		
515	115/230 110/220	1	50	H6			
6D	240/480	3	60	H5	SERIES DELTA		
15	120/240	3	60	H5			
515	115/230 110/220	3	50	H6			
15	120/208 127/220	3	60	H3	PARALLEL WYE		
	127/220	3	60	H4			
	139/240	3	60	H5			
515	110/190 115/200	3	50	H3			
	120/208	3	50	H4			
	127/220	3	50	H5			
15	240/416 254/440	3	60	H3	SERIES WYE		
	277/480	3	60	H5			
515	220/380	3	50	H3			
	230/400	3	50	H4			
	240/416	3	50	H4			
	254/440	3	50	H5			
7	220/380	3	60	H3			

98C2193

FIGURE 15. VOLTAGE CONNECTIONS

- Open hinged control panel doors. Connect lead from terminal 63 to correct terminal for voltage desired. These terminals are labeled H2, H3, H4, H5 and H6. See Figure 16.
- Close front panel and secure with 1/4 turn fasteners.
- Connect load wires to generator leads.

Preceding instructions do not apply to models with a 347/600 voltage (designated 9X); this connection is made at the factory. The installer must only connect load wires.




FIGURE 16. CONNECTING LEAD FROM TERMINAL 63

3 Phase, 4 Wire, Wye Connected Set; 12 Lead: The 3 phase, 4 wire set produces line to neutral voltage and line to line voltage. The line to neutral voltage is the lower voltage as noted on the unit nameplate, and the line to line voltage is the higher nameplate voltage.

For 3 phase loads, connect separate load wires to each of the set terminals L1, L2 and L3. Single phase output is obtained between any two 3 phase terminals.

The terminal marked L0 can be grounded. For 1 phase loads, connect the neutral (white) load wire to the L0 terminal. Connect the black load wire to any one of the other three terminals—L1, L2 or L3. Three separate 1 phase circuits are available, with not more than 1/3 the rated capacity of the set from any one circuit.

If using 1 phase and 3 phase current at the same time, use care to properly balance the 1 phase load, and not to exceed rated line current.

Figure 18 shows load connections for 120/208 voltage. Other voltages are available from either parallel wye or series wye illustration in Figure 15.




FIGURE 18. 3 PHASE, WYE CONNECTION, 12 LEAD

120/240 Volt, 3 Phase, 4 Wire Delta Connected Set; 12 Lead: The 3 phase Delta connected set is designed to supply 120- and 240 volt, 1 phase current and 240 volt, 3 phase current, Figure 17. For 3 phase operation, connect the three load wires to generator terminals L1, L2 and L3—one wire to each terminal. For 3 phase operation the L0 terminal is not used.

For 120/240 volt, 1 phase, 3 wire operation, terminals L1 and L2 are the "hot" terminals. The L0 terminal is the neutral, which can be grounded if required. For 120 volt service, connect the black load wire to either the L1 or L2 terminal. Connect the neutral (white) wire to the L0 terminal. Two 120 volt circuits are available. Any combination of 1 phase and 3 phase loading can be used at the same time as long as no terminal current exceeds the NAMEPLATE rating of the generator. If no 3 phase output is used, usable 1 phase output is 2/3 of 3 phase KVA.




FIGURE 17. 3 PHASE, DELTA CONNECTION, 12 LEAD

TABLE 2.
UR GENERATOR VOLTAGE OPTIONS

150.0 kW 187.5 kVA 60 Hz
125.0 kW 156.25 kVA 50 Hz

VOLTS	FREQ	PHASE	AMPERES	SERIES DELTA	PARALLEL WYE	SERIES WYE	REF. VOLTAGE WIRE (W12) TAP
120/240	60 Hz	3	451	x			H5
115/230	50 Hz	3	393	x			H6
120/208	60 Hz	3	520		x		H3
127/220	60 Hz	3	492		x		H4
139/240	60 Hz	3	451		x		H5
110/190	50 Hz	3	475		x		H3
115/200	50 Hz	3	452		x		H4
240/416	60 Hz	3	260			x	H3
254/440	60 Hz	3	246			x	H4
277/480	60 Hz	3	225			x	H5
220/380	50 Hz	3	238			x	H3
230/400	50 Hz	3	226			x	H4
9X 347/600	60 Hz	3	180				H3 Not Reconnectible

TABLE 2A.
UR GENERATOR VOLTAGE OPTIONS

175.0 kW 218.75 kVA 60 Hz
145.0 kW 181.25 kVA 50 Hz

VOLTS	FREQ	PHASE	AMPERES	SERIES DELTA	PARALLEL WYE	SERIES WYE	REF. VOLTAGE WIRE (W12) TAP
120/240	60 Hz	3	527	x			H5
115/230	50 Hz	3	455	x			H6
120/208	60 Hz	3	608		x		H3
127/220	60 Hz	3	575		x		H4
139/240	60 Hz	3	527		x		H5
110/190	50 Hz	3	551		x		H3
115/200	50 Hz	3	523		x		H4
240/416	60 Hz	3	304			x	H3
254/440	60 Hz	3	287			x	H4
277/480	60 Hz	3	263			x	H5
220/380	50 Hz	3	275			x	H3
230/400	50 Hz	3	262			x	H4
9X 347/600	60 Hz	3	211				H3 Not Reconnectible

ELECTRICAL

200 kW

REMOTE CONTROL CONNECTIONS

Provision is made for addition of remote starting. This is accomplished on a 4 place terminal block situated within the control box. Connect one or more remote switches across remote terminal and B+ terminal as shown in Figure 19. If the distance between the set and remote station is less than 1000-feet, use No. 18 AWG wire, between 1000- and 2000-feet, use No. 16AWG wire.




FIGURE 19. REMOTE STARTING




FIGURE 20. LOAD TRANSFER SWITCH

CONTROL BOX CONNECTION

Reconnection lead W12 on TB21 is a jumper which connects a single phase output from the generator to the appropriate tap on the voltage reference transformer. This lead is connected at one end to terminal 63 on the terminal board. The other end will be connected to a terminal marked H3, H4 or H5 depending upon the voltage option required. Refer to Table 3 and Figure 22 for voltages available and correct hookup.

WIRING CONNECTIONS

Most local regulations require that wiring connections be made by a licensed electrician and that the installation be inspected and approved before operation. All connections, wire sizes, etc. must conform to requirements of electrical codes in effect at the installation site.

If the installation is for standby service, a double throw transfer switch (Figure 20) must always be used. Connect this switch (either automatic or manual) so that it is impossible for commercial power and generator power to be connected to the load at the same time. Instructions for connecting an automatic transfer switch are included with such equipment.





FIGURE 21. CONTROL BOX CONNECTION

200 kW



SINGLE PHASE — NOT AVAILABLE

YB SERIES GENERATORS

98-2579(C)

FIGURE 22. VOLTAGE CONNECTIONS

GENERATOR CONNECTIONS

The model YB17 generator is a 3-phase 60-Hertz (or 50-Hertz) set which can be connected in either series wye or parallel wye configuration to give the line to neutral and line to line voltage options referred to in Table 1 and Figure 22. The line to neutral voltage is the lower voltage noted on the unit nameplate, while the line to line voltage is the higher nameplate rating. Refer to Figure 23 for an example of 120/208 voltage.




FIGURE 23. 3 PHASE WYE CONNECTION




FIGURE 24. LOAD WIRE CONNECTIONS

Bus bars and reconnection bars are aluminum, plated with tin to retard electrolytic corrosion. Select connecting cables and terminal lugs with care, to keep dissimilar metals apart. Do not overtorque bolts.

For 3-phase loads connect separate load wires to each of the set terminals L1, L2 and L3 (Figure 22). For a large single phase load only, connect between terminals L1 and L2. Available capacity is 2/3 maximum output.

The terminal L0 can be grounded. For 1-phase loads connect the neutral wire to the L0 terminal. Connect the load wire to either terminal — L1, L2. Two separate single phase circuits are available with a total capacity of up to 2/3 of the generator rated 3-phase output.

ONAN recommends that all connections from the generator to the bus-bars and from the bus-bars to the load be made by a qualified electrician. All applicable local and state laws should be complied with.

If using 1-phase and 3-phase current at the same time, ensure the 1-phase load is properly balanced. Do not exceed rated line current.

200 kW

TABLE 3. GENERATOR VOLTAGE OPTIONS

200.0 kW
153.0 kW

60 HZ
50 HZ

VOLTAGE	PHASE	FREQUENCY	MAXIMUM CURRENT	PARALLEL WYE	SERIES WYE	CONNECT WIRE W12
(YB17) 120/208	3	60 Hz	694 AMPS	x		H3
127/220	3	60 Hz	656 AMPS	x		H4
139/240	3	60 Hz	600 AMPS	x		H5
240/416	3	60 Hz	347 AMPS		x	H3
254/440	3	60 Hz	328 AMPS		x	H4
277/480	3	60 Hz	300 AMPS		x	H5
(YB517) 110/190	3	50 Hz	616 AMPS	x		H3
115/200	3	50 Hz	598 AMPS	x		H4
120/208	3	50 Hz	573 AMPS	x		H4
127/220	3	50 Hz	543 AMPS	x		H5
220/380	3	50 Hz	313 AMPS		x	H3
230/400	3	50 Hz	294 AMPS		x	H4
240/416	3	50 Hz	287 AMPS		x	H4
254/440	3	50 Hz	272 AMPS		x	H5

OPERATION

GENERAL

Onan DYG Series electric generating sets are given a complete running test under various load conditions and are thoroughly checked before leaving the factory. Inspect your unit closely for loose or missing parts and damage which may have occurred in transit. Tighten loose parts, replace missing parts and repair any damage before putting set into operation.

PRESTART SERVICING

Lubrication System: Engine oil was drained prior to shipment. Fill engine to capacities shown. After engine has been run, check dipstick, add oil to bring level to full mark. Record total capacity for future oil changes. For all operating conditions grade CD lubricating oil is recommended for turbocharged engines. Do not mix brands nor grades of lubricating oils.

Oil Viscosity should be as follows:

AMBIENT TEMPERATURE	USE SAE VISCOSITY
0° F (-17.8° C) and below	10W
0° F to 32° F (-17.8° C) 0° C	20-20W
Above 32° F (0° C)	30W

Oil Capacities (nominal)

Oil Pan and Filter—45-quarts (42.58 lit)

(200 kW) 60-quarts (56.8 lit.)

Oil quantity dipsticks have dual marking with high and low-level marks: static oil level on one side and engine at low speed marks on opposite side. Be sure to use proper scale.

Turbocharger: Remove oil inlet of center housing and pour .089 quarts (.085 lit) to .127 quarts (.120 lit) into the turbocharger housing. Fill oil inlet line with engine lubricating oil before reconnecting. Do this prior to initial start, and before starting if the engine has not been run for 30 days or more.

Cooling System: Cooling system was drained prior to shipment. Fill cooling system before starting. Nominal capacity is 16.5-gallons (62.5 lit). For units using either a radiator or heat exchanger (city water cooled), fill the system with clean soft water. Use a good rust and scale inhibitor additive. If a possibility

exists of a radiator cooled set being exposed to freezing temperatures use anti-freeze with an ethylene glycol base. During initial engine run, check the coolant level several times and replenish if necessary to compensate for air pockets which may have formed during filling. Refer to Allis-Chalmers engine manual for additional information.

CAUTION

1. Verify that the electric solenoid valve used with city water cooled sets is open before initial starting of unit to allow coolant chambers to fill. Overheating and damage to the engine could result from noncompliance.

2. If engine is equipped with a cooling system filter, do not use antifreeze with an anti-leak formula. The stop leak element can prevent or retard the coolant flow through the filter, thereby eliminating the filtering process completely.

WARNING

Be careful when checking coolant under pressure. It is advisable to shut engine down and bleed off pressure before removing pressure cap. Severe burns could result from contact with hot coolant.

Fuel System: Refer to the Allis-Chalmers engine manual for fuel oil specifications. Check with fuel supplier and ensure that fuel supplied meets the specifications. Filter or strain fuel when filling tank. Fuel supply tanks should be kept as nearly full as possible by topping up each time engine is used. Warm fuel returning from the injector pump heats the fuel in the supply tank. If the fuel level is low in cold weather, the upper portion of the tank not heated by returning fuel tends to increase condensation. In warm weather both the supply tank and fuel are warm. Cool night air lowers the temperature of the tank more rapidly than the temperature of the fuel. Again this tends to increase condensation.

Condensate mixing with the sulphur in the fuel forms a sulphurous acid which will corrode and damage the engine. KEEP FUEL CLEAN.

WARNING

DO NOT SMOKE while handling fuel. Diesel fuel is flammable.




FIGURE 25. FUEL FILTERS

Priming Fuel System: Verify that all connections in the fuel system are secure and no leaks exist. Proceed with priming as follows:

1. Loosen 2nd stage filter vent screw (Figure 25).
2. Using hand pump (Figure 26), prime system until fuel flow around filter vent screw is free of bubbles.
3. Secure vent screw and hand pump.

To bleed fuel injection pump sump refer to Figure 26. Disconnect fuel line from overflow valve and actuate hand primer. Continue pumping until fuel flow from valve is free of bubbles. Reconnect fuel line to overflow valve.

Ensure that hand primer pump is screwed in and secured before attempting to start engine.

Check all connections in fuel system for security, to ensure that pressure will not bleed off when engine is not in use. Pressure should be maintained for immediate starting if unit is on standby service.




FIGURE 26. FUEL INJECTION SYSTEM

Batteries

Ensure that the cable connections to the batteries are secure. Coat connections with petroleum based or non-conductive grease to retard formation of corrosive deposits.

Check level of electrolyte to be at split ring mark. Measure specific gravity of electrolyte: SG 1.260 at 80° F (26° C). If distilled water has been added or specific gravity is less than 1.260, place battery on charge until the desired reading is obtained. Do not over charge.

STARTING

When the preceding service functions have been performed, recheck to verify unit is ready to start.

1. Crankcase filled.
2. Cooling system filled—input solenoid valve open.
3. Batteries charged and connected.
4. Fuel solenoid valve open.

To start, move the "run-stop/reset-remote" switch to the "run" position. The engine should start after a few seconds of cranking. Immediately after start, observe the oil pressure gauge. Normal oil pressure is between 30 and 55 psi (207- and 379. kPa). Check the following gauges:

1. DC Ammeter—10 to 30 amperes.
2. AC Voltmeter—AC generator output voltage.
3. Frequency Meter—AC generator output frequency.

After running 10 minutes under load the water temperature gauge should have stabilized at 180° to 195° F (82.2° to 90.6° C). On city water cooled units an adjustable valve is connected in the water supply line. Adjust the hand wheel valve to provide a water flow that will keep the water temperature gauge reading within the range of 180° F to 200° F (82.2° to 93.3° C).

STOPPING

To reduce and stabilize engine temperatures, run the engine at no load for three to five minutes before shutting down. This will prevent damage to the turbocharger.

Move the run-stop/reset-remote switch to stop position to shut down the set.

Break-In Note: Run set at 50 percent rated load for the first half-hour of initial operation after reaching operating temperature.

Non-Start: If after a few seconds of cranking engine fails to start, or starts and runs then stops and fault lamp lights, refer to appropriate troubleshooting chart, Table 4 or Table 5.

TABLE 4.
TROUBLESHOOTING ENGINE SHUTDOWN SYSTEM
(Engines with only one fault lamp)

SYMPTOM	CORRECTIVE ACTION
1. Engine stops cranking and fault lamp lights, after cranking approximately 75 seconds.	<p>1. See engine service manual for troubleshooting fuel system.</p> <p>After correcting problem, reset engine monitor relay by placing Run-Stop/Reset-Remote switch to Stop/Reset, then back to the required running position.</p>
2. Fault lamp lights immediately after engine starts.	2. Check for: Overspeed condition as engine starts.
3. Fault lamp lights and engine shuts down after running for a period.	<p>3. Check the following:</p> <ul style="list-style-type: none"> a. Oil level. Engine will shut down if sensor is closed. b. Check engine manual for troubleshooting oil system. c. High engine temperature. Check coolant level; check water flow (city water cooled systems); check radiator for free air flow, and fan belts for tightness. See engine manual for troubleshooting cooling system. d. Check for faulty oil pressure sensor or faulty high engine temperature sensor.
4. Engine runs, shuts down and cranks for 75-seconds. Cranking cycle stops; fault lamp lights.	4. Check fuel supply.
5. Fault lamp lights, no fault exists.	5. To check a no-fault condition, disconnect leads from TB11 terminals 29, 30 and 31. If fault lamp lights with leads disconnected, replace engine monitor board. Reconnect leads.

TABLE 5.
TROUBLESHOOTING ENGINE SHUTDOWN
(Units with five fault lamps)

SYMPTOM	CORRECTIVE ACTION
1. Overcrank fault lamp lights and engine stops cranking after approximately 75-seconds.	1. See engine service manual for troubleshooting fuel system. After correcting fault, reset engine monitor relay by placing Run-Stop/Reset-Remote switch to Stop/Reset position, depressing Reset button, then to the required running position.
2. Engine runs, shuts down, cranks for 75-seconds, cranking cycle stops, overcrank light ON.	2. Check fuel supply.
3. *Low oil pressure shutdown.	3. Check — a. Oil level. Replenish if necessary. b. Sensor. Faulty sensor will shut down engine. c. Refer to engine service manual for troubleshooting guide for oil system.
4. *High engine temperature shutdown.	4. Check— a. Coolant level. Replenish if necessary. b. City water cooled sets. Check water flow, valves, etc. c. Check sensor; check thermostat. d. Radiator model, check fan belts, radiator for obstructions, etc.
5. Overspeed shutdown.	5. Check governor and throttle linkages for freedom of movement. Check overspeed switch.
6. Overspeed light on, no shutdown.	6. Disconnect wire at TB11-29. Light on after reset; replace engine monitor board.
7. *Low oil pressure light ON. No shutdown.	7. Disconnect wire at TB11-30. Light ON after relay reset. Replace engine monitor board.
8. *High engine temperature light ON. No shutdown.	8. Disconnect wire at TB11-31. Light ON after relay reset. Replace engine monitor board.

*NOTE: Not applicable on Pennsylvania State models.

EXERCISE PERIOD

Generating sets on continuous standby service are required to be operative at full load from a cold start in less than 10-seconds in the event of a power outage.

This imposes severe conditions on the engine. Friction of dry piston rings upon dry cylinder walls causes scuffing and rapid wearing. These can be relieved by exercising the set at least once a week for a minimum time of 30-minutes per exercise period. Preferably, run the set under at least 50 percent load to allow the engine to reach normal operating temperature. This will keep engine parts lubricated, maintain fuel prime, prevent electrical relay contacts from oxidizing and insure easy emergency starts. ONAN automatic transfer switches contain an optional exercise switch which, by pre-selection, will start, determine run period and shut down a set on a weekly frequency. For example, the switch can be set for time of start, length of run, A.M. or P.M. and day of week.

After each exercise period, refill fuel tank, check engine for leaks and unit for general condition. Locate cause of leaks (if any) and correct.

NO LOAD OPERATION

Periods of no load operation should be held to a minimum. If it is necessary to keep the engine running for long periods of time when no electric output is required, best engine performance will be obtained by connecting a "dummy" electrical load. Such a load could consist of heater elements, etc.

OUT OF SERVICE PROTECTION

For storage of all durations, refer to the Allis Chalmers engine manual.

HIGH ALTITUDE

Ratings apply to altitudes up to 1000-feet (305 m), standard cooling, normal ambients and with No. 2 Diesel fuel. Consult factory or nearest authorized Onan distributor for operating characteristics under other conditions.

Engine horsepower loss is approximately 3 percent for each 1000 feet (305 m) of altitude above sea level. Use lower power requirement at high altitudes to prevent smoke, over-fueling and high temperatures.

HIGH TEMPERATURES

1. See that nothing obstructs air flow to-and-from the set.
2. Keep cooling system clean.
3. Use correct SAE No. oil for temperature conditions.

LOW TEMPERATURES

1. Use correct SAE No. oil for temperature conditions. Change oil only when engine is warm.
2. Use fresh fuel. Protect against moisture condensation.
3. Keep fuel system clean and batteries in a well charged condition.
4. Partially restrict cool air flow but use care to avoid overheating.
5. Connect water jacket heater when set is not running.
6. Refer to Allis-Chalmers manual for further information.

Water Jacket Heater: The function of this optional heater is to keep the engine warm enough to assure starting under adverse weather conditions. Connect the heater to a source of power that will be on during the time the engine is not running. Be sure the voltage rating is correct for the heater element rating.

GENERAL MAINTENANCE

GENERAL

Follow a definite schedule of inspection and servicing, based on operating hours (Table 6). Keep an accurate logbook of maintenance, servicing, and operating time. Use the running time meter (optional equipment) to keep a record of operation and servicing. Service periods outlined below are recommended for normal service and operating conditions. For continuous duty, extreme temperature, etc., service more frequently. For infrequent use, light duty, etc., service periods can be lengthened accordingly. Refer to Allis-Chalmers engine manual for details of engine service and maintenance procedures.

WARNING Before performing any maintenance work on the engine, generator, control panel, automatic transfer switch or associated wiring, disconnect batteries. Failure to do so could result in damage to the unit or serious personal injury in the event of inadvertent starting.

ENGINE SPEED

Generator frequency is in direct ratio to engine speed, which is controlled by the governor.

A Woodward SG governor is standard equipment on the DYG generator set. High speed and low speed limit stops are set at the ONAN testing facility and normally do not require further adjustment, therefore if your set is used on continuous standby service, the governor may never need to be touched. If however the unit is used frequently, adjustment may be required due to wear of internal components. This adjustment is achieved by backing off the high speed stop screw. Screw in the low speed adjusting screw until the generator output frequency meter reads 60 Hz (generator on load). Turn in the high speed adjusting screw until it bottoms; secure the locknuts. Refer to Figure 27.

When using the generator frequency meter to determine engine speed, multiply frequency by 30 to calculate engine speed.

Example: $30 \times 61 \text{ (Hz)} = 1830 \text{ rpm}$.

Adjust engine speed to 1800 rpm for 60 Hz sets and 1500 rpm for 50 Hz sets.

Engine crankcase oil flows through the governor. Dirty oil can degrade governor operation.




FIGURE 27. WOODWARD GOVERNOR

DUST AND DIRT

1. Keep set clean. Keep cooling system free of dirt, etc.
2. Service air cleaners frequently.
3. Store oil and fuel in dust-tight containers.
4. See engine operation and maintenance manual.

AC GENERATOR

There are no brushes, brush springs or collector rings on these generators, therefore they require very little servicing. Periodic inspections, to coincide with engine oil changes, will ensure good performance.

Generator Bearing: Inspect the bearing every 1000 hours with the unit running.

If using the unit for "prime power," replace the bearing every 10,000 hours or two years. If using the set for "standby," replace the bearing every five years.

Check generator voltage. It may be necessary to make a slight readjustment of the voltage rheostat to obtain the preferred voltage at average load.

INSPECTION AND CLEANING

When inspecting the rotating rectifier assembly, make sure diodes are free of dust, dirt and grease. Excessive foreign matter on these diodes and heat sinks will cause the diodes to overheat and will result in their failure. Blow out the assembly periodically, with filtered, low pressure air. Also check to see that diodes and leadwires are properly torqued. The diodes should be torqued to 30 in. lb. (3.4 N•m) or finger tight plus a quarter turn. Blow dust out of control panel.

BATTERIES

Check the condition of the starting batteries at least every two weeks. See that connections are clean and tight. A light coating of non-conductive grease will retard corrosion at terminals. Keep the electrolyte at the proper level above the plates by adding distilled water. Check specific gravity, recharge if below 1.260.

CONNECTIONS (Fuel, Exhaust, etc.)

Operator should periodically make a complete visual inspection of the set while running at rated load. Some of the things to check for are as follows:

1. Check all fuel and oil lines for possible leakage.
2. Inspect exhaust lines and mufflers for possible leakage and cracks.
3. Periodically or daily, drain moisture from condensation traps.
4. Inspect water lines and connections for leaks and security.
5. Inspect electrical wires and connections for security and fray damage.

If generator requires major repair or servicing, contact an authorized Onan dealer or distributor.

TANK HEATERS (Optional)

A Kim Tank Heater is optional equipment on a DYG generating set. For efficient operation and optimum product life, perform the following procedure at least once a year.

1. Remove head and valve assembly.
2. Clean foreign matter out of the tank.
3. Remove element and scrape off scale accumulated on the sheathing.



compound.

When reassembling threaded aluminum parts, be sure to use anti-seize

TABLE 6. OPERATOR MAINTENANCE SCHEDULE

MAINTENANCE ITEMS	OPERATIONAL HOURS			
	8	50	100	200-250
Inspect Plant	x5			
Check Radiator Coolant	x			
Check Oil Level	x4			
Check Air Cleaner (Clean if Required)		x1		
Clean and Inspect Crankcase Breather			x	
Inspect Fan Belt			x2	
Check Cooling System			x3	
Clean and Inspect Battery Charging Alternator				x
Change Crankcase Oil			x1	
Replace Oil Filter Element			x1	
Check Batteries		x		

x1 - Or every 3 months, perform more often in extremely dusty conditions.


x2 - Or every 3 months, adjust to 1/2-inch (12 mm) depression between pulleys.

x3 - Or every 3 months, check for rust or scale formation. Flush if necessary.

x4 - For accurate readings, check oil level approximately 30 minutes after shut down. Keep oil level as near "FULL" mark on dipstick as possible. See engine manual.

x5 - Check Exhaust

NOTE: The above schedule is a minimum requirement. For the recommended service periods for your engine, refer to Topic 8 of the Allis-Chalmers engine manual.



ONAN 1400 73RD AVENUE N.E. • MINNEAPOLIS, MINNESOTA 55432
A DIVISION OF ONAN CORPORATION

