

Onan *Mobile GenSet*

Operator's Manual

HDKAL, HDKAS



Printed in U.S.A.

981-0104

California

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Table of Contents

SAFETY PRECAUTIONS	2
INTRODUCTION	4
About this Manual	4
Model Identification	4
Fuel Recommendations	4
Engine Oil Recommendations	4
Batteries	5
Genset-Mounted Control Panel	5
Remote Control Panels	5
OPERATION	6
Pre-Start Checks	6
Starting	6
Stopping	7
Powering Appliances	7
Connections to Utility Power	8
Resetting Line Circuit Breakers	8
Engine Break-In	8
No-load Operation	8
Genset Exercise	9
Genset Storage	9
Returning Genset to Service	9
PERIODIC MAINTENANCE SCHEDULE	10
MAINTENANCE PROCEDURES	11
General Inspection	11
Changing Oil and Oil Filter	12
Air Cleaner Maintenance	13
Spark Arrestor Cleaning	13
Batteries	13
Engine Cooling System	14
Fuel System	16
TROUBLESHOOTING	18
Engine Does Not Crank	18
Engine Cranks But Does Not Start	19
Fault Shutdown	19
Engine Lacks Power or Unstable	20
No Output Voltage	20
SPECIFICATIONS	21
INFORMATION FOR CALIFORNIA GENSET USERS	22
HOW TO OBTAIN SERVICE	23
MAINTENANCE RECORD	24

Safety Precautions

Thoroughly read the **OPERATOR'S MANUAL** before operating the genset. Safe operation and top performance can be obtained only by proper operation and maintenance.

The following symbols in this Manual alert you to potential hazards to the operator, service personnel and equipment.

⚠ DANGER *alerts you to an immediate hazard which will result in severe personal injury or death.*

⚠ WARNING *alerts you to a hazard or unsafe practice which can result in severe personal injury or death.*

⚠ CAUTION *alerts you to a hazard or unsafe practice which can result in personal injury or equipment damage.*

Electricity, fuel, exhaust, moving parts and batteries present hazards which can result in severe personal injury or death.

GENERAL PRECAUTIONS

- Keep ABC fire extinguishers handy.
- Make sure all fasteners are secure and torqued properly.
- Keep the genset and its compartment clean. Excess oil and oily rags can catch fire. Dirt and gear stowed in the compartment can restrict cooling air.
- Let the engine cool down before removing the coolant pressure cap or opening the coolant drain. Hot coolant under pressure can spray out and cause severe burns.
- Before working on the genset, disconnect the negative (–) battery cable at the battery to prevent starting.
- Use caution when making adjustments while the genset is running—hot, moving or electrically

live parts can cause severe personal injury or death.

- Used engine oil has been identified by some state and federal agencies as causing cancer or reproductive toxicity. Do not ingest, inhale, or contact used oil or its vapors.
- Do not work on the genset when mentally or physically fatigued or after consuming alcohol or drugs.
- Carefully follow all applicable local, state and federal codes.

GENERATOR VOLTAGE IS DEADLY!

- Generator output connections must be made by a qualified electrician in accordance with applicable codes.
- The genset must not be connected to the public utility or any other source of electrical power. Connection could lead to electrocution of utility workers, damage to equipment and fire. An approved switching device must be used to prevent interconnections.
- Use caution when working on live electrical equipment. Remove jewelry, make sure clothing and shoes are dry and stand on a dry wooden platform on the ground or floor.

FUEL IS FLAMMABLE AND EXPLOSIVE

- Keep flames, cigarettes, sparks, pilot lights, electrical arc-producing equipment and switches and all other sources of ignition well away from areas where fuel fumes are present and areas sharing ventilation.
- Fuel lines must be secured, free of leaks and separated or shielded from electrical wiring.
- Use approved non-conductive flexible fuel hose for fuel connections at the genset.

ENGINE EXHAUST IS DEADLY!

- Learn the symptoms of carbon monoxide poisoning in this manual.
- Never sleep in the vehicle while the genset is running unless the vehicle has a working carbon monoxide detector.
- The exhaust system must be installed in accordance with the genset Installation Manual.
- Do not use engine cooling air to heat the vehicle interior.
- Make sure there is ample fresh air when operating the genset in a confined area.

MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Do not wear loose clothing or jewelry near moving parts such as PTO shafts, fans, belts and pulleys.
- Keep hands away from moving parts.
- Keep guards in place over fans, belts, pulleys, etc.

BATTERY GAS IS EXPLOSIVE

- Wear safety glasses and do not smoke while servicing batteries.
- When disconnecting or reconnecting battery cables, always disconnect the negative (–) battery cable first and reconnect it last to reduce arcing.

DO NOT OPERATE IN FLAMMABLE AND EXPLOSIVE ENVIRONMENTS

Flammable vapor can cause a diesel engine to overspeed and become difficult to stop, resulting in possible fire, explosion, severe personal injury and death. ***Do not operate a diesel-powered genset where a flammable vapor environment can be created by fuel spill, leak, etc., unless the genset is equipped with an automatic safety device to block the air intake and stop the engine.*** The owners and operators of the genset are solely responsible for operating the genset safely. Contact your authorized Onan/Cummins dealer or distributor for more information.

BATTERIES

The genset requires a 12 volt battery to power its control and starting circuits. Reliable genset starting and starter service life depend upon adequate battery system capacity and maintenance. See *Specifications* for battery requirements and *Periodic Maintenance* for battery care.

GENSET-MOUNTED CONTROL PANEL

Figure 3 illustrates the genset control panel.

Start-Stop-Preheat Switch (S1): Starts the genset when held at **Start** and stops the genset when momentarily touched to **Stop**. Holding the switch at **Stop** causes the glow plugs to preheat the combustions chambers.

DC Control Breaker: Protects the control circuits from shorts to ground. Can be used as an emergency stop switch. *Reset with handle.*

Hour Meter: Indicates the number of hours the genset has run. It cannot be reset.

Fault Reset Breaker: Trips and shuts down the genset when there is a low oil pressure or high coolant temperature fault condition. *Reset by pushing in the red button.*

REMOTE CONTROL PANELS

Figure 4 illustrates one of several remote control panels that are available. The gauges on the panel shown indicate engine oil pressure, coolant temperature and control system DC voltage.




FIGURE 3. GENSET CONTROL PANEL




FIGURE 4. REMOTE PANEL WITH GAUGES

Operation

⚠ WARNING EXHAUST GAS IS DEADLY!

Engine exhaust contains carbon monoxide, a poisonous, odorless and colorless gas that can cause unconsciousness and death. Symptoms of carbon monoxide poisoning include:

- *Dizziness*
- *Throbbing in Temples*
- *Nausea*
- *Muscular Twitching*
- *Headache*
- *Vomiting*
- *Weakness*
- *Trouble Thinking Clearly*
- *Sleepiness*

GET EVERYONE OUT INTO FRESH AIR IMMEDIATELY IF ANYONE EXPERIENCES ANY OF THESE SYMPTOMS. Seek medical attention if symptoms persist.

Never sleep in the vehicle when the genset is running unless the vehicle has an operating carbon monoxide detector.

Look and listen for leaks along the entire run of the exhaust system every time you start up the genset and every eight hours if the genset is being run continuously. Shut down the genset immediately if there is a leak and do not run it until the leak has been repaired.

The installation of the exhaust system must be in accordance with the genset Installation Manual.

PRE-START CHECKS

Perform General Inspection (p. 11). **Check for fuel, exhaust, oil and coolant leaks every eight hours if the genset is being run continuously.**

Check the *Maintenance Record* and perform any maintenance due (*Periodic Maintenance Schedule*). Also see GENSET BREAK-IN if the genset is new and RETURNING THE GENSET TO SERVICE if the vehicle has been in storage.

STARTING

1. Disconnect all loads from the genset.
2. **Preheat** – Hold the control switch in the **PRE-HEAT** position for the following number of seconds depending on ambient temperature:

10 seconds—above 50° F (10° C)

15 seconds—0° F to 50° F (–17° to 10° C)

20 seconds—below 0° F (–17° C)

⚠ CAUTION Preheat times longer than 20 seconds can damage the glow plugs.

3. **Start** – Immediately after **PREHEAT** push the control switch to **START** and hold it there until the engine starts. The starter will automatically disconnect as the engine starts up.

Do not crank for more than 15 seconds at a time. Wait two minutes before trying again. See *Troubleshooting* if the engine does not start on the second try.

⚠ CAUTION Excessive cranking can over-heat and damage the starter. Do not crank for more than 15 seconds at a time and wait two minutes before trying again.

4. Connect the electrical loads after the genset has warmed up for a few minutes.
5. Check for fuel, exhaust, oil and coolant leaks and complete General Inspection (p. 11). Check the engine gauges regularly (if provided) while the genset is running.
 - **Oil Pressure Gauge:** Normal engine oil pressure is 28 – 64 psi (194 – 442 kPa) at normal operating temperature.
 - **DC Voltmeter:** Normal DC system voltage is 12.5 – 15 volts depending on battery condition and state-of-charge.
 - **Coolant Temperature Gauge:** Normal engine coolant temperature is 160 – 195° F (71 – 91° C) depending on load and ambient temperature.

STOPPING

Before stopping let the genset cool down by running at no-load for three to five minutes. Then touch the control switch momentarily to **STOP**.

⚠ CAUTION *Failure to let the engine cool down before stopping can lead to engine damage. Let the genset run three to five minutes at no-load before stopping.*

POWERING APPLIANCES

The genset can power AC motors, air conditioners, AC/DC converters and other appliances. How much appliance load* can be serviced depends upon the genset power rating. The genset will shut down or its circuit breakers will trip if the sum of the loads exceeds genset rating.

To avoid overloading the genset and causing shut-downs, compare the sum of the loads of the appliances that are likely to be used at the same time to the power rating of the genset. Use Table 1 or the ratings on the appliances themselves (if so marked) to obtain the individual appliance loads. ***It may be necessary to run fewer appliances at the same time so that the sum of the loads is not greater than genset rating.***

Note that the genset may shut down due to overload, even though the sum of the loads is less than genset rating, when a large motor or air conditioner is started last or cycles off and then on again. The reason for this is that motor startup load is much larger than running load. ***It may be necessary to run fewer appliances when large motors and air conditioners are cycling on and off.***

Note that air density decreases as altitude increases, decreasing engine power. Power decreases approximately 3 percent of rated power every 1000 feet (305 m) that elevation increases above sea level. See Table 2 for typical calculations. ***It may be necessary to operate fewer appliances at higher altitudes.***

TABLE 1. TYPICAL APPLIANCE LOADS

Appliance	Load (watt)
Air Conditioner	1400-2000
Battery Charger	Up to 800
DC Converter	300-1500
Refrigerator	600-1000
Microwave Oven	1000-1500
Electric Frying Pan/Wok	1000-1500
Electric Stove Element	350-1000
Electric Water Heater	1000-1500
Electric Iron	500-1200
Electric Hair Dryer	800-1500
Coffee Percolator	550-750
Television	200-600
Radio	50-200
Electric Drill	250-750
Electric Broom	200-500
Electric Blanket	50-200

TABLE 2. MAXIMUM POWER VS. ALTITUDE

Elevation above Sea Level	Maximum Power
at/below 500 ft (152 m)	7500 W (rated)
at 2500 ft (762 m)	7050 W
at 5500 ft (1676 m)	6375 W
above 5500 ft (1676 m)	6375 W minus 225 W every 1000 ft (305 m)

* Appliance load and genset power are measured in terms of watt (W) or kilowatt (kW), where 1 kilowatt (kW) = 1000 watt (W).

CONNECTIONS TO UTILITY POWER

A vehicle that has provisions for connection to utility power must be equipped with an approved transfer switch to keep the genset and utility power from being interconnected.

⚠WARNING *Backfeed to utility power can cause electrocution and damage to equipment. Use an approved device to prevent the genset from being interconnected with utility power.*

RESETTING LINE CIRCUIT BREAKERS

If a circuit breaker in the main power distribution panel in the vehicle or on the genset (Figure 5) trips, there is either a short circuit or too much load. Note that the genset will continue to run after a circuit breaker trips.

If a circuit breaker trips, disconnect or turn off as many appliances as possible and reset the circuit breaker. (Push the circuit breaker **OFF** to reset it and then **ON** to reconnect the circuit.) If the circuit breaker trips right away, either the electrical distribution system has a short or the circuit breaker is faulty. Call a qualified electrician.

If the circuit breaker does not trip, reconnect a combination of appliances that does not overload the genset or cause the circuit breaker to trip. An appliance that causes a circuit breaker to trip right away probably has a short.

Electrical appliances must be properly grounded and in good working condition.

⚠WARNING *Electrical shock can cause severe personal injury or death. Read and follow the appliance manufacturer's instructions and warnings.*

ENGINE BREAK-IN

Change the oil and oil filter after the first 50 hours of operation. See *Maintenance Procedures*.

NO-LOAD OPERATION

Keep no-load operation to a minimum. During no-load operation combustion chamber temperatures drop to the point where fuel does not burn completely, causing slobbering and white smoke. Always have some load connected when the genset is run for long periods.




FIGURE 5. GENSET MOUNTED LINE CIRCUIT BREAKERS

GENSET EXERCISE

If use is infrequent, run the genset at approximately 1/2 rated power for an hour every week. Exercising the genset results in better starting, longer engine life and increased genset reliability by driving off moisture, re-lubricating the engine, using up fuel before it becomes stale and removing oxides from electrical contacts. One longer period during which the engine and generator warm up thoroughly is better than several shorter periods.

GENSET STORAGE

If the genset will be inactive for more than 30 days and it is impractical to have someone exercise it, prepare it for storage as follows:

1. Run the genset until it has thoroughly warmed up and shut it down.

⚠WARNING *Crankcase pressure can blow out hot oil and cause severe burns. Stop the engine before checking the oil level or opening the fill cap.*

2. Change the oil and oil filter while still warm and attach a tag to the dip stick indicating the oil viscosity grade. See CHANGING OIL AND OIL FILTER in *Maintenance Procedures*.

⚠WARNING *Arcing at battery terminals or in a light switch or other equipment, flames and sparks can ignite battery gas causing severe personal injury. Ventilate the battery compartment before connecting or disconnecting battery cables—Disconnect the negative (–) cable first and reconnect it*

last—Wear safety glasses—Do not smoke—Switch lights ON and Off away from the battery.

3. Disconnect the battery cables (negative [–] cables first) and store the battery(ies) in accordance with the manufacturer's recommendations.

⚠WARNING *Hot coolant is under pressure and can cause severe burns when loosening the pressure cap. Let the engine cool before loosening the pressure cap.*

4. Check the coolant level and add coolant as necessary. Test the coolant mixture if freezing temperatures are possible and change if necessary. See ENGINE COOLING SYSTEM in *Maintenance Procedures*.
5. Clean the genset and lightly oil parts that can rust.

RETURNING GENSET TO SERVICE

1. Check the tag on the dipstick and change the oil if the viscosity is not suitable for present and anticipated ambient temperatures.
2. Reconnect the battery(ies) (negative [–] cables last) and service as necessary in accordance with the manufacturer's instructions.
3. Prime the fuel system (p. 17).
4. Perform PRE-START CHECKS and start and run the genset according to STARTING. Perform maintenance or service as required before placing the genset in service.

Periodic Maintenance Schedule

Periodic maintenance is essential for top genset performance and long service life. Use Table 3 as a guide, follow *Maintenance Procedures* and record maintenance performed in *Maintenance Record*.

⚠ WARNING *Accidental starting can cause severe personal injury or death. Disconnect the negative (–) cable(s) at the battery(ies) to prevent starting while working on the genset.*

TABLE 3. PERIODIC MAINTENANCE SCHEDULE

PROCEDURE	FREQUENCY								Page
	After first 50 Hrs	Every Day/ 8 Hrs	Every 50 Hrs	Every Month/ 100 Hrs	Every 6 Month/ 250 Hrs	Every Year/ 500 Hrs	Every 2 Years	Every 5 years	
Inspect Genset		x ¹							11
Check Oil Level		x							11
Check Coolant Level		x							11
Check Fuel Level		x							11
Clean Spark Arrestor			x						13
Clean Air Cleaner Dust Boot			x ⁵						13
Check Battery				x ²					13
Check V-Belt Tension				x ³					14
Drain Water in Fuel				x ⁴					16
Change Engine Oil and Oil Filter	x			x ⁵					12
Change Fuel Filter					x				16
Change Air Cleaner Element						x ⁵			13
Change Coolant						x			14
Adjust Valve Lash						x ⁶			–
Replace Pressure Cap							x		14
Replace Generator Bearing								x ⁶	–
1 – Check for oil, fuel, coolant and exhaust system leaks. 2 – See battery manufacturer's recommendations. 3 – Check for slippage. 4 – Drain about one cup to remove water and sediment. 5 – Perform more often in dusty conditions. 6 – Must be performed by an authorized Onan dealer.									

Maintenance Procedures

GENERAL INSPECTION

Perform these checks and inspections every time the genset is started or every eight hours if the genset is being run continuously.

Oil Level Check

⚠ WARNING *Crankcase pressure can blow out hot oil and cause severe burns. Stop the engine before checking the oil level or opening the fill cap.*

Shut down the genset to check engine oil level and wait a few minutes for the oil to drain down to the crankcase to get an accurate indication of oil level.

Keep the oil level between FULL and ADD on the dipstick (Figure 6). See ENGINE OIL RECOMMENDATIONS (p. 4) for the oil to use.

⚠ CAUTION *Too little oil can lead to severe engine damage and too much oil to high oil consumption and foaming, which can cause engine shutdown. Keep the oil level between FULL and ADD.*

Coolant Level Check

Replenish the normal loss of coolant by keeping the level in the coolant recovery tank between COLD and HOT. See COOLING SYSTEM for the recommended mixture of antifreeze and if it is necessary to refill the system.

Exhaust Leaks

Look and listen for exhaust system leaks while the genset is running. Shut down the genset if a leak is found and have it repaired before operating the genset.

Look for openings or holes between the genset compartment and vehicle cab or living space if the genset engine sounds louder than usual. Have all such openings or holes closed off or sealed to prevent exhaust gases from entering the vehicle.

Replace dented, bent or severely rusted sections of the tailpipe and make sure the tailpipe extends at least 1 inch (25.4 mm) beyond the perimeter of the vehicle.

Park the vehicle so that the genset exhaust gases can disperse away from the vehicle. Barriers such as walls, snow banks, high grass, brush and other

vehicles can cause exhaust gases to accumulate in and around the vehicle.

To avoid drawing exhaust gases into the vehicle, do not turn on power ventilators or exhaust fans when the genset is running and the vehicle is standing still.

⚠ WARNING *EXHAUST GAS IS DEADLY! Do not operate the genset if there is an exhaust leak or any danger of exhaust gases entering or being drawn into the vehicle.*

⚠ WARNING *Do not park the vehicle in high grass or brush. Contact with the exhaust system can cause a fire.*

Fuel System Inspection

Check for leaks at all fuel line fittings and gaskets. Replace fuel hose that has been abraded or cut and install new hose in such a way that it will not become kinked, rub against other parts or come in contact with sharp edges, hot surfaces or wiring.

⚠ WARNING *Fuel leaks can lead to fire. Repair leaks immediately. Do not run the genset if it causes fuel to leak.*

Prime the fuel system if the genset ran out of fuel or a fuel filter was replaced. See FUEL SYSTEM.

Battery Inspection

Check for clean, tight battery connections. Loose and corroded connections make for hard starting because of high electrical resistance. See BATTERIES.

⚠ WARNING *Arcing at battery terminals or in a light switch or other equipment, flames and sparks can ignite battery gas causing severe personal injury. Ventilate the battery compartment before connecting or disconnecting battery cables—Disconnect the negative (–) cable first and reconnect it last—Wear safety glasses—Do not smoke—Switch lights ON and Off away from the battery.*

Mechanical Inspection

Check for unusual noises and vibrations, loose genset mounts and signs of mechanical damage. Check the engine gauges regularly (if provided) while the genset is running. See *Operation* for normal gauge readings.

Keep the genset clean. Do not clean the genset while it is running. Protect the generator, control panel, and electrical connections from cleaning solvents. Remove the generator endbell cover and use compressed air to blow dust out of the generator and radiator core.

⚠WARNING *Wear safety glasses when using compressed air to prevent eye injury.*

CHANGING OIL AND OIL FILTER

⚠WARNING *State and federal agencies have determined that contact with used engine oil can cause cancer or reproductive toxicity. Take care to limit skin contact and breathing of vapors. Use protective gloves and wash exposed skin.*

See Table 3 for frequency of maintenance.

⚠WARNING *Crankcase pressure can blow out hot oil and cause severe burns. Stop the engine before checking the oil level or opening the fill cap.*

Draining Engine Oil: To drain the engine oil, run the engine until thoroughly warm and stop it. Open either the side or bottom service access door to get at the oil drain valve and oil filter (Figure 6). Drain

the oil into a suitable container and **close the valve when the oil has completely drained.**

Changing Oil Filter: To change the oil filter, place a container under the oil filter (Figure 6) to catch oil that drips out and then spin off the oil filter. Clean the filter mounting surface (making sure to remove the old gasket), apply oil to the new filter gasket and spin the filter on until the gasket just touches the mounting pad. Then tighten an additional 3/4 turn.

Refilling Engine Oil: See ENGINE OIL RECOMMENDATIONS (p. 4) for the oil to use and Specifications for the amount. Refill with the proper amount of oil, start the engine and check for leakage around the filter gasket. **Tighten the filter only enough to stop leakage.** Shut off the genset, re-check the oil level and add oil as necessary. Secure the access door.

⚠CAUTION *Too little oil can lead to severe engine damage and too much oil to high oil consumption and foaming, which can cause engine shutdown. Keep the oil level between FULL and ADD.*

Disposing of Used Oil and Oil Filter: Dispose of the used oil and oil filter according to local environmental regulations.




FIGURE 6. OIL CHECK, FILL, DRAIN AND FILTER

AIR CLEANER MAINTENANCE

See Table 3 for frequency of maintenance. The air cleaner element must be handled carefully and must never have oil applied to it. Before changing the filter element, squeeze the dust boot to release any trapped dust. Install the new filter element as follows:

1. Unclip the cover (Figure 7) and pull the filter element out gently to reduce the amount of dust dislodged. Gently twist or move the element side to side to disengage the seal and pull it out.
2. Clean the sealing surface and inside of the outlet tube to keep dust and dirt from entering the engine.
3. Examine the old filter element for dust on the clean-air side of the element. This could indicate leakage on the sealing surface. Correct as necessary.
4. Inspect the new element for damage. *Do not install a damaged element.* Insert the new element into the housing, applying pressure at the outer rim of the element and not on its flexible center, and secure the cover.

SPARK ARRESTOR CLEANING

See Table 3 for frequency of maintenance. Cleaning is necessary to maintain good performance and meet Forest Service requirements. To clean the spark arrestor, remove the 1/8 inch pipe plug in the bottom of the muffler and run the genset for five minutes at full load. Replace the plug when the muffler has cooled down. See Figure 8.

BATTERIES

See Table 3 for frequency of maintenance. Sealed, maintenance-free batteries are recommended. Follow the manufacturer's instructions for battery care. Keep the terminals clean and tight.

⚠WARNING *Arcing at battery terminals or in a light switch or other equipment, flames and sparks can ignite battery gas causing severe personal injury. Ventilate the battery compartment before connecting or disconnecting battery cables—Disconnect the negative (–) cable first and reconnect it last—Wear safety glasses—Do not smoke—Switch lights ON and Off away from the battery.*




FIGURE 7. AIR CLEANER ASSEMBLY




FIGURE 8. SPARK ARRESTOR WITH CLEANOUT PLUG

ENGINE COOLING SYSTEM

See Table 3 for frequency of maintenance.

Cooling System Overview

The engine is cooled by a pressurized, closed-loop liquid cooling system. Coolant is pumped through passages in the engine block and head and is cooled in a genset-mounted radiator. The radiator fan is arranged to either pull or push air through the radiator.

Recommended Coolant Mixture

Use the best quality ethylene or propylene glycol antifreeze solution available. It should be fully formulated with rust inhibitors and coolant stabilizers **but not with stop-leak additives**. Use fresh water that is low in minerals and corrosive chemicals. Distilled water is best. Unless prohibited by shipping regulations, gensets are shipped with the recommended 50/50 mixture of water and ethylene glycol, which is good for -34° F (-37° C).

Adjusting V-Belt Tension

See Table 3 for frequency of maintenance. The V-belt (Figure 9) drives the coolant pump and battery charging alternator. (The radiator fan is mounted on the crankshaft pulley and therefore is not driven by the belt.)

⚠WARNING *Accidental starting can cause severe personal injury or death. Disconnect the negative (–) cable(s) at the battery(ies) to prevent the engine from starting.*

1. Disconnect the negative (–) cable(s) at the battery(ies) to prevent the engine from starting and remove the top belt guard.
2. Loosen the alternator pivot bolt first and then the adjusting bracket bolt on top.
3. Tighten belt tension by pivoting the alternator outwards. Hold tension by tightening the adjusting bracket bolt. Apply 20 pounds (10 kg) as shown to the middle of the pulley span and measure belt deflection, which should be 0.4 inch (10 mm). Tighten the alternator bolts when tension is correct.
4. Secure the belt guard and reconnect the battery cables (negative [–] last).




FIGURE 9. ADJUSTING V-BELT TENSION

Pressure Cap

See Table 3 for frequency of replacement. Replace the pressure cap as recommended to maintain optimal engine cooling and minimal coolant loss.

Coolant Recovery Tank

Replenish the normal loss of coolant by keeping the level in the recovery tank between COLD and HOT. Use the recommended mixture of antifreeze. See Changing Coolant if it is necessary to fill the system.

Changing Coolant

⚠ WARNING *Hot coolant is under pressure and can cause severe burns when loosening the pressure cap. Let the engine cool before loosening the pressure cap.*

⚠ WARNING *Accidental starting can cause severe personal injury or death. Disconnect the negative (–) cable(s) from the battery(ies) to prevent the engine from starting.*

Draining the System: Let the engine cool down, disconnect the negative (–) cable(s) at the battery(ies) to prevent the engine from starting, remove the system pressure cap and open the

block and radiator drain valves (Figure 10). Collect used coolant in containers for proper disposal.

⚠ WARNING *Ethylene glycol antifreeze is considered toxic. Dispose of it according to local regulations for hazardous substances.*

Cleaning and Flushing the System: Use radiator cleaning chemicals to clean and flush the cooling system before new coolant is added. Follow the manufacturer's instructions.

⚠ CAUTION *Filling a hot engine with cold water can cause cracks in the manifold, head and block. Follow the manufacturer's instructions for cleaning and flushing.*

Filling the System: Close all drain valves and secure all hose clamps and fill the system through the fill opening, holding the fill hose vertical. The system will fill only as fast as the air can escape. Start and run the engine for a minute to dislodge air pockets and shut it down. Add as much coolant as necessary to fill up the tube and secure the pressure cap.

⚠ CAUTION *Low coolant level can cause severe engine damage. Make sure the system is full.*




FIGURE 10. COOLING SYSTEM

FUEL SYSTEM

Fuel Handling Precautions

Keep dirt, water and other contaminants from entering the fuel system and damaging, corroding or clogging fuel injection components. The genset has a water-separator type of fuel filter.

A primary source of water in fuel, which can clog fuel passages by freezing and cause corrosion by forming sulfuric acid with the sulfur in the fuel, is the condensation of humid air on the walls of the fuel tank. Keeping fuel tanks as full as possible reduces condensation by reducing the area on which condensation can take place.

Fuel Filter

Draining Water and Sediment: See Table 3 for frequency of maintenance. Drain more often if fuel quality is poor or condensation cannot be avoided.

To drain the filter, remove the plug (Figure 11), collect the water and sediment (about 1/2 cup [120 ml]) in a suitable container and dispose of properly.

Reinstall the plug securely.

Replacing the Filter Element: See Table 3 for frequency of maintenance. Replace the filter sooner if the engine lacks power or surges.

1. Drain the filter as explained above and spin off the element.
2. Clean the contact surface of the base.
3. Lubricate the new element and its gasket, and fill the element with clean diesel fuel.
4. Spin the new element onto the base and hand tighten.
5. Start and run the genset and check for fuel leakage. Tighten the filter only enough to stop leakage. See Priming the Fuel System if the genset does not start.




FIGURE 11. FUEL SYSTEM

Priming the Fuel System

Priming the Low-Pressure Side: The fuel lift pump is usually able to prime the low-pressure side during cranking. If the engine does not start after two tries (15 second crankings with a two minute rest between crankings), jumper the fuel lift pump directly to the 12 VDC cranking battery and let the pump run for a few minutes to make sure the fuel lines, fuel filter and injection pump have been purged of all air. (The air and fuel are returned to the fuel tank. There are no bleed screws to open.)

Note: If the genset has been mounted at an elevated location on the vehicle, the vehicle manufacture probably has provided an auxiliary fuel pump and solenoid shutoff valve which must also be energized during priming. Check with the vehicle manufacturer if it is not clear as to how the auxiliary pump and solenoid should be energized.

Priming the High-Pressure Side: This procedure should only be performed by a diesel mechanic.

⚠WARNING *The high pressure oil spray from an injector line fitting can penetrate the skin, leading to possible blood poisoning. Wear safety glasses and keep your hands away from the spray. Do not delay getting proper medical attention if oil spray penetrates your skin.*

1. Loosen the high pressure fittings at the nozzles. Use two wrenches to keep from twisting the return fittings. Use flare-nut wrenches to keep from rounding the shoulders.
2. Crank the genset until fuel appears at the loosened fittings and then snug up each fitting. The engine should start and run when the first fitting is snugged.
3. Shut down the engine and torque the fittings to 19 – 25 lb-ft (25 – 34 N-m).

USE TWO FLARE-NUT WRENCHES TO LOOSEN THESE FITTINGS TO BLEED HIGH PRESSURE INJECTOR LINES
WEAR SAFETY GLASSES AND KEEP FINGERS OUT OF SPRAY




FIGURE 12. PRIMING THE HIGH-PRESSURE FUEL INJECTION SYSTEM

Troubleshooting

The following troubleshooting tables are designed to help you think through genset problems. The problem could be as simple as an empty fuel tank, closed fuel shutoff valve or tripped circuit breaker. If you fail to resolve the problem after taking the corrective actions suggested, see *How to Obtain Service*.

Troubleshooting time can be saved if abnormal engine gauge readings were noted before shutdown; that is, whether shutdown was due to low oil pressure or to high engine temperature. Note that shutdown occurs when oil pressure falls below 14 psi (97 kPa) or engine temperature reaches 222° F (106° C).

ENGINE DOES NOT CRANK	
⚠ WARNING <i>There are hazards present in troubleshooting that can cause equipment damage, severe personal injury or death. Troubleshooting must be performed by qualified persons who know about the hazards of fuel, electricity and machinery. Read Safety Precautions and observe all instructions and precautions in this manual.</i>	
Possible Cause	Corrective Action
1. Faulty remote circuit	Try starting at the genset control panel. If the genset starts, have the remote circuit repaired as necessary.
2. Fault shutdown	Perform maintenance or have service performed as necessary to clear the fault condition. Push the red button on the fault reset breaker on the genset-mounted control panel to reset the control panel.
3. Tripped DC control breaker	Reset the control breaker handle. Have the genset serviced if it keeps tripping.
4. Low cranking voltage	a. Clean and tighten or replace the positive (+) and negative (–) battery cable connectors and cables at the battery and the genset. b. Recharge or replace the battery. Specific gravity for a fully charged battery is approximately 1.260 at 80° F (27° C).

ENGINE CRANKS BUT DOES NOT START

⚠ WARNING *There are hazards present in troubleshooting that can cause equipment damage, severe personal injury or death. Troubleshooting must be performed by qualified persons who know about the hazards of fuel, electricity and machinery. Read Safety Precautions and observe all instructions and precautions in this manual.*

Possible Cause	Corrective Action
1. Engine not getting fuel	<ul style="list-style-type: none"> a. Open any closed shutoff valve. b. Check fuel level and refill as necessary. c. Prime the fuel system (p.12). d. Check for fuel (air) leaks at all fittings and tighten as necessary. e. Replace the fuel filter (p. 16).
2. Low engine temperature	<ul style="list-style-type: none"> a. Plug in, repair or install engine coolant and engine oil heaters. b. Replace the engine oil if it is not of the recommended viscosity for the ambient temperature.
3. Low cranking voltage	<ul style="list-style-type: none"> a. Clean and tighten or replace the positive (+) and negative (–) battery cable connectors and cables at the battery and the genset. b. Recharge or replace the battery. Specific gravity for a fully charged battery is approximately 1.260 at 80° F (27° C).
4. Blocked air inlet	Service as necessary.

FAULT SHUTDOWN

⚠ WARNING *There are hazards present in troubleshooting that can cause equipment damage, severe personal injury or death. Troubleshooting must be performed by qualified persons who know about the hazards of fuel, electricity and machinery. Read Safety Precautions and observe all instructions and precautions in this manual.*

Possible Cause	Corrective Action
1. Low engine oil pressure	Check engine oil level, repair any leaks and fill to the proper level (p. 12).
2. High engine temperature	<ul style="list-style-type: none"> a. Check engine coolant level, repair any leaks and fill to the proper level (p. 14). b. Check V-belt tension (p. 14). c. Clean and service the cooling system as required to restore full cooling capacity (p. 14).

ENGINE LACKS POWER OR UNSTABLE

⚠ WARNING *There are hazards present in troubleshooting that can cause equipment damage, severe personal injury or death. Troubleshooting must be performed by qualified persons who know about the hazards of fuel, electricity and machinery. Read Safety Precautions and observe all instructions and precautions in this manual.*

Possible Cause	Corrective Action
1. Inadequate fuel delivery	a. Check for fuel (air) leaks at all fittings and tighten as necessary. b. Replace the fuel filter (p. 16).
2. Contaminated fuel	Connect the fuel lift pump to a container of fuel of known quality. Replace the contents of the fuel supply tank if there is a noticeable difference in performance.

NO OUTPUT VOLTAGE

⚠ WARNING *There are hazards present in troubleshooting that can cause equipment damage, severe personal injury or death. Troubleshooting must be performed by qualified persons who know about the hazards of fuel, electricity and machinery. Read Safety Precautions and observe all instructions and precautions in this manual.*

Possible Cause	Corrective Action
1. Line circuit breaker Off .	Find out why the circuit breaker was turned Off , make sure it is safe to reconnect power, and then throw the circuit breaker On .
2. Line circuit breaker Tripped .	Shut down the genset and have service performed as necessary to clear the short circuit or ground fault that caused tripping. Then Reset the circuit breaker and start the genset.

Specifications

Control System

- Unit Mounted, Drip-Proof, Vibration Isolated Console
- **DC Controls - 12-Volt System**
 - Start/Stop/Preheat Switch
 - Sealed Remote Connector for Start/Stop/Preheat Switch Gauge Package
 - Manual Reset Fault Relay Indicating Engine Shutdown for High Coolant Temperature, Low Oil Pressure
- **AC Controls**
 - Voltage Regulator (See Generator Detail)
 - One or Two Circuit Breakers

Engine Detail

Design: 4-Cycle, Liquid-cooled Diesel Engine
Cylinders: Inline Vertical - 3
Bore:
HDKAL 3.07 in (78 mm)
HDKAS 2.83 in (72 mm)
Stroke:
HDKAL 3.09 in 78.4 mm
HDKAS 2.90 in (73.6 mm)
Displacement
HDKAL 68.53 in³ (1124 cm³)
HDKAS 54.8 in³ (898 cm³)
Compression Ratio: 22 to 1
Lube Oil Capacity: 4.34 qt (4.1 L) Including Filter
Cooling System Capacity: 1.25 gal (4.73 L)
Engine Power (max) at 1800 r/min:
HDKAL 15.4 bhp
HDKAS 11.9 bhp

Starting System: Remote, 12-volt
Fuel Injection Pump: Bosch K mini
Combustion Chamber: Spherical
Fuel Consumption: No. 2 Diesel Fuel, gph/lph

	No Load	Half Load	Full Load
HDKAL	0.24 gph 0.90 lph	0.49 gph 1.85 lph	0.85 gph 3.2 lph
HDKAS	0.23 gph 0.87 lph	0.46 gph 1.74 lph	0.8 gph 3.03 lph

Generator Detail

Design: Onan, Brush type, Drip-proof Construction.
Insulation System Rise: Class F per NEMA
MGI-1.65 and BS 2757 Insulating Varnish Conforms to MIL-1-24092, Grade CB, Class 155 C.
Exciter System: Electronic Voltage Regulator

Bearing: Double Sealed Prelubricated Ball Bearing
Cooling: Direct Drive Centrifugal Blower
Damper Bar: Improves Harmonics and Voltage Waveforms (Comm HDKAL/HDKAS Only)

GenSet Performance

Regulation, No Load to Rated Load
Voltage: $\pm 2.5\%$
Frequency: $\pm 2.5\%$
Battery Charging: 12 Volt Battery Charging DC Alternator (30 amp output)
Sound Level: 76 dB(a) @ 3 m rated load
Random Frequency Variation for Constant Loads

from No Load to Full Load is $\pm 1\%$
Random Voltage Variation: Under These Conditions is $\pm 1\%$
Maximum Operating Ambient Temperature:
Efficient Radiator Cooling System Permits Operation at Ambient Temperatures up to 120°F (49°C).

Accessories

- Required Accessory**
- (USDA Forest Service Approved Spark Arrester Muffler.
- Optional Accessories**
- Battery - 12 volt, 475 Cold Cranking Amps at 0°F (-17.8°C)
 - Remote Gauge Package with Start/Stop/Preheat Switch, Voltage Meter, Water Temperature Gauge, Oil Pressure Gauge, Hour Meter (Standard on Comm HDKAL/HDKAS)
 - Remote Circuit Breaker Kits
 - Remote Wiring Harness, 10 or 30 ft.
 - Engine Block Heater (Comm HDKAL/HDKAS Only)
 - RACOR Fuel/Water/Separator (Comm HDKAL/HDKAS Only)
 - Remote DC Gauge Kit (Comm HDKAL/HDKAS Only)

Information for California Genset Users

These gensets meet the requirements of California’s Exhaust Emissions Standards for 1995 and later for Utility and Lawn and Garden Equipment Engines.

As a California user of these gensets, please be aware that unauthorized modifications or replacement of fuel, exhaust, air intake, or speed control system components that affect engine emissions are prohibited. Unauthorized modification, removal or replacement of the genset label is prohibited.

You should carefully review Operator (Owner), Installation and other manuals and information you receive with your genset. If you are unsure that the installation, use, maintenance or service of your genset is authorized, you should seek assistance from an authorized dealer.

California genset users may use Table 4 as an aid in locating information related to the California Air Resources Board requirements for emissions control.

TABLE 4. EMISSIONS CONTROL INFORMATION

Genset Warranty Information	The California emissions control warranty statement is located in the same packet of information as this manual when the engine is shipped from the factory.
Engine Fuel Requirements	The engine is certified to operate on diesel fuel. See FUEL RECOMMENDATIONS.
Engine Lubricating Oil Requirements	See ENGINE OIL RECOMMENDATIONS.
Engine Adjustments	High Idle Speed. This is a service procedure requiring trained personnel and proper tools. See the Service Manual.
Engine Emission Control System	The engine emission control system consists of engine design and precision manufacture. (IFI)

How to Obtain Service

When you need parts or service for your genset contact the nearest authorized dealer or distributor. Onan has factory-trained representatives to handle your needs for genset parts and service. To locate the nearest authorized distributor:

When you need parts or service for your genset contact the nearest authorized dealer or distributor. Onan has factory-trained representatives to handle your needs for genset parts and service. To locate the nearest authorized distributor:

1. Check the North American Sales and Service Directory (F-118) and the International Sales and Service Directory (IN-1013) supplied with your Onan genset. These directories list authorized distributors who will assist you in locating the nearest authorized dealer.
2. Consult the Yellow Pages. Typically, our distributors are listed under:

GENERATORS – ELECTRIC,
ENGINES – GASOLINE OR DIESEL, or
RECREATIONAL VEHICLES – EQUIPMENT,
PARTS AND SERVICE.

3. Call 1-800-888-ONAN for the name and telephone number of the nearest Cummins/Onan or Onan-only distributor in the United States or Canada. (This automated service utilizes touch-tone phones only). By calling this number you can also request a directory of authorized RV servicing dealers: RV Sales and Service Directory F-919.

To get service, contact the authorized dealer or distributor nearest you, explain the problem and make an appointment. If you have difficulty in arranging for service or resolving a problem, please contact the dealer coordinator or service manager at the nearest Cummins/Onan distributor for assistance.

Before calling for service, have the following information available:

1. *Complete model number and serial number*
2. *Date of purchase*
3. *Nature of the problem.*

⚠ WARNING *Improper service or replacement of parts can result in severe personal injury, death, and/or equipment damage. Service personnel must be qualified to perform electrical and/or mechanical service.*

Maintenance Record

Use the following table to keep a record of all periodic and unscheduled maintenance and service. See *Periodic Maintenance*.

[illegible]

Record the name, address, and phone number of your authorized Onan service center.



Cummins Power Generation
1400 73rd Avenue N.E.
Minneapolis, MN 55432
763-574-5000
Fax: 763-528-7229

Cummins and Onan are registered trademarks of Cummins Inc.