

The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 20616AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5575-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct Air Outlet			
		Skid And Battery Rack			
		Oil Base Heater			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
		Overspeed Cut Off			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Relay			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4XR SPEC 20618AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4998-04 (AC)612-1851-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Meter Panel			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
301-2308	1	Panel, Meter - Instrument			
304-0305	1	Resistor, Fixed (45,000 ohm, 10 Watt)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Latching - High Temp, Overspeed, Low Oil Pressure			
332-0707	1	Strip, Marker			
301-3567	1	Panel, Control Box			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 20619AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
201-2158	1	Rotor Assembly, Wound			
220-2043	1	Stator, Wound			

SPECIAL PARTS LIST FOR MODEL 9,0DJC-518R SPEC 20729AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5042-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Air Duct			
		Oil Base Heater			
		Voltage Regulator Filter			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
		Overspeed Cut Off			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			
323-1042	1	Socket, Relay			
332-0706	1	Block, Terminal - 8 Place			



SPECIAL PARTS LIST FOR MODEL 12.0DJC-4XR SPEC 20784AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-4998-02 (AC)612-1859-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Muffler Mounted On Housing			
		Meter Panel			
		Mounted Fuel Tank			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
301-2373	1	Panel, Meter - Instrument			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Latching - High Temp., Overspeed, Low Oil Pressure			
332-0707	1	Strip, Marker			
301-3567	1	Panel, Control Box			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4R SPEC 20786AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-4791-02 (AC)612-5650-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Meter Panel			
		Muffler Mounted On Housing			
		Oil Base Heater			
301-2204	1	Panel, Meter - Instrument			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 20814AA

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4998-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Muffler Mounted On Housing			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Latching - High Temp., Overspeed, Low Oil Pressure			
332-0707	1	Strip, Marker			
301-3567	1	Panel, Control Box			
320-0259	1	Relay, Emergency - Low Oil Pressure			

WIRING DIAGRAM NO. (ENG)612-5136-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractor Type Air Cleaner Duct Air Outlet Low Oil Pressure Cut Off					
123-1104	1	Indicator, Oil Level - Assembly			
120-0638	1	Cup Assembly, Oil Pump Intake			
220-2308	1	Stator, Wound - Exciter			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
201-2313	1	Rotor Assembly, Wound			
220-2653	1	Stator, Wound			
305-0585	1	Regulator Assembly, Voltage - (Environmentally Protected) Without Voltage Adjustment			
301-3834	1	Panel, Voltage Regulator Mounting			
300-1654	1	Board Assembly, Voltage Regulator (Polyurethane Coated) - For Parts Break- down Use 300-1540 In Parts Catalog			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 20830AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5705-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Contractor Type Air Cleaner			
		Duct Air Outlet			
		Low Oil Pressure Cut Off			
102-0559	1	Extension Oil Base			
123-1104	1	Cap And Indicator Assembly - Oil			
104-1118	1	Crankshaft			
120-0638	1	Cup Assembly, Oil Pump Intake			
220-2308	1	Stator, Wound - Exciter			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
201-2313	1	Rotor Assembly, Wound			
220-2653	1	Stator, Wound			

SPECIAL PARTS LIST FOR MODEL 12.0DJG-4XR SPEC 20927AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4998-04 (AC)612-1851-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Duct Air Outlet			
		Muffler Mounted On Housing			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
301-2308	1	Panel, Meter - Instrument			
304-0305	1	Resistor, Fixed (45,000 ohm, 10 Watt)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Latching - High Temp., Overspeed, Low Oil Pressure			
332-0707	1	Strip, Marker			
301-3567	1	Panel, Control Box			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4R SPEC 20927AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5574-04 (AC)612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Duct Air Outlet			
		Muffler Mounted On Housing			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			
301-2204	1	Panel, Meter - Instrument			

SPECIAL PARTS LIST FOR MODEL 12,0DJC-18R SPEC 20929AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-4998-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
201-2158	1	Rotor Assembly, Wound			
220-2043	1	Stator, Wound			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Latching - High Temp., Overspeed, Low Oil Pressure			
332-0707	1	Strip, Marker			
301-3567	1	Panel, Control Box			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-4R **SPEC** 20943AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-4792-02 (AC)612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Air Duct And Shutter			
		Meter Panel			
		Oil Base Heater			
		Muffler Mounted On Housing			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
301-2204	1	Panel, Meter - Instrument			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 21016AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5042-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Air Duct And Shutter					
Mounted Fuel Tank					
Oil Base Heater					
Overspeed Cut Off					
High Air Temperature Cut Off (Normally Open)					
Low Oil Pressure Cut Off					
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			
323-1042	1	Socket, Relay			
332-0706	1	Block, Terminal - 8 Place			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR SPEC 21088AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5677-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Oil Base Heater			
		Low Oil Pressure Cut Off			
231-0171	1	Adapter, Generator (Right Hand)			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR SPEC 21094AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5574-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Air Duct And Shutter			
		Oil Base Heater			
		Generator Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3R SPEC 21192AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4998-01 (AC)612-1786-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Meter Panel			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
301-1554	1	Panel, Meter - Control			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Latching - High Temp., Overspeed, Low Oil Pressure			
332-0707	1	Strip, Marker			
301-3567	1	Panel, Control Box			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR SPEC 21233AA

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4792-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Duct Air Outlet			
		Oil Base Heater			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
102-0622	1	Base, Oil			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 21233AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4792-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Duct Air Outlet			
		Oil Base Heater			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
102-0622	1	Base, Oil			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 21277AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5042-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Mounted Fuel Tank			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			
323-1042	1	Socket, Relay			
332-0706	1	Block, Terminal - 8 Place			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4XR SPEC 21441AC

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5578-02 (AC)612-1851-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Meter Panel			
		Muffler Mounted On Housing			
		Oil Base Heater			
		Low Oil Pressure Cut Off			
301-2308	1	Panel, Meter - Instrument			
304-0305	1	Resistor, Fixed (45,000 ohm, 10 Watt)			
320-0221	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4R SPEC 21516AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-02 (AC)612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Meter Panel			
		Mounted Fuel Tank			
		Muffler Mounted On Housing			
		Voltage Regulator Filter			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
301-2204	1	Panel, Meter - Instrument			

WIRING DIAGRAM NO. (ENG)612-5575-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Oil Base Heater			
		Muffler Mounted On Housing			
		Mounted Fuel Tank			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Relay			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4R SPEC 21682AC

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5567-04 (AC)612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Meter Panel			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
301-2204	1	Panel, Meter - Instrument			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	1	Relay, Emergency Latch - Overspeed			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3R SPEC 21727AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5556-01 (AC)612-1559-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit Duct Air Outlet Meter Panel Muffler Mounted On Housing Mounted Fuel Tank					
301-2288	1	Panel, Control - Upper			
625-1487-01	1	Mounted Glow Plug Control (Consists Of Following Parts Marked *)			
301-4428	1	*Box, Control			
301-4429	1	*Cover, Control Box			
508-0901	2	*Grommet, Control Box			
332-0238	1	*Strip, Marker - Use With 332-0236			
332-0236	1	*Block, Terminal			
332-0426	1	*Strip, Marker - Use With 332-0406			
332-0406	1	*Block, Terminal - 3 Place			
315-0433	1	*Transformer Assembly			
307-1274	1	*Relay, Glow Plug			
332-0592	3	*Jumper, Ground			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4XR SPEC 21727AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5556-02 (AC)612-1851-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Duct Air Outlet					
Muffler Mounted On Housing					
Mounted Fuel Tank					
Meter Panel					
301-2308	1	Panel, Meter - Instrument			
304-0305	1	Resistor, Fixed (45,000 ohm, 10 Watt)			
625-1487-01	1	Mounted Glow Plug Control (Consists Of Following Parts Marked *)			
301-4428	1	*Box, Control			
301-4429	1	*Cover, Control Box			
508-0001	2	*Grommet, Control Box			
332-0238	1	*Strip, Marker - Use With 332-0236			
332-0236	1	*Block, Terminal			
332-0426	1	*Strip, Marker - Use With 332-0406			
332-0406	1	*Block, Terminal - 3 Place			
315-0433	1	*Transformer Assembly			
307-1274	1	*Relay, Glow Plug			
332-0592	3	*Jumper, Ground			

SPECIAL PARTS LIST FOR **MODEL** 9.0DJC-53CR **SPEC** 21795AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Spanish Nameplate Low Oil Pressure Cut Off High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 21795AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5557-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Spanish Nameplate Low Oil Pressure Cut Off High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 21807AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit Spanish Nameplate Low Oil Pressure Cut Off High Air Temperature Cut Off (Normally Closed) Air Duct And Shutter			

SPECIAL PARTS LIST FOR MODEL 9.0DJG-53CR SPEC 21809AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5575-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractor Type Air Cleaner					
Duct Air Outlet					
Skid And Battery Rack					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off (Normally Open)					
Overspeed Cut Off					
104-1118	1	Crankshaft			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Relay			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4R SPEC 21810AC

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-02 (AC)612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Meter Panel			
		Mounted Fuel Tank			
		Muffler Mounted On Housing			
		Voltage Regulator Filter			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
301-2204	1	Panel, Meter - Instrument			
625-1487-01	1	Mounted Glow Plug Control (Consists Of Following Parts Marked *)			
301-4428	1	*Box, Control			
301-4429	1	*Cover, Control Box			
508-0001	2	*Grommet, Control Box			
332-0238	1	*Strip, Marker - Use With 332-0236			
332-0236	1	*Block, Terminal			
332-0426	1	*Strip, Marker - Use With 332-0406			
332-0406	1	*Block, Terminal - 3 Place			
315-0433	1	*Transformer Assembly			
307-1274	1	*Relay, Glow Plug			
332-0592	3	*Jumper, Ground			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 21865AC  
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5556-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Duct Air Outlet			
		Voltage Regulator Filter			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 21923AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Duct Air Outlet			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
220-2043	1	Stator, Wound			
201-2158	1	Rotor Assembly, Wound			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR SPEC 21936AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5576-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct Air Outlet			
		Oil Base Heater			
		Overspeed Cut Off			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	1	Relay, Emergency Latch - Overspeed			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-35R SPEC 21960AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5575-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Spanish Nameplate			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Relay			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			
625-0477-01	1	Control Space Heater (Consists Of Following Parts Marked *)			
333-0151	1	*Heater (300 Watt, 240 Volt)			
309-0128	1	*Thermostat (Open 105°F ±5°)			
301-1886	1	*Cover, Thermostat			
335-0110	1	*Cable Assembly			
332-0802	5	*Terminal, Crimp			
625-1675-01	1	Circuit Breaker (Attached To Generator)(Consists Of Following Parts Marked +)			
320-0781	1	+Breaker, Circuit			
301-5673	2	+Spacer, Circuit Breaker			
301-5656	1	+Cover, Output Box			
332-0613	1	+Strip, Marker			
332-0604	1	+Block, Terminal			
301-5654	1	+Box, Output			
508-0183	1	+Grommet			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 21968AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5572-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Modified For Oil Bath Air Cleaner			
		Oil Base Heater			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
104-1118	1	Crankshaft			
307-0655	1	Relay, Emergency Latch - High Air Temperature			
320-0221	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR SPEC 21997AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO. (ENG)612-5575-01**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct Air Outlet			
		Fungus Treated Control			
		Voltage Regulator Filter			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
		Overspeed Cut Off			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Relay			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 22005AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5779-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-4XR **SPEC** 22024AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5557-02 (AC)612-1851-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Oil Base Heater			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
		Duct Air Outlet			
406-0249	4	Hasp, Housing (3-1/2")			
301-2308	1	Panel, Meter - Instrument			
304-0305	1	Resistor Fixed (45,000 ohm, 10 Watt)			

SPECIAL PARTS LIST FOR MODEL 9.0DJC-518R SPEC 22028AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5575-02 (AC)612-1559-07

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Mounted Fuel Tank			
		Meter Panel			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
		Overspeed Cut Off			
		Air Duct And Shutter			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
220-2051	1	Stator, Wound			
201-2158	1	Rotor Assembly, Wound			
301-2288	1	Panel, Control - Upper			
301-3567	1	Panel, Control Box			
332-0707	1	Strip, Marker			
309-0270	1	Thermostat - Low Engine Temp.			
307-1157	1	Spring, Relay Holddown			
332-0943	2	Spacer			
323-0760	1	Socket			
307-1143	1	Relay, Generating			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
338-0917	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 12 ODIC-18R **SPEC** 22028AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5575-02 (AC) 612-1559-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Mounted Fuel Tank			
		Air Duct And Shutter			
		Meter Panel			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
		Overspeed Cut Off			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
220-2043	1	Stator, Wound			
201-2158	1	Rotor Assembly, Wound			
301-2288	1	Panel, Control - Upper			
301-3567	1	Panel, Control Box			
332-0707	1	Strip, Marker			
309-0270	1	Thermostat - Low Engine Temp.			
307-1157	1	Spring, Relay Holddown			
332-0943	2	Spacer			
323-0760	1	Socket			
307-1143	1	Relay, Generating			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
338-0917	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 22032AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5574-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
		Duct Air Outlet			
338-0917	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Emergency - Low Oil Pressure			
307-0655	3	Relay, Emergency Latch - High Temp., Overspeed & Low Oil Pressure			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
406-0249	4	Hasp, Housing (3-1/2")			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 22043AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5574-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Air Duct And Shutter			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
220-2043	1	Stator, Wound			
201-2158	1	Rotor Assembly, Wound			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 22085AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5575-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
201-2158	1	Rotor Assembly, Wound			
220-2043	1	Stator, Wound			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Relay			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 22097AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5556-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Oil Base Heater					
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
201-2158	1	Rotor Assembly, Wound			
220-2043	1	Stator, Wound			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 22098AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5575-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Duct Air Outlet			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Overspeed & Low Oil Pressure			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Relay			
332-0943	2	Spacer			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CR **SPEC** 22160AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit Voltage Regulator Filter Low Oil Pressure Cut Off High Air Temperature Cut Off (Normally Closed) Duct Air Outlet			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 22372AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO. (ENG) 612-5556-02**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Duct Air Outlet					
Skid And Battery Rack					
Voltage Regulator Filter					
Oil Base Heater					
520-0798	4	Stud, Generator Through			
520-0790	1	Stud, Rotor Through			
220-2043	1	Stator, Wound			
201-2158	1	Rotor Assembly, Wound			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 22389AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO. (ENG)612-5574-04**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct Air Outlet			
		Skid And Battery Rack			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Open)			
102-0622	1	Base, Oil			
104-1118	1	Crankshaft			
508-0117	1	Grommet, Rubber (1-1/8 I.D. X 1-3/4 O.D)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	3	Relay, Emergency Latch - High Temperature, Over- speed & Low Oil Pressure			
332-0707	1	Strip, Marker (Blank)			
301-3567	1	Panel, Control Box (With Bracket)			
320-0259	1	Relay, Emergency - Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CE SPEC 22428AC  
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5504-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		High Air Temperature Cut Off (Normally Closed) Contractors Model			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R SPEC 22448AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO. (ENG) 612-5802-02**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
122-0193	1	Filter, Oil (5-3/4")			
304-0506	1	Resistor, Adjustable (5 Amp, 6 Ohm, 150 Watt)			
304-0592	1	Spacer, Resistor			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	1	Relay, Emergency Latch - Overspeed			
308-0307	1	Switch And Resistor Assembly			
304-0697	1	Resistor And Lead Assembly (1 Ohm, 10 Watt)			

SPECIAL PARTS LIST FOR MODEL 12.0 DJC-3CE SPEC 23024AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW  
**WIRING DIAGRAM NO. 612-5862-02**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractor Model					
Overspeed Switch					
High Air Temperature Switch					
140-0961	1	Indicator, Service			
140-1260	1	Fitting, Service Indicator			
505-0008	1	Plug, Pipe (1/4" Slotted) Air Cleaner Adapter			
338-0725	1	Harness, Wiring - Switch Plate to Control			
309-0196	1	Switch, High Air Temperature			
508-0126	4	Insulator, Washer - High Air Temperature Switch Mounting			
503-0571	1	Hose, Air Cleaner Connector (4")			
320-0104	1	Relay, Low Oil Pressure			
323-0184	2	Receptacle, Duplex			
307-0655	1	Relay, Overspeed			
301-6243	1	Panel, Control			
508-0008	1	Grommet, Rubber (13/16" Hole)			
Parts Not Furnished By Onan					
Starter					
Starter Support Bracket					

SPECIAL PARTS LIST FOR MODEL 12.0 DIC-3CE SPEC 23728AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-5936-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractor Model			323-0184	2	Receptacle, Duplex
Overspeed Switch (Magnetic Sensor)			307-0655	1	Relay, Overspeed (Latching T)
High Air Temperature Switch			307-1058	1	Relay, Overspeed (Socket Moun
			323-0804	1	Socket, Overspeed Relay
140-0961	1	Indicator, Service	332-2514	1	Protector, Terminal - Overspe
140-1260	1	Fitting, Service Indicator			Switch
505-0008	1	Plug, Pipe (1/2" Slotted) Air Cleaner Adapter	301-6703	1	Panel, Control
150-1903	1	Bracket, Governor	301-6706	1	Box, Control
338-1594	1	Harness, Wiring - Overspeed	508-0008	1	Grommet, Rubber (13/16" Hole
150-1406	1	Sensor, Overspeed			Parts Not Furnished By Onan
307-2037	1	Bracket, Overspeed Sensor Mounting			Starter
338-0725	1	Harness, Wiring - Switch Plate to Control			Starter Support Bracket
309-0196	1	Switch, High Air Temperature			
234-0185	1	Cover, End Bell			
140-1784	1	Tube, Air Induction			
307-1904	1	Solenoid, Stopping - Air Cleaner System			
140-1809	1	Bracket, Solenoid Mounting - Air Cleaner System			
140-1810	1	Bracket, Linkage - Solenoid to Linkage Assembly - Air Cleaner System			
150-0939	1	Joint, Ball - Solenoid to Linkage Assembly - Air Cleaner System			
150-1132	1	Linkage Assembly, Air Shutoff - Air Cleaner System (Includes Parts Marked *)			
150-1358	1	*Joint, Ball - Linkage to Air Shutoff Valve			
870-0131	1	*Nut, Hex - With ET (#10-32)			
871-0010	2	*Nut, Hex (#10-32)			
870-0131	3	Nut, Hex - With ET (#10-32) (Air Shutoff Linkage)			
140-1781	1	Valve, Air Shutoff (Complete) Air Cleaner System			
503-0274	6	Clamp, Hose - Air Cleaner System			
155-1917	2	Clamp, Stopping Solenoid Mounting - Air Cleaner System			
503-0330	2	Hose, Rubber (2" Long) Air Cleaner System			
307-2016	1	Switch, Overspeed			
320-0104	1	Relay, Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-1E SPEC 24313AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5983-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Switch	191-1530	1	Plate, Start Disconnect
		High Air Temperature Switch	191-0731	1	Cover, Start Disconnect
		Overspeed Switch (Magnetic Sensor)	338-0394	1	Harness, Wiring-Starter to Start Solenoid
509-0112	1	Seal, Crankshaft Rear	134-4243	1	Housing, Blower
115-0194	8	Shield, Push Rod	134-4242	1	Housing, Cylinder Air-Front
154-2360	4	Tab, Lock-Exhaust Manifold Mounting	134-1977	1	Housing, Cylinder Air-Rear
115-0192	8	Washer, Flat-Push Rod Shield	134-4248	1	Baffle, Center Cylinder-Injection Pump Side
115-0193	8	Spring, Push Rod Shield	134-4247	1	Baffle, Center Cylinder-Opposite Side of Injection Pump
149-1847	1	Line, Fuel-Fuel Pump to Primary Filter	134-4241	1	Pan, Cylinder Air Housing-Bottom
149-1844	1	Line, Fuel Return-Nozzle to Return Line Adapter (#1 cyl.)	134-1969	3	Retainer, Grille
149-1843	2	Line, Fuel Return-Nozzle to Return Line Adapter (#2 & 3 Cylinders)	134-1970	1	Grille and Plate
149-1845	1	Line, Fuel Return-Nozzle to Return Line Adapter (#4 Cyl.)	134-4239	1	Cover, Cylinder Air Housing
149-1846	1	Line, Fuel Return-Return Line Adapter to Injection Pump	134-4240	1	Panel, Door-Air Housing
149-1198	1	Adapter, Fuel Filters	102-1103	1	Bracket, Oil Cooler Mounting
123-1560	1	Tube, Oil Fill	416-0803	2	Clamp, Support-Battery Cable
115-0304	2	Cover Assembly, Rocker- Includes Parts Marked *	309-0196	1	Switch, High Air Temperature
120-0628	2	*Line, Oil	508-0126	4	Insulator, Washer-High Air Temperature Switch Mounting
526-0130	2	*Washer, Flat	147-0240	2	Adapter, Injection Nozzle- # 2 & 4 Cylinders
815-0562	2	*Screw, Machine-Cross Recessed Pan Head (#10 X 5/16")	147-0241	2	Adapter, Injection Nozzle- #1 & 3 Cylinders
120-0687	1	Line, Oil-Oil Filter Adapter to Injection Pump Lubrication Tee	147-0239	4	Flange, Injection Nozzle Hold Down
120-1016	1	Line, Oil-Injection Pump Lubrication Tee to Cylinder Head Tee	140-1260	1	Fitting, Restriction Indicator Mounting
120-1017	2	Line, Oil-Cylinder Head Tee to Cylinder Head	505-0008	1	Plug, Pipe-Slotted-Air Cleaner Adapter
103-0693	1	Gearcase Assembly-Complete	140-1831	1	Adapter, Air Cleaner-Mounted on Intake Manifold
150-1249	1	Shaft, Governor	140-0584	2	Gasket, Air Cleaner Adapter
509-0111	1	Seal, Oil-Gearcase Crankshaft	140-0961	1	Indicator, Restriction
150-1254	1	Arm, Governor	503-0274	8	Clamp, Hose-Air Cleaner System
103-0685	1	Backplate, Gearcase	503-0330	3	Hose, Rubber-Air Cleaner (2" Long)
150-1251	1	Spring, Governor	140-1813	1	Tube, Hose Connector (Metal Elbow) Rubber Elbow to Air off Valve
150-1921	1	Bracket, Governor Adjusting	503-0419	1	Elbow, Rubber-Air Cleaner
338-1594	1	Harness, Wiring-Overspeed	140-1815	1	Tube, Air Induction (5 1/2") Metal
150-1406	1	Sensor, Overspeed	140-1832	1	Adapter, Air Cleaner-Mounted Bracket
307-2037	1	Bracket, Overspeed Sensor Mtg.	140-1812	1	Bracket, Air Cleaner Mounting
338-0725	1	Harness, Wiring-Switch Plate to Control	306-0254	1	Spacer, Air Cleaner Adapter

Continued . . .

SPECIAL PARTS LIST FOR MODEL 12 ODIC-1E SPEC 24313AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5983-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
800-0185	2	Screw, Cap-Hex Head (1/4-20 X 5 1/2") Air Cleaner Mounting	320-0204	1	Breaker, Circuit (30 Amp)(to Charge Ammeter)
140-1039	1	Cover, Air Cleaner	357-0043	1	Rectifier, Charge (Mounted on Saddle)
140-0606	1	Element, Air Cleaner	301-4389	1	Plate, Charge Rectifier Mounting
140-1040	1	Pan, Air Cleaner	320-0104	1	Relay, Low Oil Pressure
140-1781	1	Valve, Air Shutoff (Complete) Air Cleaner System	307-0655	1	Relay, Overspeed (Latching Type)
307-1904	1	Solenoid, Stopping-Air Cleaner System	307-1058	1	Relay, Overspeed (Socket Mounted)
140-1809	1	Bracket, Solenoid Mounting-Air Cleaner System	323-0804	1	Socket, Overspeed Relay
140-1810	1	Bracket, Linkage-Solenoid to Linkage Assembly-Air Cleaner System	307-1987	2	Hold-Down, Overspeed Relay
150-0939	1	Joint, Ball-Solenoid to Linkage Assembly-Air Cleaner System	302-1361	1	Ammeter, Charge (20-0-20)
150-1132	1	Linkage Assembly, Air Shutoff-Air Cleaner System (Includes Parts Marked #)	307-2016	1	Switch, Overspeed
150-1358	1	#Joint, Ball-Linkage to Air Shutoff Valve	332-2514	1	Protector, Terminal-Overspeed Switch
870-0131	1	#Nut, Hex-With ET (#10-32)	308-0028	2	Switch, Push (Manifold Heater and Start)
871-0010	1	#Nut, Hex (#10-32)	308-0274	2	Boot, Push Switch
870-0131	3	Nut, Hex-With ET (#10-32) (Air Shutoff Linkage)	308-0069	1	Switch, Toggle (Run-Stop)
155-1917	2	Clamp, Stopping Solenoid Mounting-Air Cleaner System	308-0273	1	Boot, Toggle Switch
220-2670	1	Stator, Wound-Generator	332-0706	1	Block, Terminal (8 Place)
201-2312	1	Rotor Assembly, Wound-Generator	332-0739	1	Strip, Marker (8 Place)
201-2299	1	Rotor, Wound-Exciter	332-0602	1	Jumper, Heater Switch to Starter Switch
220-2308	1	Stator, Wound-Exciter	336-8795	1	Lead, Charge Rectifier to Resistor (24")
234-0309	1	Cover, End Bell	301-6919	1	Panel, Control
234-0672	1	Cover Assembly, Air Outlet (Generator)(Includes Parts Marked +)	301-6920	1	Box, Control
809-0046	1	+Screw, Sheet Metal-Round Head (#10 X 3/4")	301-3955	1	Cover, Voltage Regulator
870-0177	1	+Nut, Speed (#10)	301-3956	1	Saddle, Control Box Mounting
320-0251	1	Breaker, Circuit-100 Amp	332-0052	1	Clip, Wire-Control Box
302-0592	1	Meter, Running Time			
304-0625	1	Resistor, Generator Air Outlet			
305-0585	1	Regulator Assembly, Voltage			
301-3834	1	Panel, Voltage Regulator Mounting			
300-1654	1	Board, Voltage Regulator			
338-0744	1	Harness, Wiring-Voltage Regulator to Exciter Stator			
320-0235	1	Breaker, Circuit (20 Amp)(to Charge Resistor)			

Parts Not Furnished By Onan  
 Starter  
 Starter Support Bracket

SPECIAL PARTS LIST FOR **MODEL** 12.0DJG-1E **SPEC** 24550AC  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5983-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Switch			
		High Air Temperature Switch			
		Overspeed Switch (Magnetic Sensor)			
509-0112	1	Seal, Crankshaft Rear	191-1530	1	Plate, Start Disconnect
115-0194	8	Shield, Push Rod	191-0731	1	Cover, Start Disconnect
154-2360	4	Tab, Lock-Exhaust Manifold Mounting	338-0394	1	Harness, Wiring-Starter to Start Solenoid
115-0192	8	Washer, Flat-Push Rod Shield	134-4243	1	Housing, Blower
115-0193	8	Spring, Push Rod Shield	134-4242	1	Housing, Cylinder Air-Front
149-1847	1	Line, Fuel-Fuel Pump to Primary Filter	134-1977	1	Housing, Cylinder Air-Rear
149-1844	1	Line, Fuel Return-Nozzle to Return Line Adapter (#1 Cyl.)	134-4248	1	Baffle, Center Cylinder-Injection Pump Side
149-1843	2	Line, Fuel Return-Nozzle to Return Line Adapter (#2 & 3 Cylinders)	134-4247	1	Baffle, Center Cylinder-Opposite Side of Injection Pump
149-1845	1	Line, Fuel Return-Nozzle to Return Line Adapter (#4 Cyl.)	134-4241	1	Pan, Cylinder Air Housing-Bottom
149-1846	1	Line, Fuel Return-Return Line Adapter to Injection Pump	134-1969	3	Retainer, Grille
149-1198	1	Adapter, Fuel Filters	134-1970	1	Grille and Plate
123-1560	1	Tube, Oil Fill	134-4239	1	Cover, Cylinder Air Housing
115-0304	2	Cover Assembly, Rocker- Includes Parts Marked *	134-4240	1	Panel, Door-Air Housing
120-0628	2	*Line, Oil	102-1103	1	Bracket, Oil Cooler Mounting
526-0130	2	*Washer, Flat	416-0803	2	Clamp, Support-Battery Cable
815-0562	2	*Screw, Machine-Cross Recessed Pan Head (#10 x 5/16")	309-0196	1	Switch, High Air Temperature
120-0687	1	Line, Oil-Oil Filter Adapter to Injection Pump Lubrication Tee	508-0126	4	Insulator, Washer-High Air Temperature Switch Mounting
120-1016	1	Line, Oil-Injection Pump Lubrication Tee to Cylinder Head Tee	147-0240	2	Adapter, Injection Nozzle-Number 2 and 4 Cylinders
120-1017	2	Line, Oil-Cylinder Head Tee to Cylinder Head	147-0241	2	Adapter, Injection Nozzle-Number 1 and 3 Cylinders
103-0693	1	Gearcase Assembly-Complete	147-0239	4	Flange, Injection Nozzle Hold-Down
150-1249	1	Shaft, Governor	140-0584	3	Gasket, Air Cleaner Adapter
509-0111	1	Seal, Oil-Gearcase Crankshaft	140-1831	1	Adapter, Air Cleaner-Mounted on Intake Manifold
150-1254	1	Arm, Governor	140-1832	1	Adapter, Air Cleaner-Mounted on Air Cleaner Bracket
103-0685	1	Backplate, Gearcase	140-0961	1	Indicator, Restriction
150-1251	1	Spring, Governor	140-1260	1	Fitting, Restriction Indicator Mounting
150-1921	1	Bracket, Governor Adjusting	505-0008	1	Plug, Pipe (Slotted) Manifold Air Cleaner Adapter
338-1594	1	Harness, Wiring-Overspeed	503-0274	6	Clamp, Hose-Air Cleaner System
150-1406	1	Sensor, Overspeed	503-0330	2	Hose, Rubber-Air Cleaner (2" Long)
307-2037	1	Bracket, Overspeed Sensor Mounting	140-1813	1	Tube, Hose Connector (Metal with Elbow)
338-0725	1	Harness, Wiring-Switch Plate to Control	503-1167	1	Hose, Rubber-Air Cleaner (with Elbow)
			800-0017	1	Screw, Cap-Hex Head (1/4-20 3 1/2") Air Cleaner & Adapter Mounting

Continued . . .

SPECIAL PARTS LIST FOR MODEL 12.0DJC-1E SPEC 24550AC  
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5983-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
800-0185	1	Screw, Cap-Hex Head (1/4-20 X 5 1/2") Air Cleaner & Adapter Mounting	320-0235	1	Breaker, Circuit (20 Amp) (Charge Resistor)
140-1835	1	Bracket, Air Cleaner Mounting	320-0204	1	Breaker, Circuit (30 Amp) (to Charge Ammeter)
140-1039	1	Cover, Air Cleaner	357-0043	1	Rectifier, Charge (Mounted Saddle)
140-0606	1	Element, Air Cleaner	301-4389	1	Plate, Charge Rectifier Mtg
140-1040	1	Pan, Air Cleaner	320-0104	1	Relay, Low Oil Pressure
140-1781	1	Valve, Air Shutoff (Complete) Air Cleaner System	307-0655	1	Relay, Overspeed (Latching Type)
307-1904	1	Solenoid, Stopping-Air Cleaner System	307-1058	1	Relay, Overspeed (Socket Mounted)
140-1809	1	Bracket, Solenoid Mounting-Air Cleaner System	323-0804	1	Socket, Overspeed Relay
140-1810	1	Bracket, Linkage-Solenoid to Linkage Assembly-Air Cleaner System	307-1987	2	Hold-Down, Overspeed Relay
150-0939	1	Joint, Ball-Solenoid to Linkage Assembly-Air Cleaner System	302-1361	1	Ammeter, Charge (20-0-20)
150-1132	1	Linkage Assembly, Air Shut-off -Air Cleaner System (Includes Parts Marked #)	307-2016	1	Switch, Overspeed
150-1358	1	#Joint, Ball-Linkage to Air Shutoff Valve	332-2514	1	Protector, Terminal-Overspeed Switch
870-0131	1	#Nut, Hex-With ET (#10-32)	308-0028	2	Switch, Push (Manifold Heat and Start)
871-0010	1	#Nut, Hex (#10-32)	308-0274	2	Boot, Push Switch
870-0131	3	Nut, Hex-With ET (#10-32) (Air Shutoff Linkage)	308-0069	1	Switch, Toggle (Run-Stop)
155-1917	2	Clamp, Stopping Solenoid Mounting-Air Cleaner System	308-0273	1	Boot, Toggle Switch
220-2670	1	Stator, Wound-Generator	332-0706	1	Block, Terminal (8 Place)
201-2312	1	Rotor Assembly, Wound-Generator	332-0739	1	Strip, Marker (8 Place)
201-2299	1	Rotor, Wound-Exciter	332-0602	1	Jumper, Heater Switch to St Switch
220-2308	1	Stator, Wound-Exciter	336-8795	1	Lead, Charge Rectifier to Resistor (24")
234-0309	1	Cover, End Bell	301-6919	1	Panel, Control
234-0672	1	Cover Assembly, Air Outlet (Generator)(Includes Parts Marked +)	301-6920	1	Box, Control
809-0046	1	+Screw, Sheet Metal-Round Head (#10 X 3/4")	301-3955	1	Cover, Voltage Regulator
870-0177	1	+Nut, Speed (#10)	301-3956	1	Saddle, Control Box Mounting
320-0251	1	Breaker, Circuit-100 Amp	332-0052	1	Clip, Wire-Control Box
302-0592	1	Meter, Running Time	Parts Not Furnished by Onan		
304-0625	1	Resistor, Generator Air Outlet	Starter		
305-0585	1	Regulator Assembly, Voltage	Starter Support Bracket		
301-3834	1	Panel, Voltage Regulator Mounting			
300-1654	1	Board, Voltage Regulator			
338-0744	1	Harness, Wiring-Voltage Regulator to Exciter Stator			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-57R **SPEC** 25694AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG.) 612-5557-02 (AC) 612-4310-

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
HOUSED UNIT					
MOUNTED FUEL TANK					
METER PANL W/ RTM & FREQ METER					
VOLT ADJ RHEOSTAT					
LOPKO					
HATKO					
ENVIRONMENTALLY PROTECTED GENERATOR					
309-0169	1	Low Oil Pressure Switch			
309-0196	1	High Air Temp Switch			
201-2312	1	Rotor			
220-2660	1	Stator			