

The following catalog  
has gaps in its page  
numbers, or doesn't  
have any numbers.  
We have chosen to  
leave the page  
numbering in the  
order that Acrobat  
assigns it.

SPECIAL PARTS LIST FOR MODEL 6.0DJE-4R SPEC 16478AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4998-10(AC)612-1469-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed AC Meter Panel Overspeed Switch Low Oil Pressure Cut Off High Air Temperature Cut Off			307-1519	1	Relay And Lead Assembly - High Air Temperature An Overspeed (Includes All Leads And Parts Marked
			307-0655	2	*Relay, High Air Temperatu And Overspeed
150-1688	1	Arm, Governor	321-0146	1	Fuse - 10 Amp
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	321-0175	1	Holder, Fuse
502-0003	1	Connector, Oil Fill Bracket	304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt
102-0620	1	Base, Oil	332-0706	2	Block, Terminal - 8 Place
309-0206	1	Switch, High Air Temperature	332-0707	1	Strip, Marker - Blank
141-0281	1	Gasket, Air Cleaner Adapter To Block	301-3567	1	Panel, Control Box
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
301-2204	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 16478AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5574-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Switch Fuel Tank Housed AC Meter Panel					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 16565AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5574-09(AC)612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Fuel Tank					
Housed					
AC Meter Panel					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 16649AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 16649AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			

**(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)**

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 16709AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 16882AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4853-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		Fuel Tank			
		Housed			
		Air Duct And Shutter			
		High Air Temperature Cut Off			
		AC Meter Panel			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (½" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 16897AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5575-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Switch					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 17281AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5575-09(AC) 612-1469-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch			309-0270	1	Thermostat, Low Engine Temperature
Low Oil Pressure Cut Off			332-0706	2	Block, Terminal - 8 Place
High Air Temperature Cut Off			332-0707	1	Strip, Marker - Blank
Housed			321-0146	1	Fuse - 10 Amp
Fuel Tank			321-0175	1	Holder, Fuse
AC Meter Panel			301-3567	1	Panel, Control Box
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
102-0620	1	Base, Oil			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
301-2204	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DIE-3R SPEC 17281AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5575-09(AC)612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Switch					
Housed					
AC Meter Panel					
Fuel Tank					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 17281AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5575-09(AC)612-1559-01

FART NO.	QTY.	DESCRIPTION	FART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Housed			
		AC Meter Panel			
		Fuel Tank			
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CE SPEC 17348AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5586-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

Note: Contractor Model

301-2467	1	Box, Output
301-2466	1	Cover, Output Box

Parts Not Furnished By Onan  
Inner Components Of Output Box

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 17417AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Fuel Tank					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain ( $\frac{1}{2}$ " Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 17417AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Fuel Tank			
		Housed			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			



SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 17850AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4853-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
150-1661	1	Switch Assembly, Overspeed			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 17850AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5567-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Air Duct And Shutter			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
150-1661	1	Switch Assembly, Overspeed			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 17872AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5572-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
320-0221	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1129	1	Relay Assembly, High Air Temperature (Includes Leads)			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 17893AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4853-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank			The following Parts refer to the Glow Plug Control:		
Housed					
AC Meter Panel			332-0592	3	Jumper, Ground
Overspeed Switch			307-1274	1	Relay (DPDT)
Low Oil Pressure Cut Off			315-0433	1	Transformer
High Air Temperature Cut Off			332-0406	1	Block, Terminal - 3 Plac
150-1688	1	Arm, Governor			(TB 1) Length 2 1/4" Mou
502-0099	1	Elbow, Fuel Filter Adapter To			Hole To Mounting Hole
		Fuel Line	332-0426	1	Strip, Marker - 1 1/4" Wide
502-0003	1	Connector, Oil Fill Bracket			(Used With 332-0406 Te
		To Oil Line			Block)
102-0620	1	Base, Oil	332-0236	1	Block, Terminal - 3 Plac
141-0281	1	Gasket, Air Cleaner Adapter			(TB 2) Length 2 3/4"
		To Block			Mounting Hole to Mount
159-0802	1	Tank, Fuel (9 Gallon)			Hole
504-0007	1	Valve, Shut-Off (Return)	332-0238	1	Strip, Marker - 1 7/8" W
501-0004	1	Line, Fuel - 12" (Tank To			(Used With 332-0236
		Fuel Pump)			Terminal Block)
501-0131	1	Line, Fuel - 24" (Return)	301-4428	1	Box, Control
504-0013	1	Valve, Shut-Off (Fuel Tank	301-4429	1	Cover, Control Box
		Outlet) (Screened)	508-0001	2	Grommet, Rubber
155-0360	1	Muffler, Exhaust	625-1487	-	Diagram, Wiring
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/4" Close)			
402-0327	1	Hardware Package, Mounting			
		(Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped-Adjustable			
		(Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage			
		Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed			
		(Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-4R SPEC 17893AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4853-10 (AC) 612-1469-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank			The following Parts refer to the Glow Plug Control:		
Housed					
AC Meter Panel			332-0592	3	Jumper, Ground
Overspeed Switch			307-1274	1	Relay (DPDT)
Low Oil Pressure Cut Off			315-0433	1	Transformer
High Air Temperature Cut Off			332-0406	1	Block, Terminal - 3 Place
150-1688	1	Arm, Governor			(TB 1) Length 2 1/4" Mount:
502-0099	1	Elbow, Fuel Filter Adapter			Hole To Mounting Hole
		To Fuel Line	332-0426	1	Strip, Marker - 1 1/2" Wide
502-0003	1	Connector, Oil Fill Bracket			With 332-0406 Terminal 1
		To Oil Line	332-0236	1	Block, Terminal - 3 Place
141-0281	1	Gasket, Air Cleaner Adapter			(TB 2) Length 2 3/4"
		To Block			Mounting Hole To Mounti
159-0802	1	Tank, Fuel (9 Gallon)			Hole
504-0007	1	Valve, Shut-Off (Return)	332-0238	1	Strip, Marker - 1 7/8" Wi
501-0004	1	Line, Fuel - 12" (Tank To			(Used With 332-0236 Ter
		Fuel Pump)			Block)
501-0131	1	Line, Fuel - 24" (Return)	301-4428	1	Box, Control
504-0013	1	Valve, Shut-Off (Fuel Tank	301-4429	1	Cover, Control Box
		Outlet) (Screened)	508-0001	2	Grommet, Rubber
155-0360	1	Muffler, Exhaust	625-1487	-	Diagram, Wiring
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting			
		(Set of 4- Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
301-2204	1	Panel, Meter			
304-0500	1	Resistor, Tapped-Adjustable			
		(Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage			
		Regulator To Exciter			
		Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed			
		(includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			

**WIRING DIAGRAM NO.** (ENG)612-5567-09

**Dated** Sept. 1, 1979      **Revised** \_\_\_\_\_      **Page** 1 **of** 1

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 18145AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Air Duct And Shutter					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain ( $\frac{1}{2}$ " Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 18484AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5042-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch			232-2462	1	Box, Mounting
Low Oil Pressure Cut Off			232-2463	1	Cover, Mounting Box
High Air Temperature Cut Off			312-0197	1	Capacitor
			312-0198	2	Bracket, Capacitor Mountin
141-0281	1	Gasket, Air Cleaner Adapter To Block	508-0071	1	Grommet, Rubber - 7/8" Hol
150-1688	1	Arm, Governor	304-0120	2	Resistor, Fixed - 2 Ohm, 2 Watt
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	304-0015	4	Washer, Resistor Centering
502-0003	1	Connector, Oil Fill Bracket	304-0292	2	Insulator, Resistor
309-0206	1	Switch, High Air Temperature	813-0112	2	Screw, Machine - Round Hea (#10-32 x 2 1/2") Resistor Mounting
304-0500	1	Resistor, Tapped-Adjustable (Generator Air Outlet)	338-1165	1	Harness, Wiring
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator	625-1304	-	Diagram, Wiring
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Includes all Leads and Parts Marked *)			
307-0655	2	*Relay, High Air Temperature and Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
309-0270	1	Thermostat, Low Engine Temp.			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			
The following Parts refer to the Regulator Filter Assembly:					
232-2589	1	Regulator Filter Package - (For Complete Replacement) Includes Drawings and Unlisted Miscellaneous Hardware Items			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 18508AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber - 2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mtg.			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 18508AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Low Oil Pressure Cut Off					
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber-2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mounting			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 18639AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4853-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank					
Housed					
Air Duct And Shutter					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 18672AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-4976-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
322-0004	2	Lamp, Indicator			
322-0069	2	Holder, Indicator Lamp			
320-0221	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
301-2376	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 18704AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4998-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-9XR SPEC 18704AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5648-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Air Duct And Shutter			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 18727AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4791-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct And Shutter					
509-0112	1	Seal, Crankshaft Rear			
509-0111	1	Seal, Oil - Gearcase			
103-0454	1	Gearcase Assembly - Complete			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



**SPECIAL PARTS LIST FOR MODEL** 6.0DJE-4XR **SPEC** 18748AB  
**FOR STANDARD PARTS REFER TO CATALOG** 967-0225 **KEY NO.** -  
**(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)**

**WIRING DIAGRAM NO.** (ENG) 612-4792-10(AC) 612-1851-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank					
Housed					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
AC Meter Panel					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
102-0620	1	Base, Oil			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (½" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0484	1	Breaker, Circuit - 12 Amp			
304-0305	1	Resistor, Fixed - 45,000 Ohm, 10 Watt			
301-2308	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 18770AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5042-09 (AC) 612-1786-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
309-0206	1	Switch, High Air Temperature			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-1554	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
309-0270	1	Thermostat, Low Engine Temperature			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 18770AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5575-09(AC) 612-1786-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed			307-1157	1	Spring, Relay Hold-Down
AC Meter Panel			304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt
Overspeed Switch			309-0270	1	Thermostat, Low Engine Temperature
Low Oil Pressure Cut Off			332-0706	2	Block, Terminal - 8 Place
High Air Temperature Cut Off			332-0707	1	Strip, Marker - Blank
150-1688	1	Arm, Governor	321-0146	1	Fuse - 10 Amp
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	321-0175	1	Holder, Fuse
502-0003	1	Connector, Oil Fill Bracket To Oil Line	301-3567	1	Panel, Control Box
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-1554	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 18770AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5575-09 (AC) 612-1786-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Switch Housed AC Meter Panel					
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 18832AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
102-0880	1	Base, Oil			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 18832AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0880	1	Base, Oil			
134-1804	1	Duct, Air			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 18880AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
231-0171	1	Adapter, Generator			
154-0695	1	Manifold, Exhaust			
154-0133	1	Gasket, Adapter To Manifold			
155-0170	1	Adapter, Exhaust Manifold			
526-0127	2	Spacer, Exhaust Manifold			
134-1804	1	Duct, Air			
234-0492	1	Cover, Generator Air Outlet			
220-2667	1	Stator, Wound			
201-2309	1	Rotor Assembly, Wound			
201-2299	1	Rotor, Wound - Exciter			
220-2308	1	Stator, Wound - Exciter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
234-0532	1	Baffle, Air - Generator			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-4XR **SPEC** 18913AB  
**FOR STANDARD PARTS REFER TO CATALOG** 967-0225 **KEY NO.** -  
**(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)**  
**WIRING DIAGRAM NO.** (ENG) 612-5042-12(AC) 612-1851-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
Adjustable Voltage Regulator					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
309-0206	1	Switch, High Air Temperature			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0484	1	Breaker, Circuit - 12 Amp			
304-0305	1	Resistor, Fixed - 45,000 Ohm, 10 Watt			
301-2308	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
309-0270	1	Thermostat, Low Engine Temperature			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-1R SPEC 19078AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5008-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off			320-0235	1	Breaker, Circuit - 20 Amp
High Air Temperature Cut Off			320-0204	1	Breaker, Circuit - 30 Amp (Mounted In Control Panel)
150-1688	1	Arm, Governor	305-0517	1	Rectifier, Bridge
231-0199	1	Adapter, Generator	301-4389	1	Plate, Mounting - Bridge Rectifier
191-0506	1	Seal, Dirt - Starter	321-0020	1	Fuse - 60 Amp
191-0505	1	Cover Plate, Dirt Seal - Starter	321-0148	1	Holder, Fuse
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	302-0554	1	Ammeter, Charge (15-0-15)
502-0003	1	Connector, Oil Fill Bracket To Oil Line	302-0592	1	Meter, Running Time
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Hose)	304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt
141-0281	1	Gasket, Air Cleaner Adapter To Block	301-2650	1	Box, Control
134-3290	1	Cover, Cylinder Air Housing	234-0532	1	Baffle, Air - Generator
234-0492	1	Cover, Generator Air Outlet			
134-1804	1	Duct, Air			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
140-0722	2	Band, Air Cleaner Mounting			
503-0274	6	Clamp, Hose (Air Cleaner)			
503-0419	2	Elbow, Air Cleaner (Rubber)			
503-0330	1	Hose, Connector (Rubber - 2") Air Cleaner			
140-1271	1	Bracket, Air Cleaner Mtg.			
140-1334	1	Tube, Air Cleaner-Steel-8"			
140-0741	1	Tube, Air Cleaner-Steel-15" (This Tube Has An Elbow)			
140-0852	1	Support, Air Cleaner Hose			
336-1538	1	Lead, Control To Resistor (14½")			
220-2667	1	Stator, Wound			
201-2309	1	Rotor Assembly, Wound			
201-2299	1	Rotor, Wound - Exciter			
220-2308	1	Stator, Wound - Exciter			
304-0625	1	Resistor, Adjustable - 1 Ohm, 150 Watt (Generator Air Outlet)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-1R SPEC 19078AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5603-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off			320-0235	1	Breaker, Circuit - 20 Amp
High Air Temperature Cut Off			320-0204	1	Breaker, Circuit - 30 Amp (Mounted In Control Panel)
150-1688	1	Arm, Governor	305-0517	1	Rectifier, Bridge
231-0199	1	Adapter, Generator	301-4389	1	Plate, Mounting - Bridge Rectifier
191-0506	1	Seal, Dirt - Starter	321-0020	1	Fuse - 60 Amp
191-0505	1	Cover Plate, Dirt Seal - Starter	321-0148	1	Holder, Fuse
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	302-0554	1	Ammeter, Charge (15-0-15)
502-0003	1	Connector, Oil Fill Bracket To Oil Line	302-0592	1	Meter, Running Time
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Hose)	304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt
141-0281	1	Gasket, Air Cleaner Adapter To Block	301-2650	1	Box, Control
134-3290	1	Cover, Cylinder Air Housing	234-0532	1	Baffle, Air - Generator
234-0492	1	Cover, Generator Air Outlet			
134-1804	1	Duct, Air			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
140-0722	2	Band, Air Cleaner Mounting			
503-0274	6	Clamp, Hose (Air Cleaner)			
503-0419	2	Elbow, Air Cleaner (Rubber)			
503-0330	1	Hose, Connector (Rubber - 2") Air Cleaner			
140-1271	1	Bracket, Air Cleaner Mtg.			
140-1334	1	Tube, Air Cleaner-Steel-8"			
140-0741	1	Tube, Air Cleaner-Steel-15" (This Tube Has An Elbow)			
140-0852	1	Support, Air Cleaner Hose			
336-1538	1	Lead, Control To Resistor (14½")			
220-2667	1	Stator, Wound			
201-2309	1	Rotor Assembly, Wound			
201-2299	1	Rotor, Wound - Exciter			
220-2308	1	Stator, Wound - Exciter			
304-0625	1	Resistor, Adjustable - 1 Ohm, 150 Watt (Generator Air Outlet)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-1R SPEC 19078AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5603-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
231-0199	1	Adapter, Generator			
191-0506	1	Seal, Dirt - Starter			
191-0505	1	Cover Plate, Dirt Seal - Starter			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Hose)			
134-3290	1	Cover, Cylinder Air Housing			
234-0492	1	Cover, Generator Air Outlet			
134-1804	1	Duct, Air			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
140-0722	2	Band, Air Cleaner Mounting			
503-0274	6	Clamp, Hose (Air Cleaner)			
503-0419	2	Elbow, Air Cleaner (Rubber)			
503-0330	1	Hose, Connector (Rubber-2") Air Cleaner			
140-1271	1	Bracket, Air Cleaner Mounting			
140-1334	1	Tube, Air Cleaner - Steel-8"			
140-0741	1	Tube, Air Cleaner - Steel-15" (This Tube Has An Elbow)			
140-0852	1	Support, Air Cleaner Hose			
336-1538	1	Lead, Control To Resistor (14½")			
220-2667	1	Stator, Wound			
201-2309	1	Rotor Assembly, Wound			
201-2299	1	Rotor, Wound - Exciter			
220-2308	1	Stator, Wound - Exciter			
234-0532	1	Baffle, Air - Generator			
304-0625	1	Resistor, Adjustable - 1 Ohm, 150 Watt (Generator Air Outlet)			
320-0235	1	Breaker, Circuit - 20 Amp			
320-0204	1	Breaker, Circuit - 30 Amp (Mounted In Control Panel)			
305-0517	1	Rectifier, Bridge			
301-4389	1	Plate, Mounting - Bridge Rectifier			
321-0020	1	Fuse - 60 Amp			
321-0148	1	Holder, Fuse			
302-0554	1	Ammeter, Charge (15-0-15)			
302-0592	1	Meter, Running Time			
301-2650	1	Box, Control			

SPECIAL PARTS LIST FOR MODEL 6.0DIE-18R SPEC 19103AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5572-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (½" Close)			
309-0206	1	Switch, High Air Temperature			
320-0221	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1129	1	Relay Assembly, High Air Temperature (Includes Leads)			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-1E SPEC 19116AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off			134-1974	1	Panel, Air Housing Door
High Air Temperature Cut Off			134-1973	1	Cover, Cylinder Air Housing
234-0532	1	Baffle, Air - Generator	134-1972	1	Bracket, Air Housing Door Panel
141-0281	1	Gasket, Air Cleaner Adapter To Block	134-1971	1	Support, Blower Housing And Grille
103-0326	1	Backplate, Gearcase	134-1970	1	Grille, Blower Housing
103-0325	1	Gearcase Assembly - Complete	134-1969	3	Retainer, Blower Housing Grille
150-1249	1	Shaft, Governor	123-1095	1	Tube, Breather
150-1686	1	Arm, Governor	134-3671	1	Brace, Cylinder Air Housing Panel - Bottom
115-0192	8	Washer, Push Rod Shield Spring Retaining	309-0206	1	Switch, High Air Temperature
231-0199	1	Adapter, Generator	234-0309	1	Cover, End Bell
147-0240	1	Adapter, Injection Nozzle (#2 Cylinder)	234-0525	1	Cover, Generator Air Outlet
147-0241	1	Adapter, Injection Nozzle (#1 Cylinder)	191-0731	1	Cover, Plate - Start Disconnect
147-0239	1	Flange, Injection Nozzle	220-2667	1	Stator, Wound
115-0194	4	Shield, Push Rod	201-2309	1	Rotor Assembly, Wound
115-0193	4	Spring, Shield Retainer	201-2299	1	Rotor, Wound - Exciter
149-1198	1	Adapter, Fuel Filter	220-2308	1	Stator, Wound - Exciter
123-1096	1	Tube Assembly, Oil Fill	304-0625	1	Resistor, Adjustable - 1 Ohm, 150 Watt (Generator Air Outlet)
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	301-3834	1	Panel, Mounting - Voltage Regulator
502-0003	1	Connector, Oil Fill Bracket To Oil Line	305-0541	1	Regulator, Voltage (Without Voltage Adjustment)
115-0191	1	Cover Assembly, Rocker	300-1405	1	Board, Voltage Regulator (For Component Parts Use Parts Listed For 300-1404 Voltage Regulator Board)
191-0729	1	Plate, Centrifugal Switch	320-0235	1	Breaker, Circuit - 20 Amp
338-0306	1	Harness, Wiring - Starter	320-0204	1	Breaker, Circuit - 30 Amp (Mounted In Control Panel)
120-0832	1	Line, Oil - Adapter To Cylinder Head	305-0517	1	Rectifier, Bridge
149-1203	1	Line, Fuel - Fuel Pump To Filter	301-4389	1	Plate, Mounting - Bridge Rectifier
150-1251	1	Spring, Governor	321-0020	1	Fuse - 60 Amp
150-1250	1	Bracket, Governor Spring	321-0148	1	Holder, Fuse
149-1583	1	Line, Nozzle Fuel Return (#1 Cylinder)	302-0554	1	Ammeter, Charge (15-0-15)
149-1584	1	Line, Nozzle Fuel Return (#2 Cylinder)	302-0592	1	Meter, Running Time
140-1041	1	Adapter, Air Cleaner To Block	308-0028	2	Switch, Push (Start-Heater)
140-1040	1	Pan, Air Cleaner	308-0274	2	Boot, Weather (Used On Push Switches)
140-0606	1	Element, Air Cleaner	308-0069	1	Switch, Toggle (Run-Stop)
140-1039	1	Cover, Air Cleaner	301-4797	1	Panel, Control Box
134-1978	1	Housing, Cylinder Air - Front	301-3098	1	Box, Control
134-1977	1	Housing, Cylinder Air - Rear	301-3955	1	Cover, Voltage Regulator
338-0408	1	Harness, Wiring - Start Disconnect To Control	301-3956	1	Saddle, Control Box
307-1644	1	Bracket, Solenoid Mounting			
134-1976	1	Housing, Blower			
134-3670	1	Panel, Cylinder Air Housing (Bottom)			

Parts Not Furnished By Onan: Starter, Starter Spacer, Starter Bracket



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19122AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4853-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Fuel Tank					
Housed					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19122AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5567-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Fuel Tank			
		Housed			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19212AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4853-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
134-1804	1	Duct, Air			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber - 2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mtg.			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19231AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter			
		To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
		To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter			
		To Block			
102-0620	1	Base, Oil			
304-0500	1	Resistor, Tapped - Adjustable			
		(Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 19231AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Air Duct And Shutter			
		Low Oil Pressure Cut Off			
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-1E SPEC 19292AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off			134-3670	1	Panel, Cylinder Air Housing (Bottom)
High Air Temperature Cut Off			134-1974	1	Panel, Air Housing Door
234-0532	1	Baffle, Air - Generator	134-1973	1	Cover, Cylinder Air Housing
103-0326	1	Backplate, Gearcase	134-1972	1	Bracket, Air Housing Door Panel
103-0325	1	Gearcase Assembly - Complete	134-1971	1	Support, Blower Housing Air Grille
150-1249	1	Shaft, Governor	134-1970	1	Grille, Blower Housing
150-1686	1	Arm, Governor	134-1969	3	Retainer, Blower Housing Grille
115-0192	8	Washer, Push Rod Shield Spring Retaining	123-1095	1	Tube, Breather
231-0199	1	Adapter, Generator	134-3671	1	Brace, Cylinder Air Housing Panel - Bottom
191-0506	1	Seal, Dirt - Starter	309-0206	1	Switch, High Air Temperature
191-0505	1	Cover Plate, Dirt Seal - Starter	234-0309	1	Cover, End Bell
147-0240	1	Adapter, Injection Nozzle (#2 Cylinder)	234-0525	1	Cover, Generator Air Outlet
147-0241	1	Adapter, Injection Nozzle (#1 Cylinder)	191-0731	1	Cover, Plate - Start Disconnect
147-0239	1	Flange, Injection Nozzle	220-2667	1	Stator, Wound
115-0194	4	Shield, Push Rod	201-2309	1	Rotor Assembly, Wound
115-0193	4	Spring, Shield Retainer	201-2299	1	Rotor, Wound - Exciter
149-1198	1	Adapter, Fuel Filter	220-2308	1	Stator, Wound - Exciter
123-1096	1	Tube Assembly, Oil Fill	304-0625	1	Resistor, Adjustable - 1 Ohm, 150 Watt (Generator Air Outlet)
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	301-3834	1	Panel, Mounting - Voltage Regulator
502-0003	1	Connector, Oil Fill Bracket To Oil Line	305-0541	1	Regulator, Voltage (Without Voltage Adjustment)
115-0191	1	Cover Assembly, Rocker	300-1405	1	Board, Voltage Regulator (For Component Parts Use Parts Listed For 300-1405 Voltage Regulator Board)
191-0729	1	Plate, Centrifugal Switch	320-0235	1	Breaker, Circuit - 20 Amp
338-0306	1	Harness, Wiring - Starter	320-0204	1	Breaker, Circuit - 30 Amp (Mounted In Control Panel)
120-0832	1	Line, Oil - Adapter To Cylinder Head	305-0517	1	Rectifier, Bridge
149-1203	1	Line, Fuel - Fuel Pump To Filter	301-4389	1	Plate, Mounting - Bridge Rectifier
150-1251	1	Spring, Governor	321-0020	1	Fuse - 60 Amp
150-1250	1	Bracket, Governor Spring	321-0148	1	Holder, Fuse
149-1583	1	Line, Nozzle Fuel Return (#1 Cylinder)	302-0554	1	Ammeter, Charge (15-0-15)
149-1584	1	Line, Nozzle Fuel Return (#2 Cylinder)	302-0592	1	Meter, Running Time
140-1041	1	Adapter, Air Cleaner To Block	308-0028	2	Switch, Push (Start-Heater)
141-0281	1	Gasket, Air Cleaner Adapter To Block	308-0274	2	Boot, Weather (Used On Push Switches)
140-1040	1	Pan, Air Cleaner	308-0069	1	Switch, Toggle (Run-Stop)
140-0606	1	Element, Air Cleaner	301-4797	1	Panel, Control Box
140-1039	1	Cover, Air Cleaner	301-3098	1	Box, Control
134-1978	1	Housing, Cylinder Air - Front	301-3955	1	Cover, Voltage Regulator
134-1977	1	Housing, Cylinder Air - Rear	301-3956	1	Saddle, Control Box
338-0408	1	Harness, Wiring - Start Disconnect To Control			
307-1644	1	Bracket, Solenoid Mounting			
134-1976	1	Housing, Blower			

Dated March 1, 1979

Revised

Page 1 of 1

SPECIAL PARTS LIST FOR MODEL 6.0DJE-1E SPEC 19292AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off			134-3670	1	Panel, Cylinder Air Housing (Bottom)
High Air Temperature Cut Off			134-1974	1	Panel, Air Housing Door
234-0532	1	Baffle, Air - Generator	134-1973	1	Cover, Cylinder Air Housing
103-0326	1	Backplate, Gearcase	134-1972	1	Bracket, Air Housing Door Panel
103-0325	1	Gearcase Assembly - Complete	134-1971	1	Support, Blower Housing And Grille
150-1249	1	Shaft, Governor	134-1970	1	Grille, Blower Housing
150-1686	1	Arm, Governor	134-1969	3	Retainer, Blower Housing Grille
115-0192	8	Washer, Push Rod Shield Spring Retaining	123-1095	1	Tube, Breather
231-0199	1	Adapter, Generator	134-3671	1	Brace, Cylinder Air Housing Panel - Bottom
191-0506	1	Seal, Dirt - Starter	309-0206	1	Switch, High Air Temperature
191-0505	1	Cover Plate, Dirt Seal - Starter	234-0309	1	Cover, End Bell
147-0240	1	Adapter, Injection Nozzle (#2 Cylinder)	234-0525	1	Cover, Generator Air Outlet
147-0241	1	Adapter, Injection Nozzle (#1 Cylinder)	191-0731	1	Cover, Plate - Start Disconnect
147-0239	1	Flange, Injection Nozzle	220-2667	1	Stator, Wound
115-0194	4	Shield, Push Rod	201-2309	1	Rotor Assembly, Wound
115-0193	4	Spring, Shield Retainer	201-2299	1	Rotor, Wound - Exciter
149-1198	1	Adapter, Fuel Filter	220-2308	1	Stator, Wound - Exciter
123-1096	1	Tube Assembly, Oil Fill	304-0625	1	Resistor, Adjustable - 1 Ohm, 150 Watt (Generator Air Outlet)
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line	301-3834	1	Panel, Mounting - Voltage Regulator
502-0003	1	Connector, Oil Fill Bracket To Oil Line	305-0585	1	Regulator, Voltage (Without Voltage Adjustment)
115-0191	1	Cover Assembly, Rocker	300-1654	1	Board, Voltage Regulator (For Component Parts Use Parts Listed For 300-1540 Voltage Regulator Board)
191-0729	1	Plate, Centrifugal Switch	320-0235	1	Breaker, Circuit - 20 Amp
338-0306	1	Harness, Wiring - Starter	320-0204	1	Breaker, Circuit - 30 Amp (Mounted In Control Panel)
120-0832	1	Line, Oil - Adapter To Cylinder Head	305-0517	1	Rectifier, Bridge
149-1203	1	Line, Fuel - Fuel Pump To Filter	301-4389	1	Plate, Mounting - Bridge Rectifier
150-1251	1	Spring, Governor	321-0020	1	Fuse - 60 Amp
150-1250	1	Bracket, Governor Spring	321-0148	1	Holder, Fuse
149-1583	1	Line, Nozzle Fuel Return (#1 Cylinder)	302-0554	1	Ammeter, Charge (15-0-15)
149-1584	1	Line, Nozzle Fuel Return (#2 Cylinder)	302-0592	1	Meter, Running Time
140-1041	1	Adapter, Air Cleaner To Block	308-0028	2	Switch, Push (Start-Heater)
141-0281	1	Gasket, Air Cleaner Adapter To Block	308-0274	2	Boot, Weather (Used On Push Switches)
140-1040	1	Pan, Air Cleaner	308-0069	1	Switch, Toggle (Run-Stop)
140-0606	1	Element, Air Cleaner	301-4797	1	Panel, Control Box
140-1039	1	Cover, Air Cleaner	301-3098	1	Box, Control
134-1978	1	Housing, Cylinder Air - Front	301-3955	1	Cover, Voltage Regulator
134-1977	1	Housing, Cylinder Air - Rear	301-3956	1	Saddle, Control Box
338-0408	1	Harness, Wiring - Start Disconnect To Control			
307-1644	1	Bracket, Solenoid Mounting			
134-1976	1	Housing, Blower			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-1E SPEC 19292AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off			134-1971	1	Support, Blower Housing An
High Air Temperature Cut Off					Grille
103-0326	1	Backplate, Gearcase	134-1970	1	Grille, Blower Housing
103-0325	1	Gearcase Assembly-Complete	134-1969	3	Retainer, Blower Housing
150-1249	1	Shaft, Governor			Grille
150-1686	1	Arm, Governor	123-1095	1	Tube, Breather
115-0192	8	Washer, Push Rod Shield	134-3671	1	Brace, Cylinder Air Housin
		Spring Retaining			Panel - Bottom
231-0199	1	Adapter, Generator	309-0206	1	Switch, High Air Temperatu
191-0506	1	Seal, Dirt - Starter	234-0309	1	Cover, End Bell
191-0505	1	Cover Plate, Dirt Seal -	234-0525	1	Cover, Generator Air Outle
		Starter	191-0731	1	Cover, Plate ~ Start
147-0240	1	Adapter, Injection Nozzle			Disconnect
		(#2 Cylinder)	220-2667	1	Stator, Wound
147-0241	1	Adapter, Injection Nozzle	201-2309	1	Rotor Assembly, Wound
		(#1 Cylinder)	201-2299	1	Rotor, Wound - Exciter
147-0239	1	Flange, Injection Nozzle	220-2308	1	Stator, Wound - Exciter
115-0194	4	Shield, Push Rod	234-0532	1	Baffle, Air - Generator
115-0193	4	Spring, Shield Retainer	304-0625	1	Resistor, Adjustable -
149-1198	1	Adapter, Fuel Filter			1 Ohm, 150 Watt
123-1096	1	Tube Assembly, Oil Fill			(Generator Air Outlet)
115-0191	1	Cover Assembly, Rocker	301-3834	1	Panel, Mounting - Voltage
191-0729	1	Plate, Centrifugal Switch			Regulator
338-0306	1	Harness, Wiring - Starter	305-0585	1	Regulator, Voltage (Withou
120-0832	1	Line, Oil - Adapter To			Voltage Adjustment)
		Cylinder Head	300-1654	1	Board, Voltage Regulator
149-1203	1	Line, Fuel - Fuel Pump To			(For Component Parts Use
		Filter			Parts Listed For 300-154
150-1251	1	Spring, Governor			Voltage Regulator Board)
150-1250	1	Bracket, Governor Spring	320-0235	1	Breaker, Circuit - 20 Amp
149-1583	1	Line, Nozzle Fuel Return	320-0204	1	Breaker, Circuit - 30 Amp
		(#1 Cylinder)			(Mounted In Control Pane
149-1584	1	Line, Nozzle Fuel Return	305-0517	1	Rectifier, Bridge
		(#2 Cylinder)	301-4389	1	Plate, Mounting - Bridge
140-1041	1	Adapter, Air Cleaner To Block			Rectifier
140-1040	1	Pan, Air Cleaner	321-0020	1	Fuse - 60 Amp
140-0606	1	Element, Air Cleaner	321-0148	1	Holder, Fuse
140-1039	1	Cover, Air Cleaner	302-0554	1	Ammeter, Charge (15-0-15)
134-1978	1	Housing, Cylinder Air - Front	302-0592	1	Meter, Running Time
134-1977	1	Housing, Cylinder Air - Rear	308-0028	2	Switch, Push (Start-Heater
338-0408	1	Harness, Wiring - Start	308-0274	2	Boot, Weather (Used On Pus
		Disconnect To Control			Switches)
307-1644	1	Bracket, Solenoid Mounting	308-0069	1	Switch, Toggle (Run-Stop)
134-1976	1	Housing, Blower	301-4797	1	Panel, Control Box
134-3670	1	Panel, Cylinder Air Housing	301-3098	1	Box, Control
		(Bottom)	301-3955	1	Cover, Voltage Regulator
134-1974	1	Panel, Air Housing Door	301-3956	1	Saddle, Control Box
134-1973	1	Cover, Cylinder Air Housing			
134-1972	1	Bracket, Air Housing Door			
		Panel			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 19352AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5567-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Skid And Battery Rack					
Adjustable Voltage Regulator					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Hose)			
134-1804	1	Duct, Air			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
Parts Not Furnished By Onan Air Cleaner And Associated Parts					

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 19352AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5567-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Skid And Battery Rack			
		Adjustable Voltage Regulator			
102-0620	1	Base, Oil			
140-0645	1	Adapter, Air Cleaner			
134-1804	1	Duct, Air			



SPECIAL PARTS LIST FOR MODEL 4.5DJE-57R SPEC 19501AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4791-06 (AC) 612-4310-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed Air Duct And Shutter High Air Temperature Cut Off AC Meter Panel					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain ( $\frac{1}{2}$ " Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
220-2048	1	Stator, Wound - Generator			
201-2155	1	Rotor Assembly - Generator			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
320-0483	1	Breaker, Circuit - 10 Amp			
302-0612	1	Voltmeter, AC (0-500)			
302-0469	1	Meter, Running Time			
301-2308	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19511AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4998-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Skid And Battery Rack					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
309-0206	1	Switch, High Air Temperature			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 19717AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5581-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber-2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mounting			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
304-0521	1	Resistor, Adjustable - 8 Ohm, 150 Watt (Charging)			
305-0383	1	Regulator, Voltage (Charging)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19866AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber - 2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mtg.			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19866AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Low Oil Pressure Cut Off					
134-1804	1	Duct, Air			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber-2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mounting			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 19926AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
The Following Parts Refer To The Regulator Filter Assembly:					
232-2589	1	Regulator Filter Package - (For Complete Replacement) Includes Drawings And Unlisted Miscellaneous Hardware Items			
232-2462	1	Box, Mounting			
232-2463	1	Cover, Mounting Box			
312-0197	1	Capacitor			
312-0198	2	Bracket, Capacitor Mounting			
508-0071	1	Grommet, Rubber - 7/8" Hole			
304-0120	2	Resistor, Fixed - 2 Ohm, 25 Watt			
304-0015	4	Washer, Resistor Centering			
304-0292	2	Insulator, Resistor			
813-0112	2	Screw, Machine - Round Head (#10-32 X 2-1/2") Resistor Mounting			
338-1165	1	Harness, Wiring			
625-1304	-	Diagram, Wiring			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 19926AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off Voltage Regulator Filter			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 19973AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
150-1688	1	Arm, Governor			
333-0157	1	Heater, Immersion - Generator End Bell Cover			
234-0542	1	Cover, End Bell			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 19973AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
234-0542	1	Cover, End Bell			
333-0157	1	Heater, Immersion - End Bell Cover			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 20225AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5557-09(AC)612-1786-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
AC Meter Panel					
102-0620	1	Base, Oil			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 20466AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5575-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Adjustable Voltage Regulator			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 20608AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack Low Oil Pressure Cut Off High Air Temperature Cut Off  102-0620     1     Base, Oil 134-1804     1     Duct, Air 220-2040     1     Stator, Wound 201-2155     1     Rotor Assembly, Wound 520-0795     4     Stud, Generator Through 520-0787     1     Stud, Rotor Through					

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 20767AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5567-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Overspeed Switch			
140-0645	1	Adapter, Air Cleaner			

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Housed			
		AC Meter Panel			
		Air Duct And Shutter			
		Voltage Regulator Filter			
309-0206	1	Switch, High Air Temperature			
320-0221	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1129	1	Relay Assembly, High Air Temperature (Includes Leads)			
301-2376	1	Panel, Control			

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		High Air Temperature Cut Off			
134-1804	1	Duct, Air			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 21048AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5567-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Air Duct And Shutter					
102-0620	1	Base, Oil			
The Following Parts Refer To The Glow Plug Control:					
332-0592	3	Jumper, Ground			
307-1274	1	Relay (DPDT)			
315-0433	1	Transformer			
332-0406	1	Block, Terminal - 3 Place (TB 1) Length 2-1/4" Mounting Hole To Mounting Hole			
332-0426	1	Strip, Marker - 1-1/2" Wide (Used With 332-0406 Terminal Block)			
332-0236	1	Block, Terminal - 3 Place (TB 2) Length 2-3/4" Mounting Hole To Mounting Hole			
332-0238	1	Strip, Marker - 1-7/8" Wide (Used With 332-0236 Terminal Block)			
301-4428	1	Box, Control			
301-4429	1	Cover, Control Box			
508-0001	2	Grommet, Rubber			
625-1487	-	Diagram, Wiring			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 21094AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5574-11

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Air Duct And Shutter			
		Adjustable Voltage Regulator			
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
333-0157	1	Heater, Immersion-Generator			
		End Bell Cover			
234-0543	1	Cover, End Bell			
320-0259	1	Relay, Low Oil Pressure			
		(Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low			
		Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly -			
		High Air Temperature And			
		Overspeed (Includes All			
		Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature			
		And Overspeed			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 21132AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5567-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 21159AE  
**FOR STANDARD PARTS REFER TO CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5575-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Switch					
Skid And Battery Rack					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-4XR SPEC 21192AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5574-10 (AC) 612-1859-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
309-0206	1	Switch, High Air Temperature			
301-2373	1	Panel, Meter			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 6.0 DJE - 1E**SPEC** 23182 AEFOR STANDARD PARTS REFER TO **CATALOG** 967-0225**KEY NO.** \_\_\_\_\_

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LOW OIL PRESSURE SWITCH			134-1969	3	Retainer, Blower Housing Grille
HIGH AIR TEMPERATURE SWITCH			134-3671	1	Brace, Cylinder Air Housing Panel - Bottom
CONTRACTOR AIR CLEANER			307-1644	1	Bracket, Solenoid Mounting
103-0326	1	Backplate, Gearcase	123-1095	1	Tube, Breather
103-0325	1	Gearcase Assembly - Complete	309-0206	1	Switch, High Air Temperature
150-1249	1	Shaft, Governor	231-0199	1	Adapter, Generator
150-1686	1	Arm, Governor	508-0180	1	Grommet, Rubber (1/2" Hole)
115-0192	8	Washer, Push Rod Spring Retaining			Generator Adapter Air Outlet
115-0193	4	Spring, Push Rod Shield	234-0309	1	Cover, End Bell
115-0194	4	Shield, Push Rod	234-0525	1	Cover, Generator Air Outlet
191-0728	1	Bracket, Starter	191-0506	1	Seal, Dirt - Starter
149-1198	1	Adapter, Fuel Filter	191-0505	1	Cover Plate, Dirt Seal - Starter
115-0191	2	Cover Assembly, Rocker	520-0662	2	Stud, Starter Mounting
815-0562	2	Screw, Machine - Cross Recessed Pan Head (#10 x 5/16") Rocker Cover Oil Line Retaining	154-0695	1	Manifold, Exhaust
191-1530	1	Plate, Start Disconnect	147-0240	1	Adapter, Injection Nozzle (No. 2 Cylinder)
191-0731	1	Cover, Start Disconnect	147-0241	1	Adapter, Injection Nozzle (No. 1 Cylinder)
338-0306	1	Harness, Wiring - Starter	147-0239	2	Flange, Injection Nozzle
338-0408	1	Harness, Wiring - Start Disconnect to Control	123-1096	1	Tube Assembly, Oil Fill
149-1794	1	Line, Fuel Return - Nozzle Fuel Return Lines Tee to Fuel Pump Return Line Tee	220-2308	1	Stator, Wound - Exciter
120-0832	1	Line, Oil - Adapter to Cylinder Head	234-0532	1	Baffle, Air - Generator
149-1203	1	Line, Fuel - Fuel Pump to Fuel Filter Adapter	220-2667	1	Stator, Wound - Generator
150-1251	1	Spring, Governor	201-2309	1	Rotor Assembly, Wound - Generator
150-1250	1	Bracket, Governor Spring	201-2299	1	Rotor, Wound - Exciter
149-1583	1	Line, Nozzle Fuel Return - No. 1 Cylinder	304-0625	1	Resistor, Tap (Adjustable) Generator Air Outlet
149-1584	1	Line, Nozzle Fuel Return - No. 2 Cylinder	301-3834	1	Panel, Mounting - Voltage Regulator
134-1978	1	Housing, Cylinder Air - Front	300-1654	1	Board, Voltage Regulator
134-1977	1	Housing, Cylinder Air - Rear	305-0585	1	Regulator, Voltage (Without Adjustment)
134-1976	1	Housing, Blower	320-0235	1	Breaker, Circuit (20 amp) Mounted on Control Box Saddle
134-3670	1	Panel, Cylinder Air Housing - Bottom	320-0204	1	Breaker, Circuit (30 amp) Mounted on Control Panel
134-1974	1	Panel, Air Housing Door	357-0043	1	Rectifier, Bridge (Charge) Mounted on Control Box Saddle
134-1973	1	Cover, Cylinder Air Housing	301-4389	1	Plate, Mounting-Bridge Rectifier
134-1972	1	Bracket, Air Housing Door Panel	321-0020	1	Fuse (60 amp)
134-1971	1	Support, Blower Housing and Grille	321-0148	1	Holder, Fuse
134-1970	1	Grille, Blower Housing	302-1367	1	Ammeter Kit, Charge - Include Mounting Hardware (15-0-15)
			302-0592	1	Meter, Running Time
			308-0028	2	Switch, Push (Start and Heater)
			308-0274	2	Boot - Push Switches
			308-0069	1	Switch, Toggle - Run/Stop

Continued ....



SPECIAL PARTS LIST FOR MODEL 6.0 DJE - 1E SPEC 24264 AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO.         
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LOW OIL PRESSURE SWITCH					
HIGH AIR TEMPERATURE SWITCH					
CONTRACTOR AIR CLEANER					
103-0326	1	Backplate, Gearcase	134-1969	3	Retainer, Blower Housing Grille
103-0325	1	Gearcase Assembly - Complete	134-3671	1	Brace, Cylinder Air Housing Panel - Bottom
150-1249	1	Shaft, Governor	307-1644	1	Bracket, Solenoid Mounting
150-1686	1	Arm, Governor	123-1095	1	Tube, Breather
115-0192	8	Washer, Push Rod Spring Retaining	309-0206	1	Switch, High Air Temperature
115-0193	4	Spring, Push Rod Shield	231-0199	1	Adapter, Generator
115-0194	4	Shield, Push Rod	508-0180	1	Grommet, Rubber (1/2" Hole) Generator Adapter Air Outlet
191-0728	1	Bracket, Starter	234-0309	1	Cover, End Bell
149-1198	1	Adapter, Fuel Filter	234-0525	1	Cover, Generator Air Outlet
115-0191	2	Cover Assembly, Rocker	191-0506	1	Seal, Dirt - Starter
815-0562	2	Screw, Machine - Cross Recessed Pan Head (#10 x 5/16") Rocker Cover Oil Line Retaining	191-0505	1	Cover Plate, Dirt Seal - Starter
191-1530	1	Plate, Start Disconnect	520-0662	2	Stud, Starter Mounting
191-0731	1	Cover, Start Disconnect	154-0695	1	Manifold, Exhaust
338-0306	1	Harness, Wiring - Starter	147-0240	1	Adapter, Injection Nozzle (No. 2 Cylinder)
338-0408	1	Harness, Wiring - Start Disconnect to Control	147-0241	1	Adapter, Injection Nozzle (No. 1 Cylinder)
149-1794	1	Line, Fuel Return - Nozzle Fuel Return Lines Tee to Fuel Pump Return Line Tee	147-0239	2	Flange, Injection Nozzle
120-0832	1	Line, Oil - Adapter to Cylinder Head	123-1096	1	Tube Assembly, Oil Fill
149-1203	1	Line, Fuel - Fuel Pump to Fuel Filter Adapter	150-1926	1	Post and Arm Assembly, Governor (Includes Ball Joint, Injection Pump Governor Arm, Screw and Washer)
150-1251	1	Spring, Governor	140-1807	1	Tab, Air Induction Support
150-1250	1	Bracket, Governor Spring	503-0274	4	Clamp, Hose
149-1583	1	Line, Nozzle Fuel Return - No. 1 Cylinder	503-0004	1	Clamp, Hose
149-1584	1	Line, Nozzle Fuel Return - No. 2 Cylinder	503-0419	2	Elbow, Rubber - Air Cleaner
134-1978	1	Housing, Cylinder Air - Front	140-1805	1	Tube, Air Induction
134-1977	1	Housing, Cylinder Air - Rear	402-0359	1	Hardware Package, Mounting (Includes Parts Marked *)
134-1976	1	Housing, Blower	800-0199	4	*Screw, Cap - Hex Head
134-3670	1	Panel, Cylinder Air Housing - Bottom	526-0195	4	*Washer, Flat (3/4" OD)
134-1974	1	Panel, Air Housing Door	402-0406	4	*Bushing, Spacer
134-1973	1	Cover, Cylinder Air Housing	402-0282	4	*Snubber, Shock Mounting
134-1972	1	Bracket, Air Housing Door Panel	526-0014	4	*Washer, Flat (1 1/2" OD)
134-1971	1	Support, Blower Housing and Grille	850-0055	4	*Washer, Lock - Spring (7/16")
134-1970	1	Grille, Blower Housing	862-0004	4	*Nut, Hex (7/16 - 14)
			526-0198	8	*Washer, Flat (5/8" ID x 1 1/2" O x 1/16" Thk) Use as Required
			220-2308	1	Stator, Wound - Exciter
			234-0532	1	Baffle, Air - Generator
			220-2667	1	Stator, Wound - Generator
			201-2309	1	Rotor Assembly, Wound - Generator
			201-2299	1	Rotor, Wound - Exciter

SPECIAL PARTS LIST FOR **MODEL** 6.0 DJE - 1E **SPEC** 24264 AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.**           
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
304-0625	1	Resistor, Tap (Adjustable) Generator Air Outlet			
301-3834	1	Panel, Mounting - Voltage Regulator			
300-1654	1	Board, Voltage Regulator			
305-0585	1	Regulator, Voltage (Without Adjustment)			
320-0235	1	Breaker, Circuit (20 amp) Mounted on Control Box Saddle			
320-0204	1	Breaker, Circuit (30 amp) Mounted on Control Panel			
357-0043	1	Rectifier, Bridge (Charge) Mounted on Control Box Saddle			
301-4389	1	Plate, Mounting - Bridge Rectifier			
321-0020	1	Fuse (60 amp)			
321-0148	1	Holder, Fuse			
302-1367	1	Ammeter Kit, Charge - Includes Mounting Hardware (15-0-15)			
302-0592	1	Meter, Running Time			
308-0028	2	Switch, Push (Start and Heater)			
308-0274	2	Boot - Push Switches			
308-0069	1	Switch, Toggle - Run/Stop			
301-4797	1	Panel, Control			
301-3098	1	Box, Control			
301-3955	1	Cover, Voltage Regulator			
301-3956	1	Saddle, Control Box			



SPECIAL PARTS LIST FOR **MODEL** 6.0 DJE - 1E **SPEC** 24553 AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** \_\_\_\_\_  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LOW OIL PRESSURE SWITCH					
HIGH AIR TEMPERATURE SWITCH					
CONTRACTOR AIR CLEANER					
103-0326	1	Backplate, Gearcase	140-1559	1	Hood, Air Inlet - Air Cleaner
103-0325	1	Gearcase Assembly - Complete	134-1969	3	Retainer, Blower Housing Grill
150-1249	1	Shaft, Governor	134-3671	1	Brace, Cylinder Air Housing Panel - Bottom
150-1686	1	Arm, Governor	307-1644	1	Bracket, Solenoid Mounting
115-0192	8	Washer, Push Rod Spring Retaining	123-1095	1	Tube, Breather
115-0193	4	Spring, Push Rod Shield	309-0206	1	Switch, High Air Temperature
115-0194	4	Shield, Push Rod	231-0199	1	Adapter, Generator
191-0728	1	Bracket, Starter	508-0180	1	Grommet, Rubber ( $\frac{1}{2}$ " Hole) Generator Adapter Air Outlet
149-1198	1	Adapter, Fuel Filter	234-0309	1	Cover, End Bell
115-0191	2	Cover Assembly, Rocker	234-0525	1	Cover, Generator Air Outlet
815-0562	2	Screw, Machine - Cross Recessed Pan Head (#10 x 5/16") Rocker Cover Oil Line Retaining	191-0506	1	Seal, Dirt - Starter
191-1530	1	Plate, Start Disconnect	191-0505	1	Cover Plate, Dirt Seal - Start
191-0731	1	Cover, Start Disconnect	520-0662	2	Stud, Starter Mounting
338-0306	1	Harness, Wiring - Starter	154-0695	1	Manifold, Exhaust
338-0408	1	Harness, Wiring - Start Disconnect to Control	147-0240	1	Adapter, Injection Nozzle (No. 2 Cylinder)
149-1794	1	Line, Fuel Return - Nozzle Fuel Return Lines Tee to Fuel Pump Return Line Tee	147-0241	1	Adapter, Injection Nozzle (No. 1 Cylinder)
120-0832	1	Line, Oil - Adapter to Cylinder Head	147-0239	2	Flange, Injection Nozzle
149-1203	1	Line, Fuel - Fuel Pump to Fuel Filter Adapter	123-1096	1	Tube Assembly, Oil Fill
150-1251	1	Spring, Governor	150-1926	1	Post and Arm Assembly, Governor (Includes Ball Joint, Injection Pump Governor Arm, Screw and Washer)
150-1250	1	Bracket, Governor Spring	140-1807	1	Tab, Air Induction Support
149-1583	1	Line, Nozzle Fuel Return - No. 1 Cylinder	503-0274	4	Clamp, Hose
149-1584	1	Line, Nozzle Fuel Return - No. 2 Cylinder	503-0004	1	Clamp, Hose
134-1978	1	Housing, Cylinder Air - Front	503-0419	2	Elbow, Rubber - Air Cleaner
134-1977	1	Housing, Cylinder Air - Rear	140-1805	1	Tube, Air Induction
134-1976	1	Housing, Blower	402-0359	1	Hardware Package, Mounting (Includes Parts Marked *)
134-3670	1	Panel, Cylinder Air Housing - Bottom	800-0199	4	*Screw, Cap - Hex Head
134-1974	1	Panel, Air Housing Door	526-0195	4	*Washer, Flat ( $3\frac{1}{4}$ " OD)
134-1973	1	Cover, Cylinder Air Housing	402-0406	4	*Bushing, Spacer
134-1972	1	Bracket, Air Housing Door Panel	402-0282	4	*Snubber, Shock Mounting
134-1971	1	Support, Blower Housing and Grille	526-0014	4	*Washer, Flat ( $1\frac{1}{2}$ " OD)
134-1970	1	Grille, Blower Housing	850-0055	4	*Washer, Lock - Spring (7/16")
			862-0004	4	*Nut, Hex (7/16 - 14)
			526-0198	8	*Washer, Flat (5/8" ID x $1\frac{1}{2}$ " OD x 1/16" Thk) Use as Required
			220-2308	1	Stator, Wound - Exciter
			234-0532	1	Baffle, Air - Generator
			220-2667	1	Stator, Wound - Generator
			201-2309	1	Rotor Assembly, Wound - Genera
			201-2299	1	Rotor, Wound - Exciter

SPECIAL PARTS LIST FOR **MODEL** 6.0 DJE - 1E **SPEC** 24553 AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.**             
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5542-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
304-0625	1	Resistor, Tap (Adjustable) Generator Air Outlet			
301-3834	1	Panel, Mounting - Voltage Regulator			
300-1654	1	Board, Voltage Regulator			
305-0585	1	Regulator, Voltage (Without Adjustment)			
320-0235	1	Breaker, Circuit (20 amp) Mounted on Control Box Saddle			
320-0204	1	Breaker, Circuit (30 amp) Mounted on Control Panel			
357-0043	1	Rectifier, Bridge (Charge) Mounted on Control Box Saddle			
301-4389	1	Plate, Mounting - Bridge Rectifier			
321-0020	1	Fuse (60 amp)			
321-0148	1	Holder, Fuse			
302-1367	1	Ammeter Kit, Charge - Includes Mounting Hardware (15-0-15)			
302-0592	1	Meter, Running Time			
308-0028	2	Switch, Push (Start and Heater)			
308-0274	2	Boot - Push Switches			
308-0069	1	Switch, Toggle - Run/Stop			
301-4797	1	Panel, Control			
301-3098	1	Box, Control			
301-3955	1	Cover, Voltage Regulator			
301-3956	1	Saddle, Control Box			