

The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR SPEC 7899A A
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4853-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct Air Outlet			
		Low Oil Pressure Cut-Off			
		Overspeed Cut-Off			
134-1375	1	Plate, Exhaust Outlet Cover			
416-0021	2	Cables, Battery			
338-0917	1	Wiring Harness, Exciter			
		Stator to Control			
307-0655	1	Relay, Latching-Overspeed			
517-0012	1	Plug, Button			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR SPEC 7899AC
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5567-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct Air Outlet			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	1	Relay, Emergency Latch - Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-57R **SPEC** 8232AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5001-08 (AC) 612-4791-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
High Temperature Cut-Off					
Air Duct W/Shutter					
Meter Panel					
504-0007	1	Valve, Fuel Tank (Return)			
504-0013	1	Valve, Fuel Tank (Outlet)			
405-1674	1	Shield, Rain-Exhaust Pipe			
301-2373	1	Panel, Instrument			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-53CR **SPEC** 8347AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4791-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid Base			
416-0021	2	Cable, Battery			

SPECIAL PARTS LIST FOR MODEL 9.0DJC-518R SPEC 8347AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4791-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid, Base and Battery Rack			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CR **SPEC** 8347AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4791-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid Base and Battery Rack			

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-18R **SPEC** 8347AC
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-53R **SPEC** 8375AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-1559-07 (AC) 612-4791-01 (ENI

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Mounted Fuel Tank					
Meter Panel					
504-0007	1	Valve-Tank Return			
504-0013	1	Valve, Tank Outlet			
405-1674	1	Shield, Rain-Exhaust Pipe			
301-2288	1	Panel, Control Meter			

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4310-08 (AC) 612-4791-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Mounted Fuel Tank					
Meter Panel					
504-0007	1	Valve Fuel Tank (Return)			
504-0013	1	Valve Fuel Tank (Outlet)			
405-1674	1	Shield Rain-Exhaust Pipe			
301-2308	1	Panel, Instrument			

Housed
Mounted Fuel Tank
Meter Panel

504-0007	1	Valve Fuel Tank (Return)
504-0013	1	Valve Fuel Tank (Outlet)
405-1674	1	Shield Rain-Exhaust Pipe
301-2308	1	Panel, Instrument

SPECIAL PARTS LIST FOR MODEL 12.0 DJC-3R SPEC 8375AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1559-04 (ENG) 612-4791-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housing			
		Mounted Fuel Tank			
		Meter Panel			
301-2288	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-4R **SPEC** 8375AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (AC) 612-1469-04 (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Meter Panel					
301-2204	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-4XR **SPEC** 8375AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1851-04 (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Meter Panel					
301-2308	1	Panel, Control - Upper			
304-0305	1	Resistor, Control Panel			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CR **SPEC** 8489AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4791-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Duct Air Outlet Skid Base and Battery Rack					
134-1375	1	Plate, Exhaust Outlet Cover			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-18R **SPEC** 8489AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Duct Air Outlet Skid Base and Battery Rack					
134-1375	1	Plate, Exhaust Outlet Cover			

SPECIAL PARTS LIST FOR MODEL 12.0 DJC-3R SPEC 8509AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1559-04 (ENG) 612-4792-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housing			
		Air Duct With Shutter			
		Low Oil Pressure Cut Off			
		High Temperature Cut Off			
		Meter Panel			
301-2288	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CE **SPEC** 8523T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-2667-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractors Model Duct and Shutter High Temperature Cut-Off					
509-0111	1	Seal, Oil-Crankshaft Front			
509-0112	1	Seal, Oil-Crankshaft Rear			
103-0454	1	Gearcase Assembly			
338-0725	1	Wiring Harness-Switch Plate to Control			
338-0394	1	Wiring Harness-Stator Motor to Control			
503-0365	3	Clamp, Air Cleaner Hose			
503-0571	1	Hose, Air Cleaner Connector			
220-0600	1	Stator Assembly, Wound			
508-0009	1	Grommet Rubber Control Box			
308-0069	1	Switch, Run-Stop			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CE **SPEC** 8523AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4826-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractor Model					
High Temperature Cut-Off					
Duct and Shutter					
509-0111	1	Seal, Oil-Crankshaft Front			
509-0112	1	Seal, Oil-Crankshaft Rear			
103-0454	1	Gearcase Assembly			
416-0021	2	Cables, Battery			
338-0725	1	Wiring Harness-Switch Plate to Control			
338-0394	1	Wiring Harness-Starter Motor to Control			
308-0069	1	Switch, Run-Stop			
508-0008	1	Grommet, Rubber Control Box			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CE **SPEC** 8523AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5504-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Air Duct And Shutter Contractors Model High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CE **SPEC** 8523AC
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-5504-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Contractors Model Air Duct And Shutter High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-3R **SPEC** 8574AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1559-04 (ENG) 612-4853-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housing					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Temperature Cut Off					
Meter Panel					
301-2288	1	Meter Panel - Upper			
338-0917	1	Wiring Harness, Exciter			
		Stator to Control			
307-0655	1	Relay, Latching			
		(Overspeed)			
517-0012	1	Plug, Button			

Dated

Mar 1, 1978

Revised

Page

1

of

1

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-4R **SPEC** 8574AC
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5567-02 (AC) 612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Duct Air Outlet			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
338-0917	1	Harness, Wiring - Overspeed			
307-0655	1	Relay, Emergency Latch - Overspeed			
301-2204	1	Panel, Meter - Instrument			

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4310-08 (AC) 612-4792-02 (ENG)

Housed
Low Oil Pressure Cut-Off
High Temperature Cut-Off
Meter Panel

405-1674	1	Shield, Rain-Exhaust Pipe
301-2308	1	Panel, Instrument

SPECIAL PARTS LIST FOR MODEL 12.0 DJC-3R SPEC 8706AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1559-04 (ENG) 612-4792-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housing			
		Low Oil Pressure Cut Off			
		High Temperature Cut Off			
		Meter Panel			
301-2288	1	Panel, Control- Upper			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3R **SPEC** 8706AC
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-5557-01 (AC)612-1559-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Duct Air Outlet					
Meter Panel					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off (Normally Closed)					
301-2288	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-5DR **SPEC** 8777T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-2662-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractor Type Air Cleaner					
Shutter Assembly					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
122-0193	1	Filter, Oil			
503-0365	4	Clamp, Hose Air Cleaner			
503-0571	1	Hose, Air Cleaner			
416-0021	2	Cable, Battery			
220-1499	1	Stator Assembly, Wound			
201-1811	1	Rotor Assembly, Wound			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-55DR **SPEC** 8871AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-1556-12 (AC) 612-4791-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		High Temperature Cut-Off Housed Duct and Shutter Meter Panel Mounted Fuel Tank			
320-0058	3	Circuit Breaker			
301-2204	1	Panel, Instrument			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-3R **SPEC** 8915AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1559-04 (ENG) 612-4791-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Meter Panel					
Housed					
155-0360	1	Muffler, Exhaust			
155-0949	1	Tube, Flexible Exhaust			
140-0078	2	Band, Muffler Mounting			
338-0305	1	Wiring Harness, Start-Stop			
301-2288	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-4R **SPEC** 8915AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1469-04 (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Meter Panel					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0949	1	Tube, Flexible Exhaust			
338-0305	1	Wiring Harness, Start-Stop			
301-2204	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4XR SPEC 8915AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4791-02 (AC) 612-1851-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Duct Air Outlet			
		Muffler Mounted On Housing			
		Mounted Fuel Tank			
301-2308	1	Panel, Meter - Instrument			
304-0305	1	Resistor, Fixed (45,000 ohm, 10 Watt)			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-4XR **SPEC** 8941T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (AC) 612-1851-04 (ENG) 612-2661-(

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Meter Panel					
220-0769	1	Stator Assembly, Wound			
304-0305	1	Resistor, (45,000 OHM 10 W)			
301-2308	1	Panel, Control Meter			
508-0001	1	Grommet, Control Box			
508-0117	1	Grommet, Output Box			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-53R **SPEC** 8941AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** _____
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

SPEC

8941AA

967-0222

KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4791-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
405-1674	1	Shield, Rain-Exhaust Pipe			
301-2288	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-4R **SPEC** 8941AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4791-02 (AC) 612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Duct Air Outlet			
301-2204	1	Panel, Meter - Instrument			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-4XR **SPEC** 8941AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4791-02 (AC) 612-1851-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Duct Air Outlet			
301-2308	1	Panel, Meter - Instrument			
304-0305	1	Resistor, Fixed (45,000 ohm, 10 Watt)			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3R **SPEC** 8941AC
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-01 (AC) 612-1559-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Meter Panel					
Duct Air Outlet					
301-2288	1	Panel, Meter - Control (Upper)			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-4R **SPEC** 8941AC
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-02 (AC) 612-1469-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Meter Panel					
Duct Air Outlet					
301-2204	1	Panel, Meter - Instrument			

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. _____
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1859-04 (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housing			
		Mounted Fuel Tank			
		Duct and Shutter			
		Meter Panel			
301-2373	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-53R **SPEC** 9279AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (AC) 612-1559-07 (ENG) 612-4792-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Mounted Fuel Tank			
		Air Duct And Shutter			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Meter Panel			
301-2288	1	Panel, Control Meter			

SPECIAL PARTS LIST FOR **MODEL** 9.0DJC-57R **SPEC** 9279AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4792-02 (AC)612-4310-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Meter Panel			
		Mounted Fuel Tank			
		Air Duct And Shutter			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			
301-2308	1	Panel, Instrument			
320-0486	1	Breaker, Circuit - 20 AMP			

SPECIAL PARTS LIST FOR MODEL 12.0 DJC-3R SPEC 9279AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1559-04 (ENG) 612-4792-0

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housing			
		Mounted Fuel Tank			
		Air Duct And Shutter			
		Low Oil Pressure Cut Off			
		High Temperature Cut Off			
		Meter Panel			
301-2288	1	Panel, Control - Upper			

FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5504-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Contractors Model High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-53CE **SPEC** 9387AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4826-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractors Model Skid Base					
103-0454	1	Gearcase Assembly			
509-0111	1	Seal, Oil-Crankshaft-Front			
509-0112	1	Seal, Oil-Crankshaft-Rear			
416-0021	2	Cable, Battery			
338-0725	1	Wiring Harness, Switch Plate to Control			
338-0394	1	Wiring Harness, Starter Motor to Control			
308-0069	1	Switch, Run-Stop			
332-1695	2	Tab, Terminal Connector			
508-0008	1	Grommet, Rubber			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CE SPEC 9387AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4826-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Contractor Model Skid Base and Battery Rack					
509-0112	1	Seal, Oil-Crankshaft-Rear			
103-0454	1	Gearcase Assembly			
509-0111	1	Seal, Oil-Crankshaft-Front			
338-0725	1	Wiring Harness-Switch Plate to Control			
338-0394	1	Wiring Harness-Starter Motor to Control			
308-0069	1	Switch, Run-Stop			
508-0008	1	Grommet, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CE **SPEC** 9387AC
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5504-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Contractors Model Skid And Battery Rack			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-3CR **SPEC** 9391T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-3129-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
416-0021	2	Cables, Battery			
220-0808	1	Stator Assembly Wound			
320-0221	1	Limiter Assembly Cranking (Low Oil Pressure)			
307-0655	1	Relay, Latching (Overspeed)			
332-0751	1	Terminal Block			
332-1235	1	Marker Strip			
508-0001	1	Grommet, Control Box			
508-0117	1	Grommet, Output Box			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-4R **SPEC** 9413AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (AC) 612-1486-04 (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Meter Panel					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0949	1	Tube, Flexible Exhaust			
338-0305	1	Wiring Harness, Start-Stop			
301-2088	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-4XR **SPEC** 9413AC
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-02 (AC) 612-1859-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit Meter Panel Muffler Mounted On Housing Duct Air Outlet					
301-2373	1	Panel, Meter - Instrument			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-3CR **SPEC** 9582AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4791-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed					
102-0549	1	Base, Oil			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-18R **SPEC** 9582AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Mounted Fuel Tank Housed			
102-0549	1	Base, Oil			

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			
		Skid Base			

SPECIAL PARTS LIST FOR **MODEL** 9.0DJC 518R **SPEC** 9640AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4792-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			
		Skid Base and Battery Rack			

WIRING DIAGRAM NO. 612-4792-01 (ENG)

Dated Mar 1, 1978 **Revised** _____ **Page** 1 **of** 1

WIRING DIAGRAM NO. (ENG) 612-4792-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid Base and Battery Rack			
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			

SPECIAL PARTS LIST FOR **MODEL** 12.0DJC-3CR **SPEC** 9640AC
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** -
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-5557-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-18R **SPEC** 9640AC
FOR STANDARD PARTS REFER TO CATALOG 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-53R **SPEC** 9768AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-1559-07 (AC) 612-4792-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut-Off					
High Temperature Cut-Off					
Mounted Fuel Tank					
Meter Panel					
504-0007	1	Valve, Fuel Tank (Return)			
504-0013	1	Valve, Fuel Tank (Outlet)			
405-1674	1	Shield, Rain-Exhaust Pipe			
301-2288	1	Panel, Control Box- Meter			

SPECIAL PARTS LIST FOR MODEL 9.0 DJC-55DR SPEC 9768AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-1556-12 (AC) 612-4792-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Mounted Fuel Tank			
		Housed			
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			
		Meter Panel			
504-0007	1	Valve, Fuel Tank (Return)			
504-0013	1	Valve, Fuel Tank (Outlet)			
405-1674	1	Shield, Rain-Exhaust Pipe			
320-0058	3	Circuit Breaker (30A)			
301-2204	1	Panel, Instrument			

SPECIAL PARTS LIST FOR **MODEL** 9.0 DJC-57XR **SPEC** 9768AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4943-07 (AC) 612-4792-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Mounted Fuel Tank			
		Housed			
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			
		Meter Panel			
320-0483	1	Circuit Breaker (15A)			
301-2308	1	Panel, Instrument			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-4XR SPEC 9768AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO.
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (AC) 612-1851-04 (ENG) 612-4792-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Mounted Fuel Tank			
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			
		Meter Panel			
301-2308	1	Panel, Control - Upper			
304-0305	1	Resistor (45,000-Ohm, 10 Watt)			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-3CR **SPEC** 9788T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2661-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housing					
Mounted Fuel Tank					
102-0549	1	Base, Oil			
155-0360	1	Muffler, Exhaust			
140-0078	2	Bands, Muffler Mounting			
155-0949	1	Tube, Exhaust Flexible			
338-0305	1	Wiring Harness Assembly			
		Start Stop			
220-0600	1	Stator Assembly Wound			
516-0083	2	Pin, Roll Generator Frame			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-18R **SPEC** 9788AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4791-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Mounted Fuel Tank					
102-0549	1	Base, Oil			
155-0360	1	Muffler, Exhaust			
155-0949	1	Tube, Flexible Exhaust			
140-0078	2	Band, Muffler Mounting			
338-0305	1	Wiring Harness, Start - Stop			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-18R **SPEC** 9799AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4976-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Duct Air Outlet					
Low Oil Pressure Cut-Off					
High Air Temperature Cut-Off					
102-0549	1	Base, Oil			
134-1375	1	Plate, Exhaust Outlet Cover			
309-0206	1	Switch, Thermostat High Temperature			
320-0221	1	Limiter, Cranking - Low Oil Pressure			
322-0004	2	Lamp (1) Low Oil Pressure (1) High Temperature			
307-0655	1	Relay, Latching - High Temperature			

PARTS LIST FOR **MODEL** 9.0 DJC-53CR **SPEC** 9837AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** _____
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4792-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			
102-0549	1	Base, Oil			
416-0021	2	Cables, Battery			

SPECIAL PARTS LIST FOR **MODEL** 9.0EJC-518R **SPEC** 9837AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4792-02 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut-Off					
High Temperature Cut-Off					
416-0021	2	Cables, Battery			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-18R **SPEC** 9837AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** _____
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4792-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut-Off					
High Air Temperature Cut-Off					
102-0549	1	Base, Oil			
416-0021	2	Cable, Battery			

FOR STANDARD PARTS REFER TO CATALOG 967-0222 KEY NO. -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Oil Base Heater			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR **MODEL** 12-0 DJC-3CR **SPEC** 9861AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4853-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Duct Air Inlet					
Low Oil Pressure Cut Off					
High Temperature Cut Off					
416-0021	2	Cables, Battery			
102-0549	1	Base, Oil			
134-1375	1	Plate, Exhaust Outlet Cover			
338-0917	1	Wiring Harness Exciter			
		Stator to Control			
307-0655	1	Relay, Latching (Overspeed)			
517-0012	1	Plug, Button Control Box			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-18R **SPEC** 9861AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4853-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct, Air Outlet			
		Low Oil Pressure Cut-Off			
		High Air Temperature Cut-Off			
		Overspeed Cut-Off			
102-0549	1	Base, Oil			
416-0021	2	Cable, Battery			
134-1375	1	Plate, Exhaust Outlet Cover			
338-0768	1	Wiring Harness, Overspeed			
338-0917	1	Wiring Harness, Exciter			
		Stator to Control			
307-0655	1	Relay, Latching Overspeed			
517-0012	1	Plug, Button - Control Box			

PARTS LIST FOR **MODEL** 12.0DJC-3CR **SPEC** 9865AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** _____
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4792-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid Base and Battery Rack			
		Duct Air Outlet			
		Low Oil Pressure Cut-Off			
134-1375	1	Plate, Exhaust Outlet Cover			

PARTS LIST FOR **MODEL** 12.0 DJC-3CR **SPEC** 9918AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.** _____
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____ **(ENG) 612-4791-01**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
102-0549	1	Base, Oil			

SPECIAL PARTS LIST FOR MODEL 12.0DJC-3CR **SPEC** 9923AA
FOR STANDARD PARTS REFER TO CATALOG 967-0222 **KEY NO.** -
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4792-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Oil Base Heater			
		Duct Air Outlet			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off (Normally Closed)			

SPECIAL PARTS LIST FOR **MODEL** 12.0 DJC-18R **SPEC** 9923AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0222 **KEY NO.**
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Duct, Air Outlet			
		Low Oil Pressure Cut-Off			
		High Temperature Cut-Off			
102-0549	1	Base, Oil			
416-0021	2	Cable, Battery			
134-1375	1	Plate, Exhaust Outlet Cover			