

The following catalog  
has gaps in its page  
numbers, or doesn't  
have any numbers.  
We have chosen to  
leave the page  
numbering in the  
order that Acrobat  
assigns it.

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 7328AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5567-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
134-1804	1	Duct, Air			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 7328AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5567-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
134-1804	1	Duct, Air			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 8000AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-1CR **SPEC** 8347AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 8375AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5556-05 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed AC Meter Panel					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			





SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 8489AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 8489AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - ½" X 3"			
505-0100	1	Nipple, Oil Drain - ½" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 8489AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
134-1804	1	Duct, Air			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53R SPEC 8509AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-09(AC) 612-1559-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
AC Meter Panel					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0018	2	Breaker, Circuit - 20 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJF-3CE **SPEC** 8523AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 267-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5504-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter High Air Temperature Cut Off Note: Contractor Model					

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3R **SPEC** 8574AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4853-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter			
		To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
		To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter			
		To Block			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting			
		(Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable			
		(Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage			
		Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed			
		(Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 8706AB

FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			





SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-518R **SPEC** 8727AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed Air Duct And Shutter High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-4XR **SPEC** 8915AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4791-06 (AC) 612-1851-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed AC Meter Panel					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0484	1	Breaker, Circuit - 12 Amp			
304-0305	1	Resistor, Fixed - 45,000 Ohm, 10 Watt			
301-2308	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-4XR **SPEC** 8915AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5556-06 (AC) 612-1851-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed AC Meter Panel					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain ( $\frac{1}{2}$ " Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0484	1	Breaker, Circuit - 12 Amp			
304-0305	1	Resistor, Fixed - 45,000 Ohm, 10 Watt			
301-2308	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 9102AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
WIRING DIAGRAM NO. (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
134-1804	1	Duct, Air			

**WIRING DIAGRAM NO.** (ENG)612-5557-09(AC)612-1559-06

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-57R **SPEC** 9279AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5557-10(AC)612-4310-06



**WIRING DIAGRAM NO.** \_\_\_\_\_ **(ENG)612-5504-01**

High Air Temperature Cut Off  
Note: Contractor Model



WIRING DIAGRAM NO. (ENG) 612-5504-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack Note: Contractor Model					
416-0522	1	Plate, Battery Mounting			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-4R **SPEC** 9413AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5556-06(AC)612-1486-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed AC Meter Panel					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain ( $\frac{1}{2}$ " Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
301-2088	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-4R **SPEC** 9413AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5556-06 (AC) 612-1486-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed AC Meter Panel					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (½" Close)			

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-518R **SPEC** 9640AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 9640AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 9693AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53R **SPEC** 9768AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4792-09 (AC) 612-1559-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed Low Oil Pressure Cut Off High Air Temperature Cut Off AC Meter Panel					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0018	2	Breaker, Circuit - 20 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53R **SPEC** 9768AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5557-09(AC)612-1559-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Fuel Tank			
		Housed			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		AC Meter Panel			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 9788AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed					
102-0620	1	Base, Oil			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 9923AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 9996AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
102-0620	1	Base, Oil			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 9996AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 9996AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 10176AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
102-0620	1	Base, Oil			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain ( $\frac{1}{2}$ " Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 10245AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Skid And Battery Rack					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 10245AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Skid And Battery Rack					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank					
Housed					
Low Oil Pressure Cut Off					
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 10616AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Housed			
		AC Meter Panel			
		Air Duct And Shutter			
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 10662AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
102-0620	1	Base, Oil			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 10662AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 10662AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 10690AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-09(AC)612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Fuel Tank			
		Housed			
		AC Meter Panel			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 10928AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5567-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 11039AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Hose)			
140-0500	1	Cleaner, Air - Oil Bath			
140-0519	1	Band, Mounting - Oil Bath Air Cleaner			
503-0274	2	Clamp, Hose - Oil Bath Air Cleaner			
503-0444	1	Hose, Oil Bath Air Cleaner			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 12053AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 12053AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 12053AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
102-0620	1	Base, Oil			
134-1804	1	Duct, Air			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 12640AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Air Duct And Shutter					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 13011AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5572-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
320-0221	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1129	1	Relay Assembly, High Air Temperature (Includes Leads)			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-4R SPEC 14017AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5572-10(AC)612-1469-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Housed			
		AC Meter Panel			
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
320-0221	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1129	1	Relay Assembly, High Air Temperature (Includes Leads)			
301-2376	1	Panel, Control			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-4R SPEC 14019AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5575-10(AC)612-1469-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
Fuel Tank					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Switch					
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18E **SPEC** 14513AB  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-4855-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

Note: Contractor Model

301-2467	1	Box, Output
301-2466	1	Cover, Output Box

Parts Not Furnished By Onan  
Inner Components Of Output Box

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53CE **SPEC** 14513AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5586-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
<p>Note: Contractor Model</p> <p>301-2467    1    Box, Output</p> <p>301-2466    1    Cover, Output Box</p> <p>Parts Not Furnished By Onan</p> <p>Inner Components Of Output Box</p>					







SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 14527AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 14527AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			



SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53CR **SPEC** 14603AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5575-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Switch					
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 14603AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5575-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Switch					
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 14627AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4853-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack Overspeed Switch Low Oil Pressure Cut Off High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
134-1804	1	Duct, Air			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 14876AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5575-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0059	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 14876AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5575-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 14928AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
102-0620	1	Base, Oil			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 15024AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 15024AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DIE-18R **SPEC** 15024AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
134-1804	1	Duct, Air			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 15033AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4998-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 15400AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 15400AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 15400AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
220-2040	1	Stator, Wound			
201-2155	1	Rotor Assembly, Wound			
520-0795	4	Stud, Generator Through			
520-0787	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 15656AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
509-0112	1	Seal, Crankshaft Rear			
509-0111	1	Seal, Oil - Gearcase			
103-0454	1	Gearcase Assembly - Complete			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			





SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 15706AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4998-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 15706AB  
**FOR STANDARD PARTS REFER TO CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-4998-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 15757AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4998-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
309-0206	1	Switch, High Air Temperature			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 15757AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5574-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 15949AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4998-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
309-0206	1	Switch, High Air Temperature			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 15949AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5574-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 15949AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5574-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 15949AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5574-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
309-0206	1	Switch, High Air Temperature			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3R SPEC 16206AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-09 (AC) 612-1559-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed Air Duct And Shutter AC Meter Panel Low Oil Pressure Cut Off High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
102-0620	1	Base, Oil			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (½" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-2288	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR50 SPEC 16446AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5575-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Skid And Battery Rack			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
505-0002	1	Nipple, Oil Drain - 1/2" X 3"			
505-0100	1	Nipple, Oil Drain - 1/2" X Close			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR50 **SPEC** 16446AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5575-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Includes All Leads And Parts Marked *)			
307-0655	2	*Relay, High Air Temperature And Overspeed			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold-Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Blank			
301-3567	1	Panel, Control Box			