

The following catalog  
has gaps in its page  
numbers, or doesn't  
have any numbers.  
We have chosen to  
leave the page  
numbering in the  
order that Acrobat  
assigns it.

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53CR **SPEC** 1AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-4791-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
150-1688	1	Arm, Governor			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-518R SPEC 1AB  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 1AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4791-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 1AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R50 **SPEC** LAB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 1AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
150-1688	1	Arm, Governor			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-518R SPEC 1AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 1AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR50 SPEC 1AD  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 1AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-518R **SPEC** 1AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Standard Model			

SPECIAL PARTS LIST FOR **MODEL** 6.0EJE-3CR **SPEC** 1AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Standard Model			



FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO. \_\_\_\_\_ (ENG) 612-5556-06**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Standard Model			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R50 **SPEC** 1AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Standard Model					

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 7AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-4791-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 7AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 7AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 7AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
WIRING DIAGRAM NO. (ENG)612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 96AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
150-1688	1	Arm, Governor			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 96AB  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53CR **SPEC** 96AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
150-1688	1	Arm, Governor			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 96AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 96AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53CR **SPEC** 96AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 96AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 96AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 1041AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4791-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 1041AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			





SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 1634AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5567-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off Overspeed Switch			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-518R SPEC 2198AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 2198AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter			
		To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
		To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter			
		To Block			
304-0500	1	Resistor, Tapped - Adjustable			
		(Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 2198AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 2198AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			



FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 2219AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53CR **SPEC** 2219AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
134-1804	1	Duct, Air			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 2219AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 4.5DJF-53CR **SPEC** 2219AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
134-1804	1	Duct, Air			

**WIRING DIAGRAM NO.** \_\_\_\_\_ **(ENG)612-5557-09**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
134-1804	1	Duct, Air			

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
134-1804	1	Duct, Air			





PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Standard Contractor Model			

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Standard Contractor Model			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 2468AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 2468AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 2468AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
134-1804	1	Duct, Air			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 2701AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 2701AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter			
		To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
		To Oil Line			
141-0231	1	Gasket, Air Cleaner Adapter			
		To Block			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable			
		(Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 2701AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
150-1688	1	Arm, Governor			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 2701AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-C032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 2823AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 2823AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-53R **SPEC** 3631AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4792-09 (AC) 612-1786-07

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank					
Housed					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
AC Meter Panel					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0018	2	Breaker, Circuit - 20 Amp			
301-1554	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



SPECIAL PARTS LIST FOR MODEL 4.5DJE-518R SPEC 4037AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Hose)			
140-0500	1	Cleaner, Air - Oil Bath			
140-0519	1	Band, Mounting - Oil Bath Air Cleaner			
503-0274	2	Clamp, Hose - Oil Bath Air Cleaner			
503-0444	1	Hose, Oil Bath Air Cleaner			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 4540AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber-2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mounting			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 4540AE  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5557-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber-2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mtg.			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 4965AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Hose)			
140-0500	1	Cleaner, Air - Oil Bath			
140-0519	1	Band, Mounting - Oil Bath Air Cleaner			
503-0274	2	Clamp, Hose - Oil Bath Air Cleaner			
503-0444	1	Hose, Oil Bath Air Cleaner			
405-1651	1	Panel, Upper - Engine End			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 5114AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Fuel Tank					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 4.5DJE-53CR SPEC 5322AE  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber-2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mounting			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 5381AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-4792-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter			
		To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
		To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter			
		To Block			
140-0645	1	Adapter, Air Cleaner (To			
		Air Cleaner Hose)			
304-0500	1	Resistor, Tapped - Adjustable			
		(Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			
Parts Not Furnished By Onan					
Air Cleaner And Associated Parts					





SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 5663AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-5567-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
502-0099	1	Elbow, Fuel Filter Adapter To fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
150-1688	1	Arm, Governor			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

**WIRING DIAGRAM NO.** \_\_\_\_\_ **(ENG) 612-5567-09**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Switch			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3R **SPEC** 5776AD  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-5557-09 (AC) 612-1786-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
AC Meter Panel					
Housed					
Low Oil Pressure Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter			
		To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket			
		To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter			
		To Block			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting			
		(Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
320-0058	2	Breaker, Circuit - 30 Amp			
301-1554	1	Panel, Meter			
304-0500	1	Resistor, Tapped - Adjustable			
		(Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm,			
		10 Watt			

FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO. (ENG)612-5557-09(AC)612-1786-01**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		AC Meter Panel			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 6127AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4976-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
322-0004	2	Lamp, Indicator			
322-0069	2	Holder, Indicator Lamp			
320-0221	1	Relay, Low Oil Pressure (Includes Micro Switch)			
309-0042	1	Switch, Micro (Part Of Low Oil Pressure Relay)			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
301-2376	1	Panel, Control Box			
309-0206	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 6153AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 6153AD  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
High Air Temperature Cut Off					
Low Oil Pressure Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			





SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 6201AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4853-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 6241AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4853-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct And Shutter					
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 6485AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4791-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain (1/2" Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-18R SPEC 6485AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed					
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
141-0281	1	Gasket, Air Cleaner Adapter To Block			
159-0802	1	Tank, Fuel (9 Gallon)			
504-0007	1	Valve, Shut-Off (Return)			
501-0004	1	Line, Fuel - 12" (Tank To Fuel Pump)			
501-0131	1	Line, Fuel - 24" (Return)			
504-0013	1	Valve, Shut-Off (Fuel Tank Outlet) (Screened)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
234-0223	1	Cover, End Bell			
505-0100	2	Nipple, Oil Drain ( $\frac{1}{2}$ " Close)			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-18R **SPEC** 6485AE  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG)612-5556-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank Housed					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (½" Close)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 6598AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
WIRING DIAGRAM NO. (ENG) 612-5556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			



SPECIAL PARTS LIST FOR **MODEL** 6.0DJE-3CR **SPEC** 6893AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-4792-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
234-0223	1	Cover, End Bell			
402-0327	1	Hardware Package, Mounting (Set Of 4 - Less Cushions)			
405-1673	1	Shield, Rain - Top Panel			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			



FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO. \_\_\_\_\_ (ENG) 612-5557-10**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Air Duct And Shutter			
		Housed			

SPECIAL PARTS LIST FOR **MODEL** 4.5DJE-518R **SPEC** 7105AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG)612-4791-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0020	1	Elbow, Oil Pressure Gauge			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
140-0645	1	Adapter, Air Cleaner (To Air Cleaner Tube)			
503-0330	1	Hose, Connector (Rubber - 2") Air Cleaner			
503-0274	4	Clamp, Hose (Air Cleaner)			
140-0741	1	Tube, Air Induction			
503-0419	1	Elbow, Air Cleaner (Rubber)			
140-0721	1	Cleaner, Air (Includes Element And Baffle)			
140-0722	2	Band, Air Cleaner Mounting			
140-1271	1	Bracket, Air Cleaner Mtg.			
140-0723	1	Pre-Cleaner, Air Cleaner			
140-0765	1	Element, Air Cleaner			
140-1267	1	Baffle, Air Cleaner			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
321-0146	1	Fuse - 10 Amp			
321-0175	1	Holder, Fuse			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 7117AE  
FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5557-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Fuel Tank					
Housed					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
155-0360	1	Muffler, Exhaust			
140-0078	2	Band, Muffler Mounting			
155-0951	1	Tube, Exhaust			
505-0100	2	Nipple, Oil Drain (1/2" Close)			

SPECIAL PARTS LIST FOR MODEL 6.0DJE-3CR SPEC 7328AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. -  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4853-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Switch					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
141-0281	1	Gasket, Air Cleaner Adapter To Block			
150-1688	1	Arm, Governor			
502-0099	1	Elbow, Fuel Filter Adapter To Fuel Line			
502-0003	1	Connector, Oil Fill Bracket To Oil Line			
134-1804	1	Duct, Air			
304-0500	1	Resistor, Tapped - Adjustable (Generator Air Outlet)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator			
322-0069	1	Holder, Indicator Lamp			
321-0146	1	Fuse, 10 Amp			
321-0175	1	Holder, Fuse			
307-1129	1	Relay Assembly, Overspeed (Includes Leads)			
304-0032	1	Resistor, Fixed - 15 Ohm, 10 Watt			