


The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.



Parts Catalog

GCAA
GCAB
GCAC

Generator Set



PARTS BOOK


TABLE OF CONTENTS

ASSEMBLY NAME	MODEL NUMBER	PAGE NUMBER
SKID BASE	GCAA	1
SKID BASE	GCAB, GCAC	2
ALTERNATOR	GCAA-24, GCAA-48	3
ALTERNATOR	GCAB-24, GCAB-48	4
ALTERNATOR	GCAC-24, GCAC-48	5
BAFFLE	GCAA	6
BAFFLE	GCAB	7
BAFFLE	GCAC	8
ENCLOSURE	GCAA	9
ENCLOSURE	GCAB	10
ENCLOSURE	GCAC	11
FUEL SYSTEM	GCAA	12
FUEL SYSTEM	GCAB	13
FUEL SYSTEM	GCAC	14
CONTROL BOX	GCAA-24	15,16,17, 18
CONTROL BOX	GCAA-48	19,20,21,22
CONTROL BOX	GCAB-24	23,24,25,26
CONTROL BOX	GCAB-48	27,28,29,30
CONTROL BOX	GCAC-24	31,32,33,34
CONTROL BOX	GCAC-48	35,36,37,38
ENGINE	GCAA	39
ENGINE	GCAB	40
ENGINE	GCAC	41
WIRING DETAIL	GCAA - 24, NEG GROUND	42
WIRING DETAIL	GCAA - 24, POS GROUND	43
WIRING DETAIL	GCAA - 48 , NEG GROUND	44
WIRING DETAIL	GCAA - 48, POS GROUND	45
WIRING DETAIL	GCAB - 24, NEG GROUND	46
WIRING DETAIL	GCAB - 24, POS GROUND	47
WIRING DETAIL	GCAB - 48, NEG GROUND	48
WIRING DETAIL	GCAB - 48, POS GROUND	49
WIRING DETAIL	GCAC - 24, NEG GROUND	50
WIRING DETAIL	GCAC - 24, POS GROUND	51
WIRING DETAIL	GCAC - 48, NEG GROUND	52
WIRING DETAIL	GCAC - 48, POS GROUND	53
PARTS INDEX, BY DESCRIPTION		54 - 59
PARTS INDEX, BY PART NUMBER		59 - 63

June 10, 1997


PARTS BOOK

SKID BASE		MODEL #	GCAA
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5015	SKID, WELDMENT	1
2	0187-5011	MOUNT, ENGINE	4




PARTS BOOK

SKID BASE		MODEL #	GCAB, GCAC
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5015	SKID, WELDMENT	1
2	0187-5093	MOUNT, ENGINE	4



PARTS BOOK


ALTERNATOR		MODEL #	GCAA-24, GCAA-48
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5144	ALTERNATOR INSTALLATION KIT	1
2	0187-5143	COVER ASSEMBLY, ALTERNATOR	1
3	0187-5229	FAN, COOLING, PLASTIC	1
4	0187-5228	BUSHING, SPLIT TAPER	1
5	0187-5230	KEY	1
6	0187-5231	ROTOR ASSEMBLY	1
7	0187-5232	STATOR HOUSING ASSEMBLY	1



PARTS BOOK

4


ALTERNATOR		MODEL #	GCAB-24, GCAB-48
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5145	ALTERNATOR INSTALLATION KIT	1
2	0187-5143	COVER ASSEMBLY, ALTERNATOR	1
3	0187-5229	FAN, COOLING, PLASTIC	1
4	0187-5228	BUSHING, SPLIT TAPER	1
5	0187-5230	KEY	1
6	0187-5226	ROTOR ASSEMBLY	1
7	0187-5227	STATOR HOUSING ASSEMBLY	1



PARTS BOOK

5


ALTERNATOR		MODEL #	GCAC-24, GCAC-48
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5146	ALTERNATOR INSTALLATION KIT	1
2	0187-5143	COVER ASSEMBLY, ALTERNATOR	1
3	0187-5229	FAN, COOLING, PLASTIC	1
4	0187-5228	BUSHING, SPLIT TAPER	1
5	0187-5230	KEY	1
6	0187-5233	ROTOR ASSEMBLY	1
7	0187-5234	STATOR HOUSING ASSEMBLY	1



PARTS BOOK

6


BAFFLE		MODEL #	GCAA
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5103	FOAM, HOT/COLD BAFFLE FRON	1
2	0187-5001	GROMMET, RUBBER, 1" ID	1
3	0187-5002	GROMMET, SPLIT, .625" ID	1
4	0187-5078	PLATE, COVER	1
5	0187-5081	SPACER, AIR CLEANER	1
6	0187-5107	HOSE, AIR INTAKE, FLEXUST 1.25" ID	3.5"
7	0187-5131	HOSE, NEOPRENE	7.25"
8	0187-5070	SUPPORT, BAFFLE	1
9	0187-5077	SUPPORT, RIGHT SIDE	1
10	0187-5251	DECAL, WARNING, DO NOT TOUCH	2
11	0187-5255	CAPLUG #21	1



PARTS BOOK

7

BAFFLE		MODEL #	GCAB
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5179	FOAM, HOT/COLD BAFFLE FRON	1
2	0187-5001	GROMMET, RUBBER, 1" ID	1
3	0187-5002	GROMMET, SPLIT, .625" ID	1
4	0187-5078	PLATE, COVER	1
5	0187-5070	SUPPORT, BAFFLE	2
6	0187-5251	DECAL, WARNING, DO NOT TOUCH	2
7	0187-5255	CAPLUG #21	1




WARNING
DO NOT TOUCH
ENGINE COMPONENTS
HOT AFTER RUNNING

PARTS BOOK

8


BAFFLE		MODEL #	GCAC
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5180	FOAM, HOT/COLD BAFFLE FRON	1
2	0187-5001	GROMMET, RUBBER, 1" ID	1
3	0187-5002	GROMMET, SPLIT, .625" ID	1
4	0187-5078	PLATE, COVER	1
5	0187-5070	SUPPORT, BAFFLE	2
6	0187-5251	DECAL, WARNING, DO NOT TOUCH	2
7	0187-5255	CAPLUG #21	1



PARTS BOOK

9


ENCLOSURE		MODEL #	GCAA
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5018	ENCLOSURE ASSEMBLY, LESS DOOR	1
2	0187-5016	DOOR ASSEMBLY	1
3	0187-5071	ACTUATOR SWITCH BRACKET	1
4	0187-5086	LATCH, BELLCORE 216	2
5	0187-5102	BUMPER	2
6	0187-5097	FOAM, HOUSING BAFFLE TOP	2
7	0187-5101	FOAM, HOUSING BAFFLE, RIGHT SIDE	2
8	0187-5100	FOAM, HOUSING BAFFLE, LEFT SIDE	2
9	0187-5098	FOAM, ENCLOSURE, RIGHT SIDE, UPPER	1
10	0187-5099	FOAM, ENCLOSURE, TOP	1
11	0187-5020	SEAL, WHITE, DOOR	21.65 FT
12	0187-5132	DECAL, RISK OF SHOCK	1
13	0187-5129	DECAL, HOT SURFACE	2
14	0187-5130	DECAL, STARTS AUTOMATICALLY	1



PARTS BOOK

10


ENCLOSURE		MODEL #	GCAB
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5140	ENCLOSURE ASSEMBLY, LESS DOOR	1
2	0187-5016	DOOR ASSEMBLY	1
3	0187-5071	ACTUATOR SWITCH BRACKET	1
4	0187-5086	LATCH, BELLCORE 216	2
5	0187-5102	BUMPER	2
6	0187-5097	FOAM, HOUSING BAFFLE TOP	2
7	0187-5101	FOAM, HOUSING BAFFLE,RIGHT SIDE	2
8	0187-5100	FOAM, HOUSING BAFFLE, LEFT SIDE	2
9	0187-5098	FOAM, ENCLOSURE, RIGHT SIDE, UPPER	1
10	0187-5099	FOAM, ENCLOSURE, TOP	1
11	0187-5020	SEAL, WHITE, DOOR	21.65 FT
12	0187-5132	DECAL, RISK OF SHOCK	1
13	0187-5129	DECAL, HOT SURFACE	2
14	0187-5130	DECAL, STARTS AUTOMATICALLY	1



PARTS BOOK

11


ENCLOSURE		MODEL #	GCAC
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5148	ENCLOSURE ASSEMBLY, LESS	1
2	0187-5016	DOOR ASSEMBLY	1
3	0187-5071	ACTUATOR SWITCH BRACKET	1
4	0187-5086	LATCH, BELLCORE 216	2
5	0187-5102	BUMPER	2
6	0187-5183	FOAM, ENCLOSURE	1
7	0187-5184	FOAM, ENCLOSURE	1
8	0187-5254	FOAM, ENCLOSURE, UPPER, LS	1
9	0187-5186	FOAM, ENCLOSURE	1
10	0187-5187	FOAM, FRONT PANEL	2
11	0187-5188	FOAM, ENCLOSURE, UPPER, RIGHT SIDE	1
12	0187-5160	FAN ASSEMBLY	1
13	0187-5020	SEAL, WHITE, DOOR	21.65 FT
14	0187-5132	DECAL, RISK OF SHOCK	1
15	0187-5129	DECAL, HOT SURFACE	2
16	0187-5130	DECAL, STARTS AUTOMATICALLY	1



PARTS BOOK

12


FUEL SYSTEM			MODEL #	GCAA
REFERENCE #	PART #	DESCRIPTION	QTY USED	
1	0187-5028	SOLENOID ASSEMBLY	1	
2	0187-5024	ASSEMBLY, REGULATOR	1	
3	0187-5073	COVER, HOLE, FUEL SYSTEM	1	
4	0187-5128	CLAMP, MUFFLER, 1.25"	1	
5	0187-5031	HOSE, BULK	24"	
6	0187-5030	FITTING, HOSE BARB, 90° ELBOW	1	
7	0187-5032	CLAMP, HOSE	2	
8	0187-5027	NIPPLE, BLACK STEEL, 3/4 X 4 1/2	1	
9	0187-5026	ELBOW, 90°, BLACK IRON, 3/4"	2	
10	0187-5025	NIPPLE, BLACK STEEL, 3/4 X 1 1/4	1	
11	0187-5029	NIPPLE, BLACK STEEL, 3/4 X 3	1	
12	0187-5079	BATTERY HOLDDOWN BRACKET	1	
13	0187-5085	ROD, BATTERY HOLDDOWN	2	



PARTS BOOK

13


FUEL SYSTEM		MODEL #	GCAB
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5028	SOLENOID ASSEMBLY	1
2	0187-5206	REGULATOR LOW PRESSURE	1
3	0187-5073	COVER, HOLE, FUEL SYSTEM	1
4	0187-5170	LOAD BLOCK	1
5	0187-5198	HOSE	24"
6	0187-5200	BUSHING, 1/4 - 3/8	1
7	0187-5199	CLAMP, HOSE	4
8	0187-5027	NIPPLE, BLACK STEEL, 3/4 X 4 1/2	1
9	0187-5235	ELBOW, 90° STREET, BLACK IRON, 3/4"	2
10	0187-5201	NIPPLE, BLACK STEEL, 3/4 X 4	1
11	0187-5079	BATTERY HOLDDOWN BRACKET	1
12	0187-5085	ROD, BATTERY HOLDDOWN	2
13	0187-5253	ELBOW, 90°, WELDMENT	1
14	0187-5252	ELBOW, 90°, STREET WELDMENT (DUAL FUEL ONLY)	1



PARTS BOOK

14



FUEL SYSTEM		MODEL #	GCAC
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5028	SOLENOID ASSEMBLY	1
2	0187-5206	REGULATOR LOW PRESSURE	1
3	0187-5073	COVER, HOLE, FUEL SYSTEM	1
4	0187-5170	LOAD BLOCK	1
5	0187-5198	HOSE	24"
6	0187-5200	BUSHING, 1/4 - 3/8	1
7	0187-5199	CLAMP, HOSE	4
8	0187-5027	NIPPLE, BLACK STEEL, 3/4 X 4 1/2	1
9	0187-5235	ELBOW, 90° STREET, BLACK IRON, 3/4"	2
10	0187-5201	NIPPLE, BLACK STEEL, 3/4 X 4	1
11	0187-5165	BATTERY HOLDDOWN BRACKET	1
12	0187-5174	ROD, BATTERY HOLDDOWN	2
13	0187-5253	ELBOW, 90°, WELDMENT	1
14	0157-5254	ELBOW, 90°, STREET WELDMENT (DUAL FUEL ONLY)	1







PARTS BOOK

15

CONTROL BOX		MODEL #	GCAA-24
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5002	GROMMET, SPLIT .625" ID	1
2	0187-5004	METER, HOUR	1
3	0187-5010	SWITCH, INTERLOCK	1
4	0187-5127	SWITCH, MASTER, 3POS, 4POLE	1
5	0187-5012	FUSE, GLASS, FAST ACTING, 10 AMP	1
6	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP	1
7	0187-5019	BAFFLE ASSEMBLY, HOT/COLD REAR	1
8	0187-5033	WIRING HARNESS ASSEMBLY, 3KW, DC	1
9	0187-5038	STRAP, GROUND, 4"	1
10	0187-5040	CABLE ASSEMBLY, 27"	1
11	0187-5041	CABLE ASSEMBLY, 21"	2
12	0187-5157	CABLE ASSEMBLY, 20.52"	3
13	0187-5042	FUSE HOLDER, BLACK WIRE	1
14	0187-5043	FUSE HOLDER, RED WIRE	1
15	0187-5068	SUPPORT, HEATSINK	1
16	0187-5069	BRACKET, CHARGER MOUNTING	1
17	0187-5074	DOOR, CONTROL BOX	1
18	0187-5075	ANGLE, DOOR	1
19	0187-5076	BRACKET, MOUNTING, HEATSINK	1
20	0187-5078	PLATE, COVER	1
21	0187-5080	GUARD, SWITCH	1
22	0187-5082	THERMOSTAT, OIL TEMPERTURE	1
23	0187-5175	FOAM, ALT BAFFLE TOP	1
24	0187-5104	FOAM, HOT/COLD BAFFLE, REAR	1
25	0187-5105	FOAM, ALTERNATOR BAFFLE, RIGHT SIDE	1
26	0187-5106	FOAM, ALTERNATOR BAFFLE	1
27	0187-5108	TELECOM CONTROL BOARD	1
28	0187-5125	CIRCUIT BREAKER, 150 AMP	1
29	0187-5126	CHARGER, BATTERY 12VDC	1
30	0187-5003	CONTACTOR, 12VDC, 80 AMP	1
31	0187-5005	CONTACTOR, 12 VDC, 200 AMP	1
32	0187-5133	TERMINAL BLOCK	1
33	0187-5134	TERMINAL BLOCK	1
34	0187-5135	TERMINAL BLOCK	1
35	0187-5136	TERMINAL BLOCK	1
36	0187-5000	TRANSFORMER/RESISTOR ASSEMBLY	1
37	0187-5006	LATCH SERVICE KIT	2
38	0187-5090	LATCH SERVICE KIT	2
39	0187-5094	HINGE SERVICE KIT	1
40	0187-5110	PROCESSOR, 3KW, 24V	1
41	0187-5116	RECTIFIER ASSEMBLY, 3KW, 24V	1
42	0187-5256	TERMINAL BOARD, 2 STUD 3/8-24	1
43	0187-5260	GUARD, SWITCH	1
44	0187-5258	DIODE ASSEMBLY	1













PARTS BOOK

19

CONTROL BOX		MODEL #	GCAA-48
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5002	GROMMET, SPLIT .625" ID	1
2	0187-5004	METER, HOUR	1
3	0187-5010	SWITCH, INTERLOCK	1
4	0187-5127	SWITCH, MASTER, 3POS, 4POLE	1
5	0187-5012	FUSE, GLASS, FAST ACTING, 10 AMP	1
6	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP	1
7	0187-5019	BAFFLE ASSEMBLY, HOT/COLD REAR	1
8	0187-5033	WIRING HARNESS ASSEMBLY, 3KW, DC	1
9	0187-5038	STRAP, GROUND, 4"	1
10	0187-5040	CABLE ASSEMBLY, 27"	1
11	0187-5041	CABLE ASSEMBLY, 21"	2
12	0187-5072	PLATE ADAPTOR	1
13	0187-5042	FUSE HOLDER, BLACK WIRE	1
14	0187-5043	FUSE HOLDER, RED WIRE	1
15	0187-5068	SUPPORT, HEATSINK	1
16	0187-5069	BRACKET, CHARGER MOUNTING	1
17	0187-5074	DOOR, CONTROL BOX	1
18	0187-5075	ANGLE, DOOR	1
19	0187-5076	BRACKET, MOUNTING, HEATSINK	1
20	0187-5078	PLATE, COVER	1
21	0187-5080	GUARD, SWITCH	1
22	0187-5082	THERMOSTAT, OIL TEMPERTURE	1
23	0187-5175	FOAM, ALT BAFFLE TOP	1
24	0187-5104	FOAM, HOT/COLD BAFFLE, REAR	1
25	0187-5105	FOAM, ALTERNATOR BAFFLE, RIGHT SIDE	1
26	0187-5106	FOAM, ALTERNATOR BAFFLE	1
27	0187-5109	TELECOM CONTROL BOARD	1
28	0187-5123	CIRCUIT BREAKER, 70 AMP	1
29	0187-5126	CHARGER, BATTERY 12VDC	1
30, 31	0187-5003	CONTACTOR, 12VDC, 80 AMP	2
32	0187-5133	TERMINAL BLOCK	1
33	0187-5134	TERMINAL BLOCK	1
34	0187-5134	TERMINAL BLOCK	1
35	0187-5136	TERMINAL BLOCK	1
36	0187-5000	TRANSFORMER/RESISTOR ASSEMBLY	1
37	0187-5006	LATCH SERVICE KIT	2
38	0187-5090	LATCH SERVICE KIT	2
39	0187-5094	HINGE SERVICE KIT	1
40	0187-5111	PROCESSOR, 3KW, 48V	1
41	0187-5117	RECTIFIER ASSEMBLY, 3KW, 48V	1
42	0187-5256	TERMINAL BOARD, 2 STUD 3/8-24	1
43	0187-5260	GUARD, SWITCH	1
44	0187-5258	DIODE ASSEMBLY	1













PARTS BOOK

23

CONTROL BOX		MODEL #	GCAB-24
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5002	GROMMET, SPLIT .625" ID	1
2	0187-5004	METER, HOUR	1
3	0187-5010	SWITCH, INTERLOCK	1
4	0187-5127	SWITCH, MASTER, 3POS, 4POLE	1
5	0187-5012	FUSE, GLASS, FAST ACTING, 10 AMP	1
6	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP	1
7	0187-5139	BAFFLE ASSEMBLY, HOT/COLD REAR	1
8	0187-5151	WIRING HARNESS ASSEMBLY, 4.5KW, DC	1
9	0187-5038	STRAP, GROUND, 4"	1
10	0187-5040	CABLE ASSEMBLY, 27"	1
11	0187-5041	CABLE ASSEMBLY, 21"	2
12	0187-5157	CABLE ASSEMBLY, 20.52"	3
13	0187-5042	FUSE HOLDER, BLACK WIRE	1
14	0187-5043	FUSE HOLDER, RED WIRE	1
15	0187-5068	SUPPORT, HEATSINK	1
16	0187-5069	BRACKET, CHARGER MOUNTING	1
17	0187-5074	DOOR, CONTROL BOX	1
18	0187-5075	ANGLE, DOOR	1
19	0187-5161	BRACKET, HEATSINK	1
20	0187-5078	PLATE, COVER	1
21	0187-5080	GUARD, SWITCH	1
22	0187-5082	THERMOSTAT, OIL TEMPERATURE	1
23	0187-5176	FOAM, ALTERNATOR BAFFLE RIGHT SIDE	1
24	0187-5177	FOAM, HOUSING BAFFLE, TOP	1
25	0187-5106	FOAM, ALTERNATOR BAFFLE	1
26	0187-5195	FUSE, ATO, 20 AMP, 32V	1
27	0187-5108	TELECOM CONTROL BOARD	1
28	0187-5192	CIRCUIT BREAKER, 200 AMP	1
29	0187-5126	CHARGER, BATTERY 12VDC	1
30	0187-5003	CONTACTOR, 12VDC, 80 AMP	1
31	0187-5005	CONTACTOR, 12VDC, 200 AMP	1
32	0187-5133	TERMINAL BLOCK	1
33	0187-5134	TERMINAL BLOCK	1
34	0187-5134	TERMINAL BLOCK	1
35	0187-5136	TERMINAL BLOCK	1
36	0187-5202	TRANSFORMER/RESISTOR ASSEMBLY	1
37	0187-5006	LATCH SERVICE KIT	2
38	0187-5090	LATCH SERVICE KIT	2
39	0187-5094	HINGE SERVICE KIT	1
40	0187-5112	PROCESSOR, 4.5KW, 24V	1
41	0187-5118	RECTIFIER ASSEMBLY, 4.5KW, 24V	1
42	0187-5158	FUSE HOLDER ASSEMBLY	1
43	0187-5256	TERMINAL BOARD, 2 STUD 3/8-24	1
44	0187-5260	GUARD, SWITCH	1
45	0187-5258	DIODE ASSEMBLY	1













PARTS BOOK

27

CONTROL BOX		MODEL #	GCAB-48
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5002	GROMMET, SPLIT .625" ID	1
2	0187-5004	METER, HOUR	1
3	0187-5010	SWITCH, INTERLOCK	1
4	0187-5127	SWITCH, MASTER, 3POS, 4POLE	1
5	0187-5012	FUSE, GLASS, FAST ACTING, 10 AMP	1
6	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP	1
7	0187-5139	BAFFLE ASSEMBLY, HOT/COLD REAR	1
8	0187-5151	WIRING HARNESS ASSEMBLY, 4.5KW, DC	1
9	0187-5038	STRAP, GROUND, 4"	1
10	0187-5040	CABLE ASSEMBLY, 27"	1
11	0187-5041	CABLE ASSEMBLY, 21"	2
12	0187-5072	PLATE ADAPTOR	1
13	0187-5042	FUSE HOLDER, BLACK WIRE	1
14	0187-5043	FUSE HOLDER, RED WIRE	1
15	0187-5068	SUPPORT, HEATSINK	1
16	0187-5069	BRACKET, CHARGER MOUNTING	1
17	0187-5074	DOOR, CONTROL BOX	1
18	0187-5075	ANGLE, DOOR	1
19	0187-5161	BRACKET, HEATSINK	1
20	0187-5078	PLATE, COVER	1
21	0187-5080	GUARD, SWITCH	1
22	0187-5082	THERMOSTAT, OIL TEMPERTURE	1
23	0187-5176	FOAM, ALTERNATOR BAFFLE RIGHT SIDE	1
24	0187-5177	FOAM, HOUSING BAFFLE, TOP	1
25	0187-5106	FOAM, ALTERNATOR BAFFLE	1
26	0187-5195	FUSE, ATO, 20 AMP, 32V	1
27	0187-5109	TELECOM CONTROL BOARD	1
28	0187-5190	CIRCUIT BREAKER, 100 AMP	1
29	0187-5126	CHARGER, BATTERY 12VDC	1
30	0187-5003	CONTACTOR, 12VDC, 80 AMP	1
31	0187-5194	CONTACTOR, 12VDC, 100 AMP	1
32	0187-5133	TERMINAL BLOCK	1
33	0187-5134	TERMINAL BLOCK	1
34	0187-5134	TERMINAL BLOCK	1
35	0187-5136	TERMINAL BLOCK	1
36	0187-5202	TRANSFORMER/RESISTOR ASSEMBLY	1
37	0187-5006	LATCH SERVICE KIT	2
38	0187-5090	LATCH SERVICE KIT	2
39	0187-5094	HINGE SERVICE KIT	1
40	0187-5113	PROCESSOR, 4.5KW, 48V	1
41	0187-5119	RECTIFIER ASSEMBLY, 4.5KW, 48V	1
42	0187-5158	FUSE HOLDER ASSEMBLY	1
43	0187-5256	TERMINAL BOARD, 2 STUD 3/8-24	1
44	0187-5260	GUARD, SWITCH	1
45	0187-5258	DIODE ASSEMBLY	1













PARTS BOOK

31

CONTROL BOX		MODEL #	GCAC-24
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5002	GROMMET, SPLIT .625" ID	1
2	0187-5004	METER, HOUR	1
3	0187-5010	SWITCH, INTERLOCK	1
4	0187-5127	SWITCH, MASTER, 3POS, 4POLE	1
5	0187-5137	FUSE	1
6	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP	1
7	0187-5149	BAFFLE ASSEMBLY, HOT/COLD REAR	1
8	0187-5152	WIRING HARNESS ASSEMBLY, 5.5KW, DC	1
9	0187-5038	STRAP, GROUND, 4"	1
10	0187-5040	CABLE ASSEMBLY, 27"	1
11	0187-5041	CABLE ASSEMBLY, 21"	2
12	0187-5157	CABLE ASSEMBLY, 20.52"	3
13	0187-5042	FUSE HOLDER, BLACK WIRE	1
14	0187-5043	FUSE HOLDER, RED WIRE	1
15	0187-5068	SUPPORT, HEATSINK	1
16	0187-5069	BRACKET, CHARGER MOUNTING	1
17	0187-5164	DOOR, CONTROL BOX	1
18	0187-5075	ANGLE, DOOR	1
19	0187-5161	BRACKET, HEATSINK	1
20	0187-5078	PLATE, COVER	1
21	0187-5080	GUARD, SWITCH	1
22	0187-5082	THERMOSTAT, OIL TEMPATURE	1
23	0187-5105	FOAM, ALTERNATOR BAFFLE RIGHT SIDE	1
24	0187-5189	FOAM, HOT/COLD BAFFLE, REAR	1
25	0187-5106	FOAM, ALTERNATOR BAFFLE	1
26	0187-5195	FUSE, ATO, 20 AMP, 32V	1
27	0187-5108	TELECOM CONTROL BOARD	1
28	0187-5191	CIRCUIT BREAKER, 250 AMP	1
29	0187-5126	CHARGER, BATTERY 12VDC	1
30	0187-5003	CONTACTOR, 12VDC, 80 AMP	1
31	0187-5193	CONTACTOR, 24VDC, 400 AMP	1
32	0187-5133	TERMINAL BLOCK	1
33	0187-5134	TERMINAL BLOCK	1
34	0187-5134	TERMINAL BLOCK	1
35	0187-5136	TERMINAL BLOCK	1
36	0187-5203	TRANSFORMER/RESISTOR ASSEMBLY	1
37	0187-5006	LATCH SERVICE KIT	2
38	0187-5090	LATCH SERVICE KIT	2
39	0187-5094	HINGE SERVICE KIT	1
40	0187-5114	PROCESSOR, 5.5KW, 24V	1
41	0187-5120	RECTIFIER ASSEMBLY, 5.5KW, 24V	1
42	0187-5158	FUSE HOLDER ASSEMBLY	1
43	0187-5172	THERMOSTAT AIR	1
44	0187-5256	TERMINAL BOARD, 2 STUD 3/8-24	1
45	0187-5260	GUARD, SWITCH	1
46	0187-5257	DIODE ASSEMBLY	1
47	0187-5259	RELAY, 2 POLE, 30 AMP	1













PARTS BOOK

35

CONTROL BOX		MODEL #	GCAC-48
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5002	GROMMET, SPLIT .625" ID	1
2	0187-5004	METER, HOUR	1
3	0187-5010	SWITCH, INTERLOCK	1
4	0187-5127	SWITCH, MASTER, 3POS, 4POLE	1
5	0187-5137	FUSE	1
6	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP	1
7	0187-5149	BAFFLE ASSEMBLY, HOT/COLD REAR	1
8	0187-5152	WIRING HARNESS ASSEMBLY, 5.5KW, DC	1
9	0187-5038	STRAP, GROUND, 4"	1
10	0187-5040	CABLE ASSEMBLY, 27"	1
11	0187-5041	CABLE ASSEMBLY, 21"	2
13	0187-5042	FUSE HOLDER, BLACK WIRE	1
14	0187-5043	FUSE HOLDER, RED WIRE	1
15	0187-5068	SUPPORT, HEATSINK	1
16	0187-5069	BRACKET, CHARGER MOUNTING	1
17	0187-5164	DOOR, CONTROL BOX	1
18	0187-5075	ANGLE, DOOR	1
19	0187-5161	BRACKET, HEATSINK	1
20	0187-5078	PLATE, COVER	1
21	0187-5080	GUARD, SWITCH	1
22	0187-5082	THERMOSTAT, OIL TEMPERTURE	1
23	0187-5105	FOAM, ALTERNATOR BAFFLE RIGHT SIDE	1
24	0187-5189	FOAM, HOT/COLD BAFFLE, REAR	1
25	0187-5106	FOAM, ALTERNATOR BAFFLE	1
26	0187-5195	FUSE, ATO, 20 AMP, 32V	1
27	0187-5109	TELECOM CONTROL BOARD	1
28	0187-5125	CIRCUIT BREAKER, 150 AMP	1
29	0187-5126	CHARGER, BATTERY 12VDC	1
30	0187-5003	CONTACTOR, 12VDC, 80 AMP	1
31	0187-5005	CONTACTOR, 12VDC, 200 AMP	1
32	0187-5133	TERMINAL BLOCK	1
33	0187-5134	TERMINAL BLOCK	1
34	0187-5134	TERMINAL BLOCK	1
35	0187-5136	TERMINAL BLOCK	1
36	0187-5203	TRANSFORMER/RESISTOR ASSEMBLY	1
37	0187-5006	LATCH SERVICE KIT	2
38	0187-5090	LATCH SERVICE KIT	2
39	0187-5094	HINGE SERVICE KIT	1
40	0187-5115	PROCESSOR, 5.5kW, 48V	1
41	0187-5121	RECTIFIER ASSEMBLY, 5.5KW, 48V	1
42	0187-5158	FUSE HOLDER ASSEMBLY	1
43	0187-5172	THERMOSTAT AIR	1
44	0187-5256	TERMINAL BOARD, 2 STUD 3/8-24	1
45	0187-5260	GUARD, SWITCH	1
46	0187-5258	DIODE ASSEMBLY	1
47	0187-5259	RELAY, 2 POLE, 30 AMP	1








PARTS BOOK

39


ENGINE		MODEL #	GCAA
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5084	ENGINE, GASEOUS, 9hp	1
2	0187-5017	LINK ASSY, STEPPER MOTOR	1
3	0187-5021	PLATE ASSEMBLY, ENGINE MOUNTING	1
4	0187-5023	STEPPER MOTOR ASSEMBLY	1
5	0187-5207	BRACKET, MOUNTING, STEPPER MOTOR	1
6	0187-5083	THERMOSTAT, OIL TEMPERATURE	1
7	0187-5091	SPRING, CARBURETOR	1
8	0187-5088	CARBURETOR KIT	1
9	0187-5087	LOAD BLOCK	1
10	0187-5089	CAP, VACUUM	1



PARTS BOOK

40


ENGINE		MODEL #	GCAB
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5167	ENGINE, GASEOUS, 14hp	1
2	0187-5022	LINK ASSY, STEPPER MOTOR	1
3	0187-5142	PLATE ASSEMBLY, ENGINE MOUNTING	1
4	0187-5023	STEPPER MOTOR ASSEMBLY	1
5	0187-5162	BRACKET, STEPPER MOTOR	1
6	0187-5243	SWITCH, OIL TEMPERATURE	1
7	0187-5181	SPRING, ALTERED	1
8	0187-5204	CARBURETOR KIT	1
9	0187-5163	BRACKET, STEPPER MOTOR	1
10	0187-5089	CAP, VACUUM	1
11	0187-5171	CAP, VACUUM	1
12	0187-5168	SWITCH, OIL PRESSURE	1
13	0187-5169	MUFFLER	1
14	0187-5128	CLAMP, MUFFLER	1



PARTS BOOK

41


ENGINE		MODEL #	GCAC
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5166	ENGINE, GASEOUS, 18hp	1
2	0187-5022	LINK ASSY, STEPPER MOTOR	1
3	0187-5142	PLATE ASSEMBLY, ENGINE MOUNTING	1
4	0187-5023	STEPPER MOTOR ASSEMBLY	1
5	0187-5162	BRACKET, STEPPER MOTOR	1
6	0187-5243	SWITCH, OIL TEMPERATURE	1
7	0187-5181	SPRING, ALTERED	1
8	0187-5205	CARBURETOR KIT	1
9	0187-5163	BRACKET, STEPPER MOTOR	1
10	0187-5089	CAP, VACUUM	1
11	0187-5171	CAP, VACUUM	1
12	0187-5168	SWITCH, OIL PRESSURE	1
13	0187-5182	MUFFLER, MODIFIED	1
14	0187-5196	CLAMP, MUFFLER - 1 5/8	1
15	0187-5197	CLAMP, MUFFLER - 1.5 PIPE	1



PARTS BOOK

42


WIRING DETAIL		MODEL #	GCAA-24, NEG GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5138	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5036	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5122	CAPACITOR, 17000mfd 75V	1
10	0187-5044	CABLE ASSEMBLY - RED	1
11	0187-5055	CABLE ASSEMBLY - BLACK	1
12	0187-5049	CABLE ASSEMBLY - RED	1
13	0187-5063	CABLE ASSEMBLY - RED	1



PARTS BOOK

43


WIRING DETAIL		MODEL #	GCAA-24, POS GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5138	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5036	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5122	CAPACITOR, 17000mfd 75V	1
10	0187-5050	CABLE ASSEMBLY	1
11	01875053	CABLE ASSEMBLY	1
12	0187-5046	CABLE ASSEMBLY - RED	1
13	0187-5064	CABLE ASSEMBLY	1



PARTS BOOK

44


WIRING DETAIL			MODEL #	GCAA-48, NEG GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED	
1	0187-5014	BRACKET, CAPACITOR	1	
2	0187-5034	CABLE ASSEMBLY, 8"	1	
3	0187-5035	CABLE ASSEMBLY, 19.5"	1	
4	0187-5036	CABLE ASSEMBLY, 31"	1	
5	0187-5037	RESISTOR ASSEMBLY	1	
6	0187-5039	GROUND STRAP	1	
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1	
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1	
9	0187-5124	CAPACITOR, 22000mfd 100V	1	
10	0187-5058	CABLE ASSEMBLY - BLACK	1	
11	0187-5059	CABLE ASSEMBLY - BLACK	1	
12	0187-5060	CABLE ASSEMBLY - RED	1	
13	0187-5062	CABLE ASSEMBLY - BLACK	1	



PARTS BOOK

45


WIRING DETAIL		MODEL #	GCAA-48, POS GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5014	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5036	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5124	CAPACITOR, 22000mfd 100V	1
10	0187-5056	CABLE ASSEMBLY	1
11	0187-5057	CABLE ASSEMBLY	1
12	0187-5061	CABLE ASSEMBLY	1
13	0187-5065	CABLE ASSEMBLY	1



PARTS BOOK

46


WIRING DETAIL			MODEL #	GCAB-24, NEG GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED	
1	0187-5138	BRACKET, CAPACITOR	1	
2	0187-5034	CABLE ASSEMBLY, 8"	1	
3	0137-5035	CABLE ASSEMBLY, 19.5"	1	
4	0187-5036	CABLE ASSEMBLY, 31"	1	
5	0187-5037	RESISTOR ASSEMBLY	1	
6	0187-5039	GROUND STRAP	1	
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1	
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1	
9	0187-5159	WIRE ASSEMBLY ENGINE IGNITION	1	
10	0187-5122	CAPACITOR 17000mfd 75V	1	
11	0187-5044	CABLE ASSEMBLY - RED	1	
12	0187-5055	CABLE ASSEMBLY - BLACK	1	
13	0187-5049	CABLE ASSEMBLY - RED	1	
14	0187-5063	CABLE ASSEMBLY - RED	1	



PARTS BOOK

47


WIRING DETAIL		MODEL #	GCAB-24, POS GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5138	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5036	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5159	WIRE ASSEMBLY ENGINE IGNITION	1
10	0187-5122	CAPACITOR 17000mfd 75V	1
11	0187-5054	CABLE ASSEMBLY - BLACK	1
12	0187-5046	CABLE ASSEMBLY - RED	1
13	0187-5051	CABLE ASSEMBLY	1
14	0187-5064	CABLE ASSEMBLY	1



PARTS BOOK

48


WIRING DETAIL		MODEL #	GCAB-48, NEG GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5014	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5036	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5159	WIRE ASSEMBLY ENGINE IGNITION	1
10	0187-5124	CAPACITOR 22000mfd 100V	1
11	0187-5054	CABLE ASSEMBLY - BLACK	1
12	0187-5045	CABLE ASSEMBLY - BLACK	1
13	0187-5046	CABLE ASSEMBLY - RED	1
14	0187-5048	CABLE ASSEMBLY - BLACK	1



PARTS BOOK

49


WIRING DETAIL			MODEL #	GCAB-48, POS GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED	
1	0187-5014	BRACKET, CAPACITOR	1	
2	0187-5034	CABLE ASSEMBLY, 8"	1	
3	0187-5035	CABLE ASSEMBLY, 19.5"	1	
4	0187-5036	CABLE ASSEMBLY, 31"	1	
5	0187-5037	RESISTOR ASSEMBLY	1	
6	0187-5039	GROUND STRAP	1	
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1	
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1	
9	0187-5159	WIRE ASSEMBLY ENGINE IGNITION	1	
10	0187-5124	CAPACITOR 22000mfd 100V	1	
11	0187-5044	CABLE ASSEMBLY - RED	1	
12	0187-5055	CABLE ASSEMBLY - BLACK	1	
13	0187-5047	CABLE ASSEMBLY	1	
14	0187-5052	CABLE ASSEMBLY	1	



PARTS BOOK

50



WIRING DETAIL		MODEL #	GCAC-24, NEG GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5014	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5154	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5159	WIRE ASSEMBLY ENGINE IGNITION	1
10	0187-5122	CAPACITOR 17000mfd 75V	1
11	0187-5155	CABLE ASSEMBLY	1
12	0187-5156	CABLE ASSEMBLY	1



PARTS BOOK

51


WIRING DETAIL			MODEL #	GCAC-24, POS GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED	
1	0187-5014	BRACKET, CAPACITOR	1	
2	0187-5037	RESISTOR ASSEMBLY	1	
3	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1	
4	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1	
5	0187-5122	CAPACITOR 17000mfd 75V	1	
6	0187-5238	CABLE ASSEMBLY	1	
7	0187-5239	CABLE ASSEMBLY	1	
8	0187-5240	CABLE ASSEMBLY	1	



PARTS BOOK

52


WIRING DETAIL		MODEL #	GCAC-48, NEG GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5138	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5154	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5159	WIRE ASSEMBLY ENGINE IGNITION	1
10	0187-5124	CAPACITOR 22000mfd 100V	1
11	0187-5063	CABLE ASSEMBLY	1
12	0187-5155	CABLE ASSEMBLY	1
13	0187-5236	CABLE ASSEMBLY	1
14	0187-5237	CABLE ASSEMBLY	1



PARTS BOOK

53

WIRING DETAIL		MODEL #	GCAC-48, POS GROUND
REFERENCE #	PART #	DESCRIPTION	QTY USED
1	0187-5138	BRACKET, CAPACITOR	1
2	0187-5034	CABLE ASSEMBLY, 8"	1
3	0187-5035	CABLE ASSEMBLY, 19.5"	1
4	0187-5154	CABLE ASSEMBLY, 31"	1
5	0187-5037	RESISTOR ASSEMBLY	1
6	0187-5039	GROUND STRAP	1
7	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)	1
8	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)	1
9	0187-5159	WIRE ASSEMBLY ENGINE IGNITION	1
10	0187-5124	CAPACITOR 22000mfd 100V	1
11	0187-5238	CABLE ASSEMBLY	1
12	0187-5240	CABLE ASSEMBLY	1
13	0187-5241	CABLE ASSEMBLY	1
14	0187-5064	CABLE ASSEMBLY	1



PARTS BOOK

55

PARTS INDEX, BY DESCRIPTION

PAGE #'s	PART #	DESCRIPTION
42, 46, 52	0187-5063	CABLE ASSEMBLY- RED
42, 43, 44, 45, 46, 47, 48, 49, 50, 52, 53	0187-5035	CABLE ASSEMBLY, 19.5"
15, 23, 31	0187-5157	CABLE ASSEMBLY, 20.52"
15, 19, 23, 27, 31, 35	0187-5041	CABLE ASSEMBLY, 21"
15, 19, 23, 27, 31, 35	0187-5040	CABLE ASSEMBLY, 27"
42, 43, 44, 34, 36, 47, 48, 49	0187-5036	CABLE ASSEMBLY, 31"
50, 52, 53	0187-5154	CABLE ASSEMBLY, 31"
42, 43, 44, 45, 46, 47, 48, 49, 50, 52, 53	0187-5034	CABLE ASSEMBLY, 8"
39, 40, 41	0187-5089	CAP, VACUUM
40, 41	0187-5171	CAP, VACUUM
42, 43, 46, 47, 50, 51	0187-5122	CAPACITOR 17000mfd 75V
44, 45, 48, 49, 52, 53	0187-5124	CAPACITOR 22000mfd 100V
6, 7, 8	0187-5255	CAPLUG #21
39	0187-5088	CARBURETOR KIT
40	0187-5204	CARBURETOR KIT
41	0187-5205	CARBURETOR KIT
15, 19, 23, 27, 31, 35	0187-5126	CHARGER, BATTERY 12VDC
27	0187-5190	CIRCUIT BREAKER, 100 AMP
15, 35	0187-5125	CIRCUIT BREAKER, 150 AMP
23	0187-5192	CIRCUIT BREAKER, 200 AMP
31	0187-5191	CIRCUIT BREAKER, 250 AMP
19	0187-5123	CIRCUIT BREAKER, 70 AMP
12	0187-5032	CLAMP, HOSE
13, 14	0187-5199	CLAMP, HOSE
12, 40	0187-5128	CLAMP, MUFFLER
41	0187-5196	CLAMP, MUFFLER - 1 5/8
41	0187-5197	CLAMP, MUFFLER - 1.5 PIPE
15, 23, 35	0187-5005	CONTACTOR, 12 VDC, 200 AMP
27	0187-5194	CONTACTOR, 12VDC, 100 AMP
15, 19, 23, 27, 31, 35	0187-5003	CONTACTOR, 12VDC, 80 AMP
31	0187-5193	CONTACTOR, 24VDC, 400 AMP
3, 4, 5	0187-5143	COVER ASSEMBLY, ALTERNATOR
12, 13, 14	0187-5073	COVER, HOLE, FUEL SYSTEM
9, 10, 11	0187-5129	DECAL, HOT SURFACE
9, 10, 11	0187-5132	DECAL, RISK OF SHOCK
9, 10, 11	0187-5130	DECAL, STARTS AUTOMATICALLY
6, 7, 8	0187-5251	DECAL, WARNING, DO NOT TOUCH
31	0187-5257	DIODE ASSEMBLY
15, 19, 23, 27, 35	0187-5258	DIODE ASSEMBLY
9, 10, 11	0187-5016	DOOR ASSEMBLY
15, 19, 23, 27	0187-5074	DOOR, CONTROL BOX
31, 35	0187-5164	DOOR, CONTROL BOX
13, 14	0187-5235	ELBOW, 90° STREET, BLACK IRON, 3/4"
13, 14	0187-5253	ELBOW, 90°, WELDMENT
12	0187-5026	ELBOW, 90°, BLACK IRON, 3/4"
13, 14	0187-5252	ELBOW, 90°, STREET, WELDMENT
9	0187-5018	ENCLOSURE ASSEMBLY, LESS DOOR
10	0187-5140	ENCLOSURE ASSEMBLY, LESS DOOR
11	0187-5148	ENCLOSURE ASSEMBLY, LESS DOOR

PARTS BOOK

56

PARTS INDEX, BY DESCRIPTION

PAGE #'s

PART

DESCRIPTION

40	0187-5167	ENGINE, GASEOUS, 14hp
41	0187-5166	ENGINE, GASEOUS, 18hp
39	0187-5084	ENGINE, GASEOUS, 9hp
11	0187-5160	FAN ASSEMBLY
3, 4, 5	0187-5229	FAN, COOLING, PLASTIC
12	0187-5030	FITTING, HOSE BARB, 90° ELBOW
15, 19	0187-5175	FOAM, ALT BAFFLE TOP
15, 19, 23, 27, 31, 35	0187-5106	FOAM, ALTERNATOR BAFFLE
23, 27	0187-5176	FOAM, ALTERNATOR BAFFLE RIGHT SIDE
15, 19, 31, 35	0187-5105	FOAM, ALTERNATOR BAFFLE, RIGHT SIDE
11	0187-5183	FOAM, ENCLOSURE
11	0187-5184	FOAM, ENCLOSURE
11	0187-5185	FOAM, ENCLOSURE
11	0187-5186	FOAM, ENCLOSURE
9, 10	0187-5098	FOAM, ENCLOSURE, RIGHT SIDE, UPPER
9, 10	0187-5099	FOAM, ENCLOSURE, TOP
11	0187-5188	FOAM, ENCLOSURE, UPPER, RIGHT SIDE
11	0187-5187	FOAM, FRONT PANEL
6	0187-5103	FOAM, HOT/COLD BAFFLE FRON
7	0187-5179	FOAM, HOT/COLD BAFFLE FRON
8	0187-5180	FOAM, HOT/COLD BAFFLE FRON
15, 19	0187-5104	FOAM, HOT/COLD BAFFLE, REAR
31, 35	0187-5189	FOAM, HOT/COLD BAFFLE, REAR
9, 10	0187-5097	FOAM, HOUSING BAFFLE TOP
9, 10	0187-5100	FOAM, HOUSING BAFFLE, LEFT SIDE
23, 27	0187-5177	FOAM, HOUSING BAFFLE, TOP
9, 10	0187-5101	FOAM, HOUSING BAFFLE, RIGHT SIDE
11	0187-5254	FOWM ENCLOSURE, LS UPPER
31, 35	0187-5137	FUSE
23, 27, 31, 35	0187-5158	FUSE HOLDER ASSEMBLY
15, 19, 23, 27, 31, 35	0187-5042	FUSE HOLDER, BLACK WIRE
15, 19, 23, 27, 31, 35	0187-5043	FUSE HOLDER, RED WIRE
23, 27, 31, 35	0187-5195	FUSE, ATO, 20 AMP, 32V
15, 19, 23, 27	0187-5012	FUSE, GLASS, FAST ACTING, 10 AMP
15, 19, 23, 27, 31, 35	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP
6, 7, 8	0187-5001	GROMMET, RUBBER, 1" ID
6, 7, 8, 15, 19, 23, 27, 31, 35	0187-5002	GROMMET, SPLIT .625" ID
42, 43, 44, 45, 46, 47, 48, 49, 50, 52, 53	0187-5039	GROUND STRAP
15, 19, 23, 27, 31, 35	0187-5080	GUARD, SWITCH
15, 19, 23, 27, 31, 35	0187-5260	GUARD, SWITCH
15, 19, 23, 27, 31, 35	0187-5094	HINGE SERVICE KIT
13, 14	0187-5198	HOSE
6	0187-5107	HOSE, AIR INTAKE, FLEXUST 1.25" ID
12	0187-5031	HOSE, BULK
6	0187-5131	HOSE, NEOPRENE
3, 4, 5	0187-5230	KEY
15, 19, 23, 27, 31, 35	0187-5006	LATCH SERVICE KIT
15, 19, 23, 27, 31, 35	0187-5090	LATCH SERVICE KIT
9, 10, 11	0187-5086	LATCH, BELLCORE 216
39	0187-5017	LINK ASSY, STEPPER MOTOR

PARTS BOOK

57

PARTS INDEX, BY DESCRIPTION

PAGE #'s	PART #	DESCRIPTION
40, 41	0187-5022	LINK ASSY, STEPPER MOTOR
39	0187-5087	LOAD BLOCK
13, 14	0187-5170	LOAD BLOCK
15, 15, 23, 27, 31, 35	0187-5004	METER, HOUR
1	0187-5011	MOUNT, ENGINE
2	0187-5093	MOUNT, ENGINE
40	0187-5169	MUFFLER
41	0187-5182	MUFFLER, MODIFIED
12	0187-5025	NIPPLE, BLACK STEEL, 1/4 X 1 1/4
12	0187-5029	NIPPLE, BLACK STEEL, 1/4 X 3
13, 14	0187-5201	NIPPLE, BLACK STEEL, 1/4 X 4
12, 13, 14	0187-5027	NIPPLE, BLACK STEEL, 1/4 X 4 1/2
19, 27	0187-5072	PLATE ADAPTOR
39	0187-5021	PLATE ASSEMBLY, ENGINE MOUNTING
40, 41	0187-5142	PLATE ASSEMBLY, ENGINE MOUNTING
6, 7, 8, 15, 19, 23, 27, 31, 35	0187-5078	PLATE, COVER
15	0187-5110	PROCESSOR, 3KW, 24V
19	0187-5111	PROCESSOR, 3KW, 48V
23	0187-5112	PROCESSOR, 4.5KW, 24V
27	0187-5113	PROCESSOR, 4.5KW, 48V
31	0187-5114	PROCESSOR, 5.5KW, 24V
35	0187-5115	PROCESSOR, 5.5KW, 48V
15	0187-5116	RECTIFIER ASSEMBLY, 3KW, 24V
19	0187-5117	RECTIFIER ASSEMBLY, 3KW, 48V
23	0187-5118	RECTIFIER ASSEMBLY, 4.5KW, 24V
27	0187-5119	RECTIFIER ASSEMBLY, 4.5KW, 48V
31	0187-5120	RECTIFIER ASSEMBLY, 5.5KW, 24V
35	0187-5121	RECTIFIER ASSEMBLY, 5.5KW, 48V
13, 14	0187-5206	REGULATOR LOW PRESSURE
31, 35	0187-5259	RELAY, 2-POLE, 30 AMP
42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53	0187-5037	RESISTOR ASSEMBLY
12, 13	0187-5085	ROD, BATTERY HOLDDOWN
14	0187-5174	ROD, BATTERY HOLDDOWN
4	0187-5226	ROTOR ASSEMBLY
3	0187-5231	ROTOR ASSEMBLY
5	0187-5233	ROTOR ASSEMBLY
9, 10, 11	0187-5020	SEAL, WHITE, DOOR
1	0187-5015	SKID, WELDMENT
2	0187-5150	SKID, WELDMENT
12, 13, 14	0187-5028	SOLENOID ASSEMBLY
6	0187-5081	SPACER, AIR CLEANER
40, 41	0187-5181	SPRING, ALTERED
39	0187-5091	SPRING, CARBURETOR
4	0187-5227	STATOR HOUSING ASSEMBLY
3	0187-5232	STATOR HOUSING ASSEMBLY
5	0187-5234	STATOR HOUSING ASSEMBLY
39, 40, 41	0187-5023	STEPPER MOTOR ASSEMBLY
15, 19, 23, 27, 31, 35	0187-5038	STRAP, GROUND, 4"
6, 7, 8	0187-5070	SUPPORT, BAFFLE
15, 19, 23, 27, 31, 35	0187-5068	SUPPORT, HEATSINK

PARTS BOOK

58

PARTS INDEX, BY DESCRIPTION

PAGE #'s	PART #	DESCRIPTION
6	0187-5077	SUPPORT, RIGHT SIDE
15, 19, 23, 27, 31, 35	0187-5010	SWITCH, INTERLOCK
15, 19, 23, 27, 31, 35	0187-5127	SWITCH, MASTER, 3POS, 4POLE
40, 41	0187-5168	SWITCH, OIL PRESSURE
40, 41	0187-5243	SWITCH, OIL TEMPERATURE
15, 23, 31	0187-5108	TELECOM CONTROL BOARD
19, 27, 35	0187-5109	TELECOM CONTROL BOARD
15, 19, 23, 27, 31, 35	0187-5133	TERMINAL BLOCK
15, 19, 23, 27, 31, 35	0187-5134	TERMINAL BLOCK
15, 19, 23, 27, 31, 35	0187-5135	TERMINAL BLOCK
15, 19, 23, 27, 31, 35	0187-5136	TERMINAL BLOCK
15, 19, 23, 27, 31, 35	0187-5256	TERMINAL BOARD, 2 STUD, 3/8 - 24
31, 35	0187-5172	THERMOSTAT AIR
39	0187-5083	THERMOSTAT, OIL TEMPERATURE
15, 19, 23, 27, 31, 35	0187-5082	THERMOSTAT, OIL TEMPERATURE
15, 19	0187-5000	TRANSFORMER/RESISTOR ASSEMBLY
23, 27	0187-5202	TRANSFORMER/RESISTOR ASSEMBLY
31, 35	0187-5203	TRANSFORMER/RESISTOR ASSEMBLY
42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)
42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)
46, 47, 48, 49, 50, 52, 53	0187-5159	WIRE ASSEMBLY ENGINE IGNITION
15, 19	0187-5033	WIRING HARNESS ASSEMBLY, 3KW, DC
23, 27	0187-5151	WIRING HARNESS ASSEMBLY, 4.5KW, DC
31, 35	0187-5152	WIRING HARNESS ASSEMBLY, 5.5KW, DC

PARTS BOOK

59

PARTS INDEX, BY PART NUMBER

PAGE #'s	PART #	DESCRIPTION
15, 19	0187-5000	TRANSFORMER/RESISTOR ASSEMBLY
6, 7, 8	0187-5001	GROMMET, RUBBER, 1" ID
6, 7, 8, 15, 19, 23, 27, 31, 35	0187-5002	GROMMET, SPLIT .625" ID
15, 19, 23, 27, 31, 35	0187-5003	CONTACTOR, 12VDC, 80 AMP
15, 15, 23, 27, 31, 35	0187-5004	METER, HOUR
15, 23, 35	0187-5005	CONTACTOR, 12 VDC, 200 AMP
15, 19, 23, 27, 31, 35	0187-5006	LATCH SERVICE KIT
15, 19, 23, 27, 31, 35	0187-5010	SWITCH, INTERLOCK
1	0187-5011	MOUNT, ENGINE
15, 19, 23, 27	0187-5012	FUSE, GLASS, FAST ACTING, 10 AMP
15, 19, 23, 27, 31, 35	0187-5013	FUSE, GLASS, FAST ACTING, 3 AMP
44, 45, 48, 49, 50, 51	0187-5014	BRACKET, CAPACITOR
1	0187-5015	SKID, WELDMENT
9, 10, 11	0187-5016	DOOR ASSEMBLY
39	0187-5017	LINK ASSY, STEPPER MOTOR
9	0187-5018	ENCLOSURE ASSEMBLY, LESS DOOR
15, 19	0187-5019	BAFFLE ASSEMBLY, HOT/COLD REAR
9, 10, 11	0187-5020	SEAL, WHITE, DOOR
39	0187-5021	PLATE ASSEMBLY, ENGINE MOUNTING
40, 41	0187-5022	LINK ASSY, STEPPER MOTOR
39, 40, 41	0187-5023	STEPPER MOTOR ASSEMBLY
12	0187-5024	ASSEMBLY, REGULATOR
12	0187-5025	NIPPLE, BLACK STEEL, 3/4 X 1 1/4
12	0187-5026	ELBOW, 90°, BLACK IRON, 3/4"
12, 13, 14	0187-5027	NIPPLE, BLACK STEEL, 3/4 X 4 1/2
12, 13, 14	0187-5028	SOLENOID ASSEMBLY
12	0187-5029	NIPPLE, BLACK STEEL, 3/4 X 3
12	0187-5030	FITTING, HOSE BARB, 90° ELBOW
12	0187-5031	HOSE, BULK
12	0187-5032	CLAMP, HOSE
15, 19	0187-5033	WIRING HARNESS ASSEMBLY, 3KW, DC
42, 43, 44, 45, 46, 47, 48, 49, 50, 52, 53	0187-5034	CABLE ASSEMBLY, 8"
42, 43, 44, 45, 46, 47, 48, 49, 50, 52, 53	0187-5035	CABLE ASSEMBLY, 19.5"
42, 43, 44, 34, 36, 47, 48, 49	0187-5036	CABLE ASSEMBLY, 31"
42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53	0187-5037	RESISTOR ASSEMBLY
15, 19, 23, 27, 31, 35	0187-5038	STRAP, GROUND, 4"
42, 43, 44, 45, 46, 47, 48, 49, 50, 52, 53	0187-5039	GROUND STRAP
15, 19, 23, 27, 31, 35	0187-5040	CABLE ASSEMBLY, 27"
15, 19, 23, 27, 31, 35	0187-5041	CABLE ASSEMBLY, 21"
15, 19, 23, 27, 31, 35	0187-5042	FUSE HOLDER, BLACK WIRE
15, 19, 23, 27, 31, 35	0187-5043	FUSE HOLDER, RED WIRE
42, 46, 49	0187-5044	CABLE ASSEMBLY - RED
48	0187-5045	CABLE ASSEMBLY - BLACK
43, 47, 48	0187-5046	CABLE ASSEMBLY - RED
49	0187-5047	CABLE ASSEMBLY
48	0187-5048	CABLE ASSEMBLY - BLACK
42, 46	0187-5049	CABLE ASSEMBLY - RED

PARTS BOOK

60

PARTS INDEX, BY PART NUMBER

PAGE #'s	PART #	DESCRIPTION
43	0187-5050	CABLE ASSEMBLY
47	0187-5051	CABLE ASSEMBLY
49	0187-5052	CABLE ASSEMBLY
43	0187-5053	CABLE ASSEMBLY
47, 48	0187-5054	CABLE ASSEMBLY - BLACK
42, 46, 49	0187-5055	CABLE ASSEMBLY - BLACK
45	0187-5056	CABLE ASSEMBLY
45	0187-5057	CABLE ASSEMBLY
44	0187-5058	CABLE ASSEMBLY - BLACK
44	0187-5059	CABLE ASSEMBLY - BLACK
44	0187-5060	CABLE ASSEMBLY - RED
45	0187-5061	CABLE ASSEMBLY
44	0187-5062	CABLE ASSEMBLY - BLACK
42, 46, 52	0187-5063	CABLE ASSEMBLY - RED
43, 47, 53	0187-5064	CABLE ASSEMBLY
45	0187-5065	CABLE ASSEMBLY
42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53	0187-5066	WIRE ASSEMBLY (CAPACITOR WIRING - RED)
42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53	0187-5067	WIRE ASSEMBLY (CAPACITOR WIRING - BLACK)
15, 19, 23, 27, 31, 35	0187-5068	SUPPORT, HEATSINK
15, 19, 23, 27, 31, 35	0187-5069	BRACKET, CHARGER MOUNTING
6, 7, 8	0187-5070	SUPPORT, BAFFLE
9, 10, 11	0187-5071	ACTUATOR SWITCH BRACKET
19, 27	0187-5072	PLATE ADAPTOR
12, 13, 14	0187-5073	COVER, HOLE, FUEL SYSTEM
15, 19, 23, 27	0187-5074	DOOR, CONTROL BOX
15, 19, 23, 27, 31, 35	0187-5075	ANGLE, DOOR
15, 19	0187-5076	BRACKET, MOUNTING, HEATSINK
6	0187-5077	SUPPORT, RIGHT SIDE
6, 7, 8, 15, 19, 23, 27, 31, 35	0187-5078	PLATE, COVER
12, 13	0187-5079	BATTERY HOLDDOWN BRACKET
15, 19, 23, 27, 31, 35	0187-5080	GUARD, SWITCH
6	0187-5081	SPACER, AIR CLEANER
15, 19, 23, 27, 31, 35	0187-5082	THERMOSTAT, OIL TEMPERATURE
39	0187-5083	THERMOSTAT, OIL TEMPERATURE
39	0187-5084	ENGINE, GASEOUS, 9hp
12, 13	0187-5085	ROD, BATTERY HOLDDOWN
9, 10, 11	0187-5086	LATCH, BELLCORE 216
39	0187-5087	LOAD BLOCK
39	0187-5088	CARBURETOR KIT
39, 40, 41	0187-5089	CAP, VACUUM
15, 19, 23, 27, 31, 35	0187-5090	LATCH SERVICE KIT
39	0187-5091	SPRING, CARBURETOR
2	0187-5093	MOUNT, ENGINE
15, 19, 23, 27, 31, 35	0187-5094	HINGE SERVICE KIT
9, 10	0187-5097	FOAM, HOUSING BAFFLE TOP
9, 10	0187-5098	FOAM, ENCLOSURE, RIGHT SIDE, UPPER
9, 10	0187-5099	FOAM, ENCLOSURE, TOP
9, 10	0187-5100	FOAM, HOUSING BAFFLE, LEFT SIDE
9, 10	0187-5101	FOAM, HOUSING BAFFLE, RIGHT SIDE

PARTS BOOK

61

PARTS INDEX, BY PART NUMBER

PAGE #'s	PART #	DESCRIPTION
9, 10, 11	0187-5102	BUMPER
6	0187-5103	FOAM, HOT/COLD BAFFLE FRON
15, 19	0187-5104	FOAM, HOT/COLD BAFFLE, REAR
15, 19, 31, 35	0187-5105	FOAM, ALTERNATOR BAFFLE, RIGHT SIDE
15, 19, 23, 27, 31, 35	0187-5106	FOAM, ALTERNATOR BAFFLE
6	0187-5107	HOSE, AIR INTAKE, FLEXUST 1.25" ID
15, 23, 31	0187-5108	TELECOM CONTROL BOARD
19, 27, 35	0187-5109	TELECOM CONTROL BOARD
15	0187-5110	PROCESSOR, 3KW, 24V
19	0187-5111	PROCESSOR, 3KW, 48V
23	0187-5112	PROCESSOR, 4.5KW, 24V
27	0187-5113	PROCESSOR, 4.5KW, 48V
31	0187-5114	PROCESSOR, 5.5KW, 24V
35	0187-5115	PROCESSOR, 5.5KW, 48V
15	0187-5116	RECTIFIER ASSEMBLY, 3KW, 24V
19	0187-5117	RECTIFIER ASSEMBLY, 3KW, 48V
23	0187-5118	RECTIFIER ASSEMBLY, 4.5KW, 24V
27	0187-5119	RECTIFIER ASSEMBLY, 4.5KW, 48V
31	0187-5120	RECTIFIER ASSEMBLY, 5.5KW, 24V
35	0187-5121	RECTIFIER ASSEMBLY, 5.5KW, 48V
42, 43, 46, 47, 50, 51	0187-5122	CAPACITOR 17000mfd 75V
19	0187-5123	CIRCUIT BREAKER, 70 AMP
44, 45, 48, 49, 52, 53	0187-5124	CAPACITOR 22000mfd 100V
15, 35	0187-5125	CIRCUIT BREAKER, 150 AMP
15, 19, 23, 27, 31, 35	0187-5126	CHARGER, BATTERY 12VDC
15, 19, 23, 27, 31, 35	0187-5127	SWITCH, MASTER, 3POS, 4POLE
12, 40	0187-5128	CLAMP, MUFFLER
9, 10, 11	0187-5129	DECAL, HOT SURFACE
9, 10, 11	0187-5130	DECAL, STARTS AUTOMATICALLY
6	0187-5131	HOSE, NEOPRENE
9, 10, 11	0187-5132	DECAL, RISK OF SHOCK
15, 19, 23, 27, 31, 35	0187-5133	TERMINAL BLOCK
15, 19, 23, 27, 31, 35	0187-5134	TERMINAL BLOCK
15, 19, 23, 27, 31, 35	0187-5135	TERMINAL BLOCK
15, 19, 23, 27, 31, 35	0187-5136	TERMINAL BLOCK
31, 35	0187-5137	FUSE
42, 43, 46, 47, 52, 53	0187-5138	BRACKET, CAPACITOR
23, 27	0187-5139	BAFFLE ASSEMBLY, HOT/COLD REAR
10	0187-5140	ENCLOSURE ASSEMBLY, LESS DOOR
40, 41	0187-5142	PLATE ASSEMBLY, ENGINE MOUNTING
3, 4, 5	0187-5143	COVER ASSEMBLY, ALTERNATOR
3	0187-5144	ALTERNATOR INSTALLATION ASSEMBLY
4	0187-5145	ALTERNATOR INSTALLATION ASSEMBLY
5	0187-5146	ALTERNATOR INSTALLATION ASSEMBLY
11	0187-5148	ENCLOSURE ASSEMBLY, LESS DOOR
31, 35	0187-5149	BAFFLE ASSEMBLY, HOT/COLD REAR
2	0187-5150	SKID, WELDMENT
23, 27	0187-5151	WIRING HARNESS ASSEMBLY, 4.5KW, DC
31, 35	0187-5152	WIRING HARNESS ASSEMBLY, 5.5KW, DC
50, 52, 53	0187-5154	CABLE ASSEMBLY, 31"
50, 52	0187-5155	CABLE ASSEMBLY

PARTS BOOK

62

PARTS INDEX, BY PART NUMBER

PAGE #'s	PART #	DESCRIPTION
50	0187-5156	CABLE ASSEMBLY
15, 23, 31	0187-5157	CABLE ASSEMBLY, 20.52"
23, 27, 31, 35	0187-5158	FUSE HOLDER ASSEMBLY
46, 47, 48, 49, 50, 52, 53	0187-5159	WIRE ASSEMBLY ENGINE IGNITION
11	0187-5160	FAN ASSEMBLY
23, 27, 31, 35	0187-5161	BRACKET, HEATSINK
40, 41	0187-5162	BRACKET, STEPPER MOTOR
40, 41	0187-5163	BRACKET, STEPPER MOTOR
31, 35	0187-5164	DOOR, CONTROL BOX
14	0187-5165	BATTERY HOLDDOWN BRACKET
41	0187-5166	ENGINE, GASEOUS, 18hp
40	0187-5167	ENGINE, GASEOUS, 14hp
40, 41	0187-5168	SWITCH, OIL PRESSURE
40	0187-5169	MUFFLER
13, 14	0187-5170	LOAD BLOCK
40, 41	0187-5171	CAP, VACUUM
31, 35	0187-5172	THERMOSTAT AIR
14	0187-5174	ROD, BATTERY HOLDDOWN
15, 19	0187-5175	FOAM, ALT BAFFLE TOP
23, 27	0187-5176	FOAM, ALTERNATOR BAFFLE RIGHT SIDE
23, 27	0187-5177	FOAM, HOUSING BAFFLE, TOP
7	0187-5179	FOAM, HOT/COLD BAFFLE FRON
8	0187-5180	FOAM, HOT/COLD BAFFLE FRON
40, 41	0187-5181	SPRING, ALTERED
41	0187-5182	MUFFLER, MODIFIED
11	0187-5183	FOAM, ENCLOSURE
11	0187-5184	FOAM, ENCLOSURE
11	0187-5185	FOAM, ENCLOSURE
11	0187-5186	FOAM, ENCLOSURE
11	0187-5187	FOAM, FRONT PANEL
11	0187-5188	FOAM, ENCLOSURE, UPPER, RIGHT SIDE
31, 35	0187-5189	FOAM, HOT/COLD BAFFLE, REAR
27	0187-5190	CIRCUIT BREAKER, 100 AMP
31	0187-5191	CIRCUIT BREAKER, 250 AMP
23	0187-5192	CIRCUIT BREAKER, 200 AMP
31	0187-5193	CONTACTOR, 24VDC, 400 AMP
27	0187-5194	CONTACTOR, 12VDC, 100 AMP
23, 27, 31, 35	0187-5195	FUSE, ATO, 20 AMP, 32V
41	0187-5196	CLAMP, MUFFLER - 1 5/8
41	0187-5197	CLAMP, MUFFLER - 1.5 PIPE
13, 14	0187-5198	HOSE
13, 14	0187-5199	CLAMP, HOSE
13, 14	0187-5200	BUSHING, 1/4 - 3/8
13, 14	0187-5201	NIPPLE, BLACK STEEL, 1/4 X 4
23, 27	0187-5202	TRANSFORMER/RESISTOR ASSEMBLY
31, 35	0187-5203	TRANSFORMER/RESISTOR ASSEMBLY
40	0187-5204	CARBURETOR KIT
41	0187-5205	CARBURETOR KIT
13, 14	0187-5206	REGULATOR LOW PRESSURE
39	0187-5207	BRACKET, MOUNTING, STEPPER MOTOR
4	0187-5226	ROTOR ASSEMBLY

PARTS BOOK

63

PARTS INDEX, BY PART NUMBER

PAGE #'s	PART #	DESCRIPTION
4	0187-5227	STATOR HOUSING ASSEMBLY
3, 4, 5	0187-5228	BUSHING, SPLIT TAPER
3, 4, 5	0187-5229	FAN, COOLING, PLASTIC
3, 4, 5	0187-5230	KEY
3	0187-5231	ROTOR ASSEMBLY
3	0187-5232	STATOR HOUSING ASSEMBLY
5	0187-5233	ROTOR ASSEMBLY
5	0187-5234	STATOR HOUSING ASSEMBLY
13, 14	0187-5235	ELBOW, 90° STREET, BLACK IRON, 3/4"
52	0187-5236	CABLE ASSEMBLY
52	0187-5237	CABLE ASSEMBLY
51, 53	0187-5238	CABLE ASSEMBLY
51	0187-5239	CABLE ASSEMBLY
51, 53	0187-5240	CABLE ASSEMBLY
53	0187-5241	CABLE ASSEMBLY
40, 41	0187-5243	SWITCH, OIL TEMPERATURE
6, 7, 8	0187-5251	DECAL, WARNING, DO NOT TOUCH
13, 14	0187-5252	ELBOW, 90°, STREET, WELDMENT
13, 14	0187-5253	ELBOW, 90°, WELDMENT
11	0187-5254	FOWM ENCLOSURE, LS UPPER
6, 7, 8	0187-5255	CAPLUG #21
15, 19, 23, 27, 31, 35	0187-5256	TERMINAL BOARD, 2 STUD, 3/8 - 24
31	0187-5257	DIODE ASSEMBLY
15, 19, 23, 27, 35	0187-5258	DIODE ASSEMBLY
31, 35	0187-5259	RELAY, 2-POLE, 30 AMP
15, 19, 23, 27, 31, 35	0187-5260	GUARD, SWITCH