

The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



Parts Manual

Performance you rely on.™



Generator Set
5.0 and 6.0

EGH (Spec A-B)

Introduction

This manual applies to the Portable Generator Sets as listed in the Generator Set Data Table. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Parts illustrations are typical. Using the model and specification number from your generator set nameplate, select parts that apply to your set. Right and left sides are determined by facing the engine end (front) of the set.

Generator Set Data Table

MODEL AND SPECIFICATION	WATTS	RPM	VOLTS	HERTZ	WIRE	PHASE	STARTING
5.0EGH-AB/*	5000	3600	120/240	60	4	1	Recoil
5.0EGH-EB/*	5000	3600	120/240	60	4	1	Electric
6.0EGH-EB/*	6000	3600	120/240	60	4	1	Electric

* -- The diagonal line (/) in the model and specification number separates generator set characteristics from the specification number and letter. The specification number denotes customer requested options or deviations from a standard model. The specification letter advances (A to B, B to C, etc.) with major manufacturing changes.



Index

- Adapter Assy, Solenoid, **27, 29**
Adapter, Generator, **21, 22, 23, 24**
Arm, Rocker, **6**
Armature, Starter, **19**
- Back, Box – Control, **25, 26, 27, 29**
Bag, Tools, **20**
Balancer, **9**
Bearing, Ball – Balancer, **9**
Bearing, Ball – Camshaft, **7**
Bearing, Ball – Crankshaft, **8**
Bearing, Ball – Generator, **21, 22, 23, 24**
Bearing, Oilless – Electric Starter, **19**
Block, Cylinder, **4**
Body, Cleaner – Air, **5**
Body, Float, **17**
Breaker, Circuit, **25, 26, 27, 29**
Breather, **5**
Bushing, Rubber, **21, 22, 23, 24**
Bushing, Snap, **25, 26, 27, 29**
- Cable, Battery, **27, 29**
Cable, Battery – DC, **29**
Camshaft, **7**
Cap, Fuel, **18**
Cap, Gas – Gauged, **27, 29**
Cap, Plug – Spark, **14, 15**
Carburetor, **5, 17**
Carburetor, Complete, **17**
Case, Starter – Recoil, **13**
Cleaner, Air, **5**
Clutch, Starter, **19**
Coil, Charger, **15**
Control, 5/6KW (Spec 34879), **27**
Control, 5/6KW (Spec 34879A/B), **28**
Control, 5/6KW (Spec 38018), **29**
Control, 5KW (Spec 1), **25**
Control, 5KW (Spec 14000), **26**
Controller, **10**
Cover, Cleaner – Air, **5**
Cover, Crankcase, **4**
Cover, End – Stator, **21, 22, 23, 24**
Cover, Fan, **16**
Cover, Head – Cylinder, **7**
Cover, Pump – Oil, **12**
Cover, Starter – Electric, **19**
Cover, Stator, **21, 22, 23, 24**
Cowling, Head – Cylinder, **16**
Crankshaft, **8**
- Diode, **21, 22, 23, 24**
Dolly, **30**
- Element, Cleaner – Air, **5**
Endbell, **21, 22, 23, 24**
Engine, Replacement, **4**
Exhaust Extension, **30**
- Fan, Rotor, **21, 22, 23, 24**
Filter, Cleaner – Air, **5**
Filter, Fuel, **25, 26**
Float, **17**
Frame, Commutator, **19**
Frame, Starter, **19**
Fuel System, **18**
- Gauge, Fuel, **18**
Gauge, Oil, **12**
Gear, Balancer, **8, 9**
Gear, Camshaft, **7**
Gear, Crankshaft, **8**
Gear, Governor, **10**
Gear, Ring, **15**
Generator, 5KW (Spec 1 Begin 7/90, 14000, 34879B, 38018), **22**
Generator, 5KW (Spec 1 Prior to 7/90 & 34879A), **21**
Generator, 6KW (Spec 34879A), **23**
Generator, 6KW (Spec 34879B, 38018), **24**
Generator, Replacement, **24**
Generator, Replacement – 5KW (Spec 1 Begin 7/90, 14000, 34879B, 38018), **22**
Governor, **10**
Guide, Valve, **4**
- Harness, Wiring, **20**
Head, Cylinder, **4**
Hold Down, Battery, **27, 29**
Housing, Starter, **19**
- Jet, Air, **17**
Jet, Main, **17**
Joint, Tube – Breather, **7**
- Label, Choke, **5**
Label, Cleaner – Air, **5**
Label, Cover – Fan, **16**
Label, Electronic, **13**
Labels, **25, 26, 27, 29**
Lever, Choke, **17**
Lever, Control – Speed, **11**
Lever, Drive – Starter, **19**
Lever, Governor, **10**
Lifting Kit, **31**
Light, Oil – Low, **25, 26, 28, 29**
Line, Fuel, **25, 26, 27, 29**
- Magneto (34879/38018), **15**
Magneto (Spec 1/14000), **14**
Meter, Volt, **27, 29**
Module, Idler, **28, 29**
Module, Oil – Low, **25, 26, 28, 29**
Muffler, Arrestor – Spark, **25, 26, 27, 29**
- Nameplate, **16**
Nozzle, Main, **17**

Index

Panel, Control – Front, **25, 26, 27, 29**

Pilot, Jet, **17**

Pin, Piston, **8**

Pipe, Knock, **4, 6**

Piston, **8**

Plate, Control, **11**

Plate, Pressure, **11**

Plug, Spark, **14, 15**

Pulley, Start, **13**

Ratchet, **13**

Receptacle, **27, 29**

Receptacle, 12VDC, **27, 29**

Receptacle, Duplex, **27**

Receptacle, GFI, **25, 26, 27, 29**

Receptacle, Twistlock, **25, 26, 27, 29**

Rectifier, **27, 29**

Reel, Starter, **13**

Regulator, Voltage – Auto, **21, 22, 23, 24**

Ring, Piston, **8**

Rocker Arm, **6**

Rod, Connecting, **8**

Rod, Governor, **10, 20**

Rod, Push, **7**

Rollcage, **25, 26, 27, 29**

Rope, Starter, **13**

Rotor, Generator, **21, 22, 23, 24**

Rotor, Magneto (Spec 1/14000), **14**

Rotor, Magneto (Spec 34879/38018), **15**

Rotor, Pump – Oil, **12**

Shaft, Arm – Rocker, **6**

Shaft, Balancer, **9, 9**

Shaft, Governor, **10**

Shaft, Lever – Governor, **10**

Shaft, Throttle, **17**

Shaft, Weight – Fly, **7**

Shield Assy, Tank – Fuel, **27, 29**

Shield, Heat, **25, 26, 27, 29**

Sleeve, Governor, **10**

Solenoid, **20**

Speed Control Plate, **11**

Starter, **19**

Starter, Electric, **15, 19**

Starter, Recoil, **13**

Stator, **21, 22, 23, 24**

Strainer, Oil, **12**

Strap, Ground, **25, 26, 27, 29**

Support, Tank – Fuel, **25, 26**

Switch, Magnetic, **19**

Switch, Oil, **12**

Switch, On/Off, **27, 29**

Switch, Stop, **16**

Switch, Toggle, **27, 29**

Tank, Fuel (Spec 1/14000), **18**

Tank, Fuel (Spec 34879A/B), **27**

Tank, Fuel (Spec 38018), **29**

Tappet, **7**

Tools, **20**

Tube, Breather, **5**

Valve, Choke, **17**

Valve, Exhaust, **4**

Valve, Intake, **4**

Valve, Relief, **12**


Valve, Shutoff – Fuel, **25, 26**

Valve, Throttle, **17**

Weight, Fly, **7**


Wrench, Plug – Spark, **20**

Cylinder Block




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Engine, Replacement	13	185-2603	2	Circlip
			Voltage Code AB	14	185-2599	2	Spring, Valve
	100-2981	1	Spec1/14000	15	185-2601	1	Retainer, Spring - Intake
	100-2980	1	Spec 34879/38018	16	185-2600	1	Retainer, Spring - Exhaust
	100-2957	1	Voltage Code EB	17	185-2546	2	Collet, Spring - Valve (Intake)
1	185-2709	1	Cover, Crankcase	18	185-2077	2	Collet, Spring - Valve (Exhaust)
2	185-2963	1	Plug, Pin	19	185-2598	1	Seal, Stem - Valve (Intake)
3	185-2487	1	Gasket, Crankcase	20	185-2602	2	Spring, Valve - Washer
4	185-2582	2	Pin, Straight	21	185-2482	1	Gasket, Head - Cylinder
5	185-2668	8	Bolt	22	185-2671	2	Pipe, Knock
6	185-3732	1	Bolt	23	185-2831	2	Bolt, Head - Cylinder
7	NFS	1	Block, Cylinder	24	185-2592	2	Bolt, Head - Cylinder
8	185-2591	1	Head, Cylinder	25	185-2593	1	Bolt, Head - Cylinder
9	185-2604	1	Guide, Valve - Intake	26	185-2574	1	Bolt, Flange
10	185-2605	1	Guide, Valve - Exhaust	27	185-2594	2	Washer, Head Bolt
11	185-2596	1	Valve, Intake	28	185-3656	3	Plug, Drain
12	185-2597	1	Valve, Exhaust	29	185-2579	3	Gasket

Breather




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2676	1	Breather	12	185-2492	1	Carburetor (See page 19 for component parts)
2	185-2488	1	Tube, Breather	13	185-2702	1	Elbow, Intake
3	185-2797	1	Cleaner, Air	14	185-2649	1	Gasket, Elbow - Intake
4	185-2678	1	Body, Cleaner - Air	15	185-2567	1	Bolt
5	185-2680	1	Gasket, Cleaner - Air	16	185-2568	1	Bolt
6	185-2489	1	Element	17	185-2648	1	Insulator
7	185-2490	1	Filter, Sub	18	185-2650	2	Gasket, Insulator
8	185-2798	1	Cover, Cleaner - Air	19	185-2703	1	Gasket, Insulator
9	185-2800	1	Label, Cleaner - Air	20	185-2675	1	Eye, Lifting
10	185-2679	2	Nut, Cleaner - Air	21	185-2590	1	Label, Choke
11	185-2575	2	Bolt, Flange				

Rocker Arm




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2606	2	Arm, Rocker	5	185-2609	2	Washer, Arm - Rocker
2	185-2608	2	Screw, Adjusting	6	185-2577	2	Circlip, External
3	185-2408	2	Nut	7	185-2671	1	Pipe, Knock
4	185-2607	1	Shaft, Arm - Rocker	8	185-2581	1	Pin, Straight

Camshaft




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2684	1	Cover, Head - Cylinder	12	185-2672	1	Key, Woodruff
2	185-2677	1	Joint, Tube - Breather	13	185-2723	1	Pin, Decompression
3	185-2491	1	Gasket, Head - Cover	14	185-2724	1	Spring, Decompression
4	185-5159	7	Bolt	15	185-2584	1	Bearing, Ball
5	185-2610	2	Rod, Push	16			Shim
6	185-2611	2	Tappet		185-2612	1	0.50 mm
7	185-2714	1	Camshaft		185-2613	1	0.60 mm
8	185-2715	1	Gear, Camshaft		185-2614	1	0.80 mm
9	185-2725	1	Weight, Fly		185-2615	1	0.90 mm
10	185-2824	1	Shaft, Weight - Fly		185-2616	1	1.00 mm
11	185-2730	1	Pin, Spring - Decompression		185-2617	1	1.20 mm

Crankshaft




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
2			Piston	9	185-2510	1	Crankshaft
	185-2484	1	Standard	10	185-2631	1	Gear, Crankshaft
	185-2624	1	0.25 O.S.	11	185-2634	1	Gear, Balancer
	185-2625	1	0.50 O.S.	12	185-2673	1	Key, Woodruff
3			Ring, Piston	13	185-2585	1	Bearing, Ball
	185-2483	1	Standard	14	185-3095	1	Bearing, Ball
	185-2618	1	0.25 O.S.	15	185-3752	2	Seal, Oil
	185-2619	1	0.50 O.S.	16	185-2710	1	Collar, Crankshaft
4	185-2620	1	Pin, Piston	17			Shim
5	185-2621	1	Circlip, Pin - Piston		185-3449	1	0.20 mm
6			Rod, Connecting		185-3446	1	0.30 mm
	185-2485	1	Standard		185-3447	1	0.40 mm
	185-2626	1	0.25 U.S.		185-3448	1	0.50 mm
	185-2627	1	0.50 U.S.		185-2629	1	0.60 mm
7	185-3759	2	Bolt, Rod - Connecting		185-2630	1	0.70 mm
8	185-2628	2	Washer, Bolt - Rod				

Balancer



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2711	1	Balancer	10			Shim, Balancer
2	185-2633	1	Shaft, Balancer		185-2637	2	0.50 mm
3	185-2635	1	Gear, Balancer		185-2638	2	0.60 mm
4	185-2950	1	Key, Feather		185-2639	2	0.70 mm
5	185-2712	1	Balancer		185-2640	2	0.80 mm
6	185-2632	1	Shaft, Balancer		185-2641	2	0.90 mm
7	185-2636	1	Gear, Balancer		185-2642	2	1.00 mm
8	185-2950	1	Key, Feather		185-2643	2	1.20 mm
9	185-2583	4	Bearing, Ball				

Governor




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2651	1	Gear, Governor
2	185-2652	1	Shaft, Governor
3	185-3484	1	Washer
4	185-3485	1	Washer
5	185-2653	1	Sleeve, Governor
6	185-3487	1	Stopper
7	185-2785	1	Lever, Governor
8	185-2769	1	Bolt
9	185-2669	1	Nut
10	185-2654	1	Shaft, Lever - Governor
11	185-3074	1	Circlip, External
12	185-2729	1	Seal, Oil
13	185-2777	1	Washer, Flat

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
14	185-3074	1	Circlip, External
15	185-2704	1	Rod, Governor
16	185-2705	1	Spring, Rod
17	185-2655	1	Spring, Governor
18	185-2588	1	*Controller
19	185-2888	1	*Spring
20	185-4987	1	*Screw, Pan Head
21	185-3157	1	*Bolt
22	185-2786	1	Stay, Solenoid

* - Used on Spec 34879 and 38018 Only.
See Separate Page for Spec 1/14000.


Speed Control Plate (Spec 1/14000)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-5256	1	Lever, Control - Speed
2	185-5257	1	Plate
3	185-5262	1	Washer, Lock - Spring
4	185-3785	1	Plate, Pressure
5	185-3783	1	Collar
6	185-3801	1	Stud


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	185-3026	1	Nut, Hex
8	185-2381	1	Washer, Lock - Spring
9	185-5258	1	Plate, Control
10	185-3496	2	Spring
11	185-3387	2	Screw

Oil Strainer




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2542	1	Strainer, Oil	9	185-2644	1	O-Ring
2	185-2580	1	O-Ring	10	185-2570	3	Screw, Cap - Hex Head
3	185-2686	1	Gauge, Oil (Full)	11	185-2947	1	Valve, Relief
4	185-2646	1	Support, Gauge - Oil	12	185-2948	1	Spring
5	185-2645	1	Support, Gauge - Oil	13	185-2949	1	Bolt, Retainer - Spring
6	185-3079	1	O-Ring	14	185-2578	1	Gasket
7	185-2486	1	Rotor, Pump - Oil	15	185-2964	1	Switch, Oil
8	185-2685	1	Cover, Pump - Oil				

Recoil Starter



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2494	1	Starter, Recoil	10	185-2767	1	Retainer
2	185-2716	1	Starter, Recoil - Sub	11	185-2495	1	Handle
3	185-2717	1	Case	12	185-2499	1	Handle
4	185-2719	1	Spring	13	185-2721	1	Protector
5	185-2718	1	Reel	14	185-2721	1	Rope, Starter
6	185-2942	3	Spring, Dog	15	185-2722	1	Pulley, Start
7	185-2889	3	Ratchet	16	185-2563	3	Bolt
8	185-2768	1	Spring, Brake	17	185-3013	4	Bolt
9	185-2943	1	Screw, Center	18	185-4470	1	Label, Electronic

Fuel System (Spec 1/400)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-5319	1	Tank, Fuel (Includes Parts Marked *)	6	159-1442	1	+ Valve, Shutoff
2	185-4508	1	*Gasket, Fuel Cap	+ - Some units use Shutoff Valve 159-1442			
3	185-3593	1	*Gauge, Fuel				
4	185-3594	1	*Clip, Hose				
5	185-4507	1	Cap, Fuel				



This diagram shows an exploded view of a mechanical assembly. The central component is a large, rectangular housing (1). To the left, a motor (13) is shown with a shaft extending towards the housing. Above the motor, a curved pipe or hose (2) is connected to a fitting (1). To the right of the housing, a large gear (5) is shown with a smaller gear (4) mounted on its shaft. A bracket (3) is shown below the gear assembly, with a dashed line indicating its position relative to the housing. Other components include a small rectangular block (6) with a cable (8) attached, a small cylindrical component (10), a small rectangular component (11), a small cylindrical component (12), a small cylindrical component (14), and a small rectangular component (7). The diagram is labeled with numbers 1 through 14, corresponding to the parts shown.

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2543	1	Plug, Spark	9	185-2674	1	Key, Woodruff
2	185-2926	1	Cap, Plug - Spark	10	185-2670	1	Nut, Flange
3	185-2799	1	Magneto	11	185-2667	1	Clamp, Cord
4	185-2727	1	Rotor	12	185-3692	1	Bolt
5	185-2665	1	Gear, Ring	13	185-2493	1	Starter, Electric (See Separate (Page for component parts)
6	185-2511	1	T/S Magnet Unit				
7	185-2666	1	Coil, Charger	14	185-2566	2	Bolt
8	185-3691	4	Bolt				

Fan Cover




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2787	1	#Cover, Fan
2	185-4990	1	#Nameplate
3	185-2708	1	Cowling, Head - Cylinder
4	185-3503	6	#Bolt
5	185-4671	4	Bolt
6	185-5270	1	*Cover, Fan
7	185-5274	1	*Switch, Stop

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	185-5275	1	*Label, Cover - Fan (Not Shown)
	185-5276	1	*Bolt (Not Shown)
	185-2573	1	*Bolt, Flange (Not Shown)

= Used on Spec 1/14000 Only

* = Used on Spec 34879/38018 Only

Carburetor



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2492	1	Carburetor, Complete
2	185-4559	1	Screw
3	185-2693	1	Valve, Choke
4	185-2692	1	Valve, Throttle
5	185-4558	2	Screw, Cross
6	185-2953	1	Pilot, Jet
7	185-2986	1	Lever, Choke
8	185-2694	1	Ring
9	185-2691	1	Shaft, Throttle
10	185-2941	1	Spring
11	185-2589	1	Screw, Idle
12	185-2700	1	Spring
13	185-2690	1	Adjuster
14	185-4756	1	Ring
15	185-5178	1	Packing, Chamber - Float
16	185-2699	1	Pin


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
17	185-2697	1	Float
18	185-2687	1	Nozzle, Main
19	185-2701	1	Holder, Jet
20	185-2695	1	Jet, Main
	185-2972	1	Standard
	185-2972	1	High Altitude
21	185-4760	1	Bolt
22	185-2935	1	Washer
23	185-2696	1	Body, Float
24	185-3469	1	Spring
25	185-4564	1	Screw, Drain
26	185-2647	1	Needle
27	185-2698	1	Clip
28	185-2688	1	Jet, Air
29	185-2689	1	Jet, Air

**Fuel System
(Spec 1/1400)**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	185-5319	1	Tank, Fuel (Includes Parts Marked #)		185-3593	1	#Gauge, Fuel
	185-4508	1	#Gasket, Cap - Fuel		185-3594	1	#Clip, Hose
					185-4507	1	Cap, Fuel



Electric Starter




REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2493	1	Starter, Complete
2	185-2659	1	Frame, Starter
3	185-2662	4	Spring, Brush
4	185-2661	1	Holder, Brush
5	185-2664	1	Insulator
6	185-2657	1	Armature, Starter
7	185-2713	1	Clutch, Sub
8	185-2706	1	Housing, Starter
9	185-2707	1	Frame, Commutator

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
10	185-2663	1	Bearing, Oilless
11	185-2965	1	Cover
12	185-2656	1	Lever, Drive - Starter
13	185-2658	1	Switch, Magnetic
14	185-2660	2	Bolt, Through
15	185-2334	2	Nut, Hex
16	185-2669	1	Nut
17	185-2367	1	Nut
18	185-2381	1	Washer, Lock - Spring




Miscellaneous Tools & Parts



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2955	1	Bag Assembly, Tools
2	185-2754	1	Bag, Tools
3	185-2763	1	Wrench, Plug - Spark
4	185-2555	1	Switch, Oil
5	185-2551	1	Lamp Assy.
6	185-2552	1	Solenoid


REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	185-2553	1	Rod, Governor
8	185-2554	1	Pin, Spring
9	185-2782	1	Harness, Wire

**Generator
5.0KW
(Spec 1A - Prior to 7/90 and Spec 34879A)**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	249-0682	1	Generator, Complete (Replacement)	10	249-0714	1	Screw, Mount - AVR
1	249-0711	1	Adapter, Generator	11	249-0716	1	Holder, Brush
2	249-0727	1	Stator	12	249-0717	1	Cover, End - Stator
3	249-0730	1	Cover, Stator	13	249-0718	2	Bolt, Cover - End
4	249-0733	1	Rotor	14	249-0719	1	Diode Assembly, DC
5	249-0712	1	Bearing, Ball	15	249-0721	1	Terminal
6	249-0736	1	Bolt, Mount - Rotor	16	249-0720	1	Screw, Diode - DC
7	249-0713	1	Endbell	17	249-0722	1	Screw, Holder - Brush
8	249-0739	4	Bolt, Mount - Stator	18	249-0723	1	Fan, Rotor
9	249-0715	1	Regulator, Voltage - Automatic	19	249-0724	1	Screw, Ground
				20	249-0725	1	Bushing, Rubber

**Generator
5.0KW
(Spec 1A – Begin 7/90, 14000A, 34879B, 38018A)**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	249-5072	1	Replacement Generator	11	249-0716	1	Holder, Brush
1	249-0799	1	Adapter Assy, Generator	12	249-0717	1	Cover, End - Stator
2	249-0757	1	Stator	13	249-0718	2	Bolt, Cover - End
3	249-0730	1	Cover, Stator	14	185-5005	1	Diode
4	249-0733	1	Rotor	15	249-0801	1	Terminal Assy
5	249-0712	1	Bearing, Ball	16	249-0720	1	Screw, Diode
6	249-0736	1	Bolt, Mount - Rotor	17	249-0722	1	Screw, Holder - Brush
7	249-0713	1	Endbell	18	249-0723	1	Fan, Rotor
8	249-0739	4	Bolt, Mount - Stator	19	249-0724	1	Screw, Earth
9	249-0715	1	Regulator, Voltage - Automatic	20	249-0725	1	Bushing, Rubber
10	249-0714	7	Screw, Mount - Regulator				

**Generator
6.0KW
(Spec 34879A)**



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	249-0683	1	Generator, Complete (Replacement)	10	249-0714	1	Screw, Mount - Regulator
1	249-0711	1	Adapter	11	249-0716	2	Holder, Brush
2	249-0728	1	Stator	12	249-0717	1	Cover, End - Stator
3	249-0731	1	Cover, Stator	13	249-0718	2	Bolt, Cover - End
4	249-0734	1	Rotor	14	249-0719	1	Diode Assembly - DC
5	249-0712	1	Bearing, Ball	15	249-0721	1	Terminal
6	249-0737	1	Bolt, Mount - Rotor	16	249-0720	1	Screw, Diode - DCI
7	249-0713	1	Endbell	17	249-0722	1	Screw, Holder - Brush
8	249-0740	4	Bolt, Mount - Stator	18	249-0723	1	Fan, Rotor
9	249-0715	1	Regulator, Voltage - Automatic	19	249-0724	1	Screw, Ground
				20	249-0725	1	Bushing, Rubber

**Generator
6.0 KW
(Spec 34879B, 38018A)**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	249-5073	1	Replacement Generator	11	249-0716	1	Holder, Brush
1	249-0799	1	Adapter Assy	12	249-0717	1	Cover, End - Stator
2	249-0758	1	Stator	13	249-0718	2	Bolt, Cover - End
3	249-0731	1	Cover, Stator	14	185-5005	1	Diode
4	249-0734	1	Rotor	15	249-0801	1	Terminal Assy
5	249-0712	1	Bearing, Ball	16	249-0720	1	Screw, Diode
6	249-0737	1	Bolt, Mount - Rotor	17	249-0722	1	Screw, Holder - Brush
7	249-0713	1	Endbell	18	249-0723	1	Fan, Rotor
8	249-0740	4	Bolt, Mount - Stator	19	249-0724	1	Screw, Earth
9	249-0715	1	Regulator, Voltage - Automatic	20	249-0725	1	Bushing, Rubber
10	249-0714	7	Screw, Mount - Regulator				

**Control
5.0KW
(Spec 1)**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	327-0989	1	Rollcage		098-6192	1	Label, Warning Hazardous Voltage
	327-0936	1	Support Assy, Channel		098-6074	1	Label, Warning General
	327-0949	1	Support Assy, Generator		098-6277	1	Label, Do Not Overfill
	337-2462	1	Strap, Ground - 7"		327-0884	1	Label, Oil Drained
	327-0887	1	Screw, Hex Hd (5/16-18 x 3/4")		098-6370	1	Label, On/Off
	327-0833	4	Mount, Vibration		327-0926	1	Back, Box - Control
	327-0880	4	Washer, Chrome (5/16-1 1/2)		327-0937	1	Panel, Control - Front
	327-0877	13	Nut, Chrome (5/16-18)		327-0917	1	Screw, Hex Hd (M8 x 60mm)
	327-0961	4	Screw, Hex Head - Cap (5/16-18 x 1-1/2")		327-0918	1	Washer, Flat (M8)
	327-0924	4	Bolt, Hex (3/8-16 x 1-1/8")		327-0921	1	Receptacle, GFI - 125V 20A
	327-0879	4	Washer, Lock - Eng Bolt (3/8")		323-1107	1	Receptacle, Twistlock - 125V 30A (Mates with 323-0862 Plug)
	327-0859	1	Line, Fuel - 38.5"		323-1111	1	Receptacle, Twistlock - 250V 20A (Mates with 323-0857 Plug)
	327-1086	6	Clip, Fuel Line (Metal)		320-0541	2	Breaker, Circuit - 250V 20A
	155-2522	1	Muffler, Arrestor - Spark		327-0843	1	Lug, Ground
	327-0934	1	Shield, Heat		327-0846	1	Screw, Phillips Hd - Cadmium (#10-24 x 1")
	327-0931	1	Support, Tank - Fuel Left		327-0911	2	Nut (#10-24)
	327-0932	1	Right		327-0912	2	Washer, Lock (#10)
	327-0919	1	Valve, Shutoff - Fuel		327-0847	19	Screw, Phillips Hd - Black Zinc (#8-32 x 1/2")
	508-0109	1	Grommet (Round)		327-0850	9	Nut (#8-32)
	327-0964	1	Filter, Fuel		327-0851	2	Bushing, Snap (.75 x 35/64)
	410-1070	2	Clamp, "J" - Fuel Tank		327-0892	1	Clamp, Cable - .25 ID
	327-0882	1	Washer, Lock (M8)		327-0893	1	Clamp, Cable - .375 ID
	327-0881	8	Screw, Hex Head - Cap (1/4-20 x 1")		185-2967	1	Module, Oil - Low
	327-0861	8	Nut, Zinc - Black (1/4-20)		185-2551	1	Light, Oil - Low
	098-6388	1	Label, Phone Info		155-2429-01	1	Arrester, Spark
	098-6220	1	Label, Serial Number				
	098-6190	1	Label, Warning Exhaust Gas & Hot Exhaust Pipe				
	098-6191-01	1	Label, Warning Gasoline Vapor				

Miscellaneous Tools & Parts



SHIPMENT PARTS

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	185-2955	1	Bag Assembly, Tools
2	185-2754	1	Bag, Tools
3	185-2763	1	Wrench, Plug - Spark
4	185-2555	1	Switch, Oil
5	185-2551	1	Lamp Assy.
6	185-2552	1	Solenoid

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	185-2553	1	Rod, Governor
8	185-2554	1	Pin, Spring
9	185-2782	1	Harness, Wire

Control
5.0/6.0 KW
(Spec 34879 A & B)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	327-0925	1	Rollcage		327-0928	1	Back, Box - Control
	327-0923	4	Bolt, U				Panel, Control - Front
	159-1229	1	Tank, Fuel				5.0KW
	327-0909	1	Cap, Gas - Gauged		327-0941	1	Spec A
	327-0659	1	Line, Fuel - 40" (1/4"ID-1/2"OD)				Spec B
	327-0860	2	Clip, Line - Fuel (Plastic)		327-1035	1	Voltage Code AB
	327-0957	4	Screw, Hex Head - Cap (1/4-20 x 1-1/2")		327-1013	1	Voltage Code EB
							6.0KW
	327-1020	6	Retainer Assy		327-0943	1	Spec A
	403-3142	1	Shield Assy, Fuel Tank		327-0965	1	Spec B
	327-0936	1	Support Assy, Channel (Not Used on Voltage Code EB, 5.0KW)		323-1106	1	Receptacle, Duplex - 120V, 20A (Spec A Only)
	327-0961	4	Screw, Hex Head - Cap (5/16-18 x 1-1/2") (Used on 5.0AB Only)		327-0921	1	Receptacle, GFI - 125V, 20A (Spec B Only)
	327-0935	1	Shield, Heat		323-1107	1	Receptacle, Twistlock - 125V 30A (Mates with 323-0862 Plug)
	327-0861	2	Nut, Zinc - Black (1/4-20)		323-1111	1	Receptacle, Twistlock - 250V 20A (Mates with 323-0857 Plug) (Used on 5.0KW Only)
	327-0962	4	Washer (3/4") (Used on 5.0KW Only)		323-1109	1	Receptacle, Twistlock - 250V 30A (Used on 6.0KW Only)
	337-2462	1	Strap, Ground - 7"		327-0858	1	Receptacle, 12VDC
	327-0887	1	Screw, Hex Hd (5/16-18 x 3/4")		327-0971	1	Receptacle, 50A, 125V (P60) (Used on 6.0KW Only)
	327-0872	1	*Rectifier/Diode Assy (Used on Voltage Code EB Only)				Breaker, Circuit - 250V
	327-0949	1	Support Assy, Generator		320-0540	1	15A
	327-0869	1	Hold-Down - Battery (Voltage Code EB Only)		320-0541	3	20A
	327-0914	1	Cable, Battery - Red (24") (Voltage Code EB Only)		327-0972	3	25A (Used on 6.0KW Only)
	327-0915	1	Cable, Battery - Green (12") (Voltage Code EB Only)		327-0886	1	30A
	327-0887	1	Cable, Battery - DC		327-0866	1	Switch, Toggle - Full Power 20A 4PDT
	327-0899	2	Screw, Hex Head (M6 x 12mm)		327-0865	1	Switch, On/Off SPST 6A
	327-0900	2	Washer, Lock (M6)		327-0856	1	Switch, On/Off - SPDT, 15A (Used on 5.0KW, Voltage Code AB Only)
	327-0916	2	Washer, Flat (M6)		327-0871	1	Switch, On/Off - DPST (Used on 5.0/6.0KW Voltage Code EB Only)
	327-0922	1	Adapter Assy, Solenoid		327-0900	1	Washer, Lock - ET (M6)
	327-0833	4	Mount, Vibration		327-0857	1	Meter, Volt - 0-300VAC
	327-0877	13	Nut, Chrome (5/16-18)		327-0901	2	Screw, Phillips (M3 x 8mm)
	327-0924	4	Bolt, Hex (3/8-16 x 1-1/8")		327-0843	1	Lug, Ground
	327-0879	4	Washer, Lock - Split (3/8")		327-0846	1	Screw, Phillips Hd - Cadmium (#10-24 x 1")
	327-0841	3	Ty-Rap		327-0911	2	Nut (#10-24)
	155-2522	1	Muffler, Arrestor - Spark		327-0912	2	Washer, Lock - Split (#10)
	327-0917	1	Screw, Hex (M8 x 60mm)		327-0847	20	Screw, Phillips (#8-32 x 1/2")
	327-0882	1	Washer, Lock (M8)		327-0850	8	Nut, Keps (#8-32)
	099-2424	1	Label, "Serial Number"		327-0851	2	Bushing, Snap
	098-6190	1	Label, "Warning Exhaust Gas & Hot Exhaust Pipe"		327-0852	1	Clamp, Cable (5/16"ID)
	098-6191-01	1	Label, "Warning Gasoline Vapors"		327-0893	1	Clamp, Cable (3/8"ID)
	098-6192	1	Label, "Warning Hazardous Voltage"		155-2429	1	Arrestor, Spark
	098-6074	1	Label, "Warning General"		159-1442	1	Valve Assy, Shutoff
	327-0884	1	Label, "Oil Drained"				
	098-6388	1	Label, "Phone Info"				

Control
5.0/6.0 KW
(Spec 34879 A & B)


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Module, Oil - Low	327-0855	2		Washer, Lock - Split (M5)
185-2967	1		Voltage Code AB	327-0891	1		Module, Idler
185-2555	1		Voltage Code EB	327-0867	1		Spacer, Idler
185-2551	1		Light, Oil - Low	327-0896	1		Connector, Idler
327-0853	2		Screw, Phillips Hd (M5 x 30mm)	327-0897	3		Terminal, Connector
327-0854	2		Nut (M5)				



Control
5.0/6.0 KW
(Spec 38018)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	327-0925	1	Rollcage		327-1047	1	Label, Onan CSA
	327-0923	4	Bolt, U		327-0928	1	Back, Box - Control
	159-1229	1	Tank, Fuel				Panel, Control - Front
	327-0909	1	Cap, Gas - Gauged		327-1031	1	5.0AB
	327-0859	1	Line, Fuel-40" (1/4"ID-1/2"OD)		327-1030	1	5.0EB
	327-0660	2	Clip, Line - Fuel (Plastic)		327-1032	1	6.0EB
	327-0957	4	Screw, Hex Head - Cap (1/4-20 x 1-1/2")		300-4030	1	Insert Assy, Panel - Front
	327-1020	6	Retainer Assy		327-1048	1	Receptacle, GFI - 125V, 15A
	403-3142	1	Shield Assy, Gas Tank		323-1107	1	Receptacle, Twistlock - 125V 30A (Mates with 323-0862 Plug)
	327-0936	1	Support Assy, Channel (Not Used on Voltage Code EB, 5.0KW)		323-1111	1	Receptacle, Twistlock - 250V 20A (Mates with 323-0857 Plug) (Used on 5.0KW Only)
	327-0961	4	Screw, Hex Head - Cap (5/16-18 x 1-1/2") (Used on 5.0AB Only)		327-0858	1	Receptacle, 12VDC
					323-1109	1	Receptacle, Twistlock - 250V 30A (Used on 6.0KW Only)
	327-0935	1	Shield, Heat		327-0971	1	Receptacle, 50A, 125V (P60) (Used on 6.0 KW Only)
	327-0861	2	Nut, Zinc - Black (1/4-20)				Breaker, Circuit - 250V
	327-0862	4	Washer (3/4") (5.0KW Only)		320-0540	2	15A
	337-2462	1	Strap, Ground - 7"		320-0541	3	20A
	327-0887	1	Screw, Hex Hd (5/16-18 x 3/4")		327-0972	3	25A (Used on 6.0KW Only)
	327-0872	1	Rectifier/Diode Assy (Used on Voltage Code EB Only)		327-0886	1	30A
	327-0949	1	Support Assy, Generator		327-0866	1	Switch, Toggle - Full Power 20A 4PDT
	327-0869	1	Hold-Down - Battery (Voltage Code EB Only)		327-0865	1	Switch, On/Off SPST 6A
	327-0914	1	Cable, Battery - Red (24") (Voltage Code EB Only)		327-0856	1	Switch, On/Off SPDT 15A (5.0KW, Voltage Code AB)
	327-0915	1	Cable, Battery - Green (12") (Voltage Code EB Only)		327-0871	1	Switch, On/Off - DPST (Used on 5.0/6.0KW Voltage Code EB Only)
	327-0837	1	Cable, Battery - DC				Washer, Lock - ET (M6)
	327-0899	2	Screw, Hex Head (M6 x 12mm)		327-0900	1	Meter, Volt - 0-300VAC
	327-0900	2	Washer, Lock (M6)		327-0857	1	Screw, Phillips (M3 x 8mm)
	327-0916	2	Washer, Flat (M6)		327-0901	2	Lug, Ground
	327-0922	1	Adapter Assy, Solenoid		327-0843	1	Screw, Phillips Hd - Cadmium (#10-24 x 1")
	327-0833	4	Mount, Vibration		327-0846	1	Nut (#10-24)
	327-0877	13	Nut, Chrome (5/16-18)				Washer, Lock - Split (#10)
	327-0924	4	Bolt, Hex (3/8-16 x 1-1/8")		327-0911	2	Screw, Phillips (#8-32 x 1/2")
	327-0879	4	Washer, Lock - Split (3/8")		327-0912	2	Nut, Keps (#8-32)
	327-0841	3	Ty-Rap		327-0847	20	Bushing, Snap
	155-2522	1	Muffler, Arrestor - Spark		327-0850	8	Clamp, Cable (5/16"ID)
	327-0917	1	Screw, Hex (M8 x 60mm)		327-0851	2	Clamp, Cable (3/8"ID)
	327-0882	1	Washer, Lock (M8)		327-0852	1	Module, Oil - Low
			Label, "Serial Number"		327-0893	1	Voltage Code AB
	327-1044	1	5.0AB				Voltage Code EB
	327-1045	1	5.0EB		185-2967	1	Light, Oil - Low
	327-1046	1	6.0AB		185-2555	1	Screw, Phillips Hd (M5 x 30mm)
	098-6190	1	Label, "Warning Exhaust Gas & Hot Exhaust Pipe"		185-2551	1	Nut (M5)
	098-6191-01	1	Label, "Warning Gasoline Vapors"		327-0853	2	Module, Idler
	098-6192	1	Label, "Warning Hazardous Voltage"		327-0854	2	Spacer, Idler
	098-6074	1	Label, "Warning General"		327-0891	1	Connector, Idler
	327-0884	1	Label, Oil Drained		327-0867	1	Terminal, Connector
	098-6388	1	Label, Phone Info		327-0896	1	Arrester, Spark
					327-0897	3	Valve Assy, Shutoff
					155-2429-01	1	
					159-1442	1	


Dolly



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	410-1070	4	Clamp
2	410-1071	2	Handle
3	403-1477	2	Grip
4	800-0033	4	Screw, Cap - Hex Head (5/16-18 x 2)
5	526-0054	4	Washer, Flat (5/16)
6	327-0882	4	Washer, Lock (5/16)
7	327-0877	4	Nut, Hex (5/16-18)
8	410-1072	2	Wheel
9	410-1168	1	Axel Assembly
10	410-1105	4	Bolt, U
11	526-0198	4	Washer, Flat (5/8)
12	516-0115	4	Pin, Cotter (1/8 x 1.5)
13	800-0005	4	Screw, Cap - Hex Head (1/4-20 x 3/4)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
14	526-0052	16	Washer, Flat (1/4)
15	327-0861	14	Nut, Keps (1/4-20)
16	327-0953	2	Bumper
17	800-0007	2	Screw, Cap - Hex Head (1/4-20 x 1)
18	327-1018	2	Spacer
19	327-0880	2	Washer, Flat (5/16 x 1.5)
20	155-2562	1	Extension, Exhaust
21	155-1256	1	Clamp, Muffler (1-1/8)
22	370-4074	1	Spacer, Exhaust
23	410-1099	1	Bracket, Support
24	410-1100	1	Bracket, Support

Lifting Kit



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	403-3076	1	Bracket, Lifting	4	526-0054	4	Washer, Flat (5/16)
2	410-1070	4	Clamp	5	850-0045	4	Washer, Lock - Spring (5/16)
3	800-0033	4	Screw, Cap - Hex Head (5/16-18 x 2)	6	862-0015	4	Nut, Hex (5/16-18)

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
098-6074, 25, 26, 27, 29		185-2543, 14, 15		185-2604, 4		185-2646, 12	
098-6190, 25, 26, 27, 29		185-2546, 4		185-2605, 4		185-2647, 17	
098-6191-01, 25, 26, 27, 29		185-2551, 25, 26, 28, 29		185-2606, 6		185-2648, 5	
098-6192, 25, 26, 27, 29		185-2552, 20		185-2607, 6		185-2649, 5	
098-6220, 25		185-2553, 20		185-2608, 6		185-2650, 5	
098-6277, 25, 26		185-2554, 20		185-2609, 6		185-2651, 10	
098-6370, 25, 26		185-2555, 28, 29		185-2610, 7		185-2652, 10	
098-6388, 25, 26, 27, 29		185-2563, 13		185-2611, 7		185-2653, 10	
099-2424, 27		185-2566, 15		185-2612, 7		185-2654, 10	
100-2957, 4		185-2567, 5		185-2613, 7		185-2655, 10	
100-2980, 4		185-2568, 5		185-2614, 7		185-2656, 19	
100-2981, 4		185-2569, 10		185-2615, 7		185-2657, 19	
155-1256, 30		185-2570, 12		185-2616, 7		185-2658, 19	
155-2522, 25, 26, 27, 29		185-2573, 16		185-2617, 7		185-2659, 19	
155-2562, 30		185-2574, 4		185-2618, 8		185-2660, 19	
159-1229, 27, 29		185-2575, 5		185-2619, 8		185-2661, 19	
185-2077, 4		185-2577, 6		185-2620, 8		185-2662, 19	
185-2334, 19		185-2578, 12		185-2621, 8		185-2663, 19	
185-2367, 19		185-2579, 4		185-2624, 8		185-2664, 19	
185-2381, 11, 19		185-2580, 12		185-2625, 8		185-2665, 15	
185-2408, 6		185-2581, 6		185-2626, 8		185-2666, 15	
185-2482, 4		185-2582, 4		185-2627, 8		185-2667, 15	
185-2483, 8		185-2583, 9		185-2628, 8		185-2668, 4	
185-2484, 8		185-2584, 7		185-2629, 8		185-2669, 10, 19	
185-2485, 8		185-2585, 8		185-2630, 8		185-2670, 14, 15	
185-2486, 12		185-2588, 10		185-2631, 8		185-2671, 4, 6	
185-2487, 4		185-2589, 17		185-2632, 9		185-2672, 7	
185-2488, 5		185-2590, 5		185-2633, 9		185-2673, 8	
185-2489, 5		185-2591, 4		185-2634, 8		185-2674, 14, 15	
185-2490, 5		185-2592, 4		185-2635, 9		185-2675, 5	
185-2491, 7		185-2593, 4		185-2636, 9		185-2676, 5	
185-2492, 5, 17		185-2594, 4		185-2637, 9		185-2677, 7	
185-2493, 15, 19		185-2596, 4		185-2638, 9		185-2678, 5	
185-2494, 13		185-2597, 4		185-2639, 9		185-2679, 5	
185-2495, 13		185-2598, 4		185-2640, 9		185-2680, 5	
185-2499, 13		185-2599, 4		185-2641, 9		185-2684, 7	
185-2510, 8		185-2600, 4		185-2642, 9		185-2685, 12	
185-2511, 14, 15		185-2601, 4		185-2643, 9		185-2686, 12	
185-2542, 12		185-2602, 4		185-2644, 12		185-2687, 17	
		185-2603, 4		185-2645, 12		185-2688, 17	

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
185-2689, 17		185-2763, 20		185-3446, 8		185-5264, 14	
185-2690, 17		185-2767, 13		185-3447, 8		185-5265, 14	
185-2691, 17		185-2768, 13		185-3448, 8		185-5266, 14	
185-2692, 17		185-2777, 10		185-3449, 8		185-5267, 14	
185-2693, 17		185-2782, 20		185-3469, 17		185-5268, 14	
185-2694, 17		185-2785, 10		185-3484, 10		185-5269, 14	
185-2695, 17		185-2786, 10		185-3485, 10		185-5270, 16	
185-2696, 17		185-2787, 16		185-3487, 10		185-5274, 16	
185-2697, 17		185-2797, 5		185-3496, 11		185-5275, 16	
185-2698, 17		185-2798, 5		185-3503, 16		185-5276, 16	
185-2699, 17		185-2799, 15		185-3593, 18		185-5319, 18	
185-2700, 17		185-2800, 5		185-3594, 18		249-0682, 21	
185-2701, 17		185-2824, 7		185-3656, 4		249-0683, 23	
185-2702, 5		185-2831, 4		185-3691, 14, 15		249-0711, 21, 23	
185-2703, 5		185-2888, 10		185-3692, 15		249-0712, 21, 22, 23, 24	
185-2704, 10		185-2889, 13		185-3732, 4		249-0713, 21, 22, 23, 24	
185-2705, 10		185-2926, 14, 15		185-3752, 8		249-0714, 21, 22, 23, 24	
185-2706, 19		185-2935, 17		185-3759, 8		249-0715, 21, 22, 23, 24	
185-2707, 19		185-2941, 17		185-3783, 11		249-0716, 21, 22, 23, 24	
185-2708, 16		185-2942, 13		185-3785, 11		249-0717, 21, 22, 23, 24	
185-2709, 4		185-2943, 13		185-3801, 11		249-0718, 21, 22, 23, 24	
185-2710, 8		185-2947, 12		185-4470, 13		249-0719, 21, 23	
185-2711, 9		185-2948, 12		185-4507, 18		249-0720, 21, 22, 23, 24	
185-2712, 9		185-2949, 12		185-4508, 18		249-0721, 21, 23	
185-2713, 19		185-2950, 9		185-4558, 17		249-0722, 21, 22, 23, 24	
185-2714, 7		185-2953, 17		185-4559, 17		249-0723, 21, 22, 23, 24	
185-2715, 7		185-2955, 20		185-4564, 17		249-0724, 21, 22, 23, 24	
185-2716, 13		185-2963, 4		185-4671, 16		249-0725, 21, 22, 23, 24	
185-2717, 13		185-2964, 12		185-4756, 17		249-0727, 21	
185-2718, 13		185-2965, 19		185-4760, 17		249-0728, 23	
185-2719, 13		185-2967, 25, 26, 28, 29		185-4987, 10		249-0730, 21, 22	
185-2721, 13		185-2972, 17		185-4990, 16		249-0731, 23, 24	
185-2722, 13		185-2986, 17		185-5005, 22, 24		249-0733, 21, 22	
185-2723, 7		185-3013, 13		185-5159, 7		249-0734, 23, 24	
185-2724, 7		185-3026, 11		185-5178, 17		249-0736, 21, 22	
185-2725, 7		185-3074, 10		185-5256, 11		249-0737, 23, 24	
185-2727, 15		185-3079, 12		185-5257, 11		249-0739, 21, 22	
185-2729, 10		185-3095, 8		185-5258, 11		249-0740, 23, 24	
185-2730, 7		185-3157, 10		185-5262, 11		249-0757, 22	
185-2754, 20		185-3387, 11		185-5263, 14		249-0758, 24	

Numerical Index

<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>	<u>Part No.</u>	<u>Page</u>
249-0799, 22, 24		327-0880, 25, 26, 30		327-0953, 30		403-3142, 27, 29	
249-0801, 22, 24		327-0881, 26		327-0957, 27, 29		410-1070, 25, 30, 31	
249-5072, 22		327-0882, 26, 27, 29, 30		327-0961, 25, 26, 27, 29		410-1071, 30	
249-5073, 24		327-0884, 25, 27, 29		327-0964, 25, 26		410-1072, 30	
300-4030, 29		327-0886, 27, 29		327-0965, 27		410-1099, 30	
320-0540, 27, 29		327-0887, 26, 27		327-0971, 27, 29		410-1100, 30	
320-0541, 25, 26, 27, 29		327-0891, 28, 29		327-0972, 27, 29		410-1104, 30	
323-1106, 27		327-0892, 25, 26		327-0989, 25		410-1105, 30	
323-1107, 25, 27, 29		327-0893, 25, 26, 27, 29		327-1013, 27		508-0109, 25	
323-1109, 27, 29		327-0896, 28, 29		327-1018, 30		516-0115, 30	
323-1111, 25, 26, 27, 29		327-0897, 29		327-1020, 27, 29		526-0052, 30	
323-1117, 26		327-0899, 27, 29		327-1030, 29		526-0054, 30, 31	
327-0804, 26		327-0900, 27, 29		327-1031, 29		526-0198, 30	
327-0833, 25, 26, 29		327-0901, 27, 29		327-1032, 29		800-0005, 30	
327-0837, 27, 29		327-0909, 27, 29		327-1035, 27		800-0007, 30	
327-0841, 27, 29		327-0911, 25, 26, 29		327-1040, 26		800-0033, 30, 31	
327-0843, 25, 26, 27, 29		327-0912, 25, 26, 29		327-1044, 29		850-0045, 31	
327-0846, 25, 26, 27, 29		327-0914, 27, 29		327-1045, 29		862-0015, 31	
327-0847, 25, 26, 27, 29		327-0915, 27, 29		327-1046, 29			
327-0850, 25, 26, 27		327-0916, 27, 29		327-1047, 26, 29			
327-0851, 25, 26, 27, 29		327-0917, 25, 27, 29		327-1048, 26, 29			
327-0852, 27, 29		327-0918, 25		327-1086, 26			
327-0853, 28, 29		327-0919, 25, 26		327-1145, 26			
327-0854, 28, 29		327-0921, 25, 27		327-2462, 26			
327-0855, 28		327-0922, 29		337-2462, 25, 27, 29			
327-0856, 27, 29		327-0923, 27, 29		370-4074, 30			
327-0857, 27, 29		327-0924, 25, 26, 27, 29		372-0833, 27			
327-0858, 27, 29		327-0925, 27, 29		372-0850, 29			
327-0859, 25, 26, 27, 29		327-0926, 25, 26		372-0862, 27			
327-0860, 27, 29		327-0928, 27, 29		372-0872, 27, 29			
327-0861, 25, 26, 27, 29, 30		327-0931, 25, 26		372-0881, 25			
327-0862, 29		327-0932, 25, 26		372-0882, 25			
327-0865, 27, 29		327-0934, 25, 26		372-0887, 25, 29			
327-0866, 27, 29		327-0935, 27, 29		372-0897, 28			
327-0867, 28, 29		327-0936, 25, 26, 27, 29		372-0911, 27			
327-0869, 27, 29		327-0937, 25		372-0912, 27			
327-0871, 27, 29		327-0941, 27		372-0922, 27			
327-0877, 25, 26, 27, 29, 30		327-0943, 27		372-1086, 25			
327-0878, 25, 26, 27, 29		327-0947, 26		403-1477, 30			
		327-0949, 25, 26, 27, 29		403-3076, 31			

Cummins **Onan**

Cummins Power Generation

1400 73rd Ave. NE
Minneapolis, MN 55432 USA

Phone 1 763 574 5000

Toll-free 1 800 888 6626

Fax 1 763 574 5298

Email www.cumminsonan.com/contact

www.cumminsonan.com

Cummins®, Onan®, the "C" logo, and "Performance you rely on." are trademarks of Cummins Inc.

©2012 Cummins Power Generation, Inc. All rights reserved.

