



# MARINE

## Standard Repair Times

**MDKAD  
MDKAE  
MDKAF**



# Table of Contents

	Page
<b>Foreword</b> .....	<b>i</b>
<b>Standard Repair Times</b> .....	<b>v</b>
How Standard Repair Times are Developed .....	v
Productive Repair Time .....	v
Time Allowances .....	vi
<b>Group 00 – Complete Engine</b> .....	<b>1</b>
Administrative Time .....	2
Engine .....	2
Genset, Marine (Above Deck) .....	4
Genset, Marine (Below Deck) .....	4
Troubleshoot .....	5
Troubleshoot–Excess White Smoke At Start .....	9
<b>Group 01 – Cylinder Block</b> .....	<b>11</b>
Camshaft .....	12
Camshaft, Fuel .....	12
Connecting Rod .....	13
Connecting Rod Bearings .....	14
Crankshaft .....	14
Crankshaft Seal, Front .....	15
Crankshaft Seal, Rear .....	15
Gear Cover .....	16
Gear Cover Gasket .....	16
Gear, Crankshaft .....	17
Piston .....	17
Piston Rings .....	18
<b>Group 02 – Cylinder Head</b> .....	<b>21</b>
Cylinder Head .....	22
Cylinder Head Gasket .....	22
Valve Guides .....	23
Valves .....	24
<b>Group 03 – Rocker Levers</b> .....	<b>27</b>
Valves .....	28
<b>Group 04 – Cam Follower</b> .....	<b>29</b>
Valve Tappets .....	30
<b>Group 05 – Fuel System</b> .....	<b>31</b>
Fuel Pump, Electrical .....	32
Pump, Injection .....	32
<b>Group 06 – Injectors</b> .....	<b>33</b>
Injectors .....	34

<b>Group 07 – Lubricating Oil System</b> .....	<b>35</b>
Lubricating Oil And Filter .....	36
Oil Base .....	36
Oil By-Pass .....	36
Oil Filter, Full Flow .....	37
Oil Pickup Cup And Tube .....	37
Oil Pump .....	37
<b>Group 08 – Cooling System</b> .....	<b>39</b>
Belt Guard .....	40
Coolant Thermostat .....	40
Heat Exchanger .....	40
Raw Water Pump (Marine) .....	40
Water Pump .....	41
<b>Group 10 – Intake Air System</b> .....	<b>43</b>
Air Intake Silencer (Marine) .....	44
Intake Manifold .....	44
<b>Group 11 – Exhaust System</b> .....	<b>45</b>
Exhaust Manifold .....	46
Exhaust Manifold Gaskets .....	46
<b>Group 13 – Electrical Equipment</b> .....	<b>47</b>
Alternator .....	48
Glow Plugs .....	48
Starter Motor .....	48
<b>Group 16 – Mounting Adaptations</b> .....	<b>49</b>
Flywheel .....	50
<b>Group 17 – Miscellaneous</b> .....	<b>51</b>
Muffler .....	52
Sound Shield .....	52
Vibration Isolators .....	52
<b>Group 25 – Generator</b> .....	<b>53</b>
Excitor Rotor .....	54
Excitor Stator .....	54
Generator Bearing .....	54
Main Rotor .....	55
Main Stator .....	55
Rotating Diode .....	56

<b>Group 26 – Generator Control .....</b>	<b>57</b>
AC Circuit Breaker .....	58
AC Control Box .....	58
AC Voltage Regulator .....	58
AC Wire Harness .....	58
Bridge Rectifier .....	59
DC Wire Harness .....	59
Relay .....	59
Start Solenoid .....	59
Stop Solenoid .....	60



## Foreword

The Standard Repair Times (SRT) in this manual represent the time required to perform service repairs on Onan Engine and Generator Sets. These times are representative of an average mechanic in a typical dealer or distributorship using the prescribed hand tools, equipment, and all available service tools and equipment required to perform quality repairs and do all necessary testing.

The use of this manual will:

- Encourage uniform terminology throughout the Cummins/Onan organization
- Standardize Repair Order job description write-ups
- Provide shop managers with a guide for establishing flat rate quotations
- Serve as a basis for Onan Corporation, Inc. to establish its warranty labor obligations

Reporting of errors, omissions, and recommendations for improving this publication is encouraged. Send your suggestions or comments to:

**Onan Corporation**

1400 73rd Avenue NE  
Minneapolis, MN 55432

Attn: Service Department

## General Information

Standard Repair Times (SRT) are lists of work tasks (procedures) and the time required to perform those tasks. The procedures list the work tasks required to be sure an engine or generator set is ready to return to service at the lowest possible cost to the customer. A Standard Repair Time is equitable when the repair described in the procedure can be performed in a period of time less than or equal to the standard by a journeyman mechanic after he/she has performed that repair on the same model, in the same application at least once. Those SRT that a particular mechanic performs more frequently will often require less time than the standard. Conversely, those SRT that a particular mechanic does not frequently perform may require more time than the standard. Several of the procedures may be required to accurately depict all the work actually performed to return a particular engine or generator set to service because the repair of a particular engine or generator set is often unique in light of the complaint, failure model, progressive damage, condition of the parts and customer desires. To allow for differences in the time required to perform a repair because of interference by the application, a Service Accessibility Code Scheme has been created.

## Types of Standard Repair Times

There are three types of SRT. Most often at least one of each type is necessary to accurately depict the repair. The three types are:

- Administrative
- Troubleshooting
- Repair

### Administrative SRT

Administrative SRT are intended to provide time to move the vehicle engine or generator set to and from the work area, fill out the repair order, record SRT used, etc. It is intended that an administrative SRT be used only once for each repair order. There are two administrative SRT found in this manual in Group 00 – Complete Engine. One of the administrative SRT is to be used when the repair takes place in a shop operated by the repairing location. The other administrative SRT is to be used when the repair takes place away from the shop operated by the repairing location (road repairs). The time for the road repair administrative SRT is greater to allow for loading and unloading tools, equipment, parts, etc. from the service truck.

### Troubleshooting SRT

Troubleshooting SRT are found only in Group 00 – Complete Engine. These SRT are intended to be used when diagnosing and analyzing engine, generator set or component failures. Troubleshooting SRT are broken down in to logical numbered steps. The time for each step is cumulative with successive steps, including the time for the appropriate preceding step(s). Some troubleshooting SRT contain time to remove and install components to perform the check(s) listed. Most do not. If a troubleshooting SRT does **NOT** include required component removal and installation, it is intended that the SRT for the removal and installation of that component be in addition to the troubleshooting SRT. Refer to the following example:



<b>Procedure Number</b>	<b>Procedure Description</b>	<b>SRT Hours</b>
00-055	Troubleshoot – Lubricating Oil Consumption Excessive Includes:	
-01	- Check: – Oil consumption report – For external oil leaks – For overfilled oil pan – Oil specifications – For fuel contamination – Oil change interval – For engine oil in torque converter	0.4
-02	- Perform checks in Step 01 - Check: – Oil temperature – Air compressor oil consumption – Turbocharger seal – Crankcase blowby	1.0

In the above example, the time required to perform the checks in Step 01 is 0.4 hour. If the problem is not located while performing the checks in Step 01, an additional 0.6 hour is allowed to perform the checks in Step 02 for a total of 1.0 hour. The total troubleshooting time appropriate is the time indicated in the column directly in line with the final step required to locate the problem. The step required to locate the problem may or may not be the last step shown in the troubleshooting SRT. Each step contains information as to which steps are included.

## Repair SRT

Repair SRT make up the majority of this manual. These are the SRT that cover the actual repair work. The time shown on the same line as the SRT code and title is the total time for that SRT.

## Standard Repair Combined Times

Standard Repair Combined Times (SRCT) provide for the combining of the three types of SRT under one code so that, if appropriate, the user can identify the work performed with fewer SRT codes.

## Manual Organization

### SRT Coding System

Each SRT has a unique code so that SRT data can be computerized. The numbering system used is common to all the SRT manuals for all Onan engines and generator sets. The portion of the system shown in the manual contains three segments:

“Group Number” XX	“Procedure Number” XXX	“Step Number” XX
<b>Group Numbers</b>		<b>Procedure Numbers</b>
Group numbers (the first two digits in the SRT code) are used to identify major engine components. The following list explains the group numbers used in SRT manuals:		The procedure number consists of three digits. The first digit provides guidance as to the category of the repair. The second and third digits, shown as XX in the following list, are sequential numbers or alpha within the category.

<b>Group Number</b>	<b>Contents of Group</b>	<b>Specific Repair Number</b>	<b>Description of Category</b>
00	Complete Engine or Generator Set		
01	Cylinder Block	0XX	Troubleshooting
02	Cylinder Head		ONLY in Group 00
03	Rocker Levers	1XX	Remove and Install
04	Cam Followers/Tappets	2XX	Rebuild
05	Fuel System	3XX	Replace
06	Injectors and Fuel Lines	4XX	Clean and Visually Check or Inspect for Reuse
07	Lubricating Oil System		
08	Cooling System	5XX	Machine/Ream/Dowel/ Sleeve
09	Drive Units		Modify/Cut/Lap
10	Intake Air System		Adjust/Calibrate
11	Exhaust System	6XX	
12	Air (Compressed) System		
13	Electrical Equipment	7XX	Test
14	Engine or Generator Set Testing		
15	Instruments and Controls		
16	Mounting Adaptations		
17	Miscellaneous	9XX	(SRCT in Group 99) General/Miscellaneous
22	Hardware		
25	Generator Components		
26	Generator Control Components		
27	Transfer Switches		
99	SRCT		

## Step Numbers

While all SRT codes will contain a Group and Procedure number, only those procedures that are broken down into steps have step numbers. The step numbers are sequential within a SRT.

## General

There is an alphabetic index in the back of the manual. Within a particular group the procedures are arranged in alphabetical order by title, thus are not in code numeric order.

There is also a numerical index in which the procedures are arranged in numeric order and not in alphabetical order.

Within a procedure, the user will note that some lines are indented. This indentation is intended to indicate that the sub-tasks are part of the task under which they are indented.

## How Standard Repair Times are Developed

### Cummins/Onan SRT Objectives and Philosophy

The objective of Cummins/Onan SRT program is to provide credible and equitable labor time standards and procedures to the worldwide Cummins/Onan service network.

A SRT is credible when the procedure accurately depicts the work that **must** be performed to accomplish a quality engine or generator set repair.

A SRT is equitable when it can be performed in a period of time less than or equal to the standard by a journeyman mechanic after he/she has performed that repair at least once.

To establish credible and equitable SRT with sufficient flexibility to account for differences in complaints, failures, progressive damage, customer desires, etc., SRT have been structured using the following considerations:

- What must ALWAYS be done to the engine or generator set to perform the work.
- What MAY have to be done to the engine or generator set parts dependent on their condition.
- What MAY have to be removed to access the engine or generator set.
- How difficult it is for the mechanic to reach the engine or generator set even after interfering application hardware has been removed.

While the most frequent use of SRT information is the Onan Warranty System, it is Onan's intent that the SRT be applicable to repairs conducted for any customer.

As SRT are developed, it is assumed:

- That all the required tools, equipment, and supplies are available in sufficient quantity and in operating condition.
- That required Onan Service Manuals are available to the mechanic are being used.
- That the correct parts are available when the mechanic needs them.

## How Times are Developed

SRT are developed from time studies conducted in the field and Onan Technical Service Personnel. Technical Service Representatives create a comprehensive list of all the work elements or tasks required to perform specific repairs. Field studies are analyzed to find these same work elements or tasks and determine the time required for each. The time for work elements or tasks that are not included in the field time studies is determined by conducting free engine or generator set studies or by estimation using similar elements from existing time studies. A time is determined for each element of the procedure. The time for all elements is then totaled to establish the total productive repair time.

## Productive Repair Time

Productive Repair Time is described as the actual time involved doing productive work, such as: removing, disassembling, cleaning, inspecting, machining, installing and adjusting parts or components. In addition, the following operations are considered to be productive work for inclusion in a SRT:

- Clock on and off the job or repair order, including shift changes.
- Move vehicle, engine or generator set to and from the work area.
- Move tool box to the work area.
- Obtain tools from tool box, wipe and put away after use.
- Refer to service manuals.
- Obtain, unpack and clean replacement parts as necessary.
- Package and mark parts removed as necessary for warranty or local consumer laws.
- Operate engine or generator set to check for proper operation.
- Clean work area at completion of shift or repair.
- Properly dispose of used engine fluids such as oil and coolant.
- Write summary of work performed at completion of repair or work shift.
- Help from another mechanic (time for one man to complete the task times two).

## Time Allowances

After the total productive time is established, an additional allowance of 15 percent is added to cover the following:

- Personal time of 5 percent for:
  - Scheduled rest breaks
  - Personal phone calls
  - Restroom breaks
  - Shift changes
- Supplementary time of 10 percent to cover normal work interruptions:
  - Seized or hard turning fasteners
  - Extra time for extremely dirty equipment
  - Excessive waiting time for replacement parts
  - Brief assistance to other mechanics (less than 5 minutes)
  - Routine maintenance (not repair) of shop equipment

- Obtain consumable supplies
- Technical consultation with shop supervision

The following is an example of how the allowances are calculated to establish the SRT for a procedure where the productive time is 208.7 minute (3.48 hr):

Allowance Type	Allowance Percent (%)	Time (Minutes)
Productive Repair Time	100	208.7
Personal	5	10.4
Supplementary	10	20.9
<b>TOTAL</b>	<b>115</b>	<b>240.0</b>

Published Standard Repair Time = 4.0 hours

### Work Not Included in A SRT

For almost every complete repair there will be one SRT that contains most of the work performed. This is sometimes called a base repair. For example, repairing an engine for high oil consumption often requires use of the SRT title Piston and Rings – Remove and Install. This SRT contains most of the time appropriate for the repair, so it is the base repair. There can be work required that is **not** part of this base SRT. This does not mean that the other work is non-productive, rather that other work is **NOT** required EVERY TIME the pistons and rings are removed and installed. More often than not, this other work is covered by another SRT. If the other work is **not** included in the base repair or in another SRT, the work is probably still productive work required for that particular repair.

### Non-Productive Work

Analysis of past SRT time studies reveals the following general types of work that were not considered to be productive:

- Waiting on camshaft gears to heat and cool
- Waiting on another mechanic to finish using special tools or shop equipment
- Hunting for misplaced parts
- Repairing shop equipment
- Sorting through capscrews, to find the correct length, that were all thrown together into one basket during disassembly
- Repairing customer supplied components
- Salvaging parts or tools that have been damaged from improper handling or lack of correct tools
- Clearing off tables, parts carts, parts racks etc. left dirty or loaded with parts from previous repairs on other equipment
- Rework caused by installation of incorrect parts or incorrect installation of correct parts
- Fabrication or modification of special tools or equipment because the correct tools or equipment are not available

- Visiting during non–break time
- Conducting business with tool vendors
- Waiting on other mechanics to provide required help
- Waiting on parts clerk to fill orders for other mechanics
- Unnecessary inspection of new parts
- “Hot Setting” valves and injectors when not required
- Repairs to application hardware
- Rework resulting from failure to follow recommended service practices
- Performing work that is **not** part of the repair order or helping another mechanic

## **Service Accessibility Codes**

Service repairs are affected by engine or generator set accessibility. The more difficult the accessibility, the longer it will take to complete the tasks given in the SRT procedure. Accessibility for a particular application is determined by reviewing the application and rating the degree of difficulty for performing the 20 most common repairs. Four codes (A, B, C and D) are used to classify the degree of difficulty for the service accessibility of a specific model or type of equipment. An “A” accessibility code indicates the engine or generator set is easily accessible. A “D” code indicates the application does not make the engine or generator set as easily accessible, thus the highest degree of difficulty relative to SRT standards. A “S” code is included for special or specific repairs not covered in the other four classifications. The “R” code indicates the repair is completed with the component, engine or generator set removed from the application.

### **“A” Accessibility Rating**

1. Engine or generator sets mounted in equipment where 90 percent of the work can be performed while standing on the ground, shop floor, or flat work deck.
2. Engine or generator set can be accessed without removing any doors or panels.
3. Interfering application hardware can all be removed.
4. Clearance is sufficient for hands, wrenches, and drain and fill operations, making visual checks and room to stand and work.

### **“B” Accessibility Rating**

1. Engine or generator set mounted in equipment where 70 percent of the work can be performed while standing on the ground, shop floor or flat work deck.
2. Access to the engine can be gained by removing access panels or doors.
3. On 80 percent of the operations, interfering application hardware can be removed.
4. On 80 percent of the operations, clearance is sufficient for hands, wrenches, service tools, drain and fill operations, making visual checks and room to stand and work.

## “C” Accessibility Rating

1. Engine or generator set mounted in equipment where 50 percent of the work can be performed while standing on the ground, shop floor or flat work deck.
2. Access to the engine or generator set can be gained by removing the hood, structural members (bolted in) or sheet metal panels.
3. On 60 percent of the operations, interfering application hardware can be removed.
4. On 60 percent of the operations, clearance is sufficient for hands, wrenches, service tools, drain and fill operations, making visual checks and room to stand and work.

## “D” Accessibility Rating

1. Engine or generator set mounted in equipment where 25 percent of the work can be performed while standing on the ground, shop floor or flat work deck.
2. Access to the engine or generator set is limited due to interference from permanently mounted structural members, sheet metal or crossmembers.
3. On 40 percent of the operations, clearance is sufficient for hands, wrenches, service tools, drain and fill operations, making visual checks and limited room to stand and work.

## Standard Repair Combined Times (SRCT)

SRCT are the combination of some of the SRT in the manual within a distinctive code. These SRCT are based on field input of SRT that are most frequently used in combination to describe the most common field repairs on this engine.

Use of SRCT can reduce the amount of time required to determine the labor standard for a specific complete engine or generator set repair. The use of SRCT will also reduce the number of codes required when completing a warranty claim or customer invoice.

SRCT are intended to supplement, NOT replace, SRT. One SRCT code can be used instead of several SRT codes.

It is intended that other appropriate SRT can be used to supplement a SRCT as long as the work does not overlap. If there is overlapping work, do **not** use a SRCT.

## How To Use This Manual

### 1. Determine the actual work performed:

- Obtain this information from the work description on the repair order.



## **2. Determine the Accessibility Code:**

- Determine the application from the repair order.
- Look in the “Accessibility Code Listing” on page to determine the accessibility code for the application involved in the repair. If the application is not shown, assume the accessibility code is “B”.
- Write down the code.

## **3. Determine applicable SRCT:**

- Find the Contents Page for Group 99 – Standard Repair Combined Times.
- Compare the titles to the work performed to determine if a SRCT will apply.
- If there is a SRCT that seems to apply, find that SRCT and compare the SRT within the SRCT to the work performed. If you are not sure of the work included in the SRT, read that SRT and compare the procedure listing with the work performed.
- If a SRCT applies to all or part of the work performed, find the column that contains the same accessibility code determined in Step 2 above.
- Move down the column to the line containing the SRCT code and title and pick out the appropriate time.
- If all the work in the SRCT is performed and additional steps were taken, use the SRCT and continue to Step 4 to cover the additional work.
- If there is NOT an appropriate SRCT, move to Step 4.

## **4. Determine the appropriate repair SRT:**

- Use the information from the repair order to identify the parts involved.
- Use the contents page at the front of the manual or the alphabetical index in the back of the manual to determine the appropriate SRT group for the parts and/or work involved.
- Find the contents page for that group.
- Read the contents page for procedure titles that seem to correspond to the work performed.
- Find the SRT within the group.
- Read the SRT procedure listing to determine the work included.



- If the work performed and the work included in the SRT are the same, all or in part, determine and record the time.
- Repeat the steps in this paragraph until you have determined a SRT for all the work performed.

#### **5. Determine the appropriate troubleshooting SRT:**

- Read the repair order to determine what troubleshooting work was performed.
- Find the contents page for Group 00.
- Read the contents page for procedure to determine the work included in each step.
- If the work performed and the work included in the troubleshooting SRT are the same, all or in part, determine and record the time of the SRT step. Remember that troubleshooting SRT are cumulative.

#### **6. Determine the appropriate miscellaneous SRT:**

- Read the repair order to determine if any application hardware was removed and installed in order to access the engine or generator set.
- Find the contents page for Group 17.
- Read the contents page for procedure titles that seem to correspond to the work performed.
- Find the SRT within the group.
- Read the SRT procedure to determine the work included in the SRT.
- If the work performed and the work included in the SRT are the same, all or in part, determine and record the time.
- If the work required to application hardware is not given in the SRT manual, determine the time for ONLY this work from the repair order. Record the time for possible use as “99–999” or “Non–SRT Time”.

#### **7. Determine the appropriate administrative SRT:**

- Both of the administrative SRT are shown at the beginning of Group 00.
- Determine the appropriate SRT.
- Record the time.

## 8. Determine the total appropriate SRT time:

- Check to be sure that there is no duplication of tasks within the SRT procedures selected. If there is work duplicated by some of those selected, use other information contained in the manual to reduce the time of one of the SRT accordingly. If the information is not available, make an estimate.
- Total all the times obtained during performance of Steps 2 through 7.

### Standard Repair Times Review Procedure

Onan Corporation makes every effort to be sure the SRT published in this manual are credible and equitable. It will be necessary to review the published times when one or more of the following changes occur:

- Design changes to special service tools or equipment required to perform the repair
- Changes to the repair procedure

A formal SRT review procedure is available for any Cummins/Onan Authorized Repair Location that believes the SRT shown in this manual are incorrect.

To be sure prompt attention and an accurate appraisal is given to your request, the following guidelines must be met:

1. Be sure the technician has followed all the procedures and used all the service tools referred to in the appropriate service manuals.
2. Be sure a journeyman technician performed the repair, one who has completed the repair a sufficient number of times to become familiar with the procedure.
3. Be sure all the SRT, including supplemental SRT, appropriate for the repair are being used.
4. Include as much detail as possible about the specific repair.

**NOTE:** It is **NOT** the intent of this procedure to provide a forum for appealing or disputing the amount of time or the SRT judged appropriate on a particular warranty claim. Communication of this sort **must** follow the processes shown in the Onan Warranty Administration Manual.

5. Provide photographs of the installation.
6. Provide copies of all repair orders applicable to the SRT involved, the technicians time cards, and any other information related to the repair that will aid in the review process.
7. Be sure to provide the correct name of the repairing location, a phone number, and point of contact.

## Company Action

Upon receipt of the request for an SRT review, the following action will be taken:

1. The person signing the request will be contacted to acknowledge the receipt of the request.
2. All the information provided will be analyzed and compared with the history files of the specific operation.
3. All information will be analyzed to determine if an error has been made in the procedure, the operations description, or the published repair time.
4. If it is determined the published repair time is incorrect, additional studies/analysis will be performed to establish the correct time. The requester will be notified of the results, and the results will be published in the next SRT update.
5. If it is determined that the time and procedure is correct, recommendations and assistance will be offered as needed.



# Group 00 – Complete Engine

## Contents

	Page
<b>Administrative Time</b> .....	<b>2</b>
Open/Close Repair Order (Road) .....	2
Open/Close Repair Order (Shop) .....	2
<b>Engine</b> .....	<b>2</b>
Rebuild .....	2
<b>Genset, Marine (Above Deck)</b> .....	<b>4</b>
Remove And Install .....	4
<b>Genset, Marine (Below Deck)</b> .....	<b>4</b>
Remove And Install .....	4
<b>Troubleshoot</b> .....	<b>5</b>
Coolant Loss (External) .....	5
Coolant Temp Above Normal .....	5
Eng Cranks But Will Not Start (Genset) .....	5
Engine Unstable (Hunts) (Genset) .....	6
Engine Will Not Crank (Genset) .....	6
Excessive Exhaust Smoke Under Load .....	6
High Exhaust Temp (Marine) .....	7
High/Low AC Output (Genset) .....	7
No Output Voltage (Avr) (Genset) .....	7
Starts But Stops When Switch Released .....	8
Unblanced Generator Output Voltage .....	8
Unstable Voltage Eng Stable (Genset) .....	9
<b>Troubleshoot–Excess White Smoke At Start</b> .....	<b>9</b>
Up (Cold) .....	9
Up (Warm) .....	10

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>00-902 Administrative Time – Open/Close Repair Order(Road)</b>  <i>Includes:</i> <ul style="list-style-type: none"> <li>- Clock on and off the job</li> <li>- Move equipment to and from work area</li> <li>- Clean work area and write repair at the end of each shift and when job has been completed</li> <li>- Record the following:               <ul style="list-style-type: none"> <li>- Generator Set model number</li> <li>- Generator Set serial number</li> <li>- Customer name and address</li> <li>- Original date of purchase</li> <li>- Hours of operation</li> </ul> </li> </ul>	0.7	-	-	-	-	-
<b>00-901 Administrative Time – Open/Close Repair Order(Shop)</b>  <i>Includes:</i> <ul style="list-style-type: none"> <li>- Clock on and off the job</li> <li>- Move equipment to and from work area</li> <li>- Clean work area and write repair at the end of each shift and when job has been completed</li> <li>- Record the following:               <ul style="list-style-type: none"> <li>- Generator Set model number</li> <li>- Generator Set serial number</li> <li>- Customer name and address</li> <li>- Original date of purchase</li> <li>- Hours of operation</li> </ul> </li> </ul>	0.4	-	-	-	-	-
<b>00-201 Engine – Rebuild</b>  <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect</li> <li>- Wiring harness</li> <li>- Fuel lines</li> <li>- Remove and install               <ul style="list-style-type: none"> <li>- Drip pan assy</li> <li>- Heat exchanger</li> </ul> </li> </ul>	-	-	8.3	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>00-201 Engine – Rebuild</b></p> <ul style="list-style-type: none"> <li>- Air cleaner or silencer</li> <li>- Generator control assy</li> <li>- Generator end</li> <li>- Belt and fan guards</li> <li>- Fan and pulley</li> <li>- Alternator</li> <li>- Water pump</li> <li>- Rear bearing plate assy</li> <li>- Flywheel</li> <li>- Fuel lines</li> <li>- Fuel pump</li> <li>- Stop solenoid</li> <li>- Speed control assy</li> <li>- Starter</li> <li>- Intake manifold</li> <li>- Oil pan</li> <li>- Exhaust manifold</li> <li>- Injection pump</li> <li>- Valve cover and rocker assy</li> <li>- Tappets</li> <li>- Cylinder head</li> <li>- Injection pump cover</li> <li>- Governor spring</li> <li>- Gearcase cover</li> <li>- Oil filter</li> <li>- Idler gear</li> <li>- Camshaft lock</li> <li>- Piston and connecting rods</li> <li>- Fork lever assy</li> <li>- Fuel camshaft</li> <li>- Crankshaft</li> <li>- Camshaft</li> <li>- Bearings</li> </ul>	-	-	8.3	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b> <b>00-201 Engine – Rebuild</b> <ul style="list-style-type: none"> <li>– Oil seals</li> <li>– Oil pump</li> <li>– Hone or bore cylinders</li> <li>– Adjust valve lash</li> <li>– Refill oil and coolant</li> <li>– Test run unit</li> </ul>	-	-	8.3	-	-	-
<b>00-1AB Genset, Marine (Above Deck) – Remove And Install</b>  <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect</li> <li>– Battery cables</li> <li>– Main leads and associated wiring</li> <li>– Fuel lines</li> <li>– Exhaust systems</li> <li>– Coolant supply lines</li> <li>– Sound shield assembly</li> <li>– Remove and install</li> <li>– Generator set from mounting location</li> <li>– Test run for proper operation</li> </ul>	-	-	1.0	-	-	-
<b>00-1AC Genset, Marine (Below Deck) – Remove And Install</b>  <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect</li> <li>– Battery cables</li> <li>– Main leads and associated wiring</li> <li>– Fuel lines</li> <li>– Exhaust systems</li> <li>– Coolant supply lines</li> <li>– Sound shield assembly</li> <li>– Remove and install</li> <li>– Generator set from mounting location</li> <li>– Test run for proper operation</li> </ul>	-	-	8.0	-	-	-



Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b>						
<b>00-010 Troubleshoot – Coolant Loss (External)</b>	-	-	-	-	-	-
-01 – Check: <ul style="list-style-type: none"> <li>– Coolant level</li> <li>– Cracked or leaking hoses</li> <li>– Loose hose clamps</li> <li>– Radiator or heat exchanger for leaks</li> <li>– Coolant in oil</li> </ul>	-	-	0.3	-	-	-
-02 – Perform checks in step 01 <ul style="list-style-type: none"> <li>– Check:               <ul style="list-style-type: none"> <li>– Pressure test coolant system</li> <li>– Run generator set and check for leaks</li> </ul> </li> </ul>	-	-	0.5	-	-	-
<b>00-014 Troubleshoot – Coolant Temp Above Normal</b>	-	-	-	-	-	-
-01 – Check <ul style="list-style-type: none"> <li>– Engine coolant level</li> <li>– High engine temp switch</li> <li>– Fault breaker</li> <li>– Coolant level switch</li> </ul>	-	-	0.5	-	-	-
-02 – Perform checks in step 01 <ul style="list-style-type: none"> <li>– Check:               <ul style="list-style-type: none"> <li>– Pressure cap</li> <li>– Coolant pump</li> <li>– Coolant tank</li> <li>– Heat exchanger</li> </ul> </li> </ul>	-	-	1.0	-	-	-
<b>00-022 Troubleshoot – Eng Cranks But Will Not Start (Genset)</b>	-	-	-	-	-	-
-01 – Check: <ul style="list-style-type: none"> <li>– Battery condition</li> <li>– Fuel level in tank</li> <li>– Wire loose at K5</li> <li>– Wire loose at start/stop preheat switch</li> </ul>	-	-	0.5	-	-	-
-02 – Perform checks in step 01	-	-	1.0	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b> <b>00-022 Troubleshoot – Eng Cranks But Will Not Start (Genset)</b> – Check: – Fuel pump – B+ at glow plugs – Fuel shutoff solenoid	-	-	-	-	-	-
<b>00-041 Troubleshoot – Engine Unstable (Hunts) (Genset)</b> -01 – Check: – Fuel supply – Fuel Lines for leakage – Loose wire connection -02 – Perform checks in step 01 – Check: – Governor linkage for binding – Governor adjustments	-	-	0.5	-	-	-
<b>00-0AA Troubleshoot – Engine Will Not Crank (Genset)</b> -01 – Check: – Low battery voltage – Terminal connection–loose or dirty – Battery cable size – Circuit breakers -02 – Perform checks in step 01 – Check: – Remote control – Connections on PCB control board – Start solenoid – Starter – Start/Stop switch – Start relay K1	-	-	0.5	-	-	-
<b>00-046 Troubleshoot – Excessive Exhaust Smoke Under Load</b>	-	-	-	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b>						
<b>00-046 Troubleshoot – Excessive Exhaust Smoke Under Load</b>	-	-	-	-	-	-
-01 – Check: – Intake air restrictions – Overloaded generator – Valve settings	-	-	0.8	-	-	-
-02 – Perform checks in step 01 – Check: – Injection pump timing	-	-	1.5	-	-	-
<b>00-0AN Troubleshoot – High Exhaust Temp (Marine)</b>	-	-	1.0	-	-	-
<i>Includes:</i>						
– Check: – Proper coolant flow out of exhaust – Exhaust temp switch for proper operation – Damaged exhaust temp switch – Plugged sea strainer – Damaged impeller						
<b>00-0AD Troubleshoot – High/Low AC Output (Genset)</b>	-	-	-	-	-	-
-01 – Check: – Broken or loose wires – Voltage regulator – Transformer regulator – Engine speed – Voltage adjustment pot setting – Output lead wiring configuration	-	-	0.5	-	-	-
-02 – Perform checks in step 01 – Check: – Main rotor – Main stator – Excitor rotor – Excitor stator	-	-	1.0	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b>						
<b>00-0AG Troubleshoot – No Output Voltage (Avr) (Genset)</b>	-	-	-	-	-	-
-01 – Check: <ul style="list-style-type: none"> <li>– Load breaker closed</li> <li>– Broken or loose wires</li> <li>– AC output to load breakers</li> <li>– Field breaker CB21</li> <li>– Excitor field wiring</li> </ul>	-	-	0.3	-	-	-
-02 – Perform checks in step 01 <ul style="list-style-type: none"> <li>– Check:               <ul style="list-style-type: none"> <li>– Bridge rectifier CR21</li> <li>– Rotating diodes CR1–CR6</li> <li>– Voltage regulator VR21</li> <li>– Residual voltage</li> <li>– Exciter rotor</li> <li>– Exciter stator</li> <li>– Main rotor</li> <li>– Main Stator</li> </ul> </li> </ul>	-	-	1.5	-	-	-
<b>00-0AB Troubleshoot – Starts But Stops When Switch Released</b>	-	-	-	-	-	-
-01 – Check: <ul style="list-style-type: none"> <li>– Oil level</li> <li>– Oil pressure switch</li> <li>– Engine speed</li> </ul>	-	-	0.5	-	-	-
-02 – Perform checks in step 01 <ul style="list-style-type: none"> <li>– Check:               <ul style="list-style-type: none"> <li>– CB12 fault breaker</li> <li>– K12 relay operation</li> <li>– DC control breaker</li> <li>– Start/Stop switch operation</li> <li>– Governor lever setting</li> </ul> </li> </ul>	-	-	1.0	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>00-0AZ Troubleshoot – Unblanced Generator Output Voltage</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>- Check</li> <li>- Load at generator terminals</li> <li>- Generator lead connections</li> <li>- Generator stator windings</li> </ul>	-	-	0.5	-	-	-
<p><b>00-0AH Troubleshoot – Unstable Voltage Eng Stable (Genset)</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>- Check:</li> <li>- Connections to voltage regulator</li> <li>- Regulator wiring harness</li> <li>- Voltage regulator</li> </ul>	-	-	0.5	-	-	-
<p><b>00-048 Troubleshoot–Excess White Smoke At Start – Up (Cold)</b></p> <p>-01 - Check:</p> <ul style="list-style-type: none"> <li>- Glow plugs</li> <li>- Engine coolant heater</li> <li>- Valve settings</li> </ul> <p>-02 - Perform checks in step 01</p> <p>- Check:</p> <ul style="list-style-type: none"> <li>- Injection pump timing</li> <li>- Engine compression</li> </ul>	-	-	-	-	-	-
<p>-01 - Check:</p> <ul style="list-style-type: none"> <li>- Glow plugs</li> <li>- Engine coolant heater</li> <li>- Valve settings</li> </ul>	-	-	0.8	-	-	-
<p>-02 - Perform checks in step 01</p> <p>- Check:</p> <ul style="list-style-type: none"> <li>- Injection pump timing</li> <li>- Engine compression</li> </ul>	-	-	1.5	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b>						
<b>00-047 Troubleshoot-Excess White Smoke At Start - Up (Warm)</b>	-	-	-	-	-	-
-01 - Check: - Glow plugs - Valve settings - Low engine operating temp	-	-	0.8	-	-	-
-02 - Perform checks in step 01 - Check: - Injection pump timing	-	-	1.5	-	-	-

# Group 01 – Cylinder Block

## Contents

	Page
<b>Camshaft</b> .....	<b>12</b>
Replace .....	12
<b>Camshaft, Fuel</b> .....	<b>12</b>
Remove And Install .....	12
<b>Connecting Rod</b> .....	<b>13</b>
Remove And Install .....	13
<b>Connecting Rod Bearings</b> .....	<b>14</b>
Replace .....	14
<b>Crankshaft</b> .....	<b>14</b>
Remove And Install .....	14
<b>Crankshaft Seal, Front</b> .....	<b>15</b>
Replace .....	15
<b>Crankshaft Seal, Rear</b> .....	<b>15</b>
Replace (Horizontal) .....	15
<b>Gear Cover</b> .....	<b>16</b>
Remove And Install .....	16
<b>Gear Cover Gasket</b> .....	<b>16</b>
Replace .....	16
<b>Gear, Crankshaft</b> .....	<b>17</b>
Remove And Install .....	17
<b>Piston</b> .....	<b>17</b>
Remove And Install, All .....	17
<b>Piston Rings</b> .....	<b>18</b>
Replace .....	18

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>01-3AE Camshaft – Replace</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Belt and fan guards</li> <li>Drip tray</li> <li>Heat exchanger</li> <li>Fuel lines</li> <li>Speed control assy</li> <li>Valve cover and rocker assy</li> <li>Cylinder head</li> <li>Injection pump cover</li> <li>Governor spring</li> <li>Gearcase cover</li> <li>Idler gear</li> <li>Camshaft lock</li> <li>Camshaft and gear</li> <li>Crankshaft pulley</li> <li>- Adjust valve lash</li> <li>- Test run unit</li> </ul>	-	-	7.8	-	-	-
<b>01-1AC Camshaft, Fuel – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Belt and fan guards</li> <li>Alternator and pulley</li> <li>Fuel lines</li> </ul>	-	-	7.8	-	-	-



Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>01-1AC Camshaft, Fuel – Remove And Install</b></p> <ul style="list-style-type: none"> <li>Speed control assy</li> <li>Injection pump</li> <li>Valve cover and rocker assy</li> <li>Cylinder head</li> <li>Injection pump cover</li> <li>Governor spring</li> <li>Gearcase cover</li> <li>Idler gear</li> <li>Fuel camshaft stopper</li> <li>Fork lever assy</li> <li>Fuel camshaft</li> <li>Crankshaft pulley</li> <li>Bearings</li> <li>– Adjust valve lash</li> <li>– Prime and bleed fuel system</li> <li>– Test run unit</li> </ul>	-	-	7.8	-	-	-
<p><b>01-1AA Connecting Rod – Remove And Install</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect</li> <li>Wiring harness</li> <li>Fuel lines</li> <li>– Drain and refill engine fluids</li> <li>– Remove and install</li> <li>Drip pan assy</li> <li>Oil pan</li> <li>Valve cover and rocker assy</li> <li>Cylinder head</li> <li>Piston and connecting rods</li> <li>Bearings</li> <li>– Clean and visually inspect crankshaft</li> <li>– Hone or bore cylinders</li> <li>– Adjust valve lash</li> </ul>	-	-	5.5	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b> <b>01-1AA Connecting Rod – Remove And Install</b> – Test run unit	-	-	5.5	-	-	-
<b>01-3AF Connecting Rod Bearings – Replace</b> <i>Includes:</i> – Drain and refill engine fluids – Remove and install Drip pan assy Oil pan Connecting rod bearings – Clean and visually inspect crankshaft – Test run unit	-	-	5.5	-	-	-
<b>01-112 Crankshaft – Remove And Install</b> <i>Includes:</i> – Disconnect and connect Wiring harness Fuel lines – Drain and refill engine fluids – Remove and install Drip pan assy Generator control assy Generator end Flywheel Rear bearing plate assy Fan assy Belts and pulley Fan guard Alternator Water pump Oil pan Injection lines Air cleaner or silencer Valve cover and rocker assy Tappets	-	-	8.8	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>01-112 Crankshaft – Remove And Install</b> (continued from previous page) Cylinder head Injection pump cover Governor spring Speed control plate Gearcase cover Oil filter Idle gear Piston and connecting rod Connecting rod bearings Main bearings Crankshaft Oil seals Oil pump – Adjust valve lash – Clean and inspect cylinder bores – Test run unit	-	-	8.8	-	-	-
<b>01-304 Crankshaft Seal,Front – Replace</b> <i>Includes:</i> – Disconnect and connect Wiring harness – Drain and refill engine fluids – Remove and install Coolant hoses Belt and belt guards Crankshaft pulley Oil seal – Visually inspect for oil leaks – Test run unit	-	-	2.5	-	-	-
<b>01-308 Crankshaft Seal, Rear – Replace (Horizontal)</b> <i>Includes:</i> – Disconnect and connect Wiring harness	-	-	3.0	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
		R	A	B	C	D
<b>Procedure Number and Description</b> <b>(continued from previous page)</b>						
<b>01-308 Crankshaft Seal, Rear – Replace (Horizontal)</b> – Remove and install Generator control Generator end Air cleaner or silencer Drip tray Flywheel Rear bearing plate Oil seal – Visually inspect for oil leaks – Test run unit	-	-	3.0	-	-	-
<b>01-121 Gear Cover – Remove And Install</b> <i>Includes:</i> – Disconnect and connect Wiring harness Fuel lines – Drain and refill engine fluids – Remove and install Coolant hoses Belt and belt guards Drive pulley Injection pump cover Governor spring Speed control assy Crankshaft pulley Gearcase cover – Test run unit	-	-	3.0	-	-	-
<b>01-3AB Gear Cover Gasket – Replace</b> <i>Includes:</i> – Disconnect and connect Wiring harness Fuel lines – Drain and refill engine fluids	-	-	3.5	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>01-3AB Gear Cover Gasket – Replace</b></p> <ul style="list-style-type: none"> <li>– Remove and install Belt and fan guards</li> <li>Pulley</li> <li>Speed control assy</li> <li>Injection pump cover</li> <li>Governor spring</li> <li>Gearcase cover</li> <li>Gearcase cover gasket</li> <li>Crankshaft pulley</li> <li>– Test run unit</li> </ul>	-	-	3.5	-	-	-
<p><b>01-114 Gear, Crankshaft – Remove And Install</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>– Drain and refill engine fluids</li> <li>– Remove and install Alternator and belt</li> <li>Coolant hoses</li> <li>Belt and belt guards</li> <li>Injection pump cover</li> <li>Governor spring</li> <li>Speed control assy</li> <li>Crankshaft pulley</li> <li>Gearcase cover</li> <li>Idler gear</li> <li>Oil pump</li> <li>Crankshaft gear</li> <li>– Test run unit</li> </ul>	-	-	7.2	-	-	-
<p><b>01-140 Piston – Remove And Install, All</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect</li> </ul>	-	-	6.8	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>01-140 Piston – Remove And Install, All</b></p> <p>Wiring harness</p> <p>Fuel lines</p> <ul style="list-style-type: none"> <li>– Drain and refill engine fluids</li> <li>– Remove and install</li> </ul> <p>Valve cover and rocker assy</p> <p>Injection lines</p> <p>Cylinder head</p> <p>Drip pan</p> <p>Oil pan</p> <p>Connecting rod and piston assy</p> <p>Piston rings</p> <p>Wrist pin and keepers</p> <p>Connecting rod bearings</p> <ul style="list-style-type: none"> <li>– Clean and visually inspect crankshaft</li> <li>– Hone or bore cylinders</li> <li>– Adjust valve lash</li> <li>– Test run unit</li> </ul>	-	-	6.8	-	-	-
<p><b>01-3AC Piston Rings – Replace</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect</li> </ul> <p>Wiring harness</p> <p>Fuel lines</p> <ul style="list-style-type: none"> <li>– Drain and refill engine fluids</li> <li>– Remove and install</li> </ul> <p>Belt and fan guards</p> <p>Coolant hoses</p> <p>Drip pan assy</p> <p>Oil pan</p> <p>Valve cover and rocker assy</p> <p>Cylinder head</p> <p>Piston and connecting rods</p> <p>Piston rings</p>	-	-	6.8	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>01-3AC Piston Rings – Replace</b></p> <p>Bearings</p> <ul style="list-style-type: none"> <li>- Clean and visually inspect crankshaft</li> <li>- Hone or bore cylinders</li> <li>- Adjust valve lash</li> <li>- Test run unit</li> </ul>	-	-	6.8	-	-	-





# Group 02 – Cylinder Head

## Contents

	<b>Page</b>
<b>Cylinder Head</b> .....	<b>22</b>
Remove And Install .....	22
<b>Cylinder Head Gasket</b> .....	<b>22</b>
Replace .....	22
<b>Valve Guides</b> .....	<b>23</b>
Replace .....	23
<b>Valves</b> .....	<b>24</b>
Grind .....	24

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>02-104 Cylinder Head – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Coolant hoses</li> <li>Belt and belt guards</li> <li>Valve cover and rocker assy</li> <li>Injection lines</li> <li>Injectors</li> <li>Glow plugs</li> <li>Senders</li> <li>Cylinder head</li> <li>Cylinder head gasket</li> <li>Intake manifold gasket</li> <li>Exhaust manifold gasket</li> <li>- Scraping carbon from Cylinder head</li> <li>Tops of pistons</li> <li>Around valves and ports</li> <li>- Adjust valve lash</li> <li>- Torque cylinder head</li> <li>- Test run unit</li> </ul>	-	-	4.2	-	-	-
<b>02-3AA Cylinder Head Gasket – Replace</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Coolant hoses</li> </ul>	-	-	4.3	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>02-3AA Cylinder Head Gasket – Replace</b></p> <ul style="list-style-type: none"> <li>Belt and belt guard</li> <li>Valve cover and rocker assy</li> <li>Injection lines</li> <li>Cylinder head</li> <li>Cylinder head gasket               <ul style="list-style-type: none"> <li>– Scraping carbon from</li> </ul> </li> <li>Cylinder head</li> <li>Tops of pistons</li> <li>Around valves and ports               <ul style="list-style-type: none"> <li>– Adjust valve lash</li> <li>– Torque cylinder head</li> <li>– Test run unit</li> </ul> </li> </ul>	-	-	4.3	-	-	-
<p><b>02-302 Valve Guides – Replace</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect</li> <li>Wiring harness</li> <li>Fuel lines               <ul style="list-style-type: none"> <li>– Drain and refill engine fluids</li> <li>– Remove and install</li> </ul> </li> <li>Coolant hoses</li> <li>Belt and belt guards</li> <li>Valve cover and rocker assy</li> <li>Injection lines</li> <li>Injectors</li> <li>Cylinder head</li> <li>Exhaust manifold</li> <li>Intake manifold</li> <li>Valve guides               <ul style="list-style-type: none"> <li>– Remove valves from head</li> </ul> </li> <li>Caps</li> <li>Spring collet</li> <li>Spring retainer and spring</li> </ul>	-	-	5.9	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>02-302 Valve Guides – Replace</b></p> <p>Stem seal</p> <p>Valve</p> <ul style="list-style-type: none"> <li>- Scrapping carbon from Cylinder head</li> <li>Tops of pistons</li> <li>Around valves and ports</li> <li>- Refinish valve seats</li> <li>- Grind valves</li> <li>- Adjust valve lash</li> <li>- Torque cylinder head</li> <li>- Test run unit</li> </ul>	-	-	5.9	-	-	-
<p><b>02-513 Valves – Grind</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Coolant hoses</li> <li>Belt and belt guards</li> <li>Valve cover and rocker assy</li> <li>Injection lines</li> <li>Injectors</li> <li>Cylinder head</li> <li>Exhaust manifold</li> <li>Intake manifold</li> <li>- Remove valves from head</li> <li>Caps</li> <li>Spring collet</li> <li>Spring retainer and spring</li> <li>Stem seal</li> <li>Valve</li> </ul>	-	-	5.3	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>02-513 Valves – Grind</b> (continued from previous page) – Scrapping carbon from Cylinder head Tops of pistons Around valves and ports – Refinish valve seats – Grind valves – Adjust valve lash – Torque cylinder head – Test run unit	-	-	5.3	-	-	-



# Group 03 – Rocker Levers

## Contents

	<b>Page</b>
<b>Valves</b> .....	<b>28</b>
Adjust, All .....	28

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>03-603 Valves – Adjust, All</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Remove and install Valve cover</li> <li>- Adjust valve lash</li> <li>- Test run unit</li> </ul>	-	-	1.0	-	-	-



# Group 04 – Cam Follower

## Contents

	<b>Page</b>
<b>Valve Tappets</b> .....	<b>30</b>
Remove And Install .....	30

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>04-118 Valve Tappets – Remove And Install</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Drip pan</li> <li>Coolant hoses</li> <li>Valve cover and rocker assy</li> <li>Injection lines</li> <li>Cylinder head</li> <li>Tappets</li> <li>- Scrapping carbon from Cylinder head</li> <li>Tops of pistons</li> <li>Around valves and ports</li> <li>- Adjust valve lash</li> <li>- Torque cylinder head</li> <li>- Test run unit</li> </ul>	-	-	5.0	-	-	-

# Group 05 – Fuel System

## Contents

	<b>Page</b>
<b>Fuel Pump, Electrical</b> .....	<b>32</b>
Remove And Install .....	32
<b>Pump, Injection</b> .....	<b>32</b>
Remove And Install .....	32

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>05-1AC Fuel Pump, Electrical – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Fuel lines</li> <li>- Remove and install Fuel pump</li> <li>- Check Fuel lines for leaks</li> <li>- Test run unit</li> </ul>	-	-	0.5	-	-	-
<b>05-102 Pump, Injection – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Battery cables</li> <li>- Remove and install Stop solenoid linkage</li> <li>- Injection pump cover</li> <li>- Injection pump</li> <li>- Prime and bleed fuel system</li> <li>- Adjust stop solenoid</li> <li>- Test run unit</li> </ul>	-	-	1.0	-	-	-

# Group 06 – Injectors

## Contents

	<b>Page</b>
<b>Injectors</b> .....	<b>34</b>
Remove And Install .....	34

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>06-149 Injectors – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Battery cables</li> <li>- Remove and install Injection lines</li> <li>Over flow rail</li> <li>Injector</li> <li>- Bleed injection lines</li> <li>- Test run unit</li> </ul>	-	-	1.0	-	-	-

# Group 07 – Lubricating Oil System

## Contents

	<b>Page</b>
<b>Lubricating Oil And Filter</b> .....	<b>36</b>
Change .....	36
<b>Oil Base</b> .....	<b>36</b>
Remove And Install (Horizontal) .....	36
<b>Oil By-Pass</b> .....	<b>36</b>
Inspect And Reuse (Horizontal) .....	36
<b>Oil Filter, Full Flow</b> .....	<b>37</b>
Replace .....	37
<b>Oil Pickup Cup And Tube</b> .....	<b>37</b>
Remove And Install (Hor) .....	37
<b>Oil Pump</b> .....	<b>37</b>
Remove And Install .....	37

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>07-801 Lubricating Oil And Filter – Change</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Drain and fill oil base</li> <li>– Remove and install filter</li> <li>– Fill filter and engine with oil</li> <li>– Check for oil leaks</li> <li>– Test run unit</li> </ul>	-	-	0.8	-	-	-
<b>07-109 Oil Base – Remove And Install (Horizontal)</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Drain and fill oil</li> <li>– Remove and install</li> </ul> Drip tray Oil pan Oil pan gasket <ul style="list-style-type: none"> <li>– Check for oil leaks</li> <li>– Test run unit</li> </ul>	-	-	1.5	-	-	-
<b>07-410 Oil By-Pass – Inspect And Reuse (Horizontal)</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect</li> </ul> Wiring harness Fuel lines <ul style="list-style-type: none"> <li>– Remove and install</li> </ul> Oil by-pass valve O-ring Belt and belt guards <ul style="list-style-type: none"> <li>– Clean and visually inspect</li> </ul> Bore O-ring Valve assy <ul style="list-style-type: none"> <li>– Test run unit</li> </ul>	-	-	1.0	-	-	-



Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>07-301 Oil Filter, Full Flow – Replace</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>- Remove and install Oil filter</li> <li>Rubber filter gasket</li> <li>- Fill oil pan</li> <li>- Check for oil leaks</li> <li>- Test run unit</li> </ul>	-	-	0.3	-	-	-
<p><b>07-114 Oil Pickup Cup And Tube – Remove And Install (Hor)</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Drip tray</li> <li>Oil pan</li> <li>Oil pan gasket</li> <li>Oil pick-up cup</li> <li>O-ring</li> <li>- Test run unit</li> </ul>	-	-	1.6	-	-	-
<p><b>07-113 Oil Pump – Remove And Install</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>- Disconnect and connect Wiring harness</li> <li>Fuel lines</li> <li>- Drain and refill engine fluids</li> <li>- Remove and install Coolant hoses</li> <li>Drip tray</li> <li>Belt and belt guards</li> <li>Alternator</li> </ul>	-	-	4.6	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>07-113</b> <b>Oil Pump – Remove And Install</b> (continued from previous page) Injection pump cover Governor spring Speed control assy Crankshaft pulley Gearcase cover Idler gear Oil pump drive gear Oil pump – Test run unit	-	-	4.6	-	-	-

# Group 08 – Cooling System

## Contents

	<b>Page</b>
<b>Belt Guard</b> .....	<b>40</b>
Remove And Install .....	40
<b>Coolant Thermostat</b> .....	<b>40</b>
Remove And Install .....	40
<b>Heat Exchanger</b> .....	<b>40</b>
Remove And Install .....	40
<b>Raw Water Pump (Marine)</b> .....	<b>40</b>
Rebuild .....	40
Remove And Install .....	41
<b>Water Pump</b> .....	<b>41</b>
Rebuild .....	41
Remove And Install .....	41

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
		R	A	B	C	D
<b>08-142 Belt Guard – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Remove and install Belt guards</li> <li>– Test run unit</li> </ul>	-	-	0.3	-	-	-
<b>08-104 Coolant Thermostat – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>– Drain and refill engine fluids</li> <li>– Remove and install Belt guards</li> <li>Coolant hoses</li> <li>Thermostat cover</li> <li>Thermostat cover gasket</li> <li>– Test run unit</li> </ul>	-	-	1.0	-	-	-
<b>08-119 Heat Exchanger – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Drain and refill engine fluids</li> <li>– Remove and install Coolant hoses</li> <li>Heat exchanger</li> <li>– Test run unit</li> </ul>	-	-	3.0	-	-	-
<b>08-207 Raw Water Pump (Marine) – Rebuild</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Clean and visually inspect Pump cover</li> <li>Pump housing</li> <li>– Replace Cover gasket</li> <li>Impeller</li> <li>Cam</li> </ul>	-	-	2.0	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b> <b>08-207 Raw Water Pump (Marine) – Rebuild</b> Screws – Check for water leaks – Test run unit	-	-	2.0	-	-	-
<b>08-145 Raw Water Pump (Marine) – Remove And Install</b> <i>Includes:</i> – Disconnect and connect Battery cables – Remove and install Inlet and outlet lines Water pump – Prime sea water system to pump – Check for water leaks – Test run unit	-	-	1.0	-	-	-
<b>08-209 Water Pump – Rebuild</b> <i>Includes:</i> – Clean and visually inspect Pump housing Pump shaft flange Hose adapter – Replace Shaft and bearing Seal Impeller Pump gasket – Check for water leaks – Test run unit	-	-	3.0	-	-	-
<b>08-130 Water Pump – Remove And Install</b> <i>Includes:</i> – Disconnect and connect Battery cables – Drain and refill engine fluids	-	-	2.0	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>(continued from previous page)</b> <b>08-130 Water Pump – Remove And Install</b> – Remove and install Belt and belt guards Fan Coolant hoses Water pump – Test run unit	-	-	2.0	-	-	-

# Group 10 – Intake Air System

## Contents

	<b>Page</b>
<b>Air Intake Silencer (Marine)</b> .....	<b>44</b>
Remove And Install .....	44
<b>Intake Manifold</b> .....	<b>44</b>
Remove And Install .....	44

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>10-1AA Air Intake Silencer (Marine) – Remove And Install</b>  <i>Includes:</i> – Remove and install Silencer Grommet – Test run unit	-	-	0.3	-	-	-
<b>10-129 Intake Manifold – Remove And Install</b>  <i>Includes:</i> – Remove and install Air hose Air cleaner or silencer Intake manifold Intake manifold gaskets – Test run unit	-	-	0.8	-	-	-



# Group 11 – Exhaust System

## Contents

	<b>Page</b>
<b>Exhaust Manifold</b> .....	<b>46</b>
Replace .....	46
<b>Exhaust Manifold Gaskets</b> .....	<b>46</b>
Replace .....	46

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>11-3AA Exhaust Manifold – Replace</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Drain and refill engine coolant</li> <li>– Remove and install Muffler and exhaust hoses</li> <li>Coolant hoses</li> <li>Exhaust manifold</li> <li>Exhaust manifold gasket</li> <li>– Check for exhaust and coolant leaks</li> <li>– Test run unit</li> </ul>	-	-	0.5	-	-	-
<b>11-304 Exhaust Manifold Gaskets – Replace</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Drain and refill engine coolant</li> <li>– Remove and install Muffler and exhaust hoses</li> <li>Coolant hoses</li> <li>Exhaust manifold</li> <li>Exhaust manifold gasket</li> <li>– Check for exhaust and coolant leaks</li> <li>– Test run unit</li> </ul>	-	-	0.6	-	-	-

# Group 13 – Electrical Equipment

## Contents

	<b>Page</b>
<b>Alternator</b> .....	<b>48</b>
Remove And Install .....	48
<b>Glow Plugs</b> .....	<b>48</b>
Remove And Install .....	48
<b>Starter Motor</b> .....	<b>48</b>
Remove And Install .....	48

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>13-101 Alternator – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Remove and install Electrical wiring Alternator</li> <li>– Test run unit</li> </ul>	-	-	1.3	-	-	-
<b>13-114 Glow Plugs – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables Electrical wiring</li> <li>– Remove and install Injection lines Glow plugs</li> <li>– Bleed injection lines</li> <li>– Test run unit</li> </ul>	-	-	0.5	-	-	-
<b>13-104 Starter Motor – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables Wiring harness</li> <li>– Remove and install Starter</li> <li>– Test run unit</li> </ul>	-	-	0.5	-	-	-

# Group 16 – Mounting Adaptations

## Contents

	<b>Page</b>
<b>Flywheel</b> .....	<b>50</b>
Remove And Install .....	50

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>16-103 Flywheel – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>- Disconnect and connect Engine wiring harness</li> <li>Battery cables</li> <li>- Remove and install Drip tray</li> <li>Generator control assy</li> <li>Generator end</li> <li>Air cleaner or silencer</li> <li>Generator housing</li> <li>Baffle</li> <li>Flywheel</li> <li>- Test run unit</li> </ul>	-	-	3.5	-	-	-

# Group 17 – Miscellaneous

## Contents

	<b>Page</b>
<b>Muffler</b> .....	<b>52</b>
Remove And Install .....	52
<b>Sound Shield</b> .....	<b>52</b>
Remove And Install .....	52
<b>Vibration Isolators</b> .....	<b>52</b>
Remove And Install .....	52

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>17-131 Muffler – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Remove and install Muffler</li> <li>Exhaust lines</li> <li>Exhaust hose</li> <li>Hanger brackets and clamps</li> <li>– Check for exhaust leaks</li> <li>– Test run unit</li> </ul>	-	-	0.5	-	-	-
<b>17-1AC Sound Shield – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Remove and install Door assemblies</li> <li>Roof assembly</li> <li>Front panel assembly</li> <li>Generator control</li> <li>Generator housing</li> <li>Rear panel assembly</li> <li>Baffle</li> </ul>	-	-	1.5	-	-	-
<b>17-1AB Vibration Isolators – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Remove and install Drip tray</li> <li>Drip tray clamps</li> <li>Engine mounts</li> <li>– Test run unit</li> </ul>	-	-	0.5	-	-	-



# Group 25 – Generator

## Contents

	<b>Page</b>
<b>Excitor Rotor</b> .....	<b>54</b>
Remove And Install .....	54
<b>Excitor Stator</b> .....	<b>54</b>
Remove And Install .....	54
<b>Generator Bearing</b> .....	<b>54</b>
Replace .....	54
<b>Main Rotor</b> .....	<b>55</b>
Remove And Install .....	55
<b>Main Stator</b> .....	<b>55</b>
Remove And Install .....	55
<b>Rotating Diode</b> .....	<b>56</b>
Replace .....	56

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>25-1AE Excitor Rotor – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Electrical wiring</li> <li>– Remove and install End bell cover</li> <li>End bell</li> <li>Excitor stator</li> <li>O–ring</li> <li>Bearing</li> <li>Excitor rotor</li> <li>– Test run unit</li> </ul>	-	-	1.5	-	-	-
<b>25-1AF Excitor Stator – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Electrical wiring</li> <li>– Remove and install End bell cover</li> <li>End bell</li> <li>Excitor stator</li> <li>O–ring</li> <li>– Test run unit</li> </ul>	-	-	1.0	-	-	-
<b>25-3AC Generator Bearing – Replace</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Electrical wiring</li> <li>– Remove and install End bell cover</li> <li>End bell</li> <li>Excitor stator</li> </ul>	-	-	1.5	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>25-3AC Generator Bearing – Replace</b></p> <ul style="list-style-type: none"> <li>O-ring</li> <li>Bearing</li> <li>– Test run unit</li> </ul>	-	-	1.5	-	-	-
<p><b>25-1AA Main Rotor – Remove And Install</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Electrical wiring</li> <li>– Remove and install End bell cover</li> <li>End bell</li> <li>Generator control</li> <li>Air cleaner or silencer</li> <li>Excitor stator</li> <li>O-ring</li> <li>Bearing</li> <li>Vibration isolators</li> <li>Stator housing</li> <li>Drive disk</li> <li>Main rotor</li> <li>– Test run unit</li> </ul>	-	-	2.5	-	-	-
<p><b>25-1AB Main Stator – Remove And Install</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Electrical wiring</li> <li>– Remove and install End bell cover</li> <li>End bell</li> <li>Generator control</li> <li>Air cleaner or silencer</li> <li>Excitor stator</li> </ul>	-	-	1.5	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>25-1AB Main Stator – Remove And Install</b></p> <ul style="list-style-type: none"> <li>O-ring</li> <li>Bearing</li> <li>Vibration isolators</li> <li>Stator housing</li> <li>– Test run unit</li> </ul>	-	-	1.5	-	-	-
<p><b>25-3AD Rotating Diode – Replace</b></p> <p><i>Includes:</i></p> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Electrical wiring</li> <li>– Remove and install End bell cover</li> <li>End bell</li> <li>Excitor stator</li> <li>O-ring</li> <li>Diode assembly</li> <li>– Test run unit</li> </ul>	-	-	1.0	-	-	-

# Group 26 – Generator Control

## Contents

	<b>Page</b>
<b>AC Circuit Breaker</b> .....	<b>58</b>
Replace .....	58
<b>AC Control Box</b> .....	<b>58</b>
Remove And Install .....	58
<b>AC Voltage Regulator</b> .....	<b>58</b>
Replace .....	58
<b>AC Wire Harness</b> .....	<b>58</b>
Remove And Install .....	58
<b>Bridge Rectifier</b> .....	<b>59</b>
Replace .....	59
<b>DC Wire Harness</b> .....	<b>59</b>
Remove And Install .....	59
<b>Relay</b> .....	<b>59</b>
Replace .....	59
<b>Start Solenoid</b> .....	<b>59</b>
Replace .....	59
<b>Stop Solenoid</b> .....	<b>60</b>
Replace .....	60

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<b>26-3AE AC Circuit Breaker – Replace</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Stator output leads</li> <li>– Remove and install Circuit breaker panel</li> <li>Control box cover</li> <li>Circuit breaker</li> <li>– Test run unit</li> </ul>	-	-	1.0	-	-	-
<b>26-1AC AC Control Box – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>Electrical wiring</li> <li>– Remove and install Control box cover</li> <li>Control box</li> <li>– Test run unit</li> </ul>	-	-	0.5	-	-	-
<b>26-3AA AC Voltage Regulator – Replace</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Battery cables</li> <li>– Remove and install Control box cover</li> <li>Control box panel</li> <li>Voltage regulator</li> <li>– Test run unit</li> </ul>	-	-	1.0	-	-	-
<b>26-1AD AC Wire Harness – Remove And Install</b> <i>Includes:</i> <ul style="list-style-type: none"> <li>– Disconnect and connect Electrical wiring</li> </ul>	-	-	1.0	-	-	-

Standard Repair Times	Removed From Chassis	In-Chassis Service Accessibility Codes				
		R	A	B	C	D
<b>(continued from previous page)</b>						
<b>26-1AD AC Wire Harness – Remove And Install</b> Electrical connectors – Test run unit	-	-	1.0	-	-	-
<b>26-3AD Bridge Rectifier – Replace</b> <i>Includes:</i> – Disconnect and connect Battery cables – Remove and install Control box cover Control box panel Bridge rectifier – Test run unit	-	-	0.5	-	-	-
<b>26-1AB DC Wire Harness – Remove And Install</b> <i>Includes:</i> – Disconnect and connect Electrical wiring Electrical connectors – Test run unit	-	-	1.0	-	-	-
<b>26-3AL Relay – Replace</b> <i>Includes:</i> – Disconnect and connect Battery cables – Remove and install Control box cover Relay – Test run unit	-	-	0.5	-	-	-
<b>26-3AC Start Solenoid – Replace</b> <i>Includes:</i> – Disconnect and connect Battery cables – Remove and install Start solenoid	-	-	0.5	-	-	-

<b>Standard Repair Times</b>	Removed From Chassis	In-Chassis Service Accessibility Codes				
Procedure Number and Description	R	A	B	C	D	<u>Special</u> S
<p><b>(continued from previous page)</b></p> <p><b>26-3AC Start Solenoid – Replace</b> – Test run unit</p> <p><b>26-3AF Stop Solenoid – Replace</b> <i>Includes:</i> – Disconnect and connect Battery cables – Remove and install Stop solenoid linkage Stop solenoid – Adjust solenoid linkage – Test run unit</p>	-	-	0.5	-	-	-
	-	-	1.0	-	-	-



## A

AC Circuit Breaker, Replace, 58  
AC Control Box, Remove And Install, 58  
AC Voltage Regulator, Replace, 58  
AC Wire Harness, Remove And Install, 58  
Administrative Time  
  Open/Close Repair Order (Road), 2  
  Open/Close Repair Order (Shop), 2  
Air Intake Silencer (Marine), Remove And Install, 44  
Alternator, Remove And Install, 48

## B

Belt Guard, Remove And Install, 40  
Bridge Rectifier, Replace, 59

## C

Camshaft, Replace, 12  
Camshaft, Fuel, Remove And Install, 12  
Connecting Rod, Remove And Install, 13  
Connecting Rod Bearings, Replace, 14  
Coolant Thermostat, Remove And Install, 40  
Crankshaft, Remove And Install, 14  
Crankshaft Seal, Front, Replace, 15  
Crankshaft Seal, Rear, Replace (Horizontal), 15  
Cylinder Head, Remove And Install, 22  
Cylinder Head Gasket, Replace, 22

## D

DC Wire Harness, Remove And Install, 59

## E

Engine, Rebuild, 2  
Excitor Rotor, Remove And Install, 54  
Excitor Stator, Remove And Install, 54  
Exhaust Manifold, Replace, 46

Exhaust Manifold Gaskets, Replace, 46

## F

Flywheel, Remove And Install, 50  
Fuel Pump, Electrical, Remove And Install, 32

## G

Gear Cover, Remove And Install, 16  
Gear Cover Gasket, Replace, 16  
Gear, Crankshaft, Remove And Install, 17  
Generator Bearing, Replace, 54  
Genset, Marine (Above Deck), Remove And Install, 4  
Genset, Marine (Below Deck), Remove And Install, 4  
Glow Plugs, Remove And Install, 48

## H

Heat Exchanger, Remove And Install, 40

## I

Injectors, Remove And Install, 34  
Intake Manifold, Remove And Install, 44

## L

Lubricating Oil And Filter, Change, 36

## M

Main Rotor, Remove And Install, 55  
Main Stator, Remove And Install, 55  
Muffler, Remove And Install, 52

## O

Oil Base, Remove And Install (Horizontal), 36  
Oil By-Pass, Inspect And Reuse (Horizontal), 36  
Oil Filter, Full Flow, Replace, 37

Oil Pickup Cup And Tube, Remove And Install (Hor), 37

Oil Pump, Remove And Install, 37

## P

Piston, Remove And Install, All, 17

Piston Rings, Replace, 18

Pump, Injection, Remove And Install, 32

## R

Raw Water Pump(Marine)

Rebuild, 40

Remove And Install, 41

Relay, Replace, 59

Rotating Diode, Replace, 56

## S

Sound Shield, Remove And Install, 52

Start Solenoid, Replace, 59

Starter Motor, Remove And Install, 48

Stop Solenoid, Replace, 60

## T

Troubleshoot

Coolant Loss (External), 5

Coolant Temp Above Normal, 5

Eng Cranks But Will Not Start (Genset), 5

Engine Unstable (Hunts) (Genset), 6

Engine Will Not Crank (Genset), 6

Excessive Exhaust Smoke Under Load, 7

High Exhaust Temp (Marine), 7

High/Low AC Output (Genset), 7

No Output Voltage (Avr) (Genset), 8

Starts But Stops When Switch Released, 8

Unblanced Generator Output Voltage, 8

Unstable Voltage Eng Stable (Genset), 9

Troubleshoot–Excess White Smoke At Start

Up (Cold), 9

Up (Warm), 10

## V

Valve Guides, Replace, 23

Valve Tappets, Remove And Install, 30

Valves

Adjust, All, 28

Grind, 24

Vibration Isolators, Remove And Install, 52

## W

Water Pump

Rebuild, 41

Remove And Install, 41

# Request for SRT review

<b>Distributor/Dealer Data</b>		
<b>Distributor/Dealer</b>	<b>Phone No.</b>	
<b>Address</b>		
<b>City</b>	<b>State</b>	<b>Zip Code</b>
<b>Country</b>		

My experience has indicated the following repair procedures require more time:

<b>Procedure Data</b>			
<b>SRT Number</b>	<b>Procedure Discription</b>	<b>Published time Hrs.</b>	<b>Suggested time Hrs.</b>
<b>Total Hours</b>			

<b>Generator Set Model</b>
<b>Transfer Switch Model</b>
<b>Repair Date</b>
<b>Technician Name</b>

Describe how repair was performed:

---



---



---



---



---



---

Signature \_\_\_\_\_ Title \_\_\_\_\_

Mail to: **Onan Corporation**  
**Service Department**  
**1400 73rd Avenue NE**  
**Minneapolis, MN 55432**

**Onan**

Cummins Power Generation  
1400 73rd Avenue N.E.  
Minneapolis, MN 55432  
763-574-5000  
Fax: 763-528-7229

Cummins and Onan are registered trademarks of Cummins Inc.



Redistribution or publication of this document  
by any means, is strictly prohibited.